



**GE VERNOVA**

# Multilin Agile

**P24D, P24N**

**Technical Manual  
Motor Management IED**

Hardware Version: E

Firmware Version: 8.0

Publication Reference: MAP24-TM-EN-1.1



## Copyright statement

Copyright © 2025 GE Vernova. All rights reserved.

FlexLogic, FlexElement, FlexCurve, FlexAnalog, FlexInteger, FlexState, EnerVista, EnerVista Launchpad, and EnerVista D&I Setup software, CyberSentry, HardFiber, Universal Relay, Multilin, Multilin Agile, and GE Multilin are trademarks or registered trademarks of GE Vernova.

The contents of this manual are the property of GE Vernova. This documentation is furnished on license and may not be reproduced in whole or in part without the permission of GE Vernova. The content of this manual is for informational use only and is subject to change without notice.

## Disclaimer

It is the responsibility of the user to verify and validate the suitability of all GE Vernova Grid Automation products. This equipment must be used within its design limits. The proper application including the configuration and setting of this product to suit the power system assets is the responsibility of the user, who is also required to ensure that all local or regional safety guidelines are adhered to. Incorrect application of this product could risk damage to property/the environment, personal injuries or fatalities and shall be the sole responsibility of the person/entity applying and qualifying the product for use.

The content of this document has been developed to provide guidance to properly install, configure and maintain this product for its intended applications. This guidance is not intended to cover every possible contingency that may arise during commissioning, operation, service, or maintenance activities. Should you encounter any circumstances not clearly addressed in this document, contact your local GE Vernova service site.

The information contained in this document is subject to change without notice.

**IT IS THE SOLE RESPONSIBILITY OF THE USER TO SECURE THEIR NETWORK AND ASSOCIATED DEVICES AGAINST CYBER SECURITY INTRUSIONS OR ATTACKS. GE VERNOVA AND ITS AFFILIATES ARE NOT LIABLE FOR ANY DAMAGES AND/OR LOSSES ARISING FROM OR RELATED TO SUCH SECURITY INTRUSION OR ATTACKS.**

# Contents

<b>Chapter 1</b>	<b>Introduction</b>	<b>1</b>
<b>1.1</b>	<b>Chapter Overview</b>	<b>2</b>
<b>1.2</b>	<b>Foreword</b>	<b>3</b>
1.2.1	Target Audience	3
1.2.2	Typographical Conventions	3
1.2.3	Nomenclature	3
1.2.4	Compliance	4
<b>1.3</b>	<b>Product Scope</b>	<b>5</b>
1.3.1	Ordering Options	5
<b>1.4</b>	<b>Features and Functions</b>	<b>6</b>
1.4.1	Description of the Multilin Agile Motor Protection System	6
1.4.2	Introduction to Logical Devices	7
1.4.3	Protection Functions	7
1.4.4	Control Functions	9
1.4.5	Measurement Functions	10
1.4.6	Communication Functions	11
1.4.7	System Functions	11
1.4.8	HMI Main Menu	13
<b>1.5</b>	<b>Logic Diagrams</b>	<b>14</b>
<b>1.6</b>	<b>Functional Overview</b>	<b>15</b>
<b>Chapter 2</b>	<b>Safety Information</b>	<b>16</b>
<b>2.1</b>	<b>Chapter Overview</b>	<b>17</b>
<b>2.2</b>	<b>Health and Safety</b>	<b>18</b>
<b>2.3</b>	<b>Symbols</b>	<b>19</b>
<b>2.4</b>	<b>Installation, Commissioning and Servicing</b>	<b>20</b>
2.4.1	Lifting Hazards	20
2.4.2	Electrical Hazards	20
2.4.3	Fusing Requirements	21
2.4.4	Equipment Connections	21
2.4.5	Protection Class 1 Equipment Requirements	22
2.4.6	Pre-energisation Checklist	22
2.4.7	Peripheral Circuitry	23
2.4.8	Upgrading/Servicing	24
<b>2.5</b>	<b>Decommissioning and Disposal</b>	<b>25</b>
<b>2.6</b>	<b>Regulatory Compliance</b>	<b>26</b>
2.6.1	EMC Compliance: 2014/30/EU	26
2.6.2	LVD Compliance: 2014/35/EU	26
2.6.3	RoHS Compliance 2011/65/EU and (EU) 2015/863	26
<b>Chapter 3</b>	<b>Hardware Design</b>	<b>27</b>
<b>3.1</b>	<b>Chapter Overview</b>	<b>28</b>
<b>3.2</b>	<b>Hardware Architecture</b>	<b>29</b>
3.2.1	Memory and Real Time Clock	29
<b>3.3</b>	<b>Mechanical Implementation</b>	<b>30</b>
3.3.1	Housing Variants	31
3.3.2	20TE Rear Panel	32
3.3.3	30TE Rear Panel	32
3.3.4	Terminal Connections	33
3.3.4.1	I/O Options (20TE)	33
3.3.4.2	I/O Options (30TE)	34

<b>3.4</b>	<b>Front Panel</b>	<b>35</b>
3.4.1	20TE Front Panel	35
3.4.2	30TE Front Panel	35
3.4.2.1	30TE IEC Front Panel	36
3.4.2.2	30TE ANSI Front Panel	37
<b>3.5</b>	<b>Keypad</b>	<b>38</b>
3.5.1	Clear/Reset Key Functionality	38
3.5.2	20TE Keypad	38
3.5.3	30TE Keypad (IEC, ANSI Variants)	40
3.5.4	Liquid Crystal Display	42
3.5.5	USB Port	42
3.5.6	Fixed Function LEDs	43
3.5.7	Programmable LEDs	43
3.5.8	Programmable Function Keys/Pushbuttons	44
3.5.9	Local/Remote Key	45
3.5.10	Stop (O)/Start (I) Motor Switching Device (Breaker/Contactor) Control Keys	45
<b>Chapter 4</b>	<b>Software Design</b>	<b>46</b>
<b>4.1</b>	<b>Chapter Overview</b>	<b>47</b>
<b>4.2</b>	<b>Software Design Overview</b>	<b>48</b>
<b>4.3</b>	<b>System Level Software</b>	<b>49</b>
4.3.1	Real Time Operating System	49
4.3.2	System Services Software	49
4.3.3	Self-Diagnostic Software	49
4.3.4	Startup Self-Testing	49
4.3.4.1	System Boot	49
4.3.4.2	System Level Software Initialisation	49
4.3.4.3	Platform Software Initialisation and Monitoring	50
4.3.5	Continuous Self-Testing	50
<b>4.4</b>	<b>Platform Software</b>	<b>51</b>
4.4.1	Record Logging	51
4.4.2	Settings Database	51
4.4.3	Interfaces	51
<b>4.5</b>	<b>Protection and Control Functions</b>	<b>52</b>
4.5.1	Acquisition of Samples	52
4.5.2	Frequency Tracking	52
4.5.3	Fourier Signal Processing	52
4.5.4	Flexlogic Equation Editor	53
4.5.5	Event Recording	53
4.5.6	Disturbance Recorder	54
<b>Chapter 5</b>	<b>Configuration</b>	<b>55</b>
<b>5.1</b>	<b>Chapter Overview</b>	<b>56</b>
<b>5.2</b>	<b>Settings Application Software</b>	<b>57</b>
5.2.1	Setting Entry Methods	57
5.2.2	Common Settings	57
5.2.3	Settings Text Abbreviations	58
<b>5.3</b>	<b>Device</b>	<b>60</b>
5.3.1	Date and Time Configuration	60
5.3.1.1	Clock	61
5.3.1.2	PTP Protocol	61
5.3.1.3	IRIG-B	61
5.3.1.4	SNTP Protocol	62
5.3.2	Security	62
5.3.3	Communications	62



5.3.4	Disturbance Recorder	62
5.3.5	Data Logger	62
5.3.6	Fault Records	63
5.3.7	Event Data	63
5.3.8	Flex States	63
5.3.9	Front Panel	64
5.3.9.1	Display Properties	64
5.3.9.2	Default Screens	64
5.3.10	Resetting	64
5.3.11	Installation	64
5.3.12	Clear Records	65
5.3.13	Using the HMI Panel	65
5.3.13.1	Navigating the HMI Panel	66
5.3.13.2	Getting Started	67
5.3.13.3	Default Display	67
5.3.13.4	Default Display Navigation	68
5.3.13.5	Password Entry and Role Based Access Control (RBAC)	68
5.3.13.6	Password Entry and Role Based Access Control (RBAC)	68
5.3.13.7	Processing Alarms and Records	69
5.3.13.8	Menu Structure	69
5.3.13.9	Changing the Settings	70
<b>5.4</b>	<b>System</b>	<b>71</b>
5.4.1	CT Ratio	71
5.4.2	VT Ratio	71
5.4.3	Power Sensing	72
5.4.4	Power System	72
5.4.4.1	Nominal Frequency and Phase Sequence	73
5.4.4.2	Reverse Phase Sequence Rotation	73
5.4.5	Motor Setup Configuration	75
5.4.5.1	Motor Setup	75
5.4.5.2	Variable Frequency Drive (VFD)	79
5.4.6	Preset Values	85
5.4.7	Switching Devices	86
5.4.7.1	Breaker	86
5.4.7.2	Contactors	88
5.4.7.3	User Curves	90
<b>Chapter 6</b>	<b>Motor Protection Functions</b>	<b>94</b>
<b>6.1</b>	<b>Motor Protection Functions</b>	<b>95</b>
<b>6.2</b>	<b>Motor Protection Functions Menu Hierarchy</b>	<b>96</b>
<b>6.3</b>	<b>Motor Protection Functions</b>	<b>97</b>
6.3.1	Thermal Model	97
6.3.1.1	Thermal Model Implementation	97
6.3.1.2	Thermal Model Logic	115
6.3.2	Current Unbalance	116
6.3.2.1	Current Unbalance Implementation	117
6.3.2.2	Current Unbalance Logic	123
6.3.3	Mechanical Jam	124
6.3.3.1	Mechanical Jam Implementation	124
6.3.3.2	Current Unbalance Logic	126
6.3.4	Undercurrent	127
6.3.4.1	Undercurrent Implementation	127
6.3.4.2	Undercurrent Logic	129
6.3.5	Overload Alarm	129
6.3.5.1	Overload Alarm Implementation	129
6.3.5.2	Overload Alarm Logic	131
6.3.6	Short Circuit	131

6.3.6.1	Short Circuit Implementation	131
6.3.6.2	Short Circuit Logic	134
6.3.7	Ground Fault	134
6.3.7.1	Ground Fault Implementation	134
6.3.7.2	Ground Fault Logic	137
6.3.8	Acceleration Time	137
6.3.8.1	Acceleration Time Implementation	137
6.3.8.2	Acceleration Time Logic	140
6.3.9	2-Speed Motor Protection	140
6.3.9.1	2-Speed Thermal Model	141
6.3.10	2-Speed Acceleration Time	141
6.3.10.1	2-Speed Acceleration Time Implementation	141
6.3.10.2	2-Speed Acceleration Time Logic	142
6.3.11	2-Speed Undercurrent	143
6.3.11.1	2-Speed Undercurrent Implementation	143
6.3.11.2	2-Speed Undercurrent Logic	144

## **Chapter 7 Current Protection Functions 145**

<b>7.1</b>	<b>Chapter Overview</b>	<b>146</b>
<b>7.2</b>	<b>Overcurrent Protection Principles</b>	<b>147</b>
7.2.1	Function Setting Application	147
7.2.2	Principles of Implementation	147
7.2.2.1	Timer Hold Facility	148
7.2.3	IDMT Characteristics	149
7.2.3.1	IEC 60255 IDMT Curves	149
7.2.3.2	European Standards	152
7.2.3.3	North American Standards	153
7.2.3.4	IAC Curves	155
7.2.3.5	I <sup>2</sup> T Curves	155
7.2.3.6	I <sup>4</sup> T Curves	156
7.2.3.7	Differences Between the North american and European Standards	156
7.2.3.8	Programmable Curves	156
<b>7.3</b>	<b>Phase Overcurrent Protection</b>	<b>157</b>
7.3.1	Phase Overcurrent Protection Implementation	157
7.3.2	Non-Directional Overcurrent Logic	158
7.3.3	Directional Element	160
7.3.4	Directional Overcurrent Logic	162
7.3.5	Application Notes	163
7.3.5.1	Parallel Feeders	163
7.3.5.2	Ring Main Arrangements	164
7.3.5.3	Setting Guidelines	164
7.3.5.4	Setting Guidelines (Directional Element)	165
<b>7.4</b>	<b>Voltage Dependant Overcurrent Element</b>	<b>166</b>
7.4.1	Voltage Dependant Overcurrent Protection Implementation	166
7.4.1.1	Voltage Controlled Overcurrent Protection	166
7.4.1.2	Voltage Restrained Overcurrent Protection	167
7.4.1.3	Voltage Dependant Overcurrent Logic	168
7.4.2	Application Notes	169
7.4.2.1	Setting Guidelines	169
<b>7.5</b>	<b>Earth Fault Protection</b>	<b>170</b>
7.5.1	Earth Fault Protection Elements	170
7.5.2	Non-directional Earth Fault Logic	171
<b>7.6</b>	<b>Sensitive Earth Fault Protection</b>	<b>174</b>
7.6.1	SEF Protection Implementation	174
7.6.2	Non-directional SEF Logic	175
<b>7.7</b>	<b>Blocked Overcurrent Protection</b>	<b>177</b>
7.7.1	Blocked Overcurrent Implementation	177

7.7.2	Application Notes	177
7.7.2.1	Busbar Blocking Scheme	177
<b>Chapter 8</b>	<b>Restricted Earth Fault Protection</b>	<b>179</b>
<b>8.1</b>	<b>Chapter Overview</b>	<b>180</b>
<b>8.2</b>	<b>REF Protection Principles</b>	<b>181</b>
8.2.1	Resistance-Earthed Star Windings	182
8.2.2	Solidly-Earthed Star Windings	182
8.2.3	Through Fault Stability	183
8.2.4	Restricted Earth Fault Types	183
8.2.4.1	Low Impedance REF Principle	184
8.2.4.2	High Impedance REF Principle	185
<b>8.3</b>	<b>Restricted Earth Fault Protection Implementation</b>	<b>187</b>
8.3.1	Restricted Earth Fault Protection Settings	187
8.3.2	Low Impedance REF	187
8.3.2.1	Setting the Bias Characteristic	187
8.3.3	High Impedance REF	188
8.3.3.1	High Impedance REF Calculation Principles	189
<b>8.4</b>	<b>Application Notes</b>	<b>190</b>
8.4.1	Star Winding Resistance Earthed	190
8.4.2	Low Impedance REF Protection Application	191
8.4.2.1	Setting Guidelines for Biased Operation	191
8.4.2.2	Low Impedance REF Scaling Factor	191
8.4.2.3	Parameter Calculations	192
8.4.3	High Impedance REF Protection Application	193
8.4.3.1	High Impedance REF Operating Modes	193
8.4.3.2	Setting Guidelines for High Impedance Operation	194
<b>Chapter 9</b>	<b>CB Fail Protection</b>	<b>197</b>
<b>9.1</b>	<b>Chapter Overview</b>	<b>198</b>
<b>9.2</b>	<b>Circuit Breaker Fail Protection</b>	<b>199</b>
<b>9.3</b>	<b>Circuit Breaker Fail Implementation</b>	<b>200</b>
9.3.1	Circuit Breaker Failure Initiation	200
9.3.2	Circuit Breaker Failure Determination	200
9.3.3	Circuit Breaker Failure Outputs	201
<b>9.4</b>	<b>Circuit Breaker Fail Logic</b>	<b>202</b>
<b>9.5</b>	<b>Circuit Breaker Mapping</b>	<b>203</b>
<b>9.6</b>	<b>Application Notes</b>	<b>204</b>
9.6.1	Reset Mechanisms for CB Fail Timers	204
9.6.2	Setting Guidelines (CB fail Timer)	204
<b>Chapter 10</b>	<b>Current Transformer Requirements</b>	<b>206</b>
<b>10.1</b>	<b>Chapter Overview</b>	<b>207</b>
<b>10.2</b>	<b>CT requirements</b>	<b>208</b>
10.2.1	Phase Overcurrent Protection	209
10.2.1.1	Directional Elements	209
10.2.1.2	Non-directional Elements	209
10.2.2	Earth Fault Protection	209
10.2.2.1	Directional Elements	209
10.2.2.2	Non-directional Elements	209
10.2.3	SEF Protection (Residually Connected)	210
10.2.3.1	Directional Elements	210
10.2.3.2	Non-directional Elements	210
10.2.4	SEF Protection (Core-Balanced CT)	210

10.2.4.1	Directional Elements	210
10.2.4.2	Non-directional Elements	210
10.2.5	Low Impedance REF Protection	211
10.2.6	High Impedance REF Protection	211
10.2.7	High Impedance Busbar Protection	211
10.2.8	Use of Metrosil Non-linear Resistors	212
10.2.9	Use of ANSI C-class CTs	214

## **Chapter 11 Voltage Protection Functions** **215**

<b>11.1</b>	<b>Chapter Overview</b>	<b>216</b>
<b>11.2</b>	<b>Phase Reversal Protection</b>	<b>217</b>
11.2.1	Phase Reversal Implementation	217
11.2.2	Phase Reversal Logic	219
<b>11.3</b>	<b>Undervoltage Protection</b>	<b>220</b>
11.3.1	Undervoltage Protection Implementation	220
11.3.2	Undervoltage Protection Logic	222
11.3.3	Application Notes	223
11.3.3.1	Undervoltage Setting Guidelines	223
<b>11.4</b>	<b>Overvoltage Protection</b>	<b>224</b>
11.4.1	Overvoltage Protection Implementation	224
11.4.2	Overvoltage Protection Logic	225
11.4.3	Application Notes	226
11.4.3.1	Overvoltage Setting Guidelines	226
<b>11.5</b>	<b>Residual Overvoltage Protection</b>	<b>227</b>
11.5.1	Residual Overvoltage Protection Implementation	227
11.5.2	Residual Overvoltage Logic	228
11.5.3	Application Notes	228
11.5.3.1	Calculation for Solidly Earthed Systems	228
11.5.3.2	Calculation for Impedance Earthed Systems	229
11.5.3.3	Setting Guidelines	230
<b>11.6</b>	<b>Negative Sequence Overvoltage Protection</b>	<b>231</b>
11.6.1	Negative Sequence Overvoltage Implementation	231
11.6.2	Negative Sequence Overvoltage Logic	231
11.6.3	Application Notes	231
11.6.3.1	Setting Guidelines	231
<b>11.7</b>	<b>Positive Sequence Undervoltage Protection</b>	<b>233</b>
11.7.1	Positive Sequence Undervoltage Implementation	233
11.7.2	Positive Sequence Undervoltage Logic	233

## **Chapter 12 Frequency Protection Functions** **234**

<b>12.1</b>	<b>Chapter Overview</b>	<b>235</b>
<b>12.2</b>	<b>Frequency Protection Overview</b>	<b>236</b>
12.2.1	Frequency Protection Implementation	236
12.2.2	Frequency Protection Common Setup	236
<b>12.3</b>	<b>Underfrequency Protection</b>	<b>237</b>
12.3.1	Underfrequency Protection Implementation	237
12.3.2	Underfrequency Protection Logic	238
12.3.3	Application Notes	238
12.3.3.1	Setting Guidelines	238
12.3.3.2	Overfrequency Protection	239

## **Chapter 13 Power Protection Functions** **242**

<b>13.1</b>	<b>Chapter Overview</b>	<b>243</b>
<b>13.2</b>	<b>Overpower Protection</b>	<b>244</b>

13.2.1	Overpower Protection Implementation	244
13.2.2	Overpower Logic	244
13.2.3	Application Notes	245
13.2.3.1	Forward Overpower Setting Guidelines	245
13.2.3.2	Reverse Power Considerations	245
13.2.3.3	Reverse Overpower Setting Guidelines	245
<b>13.3</b>	<b>Underpower Protection</b>	<b>247</b>
13.3.1	Underpower Protection Implementation	247
13.3.2	Underpower Logic	247
13.3.3	Application Notes	248
13.3.3.1	Low Forward Power Considerations	248
13.3.3.2	Low Forward Power Setting Guidelines	248

## Chapter 14 Monitoring and Control 249

<b>14.1</b>	<b>Chapter Overview</b>	<b>250</b>
<b>14.2</b>	<b>Motor Records</b>	<b>251</b>
14.2.1	Motor Start Records	251
14.2.2	Motor Start Statistics	251
14.2.3	Learned Data	252
<b>14.3</b>	<b>Event Records</b>	<b>256</b>
14.3.1	Event Types	256
14.3.1.1	Opto-input Events	257
14.3.1.2	Relay Output Events	257
14.3.1.3	Alarm and Self-Test Error Events	257
14.3.1.4	Fault Record Events	257
14.3.1.5	Security Events	257
14.3.1.6	Protection Events	257
<b>14.4</b>	<b>Disturbance Recorder</b>	<b>258</b>
<b>14.5</b>	<b>Data Logger</b>	<b>260</b>
<b>14.6</b>	<b>Fault Records</b>	<b>262</b>
<b>14.7</b>	<b>Event Data</b>	<b>263</b>
<b>14.8</b>	<b>Flex States</b>	<b>264</b>
<b>14.9</b>	<b>Flex Elements</b>	<b>265</b>
<b>14.10</b>	<b>Device Status</b>	<b>267</b>
14.10.1	Motor Status	267
14.10.1.1	Motor Status Implementation and Logic	267
14.10.1.2	Thermal Capacity Used	271
14.10.1.3	Estimated Trip Time on Overload	271
14.10.1.4	Start Inhibit Lockout Times	272
14.10.1.5	Motor Speed	272
14.10.1.6	Motor Running Hours	272
<b>14.11</b>	<b>Measured Quantities</b>	<b>273</b>
14.11.1	Measured and Calculated Currents	273
14.11.2	Measured and Calculated Voltages	273
14.11.3	Power and Energy Quantities	273
14.11.4	Demand Values	273
14.11.5	Frequency Measurements	274
14.11.6	Other Measurements	274
<b>14.12</b>	<b>Opto-input Time Stamping</b>	<b>275</b>
<b>14.13</b>	<b>Power Factor</b>	<b>276</b>
14.13.1	Power Factor Implementation	276
14.13.2	Power Factor Logic	277
14.13.3	Power Factor Logic Setting Guidelines	278
<b>14.14</b>	<b>Breaker Arcing Current</b>	<b>281</b>
14.14.1	Breaker Arcing Current Implementation	281
14.14.2	Breaker Arcing Current Logic	282

14.14.3	Breaker Arcing Current Application Notes	282
<b>14.15</b>	<b>CB Health Monitoring</b>	<b>284</b>
14.15.1	CB Health Monitoring Logic	285
14.15.2	Application Notes	286
14.15.2.1	Setting the Thresholds for the Arc Energy	286
14.15.2.2	Setting the thresholds for the Number of Operations	287
14.15.2.3	Setting the thresholds for the Operating Time	287
14.15.2.4	Setting the Thresholds for Excessive Fault Frequency	287
<b>14.16</b>	<b>CB State Monitoring</b>	<b>288</b>
14.16.1	CB State Monitoring Logic	289
<b>14.17</b>	<b>Setpoint Group</b>	<b>290</b>
<b>14.18</b>	<b>Motor Control Functions</b>	<b>291</b>
14.18.1	Motor Control Functions Menu Hierarchy	291
14.18.2	Start Supervision	292
14.18.2.1	Thermal Inhibit	293
14.18.2.2	Maximum Starting Rate	297
14.18.2.3	Maximum Cold/Hot Starting Rate	299
14.18.2.4	Time Between Starts	304
14.18.2.5	Restart Delay	306
14.18.2.6	Reduced Voltage Starting	307
<b>14.19</b>	<b>Select Before Operate</b>	<b>312</b>
14.19.1	Select Before Operate Implementation	312
14.19.2	Select Before Operate Logic	312
14.19.2.1	Switching Device Selection using Navigation Keys	312
14.19.2.2	Switching Device Control using Front Panel	312
<b>14.20</b>	<b>Circuit Breaker/Contactor Control</b>	<b>317</b>
14.20.1	Motor Control Using the IED Menu	318
14.20.2	Motor Control Using the Hotkeys in 20TE Front Panel	318
14.20.3	Motor Control Using the Stop and Start Pushbuttons in 30TE Front Panel	319
14.20.4	Motor CB or Contactor Control Using the Opto-Inputs	319
14.20.5	Remote CB Control	319
14.20.6	CB/Contactor Healthy Check	320
14.20.7	CB Control Logic	321
14.20.8	Control Authority (IEC61850)	325
14.20.9	Control Authority (IEC61850)	327
<b>14.21</b>	<b>Switch Status and Control</b>	<b>330</b>
14.21.1	Switch Status Logic	332
14.21.2	Switch Control Logic	333
<b>14.22</b>	<b>Harmonic Detection</b>	<b>334</b>
<b>14.23</b>	<b>Demand</b>	<b>336</b>
14.23.1	Current Demand	336
14.23.2	Active Power Demand	336
14.23.3	Reactive Power Demand	337
<b>14.24</b>	<b>Digital Counters</b>	<b>338</b>
<b>14.25</b>	<b>Loss Of Communications</b>	<b>339</b>
<b>14.26</b>	<b>Trip Bus</b>	<b>340</b>
14.26.1	Trip Bus Implementation	340
14.26.2	Trip Bus Logic	341
<b>14.27</b>	<b>Digital Elements</b>	<b>342</b>
14.27.1	Digital Elements Implementation	342
14.27.2	Digital Elements Logic	343
14.27.3	Application Example	343
<b>Chapter 15 Supervision</b>		<b>344</b>
<b>15.1</b>	<b>Chapter Overview</b>	<b>345</b>
<b>15.2</b>	<b>DC Supply Monitor</b>	<b>346</b>

15.2.1	DC Supply Monitor Implementation	346
15.2.2	DC Supply Monitor Logic	347
<b>15.3</b>	<b>Voltage Transformer Supervision</b>	<b>348</b>
15.3.1	Loss of One or Two Phase Voltages	348
15.3.2	Loss of all Three Phase Voltages	348
15.3.3	VTS Implementation	348
15.3.4	VTS Logic	350
<b>15.4</b>	<b>Current Transformer Supervision</b>	<b>351</b>
15.4.1	CTS Implementation	351
15.4.2	CTS Logic	352
15.4.3	Application Notes	352
15.4.3.1	Setting Guidelines	352
<b>15.5</b>	<b>Trip Circuit Supervision</b>	<b>353</b>
15.5.1	Trip Circuit Supervision Scheme 1	353
15.5.1.1	Resistor Values	353
15.5.1.2	Flexlogic Equation Editor for TCS Scheme 1	354
15.5.2	Trip Circuit Supervision Scheme 2	354
15.5.2.1	Resistor Values	354
15.5.2.2	Flexlogic Equation Editor for TCS Scheme 2	355
15.5.3	Trip Circuit Supervision Scheme 3	355
15.5.3.1	Resistor Values	355
15.5.3.2	Flexlogic Equation Editor for TCS Scheme 3	356
15.5.4	Trip Circuit Supervision Scheme 4	356
15.5.4.1	Resistor Values	356
15.5.4.2	Flexlogic Equation Editor for TCS Scheme 4	357

## **Chapter 16 Digital I/O and Flexlogic Equation Editor 358**

<b>16.1</b>	<b>Chapter Overview</b>	<b>359</b>
<b>16.2</b>	<b>Configuring Digital Inputs and Outputs</b>	<b>360</b>
<b>16.3</b>	<b>Flexlogic Equation Editor</b>	<b>361</b>
<b>16.4</b>	<b>Configuring the Opto-Inputs</b>	<b>362</b>
<b>16.5</b>	<b>Fixed Function LEDs</b>	<b>363</b>
<b>16.6</b>	<b>Programmable LEDs</b>	<b>364</b>
<b>16.7</b>	<b>Virtual Inputs</b>	<b>365</b>
<b>16.8</b>	<b>GOOSE Subscribe (Remote Inputs, RI DPS, GOOSE Analog) and Remote Output</b>	<b>367</b>
<b>16.9</b>	<b>Relay Outputs</b>	<b>368</b>
16.9.1	Assigning Relay Outputs	368
<b>16.10</b>	<b>Virtual Outputs</b>	<b>369</b>

## **Chapter 17 Communications 370**

<b>17.1</b>	<b>Chapter Overview</b>	<b>371</b>
<b>17.2</b>	<b>Communication Interfaces</b>	<b>372</b>
<b>17.3</b>	<b>Serial Communication</b>	<b>374</b>
17.3.1	EIA(RS)485 Biasing Requirements	374
17.3.2	EIA(RS)485 Bus	374
<b>17.4</b>	<b>Standard Ethernet Communication</b>	<b>376</b>
17.4.1	USB	376
<b>17.5</b>	<b>Redundant Ethernet Communication</b>	<b>377</b>
17.5.1	Supported Protocols and Functionality	377
17.5.2	Parallel Redundancy Protocol (PRP)	378
17.5.3	High-Availability Seamless Redundancy (HSR)	379
17.5.3.1	HSR Multicast Topology	379
17.5.3.2	HSR Unicast Topology	380
17.5.4	Link Loss Alert Functionality (LLA)	380
<b>17.6</b>	<b>Data Protocols</b>	<b>381</b>

17.6.1	IEC 60870-5-103	381
17.6.1.1	Physical Connection and Link Layer	382
17.6.1.2	Initialisation	382
17.6.1.3	Time Synchronisation	382
17.6.1.4	IEC103 Interoperability	382
17.6.1.5	IEC 60870-5-103 Application Level	389
17.6.2	DNP 3.0	391
17.6.2.1	Physical Connection and Link Layer	391
17.6.2.2	Object 1 Binary Inputs	392
17.6.2.3	Object 10 Binary Outputs	393
17.6.2.4	Object 20 Binary Counters	393
17.6.2.5	Object 30 Analogue Input	394
17.6.2.6	DNP 3.0 Device Profile	394
17.6.3	Modbus	401
17.6.3.1	Physical Connection and Link Layer	401
17.6.3.2	Response Codes	402
17.6.3.3	Supported Function Codes	402
17.6.3.4	Administrator Login and Commands via Modbus	402
17.6.4	IEC 61850	405
17.6.4.1	Benefits of IEC 61850	405
17.6.4.2	IEC 61850 Interoperability	405
17.6.4.3	The IEC 61850 Data Model	405
17.6.4.4	IEC 61850 in IEDs	406
17.6.4.5	IEC 61850 Data Model Implementation	407
17.6.4.6	IEC 61850 Communication Services Implementation	407
17.6.4.7	IEC 61850 Peer-to-peer (GOOSE) communications	407
17.6.4.8	Mapping GOOSE Messages to Remote Inputs	407
17.6.4.9	Ethernet Disconnection	407
17.6.4.10	Loss of Power	408
17.6.4.11	IEC 61850 Configuration	408
<b>17.7</b>	<b>Time Synchronisation</b>	<b>409</b>
17.7.1	IEEE 1588 Precision Time Protocol (PTP Version 2)	409
17.7.1.1	Feature Summary	409
17.7.1.2	System Operation	410
17.7.2	IRIG-B	410
17.7.2.1	Demodulated IRIG-B Implementation	411
17.7.3	SNTP	411
17.7.4	Time Synchronisation using the Communication Protocols	412

## **Chapter 18 Cyber-Security 413**

<b>18.1</b>	<b>Overview</b>	<b>414</b>
<b>18.2</b>	<b>The Need for Cyber-Security</b>	<b>415</b>
<b>18.3</b>	<b>Standards</b>	<b>416</b>
18.3.1	NERC Compliance	416
18.3.1.1	CIP 002	417
18.3.1.2	CIP 003	417
18.3.1.3	CIP 004	417
18.3.1.4	CIP 005	417
18.3.1.5	CIP 006	418
18.3.1.6	CIP 007	418
18.3.1.7	CIP 008	418
18.3.1.8	CIP 009	418
18.3.2	IEEE 1686-2013	418
18.3.3	IEC 62351	419
<b>18.4</b>	<b>Cyber-Security Implementation</b>	<b>424</b>
18.4.1	RBAC Functionality	424
18.4.2	Basic Security Implementation	425



18.4.2.1	Device/Local Authentication	425
18.4.2.2	Four-level Access	425
18.4.2.3	Bypass Access	426
18.4.2.4	Enhanced Password Security	427
18.4.2.5	Disabling Physical and Logical Ports	427
18.4.2.6	Non-Encrypted/Clear Text Modbus	428
18.4.2.7	Security Events	428
18.4.3	Advanced Cyber-Security Implementation	429
18.4.3.1	Permissions Vs Access Matrix/Permission Assignment	429
18.4.3.2	Server/Remote Authentication	430
18.4.3.3	Server/Remote Authentication (RADIUS)	430
18.4.3.4	Server/Remote Authentication (LEGACY LDAP PULL MODEL)	431
18.4.4	Unique Configurable Usernames	434
18.4.5	Secure Encrypted Communication	434
18.4.5.1	ModBus/SSH	434
18.4.5.2	SFTP	434
18.4.6	Syslog	435
18.4.7	Increased Product Hardening	437
18.4.7.1	Additional Features	437
18.4.8	Lost Password	437
18.4.9	Loading Factory Configuration	437
18.4.10	Additional Features	437
18.4.10.1	Lost Password	437
18.4.10.2	Loading Factory Configuration	437
<b>18.5</b>	<b>RBAC User Management Cyber-Security Configuration Tool</b>	<b>438</b>
18.5.1	Cyber-Security Modbus Settings Configuration	438
18.5.1.1	Cyber-Security Non-Modbus Settings Configuration	438
18.5.1.2	User Management Configuration	439
18.5.1.3	Roles Configuration	440
18.5.1.4	Security Settings Configuration	441
18.5.1.5	Syslog Configuration	444

## Chapter 19 Installation 445

<b>19.1</b>	<b>Chapter Overview</b>	<b>446</b>
<b>19.2</b>	<b>Product Identification</b>	<b>447</b>
<b>19.3</b>	<b>Handling the Goods</b>	<b>448</b>
19.3.1	Receipt of the Goods	448
19.3.2	Unpacking the Goods	448
19.3.3	Storing the Goods	448
19.3.4	Dismantling the Goods	448
<b>19.4</b>	<b>Mounting the Device</b>	<b>449</b>
19.4.1	Flush Panel Mounting	449
19.4.1.1	Rack Mounting	449
19.4.1.2	Draw-out Unit Withdrawal and Insertion	450
19.4.2	Software Only	456
<b>19.5</b>	<b>Cables and Connectors</b>	<b>457</b>
19.5.1	Lug Orientation	457
19.5.2	Terminal Blocks	457
19.5.3	Power Supply Connections	459
19.5.4	Earth Connection	459
19.5.5	Phase Sequence and Transformer Polarity	460
19.5.6	Current Transformers	460
19.5.7	Voltage Transformer Connections	460
19.5.8	Watchdog (Critical Fail) Connections	461
19.5.9	EIA(RS)485 Connections	461
19.5.10	IRIG-B Connection	461

19.5.11	Opto-input Connections	462
19.5.12	Output Relay Connections	463
19.5.13	Ethernet Copper Connections	463
19.5.14	Ethernet Fibre Connections	463
19.5.15	USB Connection	463
<b>19.6</b>	<b>Case Dimensions and Panel Cutout</b>	<b>464</b>

## **Chapter 20 Commissioning Instructions 466**

<b>20.1</b>	<b>Chapter Overview</b>	<b>467</b>
<b>20.2</b>	<b>General Guidelines</b>	<b>468</b>
<b>20.3</b>	<b>Commissioning Test Menu</b>	<b>469</b>
20.3.1	Simulation	469
20.3.1.1	Pre-Fault	470
20.3.1.2	Fault	470
20.3.1.3	Post-Fault	470
20.3.2	Test LEDs	470
20.3.3	Opto-Inputs	471
20.3.4	Relay Outputs	471
20.3.5	GOOSE	471
<b>20.4</b>	<b>Commissioning Equipment</b>	<b>472</b>
20.4.1	Recommended Commissioning Equipment	472
20.4.2	Essential Commissioning Equipment	472
20.4.3	Advisory Test Equipment	473
<b>20.5</b>	<b>Product Checks</b>	<b>474</b>
20.5.1	Product Checks with the IED De-energised	474
20.5.1.1	Visual Inspection	475
20.5.1.2	Insulation	475
20.5.1.3	External Wiring	475
20.5.1.4	Watchdog (Critical Fail) Contact	475
20.5.1.5	Power Supply	475
20.5.2	Pxxx_CI_ProductChecksEnergised	476
20.5.2.1	Watchdog (Critical Fail) Contact	476
20.5.2.2	Date and Time	476
20.5.2.3	Test LEDs	476
20.5.2.4	Test Opto-inputs	476
20.5.2.5	Test Relay Outputs	477
20.5.2.6	Test Serial Communication Port COM1	477
20.5.2.7	Test Serial Communication Port COM2	478
20.5.2.8	Test Ethernet Communication	478
20.5.2.9	Test Current Inputs	478
20.5.2.10	Test Voltage Inputs	478
<b>20.6</b>	<b>Setting Checks</b>	<b>480</b>
20.6.1	Apply Application-specific Settings	480
20.6.1.1	Transferring Settings from a Settings File	480
20.6.1.2	Entering settings using the HMI	480
<b>20.7</b>	<b>Protection Timing Checks</b>	<b>482</b>
20.7.1	Overcurrent Check	482
20.7.2	Connecting the Test Circuit	482
20.7.3	Performing the Test	482
20.7.4	Check the Operating Time	482
<b>20.8</b>	<b>Onload Checks</b>	<b>483</b>
20.8.1	Confirm Current Connections	483
20.8.2	Confirm Voltage Connections	483
20.8.3	On-load Directional Test	484
<b>20.9</b>	<b>Final Checks</b>	<b>485</b>

<b>Chapter 21</b>	<b>Maintenance and Troubleshooting</b>	<b>486</b>
<b>21.1</b>	<b>Chapter Overview</b>	<b>487</b>
<b>21.2</b>	<b>Maintenance</b>	<b>488</b>
21.2.1	Motor Health Report	488
21.2.1.1	Motor Health Report Layout	489
<b>21.3</b>	<b>Maintenance Checks</b>	<b>495</b>
21.3.1	Targets and Alarms	495
21.3.2	Opto-Inputs	495
21.3.3	Relay Output Contacts	495
21.3.4	Measurement Accuracy	495
21.3.5	External Damage	496
21.3.6	Records	496
21.3.7	Out-of-Service Maintenance	496
21.3.8	Unscheduled Maintenance (system interruption)	496
<b>21.4</b>	<b>Replacing the Unit</b>	<b>497</b>
<b>21.5</b>	<b>Cleaning</b>	<b>498</b>
<b>21.6</b>	<b>Troubleshooting</b>	<b>499</b>
21.6.1	Self-Diagnostic Software	499
21.6.2	Power-up Errors	499
21.6.3	Self-test Errors	499
21.6.4	Error Code during Operation	503
21.6.5	Mal-operation during testing	503
21.6.5.1	Failure of Relay Output Contacts	503
21.6.5.2	Failure of Opto-inputs	504
21.6.5.3	Incorrect Analogue Signals	505
21.6.6	Flexlogic Equation Editor Troubleshooting	505
21.6.7	USB Port Troubleshooting	505
21.6.8	Repair and Modification Procedure	505
<b>Chapter 22</b>	<b>Technical Specifications</b>	<b>507</b>
<b>22.1</b>	<b>Chapter Overview</b>	<b>508</b>
<b>22.2</b>	<b>Interfaces</b>	<b>509</b>
22.2.1	Front USB Port	509
22.2.2	Rear Serial Port 1 (COM1)	509
22.2.3	Rear Serial Port 2 (COM2)	509
22.2.4	IRIG-B Port (shared with rear serial port COM1)	509
22.2.5	Rear Ethernet Ports Copper (ETH1, ETH2, ETH3)	510
22.2.6	Rear Ethernet Ports Fibre (ETH1, ETH2, ETH3)	510
<b>22.3</b>	<b>Performance of Motor Protection Functions</b>	<b>511</b>
22.3.1	Thermal Model	511
22.3.2	Current Unbalance	511
22.3.3	Mechanical Jam	512
22.3.4	Undercurrent	513
22.3.5	Overload Alarm	513
22.3.6	Short Circuit	514
22.3.7	Ground Fault	514
22.3.8	Acceleration Time	515
<b>22.4</b>	<b>Performance of Current Protection Functions</b>	<b>516</b>
22.4.1	Three-phase Overcurrent Protection (Directional/Non-directional)	516
22.4.1.1	Three-phase Overcurrent Directional Parameters	516
22.4.2	Earth Fault Protection (Directional/Non-directional)	516
22.4.2.1	Earth Fault Directional Parameters	517
22.4.3	Sensitive Earth Fault Protection (Non-directional)	517
22.4.4	Restricted Earth Fault Protection	517
<b>22.5</b>	<b>Performance of Voltage Protection Functions</b>	<b>518</b>

22.5.1	Phase Reversal	518
22.5.2	Undervoltage Protection	518
22.5.3	Overvoltage Protection	518
22.5.4	Residual Overvoltage Protection (Derived)	518
22.5.5	Positive Sequence Voltage Protection (UV)	519
22.5.6	Negative Sequence Voltage Protection (OV)	519
<b>22.6</b>	<b>Power Protection Functions</b>	<b>520</b>
22.6.1	Overpower/Underpower Protection	520
<b>22.7</b>	<b>Performance of Frequency Protection Functions</b>	<b>521</b>
22.7.1	Overfrequency Protection	521
22.7.2	Underfrequency Protection	521
<b>22.8</b>	<b>Performance of Monitoring and Control Functions</b>	<b>522</b>
22.8.1	Motor Control (MotorStarting)	522
22.8.1.1	Thermal Inhibit	522
22.8.1.2	Maximum Starting Rate	522
22.8.1.3	Maximum Cold/Hot Starting Rate	522
22.8.1.4	Time Between Starts	522
22.8.1.5	Restart Delay	522
22.8.1.6	Reduced Voltage Start	523
22.8.1.7	Breaker/Contactor Control	523
22.8.1.8	Local Control Mode (with Select Before Operate)	523
22.8.1.9	Switch Control	523
22.8.1.10	Current Transformer Supervision	523
22.8.1.11	Voltage Transformer Supervision	524
22.8.1.12	Breaker/Contactor State and Condition Monitoring	524
22.8.1.13	FlexLogic Timers	524
22.8.1.14	DC Supply Monitor	524
22.8.1.15	Power Factor	524
22.8.1.16	Breaker Arcing Current	525
22.8.1.17	Breaker Health	525
22.8.1.18	Demand	525
22.8.1.19	Harmonic Detection	525
22.8.1.20	Circuit Breaker Fail	526
22.8.1.21	Trip Bus (Trip Without FlexLogic)	526
22.8.1.22	Digital Elements	526
<b>22.9</b>	<b>Measurements and Recording</b>	<b>527</b>
22.9.1	Motor Measurements	527
22.9.2	Other Measurements (Currents, Voltages, Frequency, Power)	527
22.9.3	Disturbance Records	527
22.9.4	Event and Fault Records	528
22.9.5	Motor Records	528
22.9.5.1	Motor Start Records	528
22.9.5.2	Motor Start Statistics	528
22.9.5.3	Learned Data	528
<b>22.10</b>	<b>Regulatory Compliance</b>	<b>529</b>
22.10.1	EMC Compliance: 2014/30/EU	529
22.10.2	EMC Compliance: 2574-14 of ramadan 1436	529
22.10.3	LVD Compliance: 2014/35/EU	529
22.10.4	LVD Compliance: 2573-14 of ramadan 1436	529
22.10.5	RoHS Compliance 2011/65/EU and (EU) 2015/863	529
22.10.6	Mechanical Specifications	529
22.10.6.1	Physical Parameters	529
22.10.6.2	Enclosure Protection	530
22.10.6.3	Mechanical Robustness	530
22.10.6.4	Transit Packaging Performance	530
<b>22.11</b>	<b>Ratings</b>	<b>531</b>
22.11.1	AC Measuring Inputs	531
22.11.2	Current Transformer Inputs	531

22.11.3	Voltage Transformer Inputs	531
<b>22.12</b>	<b>Power Supply</b>	<b>532</b>
22.12.1	Auxiliary Power Supply Voltage	532
22.12.2	Nominal Burden	532
22.12.3	Auxiliary Power Supply Interruption	532
<b>22.13</b>	<b>Input/Output Connections</b>	<b>533</b>
22.13.1	Opto-Isolated Digital Inputs	533
22.13.1.1	Nominal Pickup and Reset Thresholds	533
22.13.1.2	Opto-Isolated Trip Circuit Supervision Inputs (TCS)*	533
22.13.2	RL1, RL2, and RL3 Output Contacts*	534
22.13.3	Auxiliary Output Contacts	534
22.13.4	Watchdog Contact	535
<b>22.14</b>	<b>Environmental Conditions</b>	<b>536</b>
22.14.1	Ambient Temperature Range	536
22.14.2	Temperature Endurance Test	536
22.14.3	Ambient Humidity Range	536
<b>22.15</b>	<b>Type Tests</b>	<b>537</b>
22.15.1	Insulation	537
22.15.2	Creepage Distances and Clearances	537
22.15.3	High Voltage (Dielectric) Withstand	537
22.15.4	Impulse Voltage Withstand Test	537
<b>22.16</b>	<b>Electromagnetic Compatibility</b>	<b>538</b>
22.16.1	1 MHz Burst High Frequency Disturbance Test	538
22.16.2	Damped Oscillatory Test	538
22.16.3	Immunity to Electrostatic Discharge	538
22.16.4	Electrical Fast Transient or Burst Requirements	538
22.16.5	Surge Withstand Capability	538
22.16.6	Surge Immunity Test	538
22.16.7	Immunity to Radiated Electromagnetic Energy	539
22.16.8	Radiated Immunity from Digital Communications	539
22.16.9	Immunity to Conducted Disturbances Induced by Radio Frequency Fields	539
22.16.10	Magnetic Field Immunity	539
22.16.11	Conducted Emissions	540
22.16.12	Radiated Emissions	540
22.16.13	Power Frequency	540
<b>Appendix A Ordering Options</b>		<b>541</b>
<b>Appendix B Settings and Signals</b>		<b>545</b>
<b>Appendix C Wiring Diagrams</b>		<b>547</b>
<b>Appendix D I/O Population - Type of Boards (usage and configuration)</b>		<b>553</b>



## CHAPTER 1

# INTRODUCTION

---

## 1.1 CHAPTER OVERVIEW

---

This chapter provides some general information about the technical manual and an introduction to the device(s) described in this technical manual.

This chapter contains the following sections:

Chapter Overview	2
Foreword	3
Product Scope	5
Features and Functions	6
Logic Diagrams	14
Functional Overview	15



---

## 1.2 FOREWORD

---

This technical manual provides a functional and technical description of GE Vernova's Multilin Agile IED, as well as a comprehensive set of instructions for using the device.

The level at which this manual is written assumes that you are already familiar with protection engineering and have experience in this discipline. The description of principles and theory is limited to that which is necessary to understand the products. For further details on general protection engineering theory, we refer you to GE Vernova's publication, PAAG (Protection & Automation Application Guide), which is available online or from our contact centre.

We have attempted to make this manual as accurate, comprehensive and user-friendly as possible. However, we cannot guarantee that it is free from errors. Nor can we state that it cannot be improved. We would therefore be very pleased to hear from you if you discover any errors or have any suggestions for improvement. Our policy is to provide the information necessary to help you safely specify, engineer, install, commission, maintain, and eventually dispose of this products. We consider that this manual provides the necessary information, but if you consider that more details are needed, please contact us.

All feedback should be sent to our contact centre via:

[GA.support@gevernova.com](mailto:GA.support@gevernova.com)

---

### 1.2.1 TARGET AUDIENCE

This manual is aimed towards all professionals charged with installing, commissioning, maintaining, troubleshooting, or operating any of the products within the specified product range. This includes installation and commissioning personnel as well as engineers who will be responsible for operating the product.

The level at which this manual is written assumes that installation and commissioning engineers have knowledge of handling electronic equipment and follow all safety precautions. Also, system and protection engineers have a thorough knowledge of protection systems and associated equipment.

---

### 1.2.2 TYPOGRAPHICAL CONVENTIONS

The following typographical conventions are used throughout this manual.

- The names for special keys appear in capital letters.  
For example: ENTER
- When describing software applications, menu items, buttons, labels etc as they appear on the screen are written in bold type.  
For example: Select **Save** from the file menu.
- Filenames and paths use the courier font  
For example: `Example\File.txt`
- Special terminology is written with leading capitals  
For example: Sensitive Earth Fault
- If reference is made to the IEDs internal settings and signals database, the menu group heading text is written in upper case italics  
For example: The *SYSTEM DATA*
- IED menu paths are shown with \ separators
- If reference is made to the IEDs internal settings and signals database, the value is written as follows:  
The **Language** setting in the *SYSTEM DATA* heading contains the value *English*

---

### 1.2.3 NOMENCLATURE

Due to the technical nature of this manual, many special terms, abbreviations and acronyms are used throughout the manual. Some of these terms are well-known industry-specific terms while others may be special product-specific terms used by GE Vernova. The first instance of any acronym or term used in a particular chapter is

explained. In addition, a separate glossary is available on the GE Vernova website, or from the GE Vernova contact centre.

We would like to highlight the following changes of nomenclature however:

- The word 'relay' is no longer used to describe the device itself. Instead, the device is referred to as the 'IED' (Intelligent Electronic Device), the 'device', or the 'product'. The word 'relay' is used purely to describe the electromechanical components within the device, i.e. the output relays.
- British English is used throughout this manual.
- The British term 'Earth' is used in favour of the American term 'Ground'.

---

## 1.2.4 COMPLIANCE

The device has undergone a range of extensive testing and certification processes to ensure and prove compatibility with all target markets. A detailed description of these criteria can be found in the Technical Specifications chapter.

---

## 1.3 PRODUCT SCOPE

---

Multilin Agile IEDs are microprocessor-based devices for the protection, control and management of medium voltage motors in industrial applications. Multilin Agile IEDs provide important motor protection elements that include thermal model, mechanical jam, short circuit and ground fault detection.

In addition to the protection features, the devices include a comprehensive range of other features and measurements and recording facilities to aid with power system diagnosis and fault analysis.

There are two different P24x models: P24N and P24D.

- The P24N is a basic motor protection device with current input only
- The P24D is an advanced motor protection device with current and voltage inputs

All models are available with a range of Input/Output options, which are described in the hardware design chapter and summarised in the ordering options.

The small footprint and the withdrawable option make the Multilin Agile ideal for panel mounting on either new or retrofit installations.

Setting programming can be accomplished with the front panel keys and display. Due to the numerous settings, this manual method can be laborious. Settings can also be entered with a PC running the EnerVista Configuration software. Even with minimal computer knowledge, this menu-driven software provides easy access to all front panel functions and to the IEC 61850 configuration tool. IEC 61850 standard is Cortec dependant (if available for the IED it should be configured using EnerVista Configuration software). Actual values and settings can be displayed, altered, stored, and printed. If settings are stored in a CID file, they can be downloaded at any time via the front panel port of the device using a USB cable connected to the USB port of a personal computer.

---

### 1.3.1 ORDERING OPTIONS

All current models and variants for this product are defined in an interactive spreadsheet called the Cortec. This is available on the company website.

Alternatively, you can obtain it via the Contact Centre at:

[GA.support@gevernova.com](mailto:GA.support@gevernova.com)

A copy of the Cortec is also supplied as a static table in the Appendices of this document. However, it should only be used for guidance as it provides a snapshot of the interactive data taken at the time of publication.

---

## 1.4 FEATURES AND FUNCTIONS

---

### 1.4.1 DESCRIPTION OF THE MULTILIN AGILE MOTOR PROTECTION SYSTEM

---

#### CPU

IED functions are controlled by a Texas Instruments AM5706 Sitara Processor, which measures all analogue signals and digital inputs, controls all output IEDs; and all the Ethernet communication protocols.

#### Analogue Input and Waveform Capture

Magnetic transformers are used to scale-down the incoming analogue signals from the source instrument transformers. The analogue signals are then passed through a low pass anti-aliasing filter. All signals are then simultaneously captured by sample and hold buffers to ensure there are no phase shifts. The signals are converted to digital values by a 16KHz 24-bit A/D converter before finally being passed on to the CPU for analysis. Both current and voltage are sampled sixty-four times per power frequency cycle. These 'raw' samples are scaled in software, then placed into the waveform capture buffer, thus emulating a fault recorder. The sampling rate for the Disturbance Recorder can be selected via setting from (128\64\32\16\8) samples per cycle. The waveforms can be retrieved from the IED via the EnerVista Configuration software for display and diagnostics or using the SCADA system.

#### Frequency

Frequency measurement is accomplished by measuring the time between zero crossings of the composite signal of three-phase bus voltages. The signals are passed through a low pass filter to prevent false zero crossings. Frequency tracking utilizes the measured frequency to set the sampling rate for voltage which results in better accuracy for the Discrete Fourier Transform (DFT) algorithm for off nominal frequencies.

The main frequency tracking source uses three-phase bus voltages. If a stable frequency signal is not available, then the tracking frequency defaults to the nominal system frequency.

#### Phasors, Transients, and Harmonics

All waveforms are processed eight times every cycle.

#### Processing of AC Current Inputs

The DC Decaying Removal Filter is a short window digital filter, which removes the DC decaying component from the asymmetrical current present at the moment a fault occurs. This is done for all current signals used for overcurrent protection; voltage signals use the same DC Decaying Removal Filter. This filter ensures no overreach of the overcurrent protection.

The Discrete Fourier Transform (DFT) uses exactly one cycle of samples to calculate a phasor quantity which represents the signal at the fundamental frequency; all harmonic components are removed. All subsequent calculations (e.g. power, etc.) are based upon the current and voltage phasors, such that the resulting values have no harmonic components. RMS (root mean square) values are calculated from one cycle of samples prior to filtering.

#### Protection Elements

Most of the voltage, current and frequency protection elements are processed eight times every cycle to determine if a pickup has occurred or a timer has expired. The voltage and current protection elements use RMS current/voltage, or the magnitude of the phasor.

## 1.4.2 INTRODUCTION TO LOGICAL DEVICES

### Logical Device definitions

The Multilin Agile IED implements an IEC 61850 server that can contain one or more Logical Devices. Each Logical Device contains a data model built from instances of specific Logical Nodes and must consist of at least an instance of the LPHD Logical Node (which is responsible for providing physical device information) and an instance of the LLN0 Logical Node (for addressing common issues across the Logical Device).

The IEC 61850 data model is contained within the Logical Devices detailed in the table below. All Multilin Agile devices will name the supported Logical Devices consistently to ensure that data model variables with the same purpose will have the same name within each Multilin Agile IED server.

Logical Device	Comment/Usage
Ctrl	Multilin Agile Controls Domain
Meter	Multilin Agile Measurements Domain
Prot	Multilin Agile Protection Domain
Master	Multilin Agile System Domain

### IEC 61850 Logical Device data model

The IEC 61850 Logical Device top-level data model consists of instances of Logical Nodes. The data model name for a Logical Node instance is constructed from an optional prefix (known as the wrapper), the Logical Node name, and an instance ID (or suffix).

The data model in Multilin Agile is in an alphabetically sorted order, rather than a logical order, because this is the natural order of the data when presented by a native MMS browser. (Higher level browsers can of course impart any ordering that they desire).

## 1.4.3 PROTECTION FUNCTIONS

The Multilin Agile IEDs offer the following protection functions. The IEC 61850 Logical Device data model for the Multilin Agile Protection Domain (Prot) is listed in the following table along with the protection functions description.

IEC 61850 Protection Domain (LD: Prot)	Product		ANSI	Protection Description	Stages
	LN Instance	P24N			
auxPTOVX	No	Yes	59X	Residual OV (M) Measured (Auxiliary Overvoltage*)	4
BrknCondGAPC1	Yes	Yes	46BC	Broken Conductor	1
gndPIOCX	Yes (P24N*1)	Yes (P24D*1)	50G	Ground (EF1 Measured) Instantaneous Overcurrent	1
gndPTOCX	Yes	Yes	51G	Ground (EF1 Measured) Time Overcurrent	1
hsePIOCX	Yes (P24N*2)	Yes (P24D*2)	50SG (50SEF)	Sensitive Ground (SEF Measured) Instantaneous Overcurrent	1
hsePTOCX	Yes (P24N*2)	Yes (P24D*2)	51SG	Sensitive Ground (SEF Measured) Time Overcurrent	1
LLN0	Yes	Yes		Protection Logical Device	NA
LPHD	Yes	Yes		Physical Device Information	NA
MotThmPTTR1	Yes	Yes	49	Motor Thermal Model	1
ndPIOCX	Yes	Yes	50N	Neutral (EF2 Derived) Instantaneous Overcurrent	2

IEC 61850 Protection Domain (LD: Prot)	Product		ANSI	Protection Description	Stages
	LN Instance	P24N			
ndPTOCX	Yes	Yes	51N	Neutral (EF2 Derived) Time Overcurrent	1
ndPTOVX	No	Yes	59N	Residual OV (D) Derived (Neutral OV*)	1
ndRDIRX	No	Yes	67N	Neutral (EF2 Derived) Directional Overcurrent	1
ngseqPTOVX	No	Yes	59_2 (47)	Negative Sequence Overvoltage	1
PDOPX	No	Yes	32OF	Underpower	2
PDUPX	No	Yes	32LF	Overpower	2
phsPIOCX	Yes	Yes	50P (50)	Phase Instantaneous Overcurrent	2
phsPTOCX	Yes	Yes	51P (51)/ 51PV (51V)	Phase Time Overcurrent/Phase Time Overcurrent with Voltage Restraint	1
phsPTOVX	No	Yes	59P (59)	Phase Overvoltage	2
phsPTUVX	No	Yes	27P (27)	Phase Undervoltage	4
phRDIRX	No	Yes	67P (67)	Phase Directional Overcurrent	1
posseqPTOVX	No	Yes	59_1 (59V)	Positive Sequence Overvoltage	2
posseqPTUVX	No	Yes	27_1 (27V)	Positive Sequence Undervoltage	2
PTOFX	No	Yes	81O	Over Frequency	4
PTUC1	Yes	Yes	37	Undercurrent	1
PTUFX	No	Yes	81U	Under Frequency	4
RGFPDIF1	Yes	Yes	64N	Restricted Earth Fault	1
SwOntoFltGAPC1	Yes	Yes	50 SOTF	Switch on to Fault	1
ThmOvIPTTR1	Yes	Yes	49	Thermal Overload	1
ScPIOCX	Yes	Yes	57	Shor Circuit	2
JamPIOCX	Yes	Yes	51R	Mechanical Jam	2
GndfltPIOCX	Yes	Yes	50SG/G	Ground Fault	2
accelPTOC	Yes	Yes	50LR	Acceleration time	1
UnbalPTOC	Yes	Yes	46	Current Unbalance	1
N/A	Yes	Yes	47	Phase Reversal	1

*Note:*  
'*X*' represents the instance number of the function.

*Note:*  
\*indicates IEC 61850 naming description

## 1.4.4 CONTROL FUNCTIONS

The Multilin Agile IEDs offer the following control functions:

Feature	
Power-up diagnostics and continuous self-monitoring	
Alternative setting groups (6)	
Programmable LEDs and Pushbuttons/Function keys (Cortec dependant)	
Watchdog contact (Critical Fail)	
Basic and advanced cyber-security (Cortec dependant)	
Programmable allocation of digital inputs and outputs	
Control inputs	
Flexlogic Equation Editor	
Circuit breaker control, status & condition monitoring	
Trip circuit and coil supervision	
CT supervision (only for products with CT inputs)	
VT supervision (only for products with CT & VT inputs)	
Motor start record	6 records, each containing a total of 60 seconds of motor starting data
Learned data	250 records

The IEC 61850 Logical Device data model for the Multilin Agile Controls Domain (Ctrl) is listed in the following table along with the control functions description.

IEC 61850 Controls Domain (LD: Ctrl)	Product		ANSI	Control Description	Stages
	LN Name	P24N			
CSWX	Yes	Yes	1	Switch Controller	8
CTSupGAPC1	Yes	Yes	CTS	CT Supervision	1
HaDetPHARX	Yes	Yes		Harmonic Detection	6
LLN0	Yes	Yes		Controls Logical Device	N/A
LPHD	Yes	Yes		Physical Device Information	N/A
RBRF1	Yes	Yes	50BF	Breaker Failure (CB Fail & I<)	1
TVTR1	No	Yes	VTS (60)	VT Supervision	1
XCBR1	Yes	Yes	52	CB Control (Circuit Breaker)	1
XSWIX	Yes	Yes	33	SW Control (Circuit Switch)	8
MtrStrtRDRE	Yes	Yes		Motor Start Records	1
ZMOT	Yes	Yes		Motor Status	1
	Yes	Yes		CB Monitoring	1
	Yes	Yes		Contactors Monitoring	1

*Note:*  
*'X' represents the instance number of the function.*

*Note:*  
\*indicates IEC 61850 naming description

### 1.4.5 MEASUREMENT FUNCTIONS

The device offers the following measurement functions:

Measurement Function	Details
Measurements (Exact range of measurements depend on the device model)	Measured currents and calculated sequence and RMS currents Measured voltages and calculated sequence and RMS voltages Power and energy quantities Peak, fixed and rolling demand values Frequency measurements Specific motor measurement Others measurements
Disturbance records (waveform capture, oscillography) Channels/duration each or total/samples per cycle	128\64\32\16\8 samples/cycle
Fault Reports	25
Event Records/Event logging	2048
Time Stamping of Opto-inputs	Yes
Specific Motor Records & Measurements*	Motor load Current unbalance Voltage unbalance Other measurements

The IEC 61850 Logical Device data model for the Multilin Agile Measurements Domain (Meter) is listed in the following table.

IEC 61850 Measurements Domain (LD: Meter)	Product		ANSI	Meter Description	Stages
LN Instance	P24N	P24D			
HThdMHA11	Yes	Yes		Harmonic Currents Metering (Harmonics and Interharmonics)	N/A
LLN0	Yes	Yes		Meter Logical Device	N/A
LPHD	Yes	Yes		Physical Device Information (name plate, health)	N/A
MMTR1	No	Yes		Energy Metering (+Whr, -Whr, +VARhr, -VARhr)	N/A
MMXU1	Yes	No		CT Bank-B Metering	N/A
MMXU1	No	Yes		VT Bank-A, CT Bank-B, Frequency and Power Metering	N/A
MSQI1	No	Yes		Sequence Currents and Voltages (Sequence Metering*)	N/A
MSQI1	Yes	No		Sequence Currents (Sequence Metering*)	N/A
PwrDmdMMTR1	No	Yes		Power Demand Metering	
CurDmdMMTR1	Yes	Yes		Current Demand Metering	

*Note:*  
\*X' represents the instance number of the function.



*Note:*  
\*indicates IEC 61850 naming description

## 1.4.6 COMMUNICATION FUNCTIONS

The device offers the following communication functions:

Communication Function	Details
Local HMI	Yes
Multi-language HMI (English (UK), English (US), Spanish (*1), French, Russian, Turkish (*1))	Yes
Front port	USB (Maintenance)
Rear serial port 1 (COM1)	RS485 or IRIG-B
Rear serial port 2 (COM2)	RS485*
Rear Ethernet port 1 (ETH1)	Single Channel Ethernet (Copper or Fibre*) for Engineering/SCADA Communication
Rear Ethernet ports 2 and 3 (ETH2 & ETH3)*	Dual channel Ethernet (Copper or Fibre) supporting redundant/LLA/independent mode of SCADA communication Ethernet Protocols available*: Modbus TCP, DNP3oE, IEC61850 Ed.2*, IEC62439-3 (PRP/HSR)
Serial protocols available	Modbus RTU, DNP3 Serial, IEC 60870-5-103
Ethernet protocols available	Modbus TCP, DNP3oE, IEC 61850 Ed.2*
Time synchronisation	IRIG-B, SNTP*, PTP*, communication protocols synchronisation*
Virtual inputs	256
Cyber-security	Yes*
EnerVista Configuration software	Yes

*Note:*  
(\*1) Cortec dependant.

*Note:*  
(\*1) Spanish available at HMI only. Turkish available at HMI only (Turkish/English partial implementation for firmware 05A). HMI only - means the HMI language is supported, but the EnerVista Configuration Software is in English.

## 1.4.7 SYSTEM FUNCTIONS

Multilin Agile IEDs offer the following generic system functions. The IEC 61850 Logical Device data model for the Multilin Agile System Domain (Master) is listed in the following table along with the generic system functions description.

IEC 61850 System Domain (LD: Master)	Product		ANSI	Master Description	Stages
	P24N	P24D			
LN Instance					
GGIO1	Yes	Yes		GGIO1 Indication (1 to 32 Status)	32
GGIO2	Yes	Yes		Opto Inputs status (the number of opto inputs depends of the Cortec I/O option selected)	Cortec related
GGIO3	Yes	Yes		Virtual Inputs (1-256)	256

IEC 61850 System Domain (LD: Master)	Product		ANSI	Master Description	Stages
	P24N	P24D			
GGIO4	Yes	Yes		Virtual Outputs (1-256)	256
GGIO5	Yes	Yes		Remote Inputs (1-128)	128
GGIO6	Yes	Yes		Output Relays status (the number of relay outputs depends of the Cortec I/O option selected)	Cortec related
LEDsIHMI1	Yes	Yes		Led status of the front panel	N/A
LCCH1	Yes	Yes		Physical communication channel supervision	N/A
LGOSX	Yes	Yes		GOOSE Subscription (1 to 32)	32
LLN0	Yes	Yes		Master Logical Device	N/A
LPHD	Yes	Yes		Physical Device Information	N/A
LTIM1	Yes	Yes		Time Management	
TmCIKLTMS1	Yes	Yes		Time Master Supervision	N/A
TransRcdRDRE1	Yes	Yes		Transients Records status	N/A
TmCIKLTMS1	Yes	Yes	Yes	Time Master Supervision	
TransRcdRDRE1	Yes	Yes	Yes	Transient Records Status	

*Note:*  
*X' represents the instance number of the function.*

*Note:*  
*\*indicates IEC 61850 naming description*

### 1.4.8 HMI MAIN MENU




Figure 1: HMI Main Menu Hierarchy

## 1.5 LOGIC DIAGRAMS

This technical manual contains many logic diagrams, which should help to explain the functionality of the device. Although this manual has been designed to be as specific as possible to the chosen product, it may contain diagrams, which have elements applicable to other products. If this is the case, a qualifying note will accompany the relevant part.

The logic diagrams follow a convention for the elements used, using defined colours and shapes. A key to this convention is provided below. We recommend viewing the logic diagrams in colour rather than in black and white. The electronic version of the technical manual is in colour, but the printed version may not be. If you need coloured diagrams, they can be provided on request by calling the contact centre and quoting the diagram number.




Figure 2: Key to logic diagrams

# 1.6 FUNCTIONAL OVERVIEW




Figure 3: Functional overview

## CHAPTER 2

# SAFETY INFORMATION

---

## 2.1 CHAPTER OVERVIEW

---

This chapter provides information about the safe handling of the equipment. The equipment must be properly installed and handled in order to maintain it in a safe condition and to keep personnel safe at all times. You must be familiar with information contained in this chapter before unpacking, installing, commissioning, or servicing the equipment.

This chapter contains the following sections:

Chapter Overview	17
Health and Safety	18
Symbols	19
Installation, Commissioning and Servicing	20
Decommissioning and Disposal	25
Regulatory Compliance	26

---

## 2.2 HEALTH AND SAFETY

---

Personnel associated with the equipment must be familiar with the contents of this Safety Information.

When electrical equipment is in operation, dangerous voltages are present in certain parts of the equipment. Improper use of the equipment and failure to observe warning notices could cause irreversible damage to the equipment and could lead to property damage, personal injury, and/or death.

Only qualified personnel may work on or operate the equipment. Qualified personnel are individuals who are:

- familiar with the installation, commissioning, and operation of the equipment and the system to which it is being connected.
- familiar with accepted safety engineering practises and are authorised to energise and de-energise equipment in the correct manner.
- trained in the care and use of safety apparatus in accordance with safety engineering practises
- trained in emergency procedures (first aid).

The documentation provides instructions for installing, commissioning and operating the equipment. It cannot, however cover all conceivable circumstances. In the event of questions or problems, do not take any action without proper authorisation. Please contact your local sales office and request the necessary information.



## 2.3 SYMBOLS

Throughout this manual you will come across the following symbols. You will also see these symbols on parts of the equipment.



**Caution:**  
Refer to equipment documentation. Failure to do so could result in damage to the equipment



**Warning:**  
Risk of electric shock



**Warning:**  
Risk of damage to eyesight



Earth terminal. *Note: This symbol may also be used for a protective conductor (earth) terminal if that terminal is part of a terminal block or sub-assembly.*



Protective conductor (earth) terminal



Instructions on disposal requirements

**Note:**

The term 'Earth' used in this manual is the direct equivalent of the North American term 'Ground'.

## 2.4 INSTALLATION, COMMISSIONING AND SERVICING

### 2.4.1 LIFTING HAZARDS

Many injuries are caused by:

- Lifting heavy objects
- Lifting things incorrectly
- Pushing or pulling heavy objects
- Using the same muscles repetitively

Plan carefully, identify any possible hazards and determine how best to move the product. Look at other ways of moving the load to avoid manual handling. Use the correct lifting techniques and Personal Protective Equipment (PPE) to reduce the risk of injury.

### 2.4.2 ELECTRICAL HAZARDS



**Caution:**  
All personnel involved in installing, commissioning, or servicing this equipment must be familiar with the correct working procedures.



**Caution:**  
Consult the equipment documentation before installing, commissioning, or servicing the equipment.



**Caution:**  
Always use the equipment as specified. Failure to do so will jeopardise the protection provided by the equipment.



**Warning:**  
Removal of equipment panels or covers may expose hazardous live parts. Do not touch until the electrical power is removed. Take care when there is unlocked access to the rear of the equipment.



**Warning:**  
Isolate the equipment before working on the terminal strips.



**Warning:**  
Use a suitable protective barrier for areas with restricted space, where there is a risk of electric shock due to exposed terminals.



**Caution:**  
Disconnect power before disassembling. Disassembly of the equipment may expose sensitive electronic circuitry. Take suitable precautions against electrostatic voltage discharge (ESD) to avoid damage to the equipment.



**Warning:**  
**NEVER** look into optical fibres or optical output connections. Always use optical power meters to determine operation or signal level.



**Warning:**  
 Testing may leave capacitors charged to dangerous voltage levels. Discharge capacitors by reducing test voltages to zero before disconnecting test leads.



**Caution:**  
 Operate the equipment within the specified electrical and environmental limits.



**Caution:**  
 Before cleaning the equipment, ensure that no connections are energised. Use a lint free cloth dampened with clean water.

*Note:*

Contact fingers of test plugs are normally protected by petroleum jelly, which should not be removed.

### 2.4.3 FUSING REQUIREMENTS



**Caution:**  
 Where UL/CSA listing of the equipment is not required, a high rupture capacity (HRC) fuse type with a maximum current rating of 10A and a minimum dc rating of 250 V dc may be used for the auxiliary supply (for example Red Spot type NIT or TIA).



**Caution:**  
 Digital input circuits should be protected by a high rupture capacity NIT or TIA fuse with maximum rating of 2A. for safety reasons, current transformer circuits must never be fused. Other circuits should be appropriately fused to protect the wire used.



**Caution:**  
 CTs must NOT be fused since open circuiting them may produce lethal hazardous voltages

### 2.4.4 EQUIPMENT CONNECTIONS



**Warning:**  
 Terminals exposed during installation, commissioning and maintenance may present a hazardous voltage unless the equipment is electrically isolated.



**Caution:**  
 Tighten M3.5 clamping screws of heavy duty terminal block connectors to a nominal torque of 0.8 Nm.  
 Tighten captive screws of terminal blocks to a nominal torque value of 0.5 Nm.



**Caution:**  
It is highly recommended that insulated crimp terminations for voltage and current connections.



**Caution:**  
Always use the correct crimp terminal and tool according to the wire size.



**Caution:**  
Watchdog (self-monitoring) contacts are provided to indicate the health of the device on some products. We strongly recommend that you hard wire these contacts into the substation's automation system, for alarm purposes.

## 2.4.5 PROTECTION CLASS 1 EQUIPMENT REQUIREMENTS



**Caution:**  
Earth the equipment with the supplied PCT (Protective Conductor Terminal).



**Caution:**  
Do not remove the PCT.



**Caution:**  
The PCT is sometimes used to terminate cable screens. Always check the PCT's integrity after adding or removing such earth connections.



**Caution:**  
Use a locknut or similar mechanism to ensure the integrity of stud-connected PCTs.



**Caution:**  
The recommended minimum PCT wire size is 2.5 mm<sup>2</sup> for countries whose mains supply is 230 V (e.g. Europe) and 3.3 mm<sup>2</sup> for countries whose mains supply is 110 V (e.g. North America). This may be superseded by local or country wiring regulations.



**Caution:**  
The PCT connection must have low-inductance and be as short as possible.



**Caution:**  
All connections to the equipment must have a defined potential. Connections that are pre-wired, but not used, should be earthed, or connected to a common grouped potential.

## 2.4.6 PRE-ENERGISATION CHECKLIST



**Caution:**  
Check voltage rating/polarity (rating label/equipment documentation).



**Caution:**  
Check CT circuit rating (rating label) and integrity of connections.



**Caution:**  
Check protective fuse or miniature circuit breaker (MCB) rating.



**Caution:**  
Check integrity of the PCT connection.



**Caution:**  
Check voltage and current rating of external wiring, ensuring it is appropriate for the application.

## 2.4.7 PERIPHERAL CIRCUITRY



**Warning:**  
Do not open the secondary circuit of a live CT since the high voltage produced may be lethal to personnel and could damage insulation. Short the secondary of the line CT before opening any connections to it.

*Note:*

*For this IED, the current transformers remain in the chassis if the unit is disassembled. Therefore external shorting of the CTs may not be required.*



**Caution:**  
Where external components such as resistors or voltage dependant resistors (VDRs) are used, these may present a risk of electric shock or burns if touched.

**Warning:**

Data communication cables with accessible screens and/or screen conductors, (including optical fibre cables with metallic elements), may create an electric shock hazard in a sub-station environment if both ends of the cable screen are not connected to the same equipotential bonded earthing system.

To reduce the risk of electric shock due to transferred potential hazards:

- i. The installation shall include all necessary protection measures to ensure that no fault currents can flow in the connected cable screen conductor.
- ii. The connected cable shall have its screen conductor connected to the protective conductor terminal (PCT) of the connected equipment at both ends.
- iii. The protective conductor terminal (PCT) of each piece of connected equipment shall be connected directly to the same equipotential bonded earthing system.
- iv. If, for any reason, both ends of the cable screen are not connected to the same equipotential bonded earth system, precautions must be taken to ensure that such screen connections are made safe before work is done to, or in proximity to, any such cables.
- v. No equipment shall be connected to any download or maintenance circuits or connectors of this product except temporarily and for maintenance purposes only.
- vi. Equipment temporarily connected to this product for maintenance purposes shall be protectively earthed (if the temporary equipment is required to be protectively earthed), directly to the same equipotential bonded earthing system as the product.

## 2.4.8 UPGRADING/SERVICING

**Warning:**

Do not insert or withdraw modules, PCBs or expansion boards from the equipment while energised, as this may result in damage to the equipment. Hazardous live voltages would also be exposed, endangering personnel.

**Caution:**

Internal modules and assemblies can be heavy and may have sharp edges. Take care when inserting or removing modules into or out of the IED.

## 2.5 DECOMMISSIONING AND DISPOSAL

**Caution:**

Before decommissioning, completely isolate the equipment power supplies (both poles of any dc supply). The auxiliary supply input may have capacitors in parallel, which may still be charged. To avoid electric shock, discharge the capacitors using the external terminals before decommissioning.

**Caution:**

Avoid incineration or disposal to water courses. This product cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling return this product to your supplier or a designated collection point. For more information go to [www.recyclethis.info](http://www.recyclethis.info)

**Note:**

Store the unit indoors in a cool, dry place. If possible, store in the original packaging. Follow the storage temperature range outlined in the Specifications. To avoid deterioration of electrolytic capacitors, power up units that are stored in a deenergized state once per year, for one hour continuously.

---

## 2.6 REGULATORY COMPLIANCE

---

Compliance with the European Commission Direction on EMC, LVD and RoHS is via the self certification route.



---

### 2.6.1 EMC COMPLIANCE: 2014/30/EU

The product specific Declaration of Conformity (DoC) lists the relevant harmonised standard(s) or conformity assessment used to demonstrate compliance with the EMC directive.

---

### 2.6.2 LVD COMPLIANCE: 2014/35/EU

The product specific Declaration of Conformity (DoC) lists the relevant harmonized standard(s) or conformity assessment used to demonstrate compliance with the LVD directive.

Safety related information, such as the installation I overvoltage category, pollution degree and operating temperature ranges are specified in the Technical Data section of the relevant product documentation and/or on the product labelling.

Unless otherwise stated in the Technical Data section of the relevant product documentation, the equipment is intended for indoor use only. Where the equipment is required for use in an outdoor location, it must be mounted in a specific cabinet or housing to provide the equipment with the appropriate level of protection from the expected outdoor environment.

---

### 2.6.3 ROHS COMPLIANCE 2011/65/EU AND (EU) 2015/863

The product complies with the directive of the Council of the European Communities on harmonization of the laws of the Member States concerning restriction on usage of hazardous substances in electrical and electronic equipment (RoHS Directive 2011/65/EU). This conformity has been proved by tests performed according to the Council Directive in accordance with the standard EN 50581.



## CHAPTER 3

# HARDWARE DESIGN

---

## 3.1 CHAPTER OVERVIEW

---

This chapter provides information about the product's hardware design.

This chapter contains the following sections:

Chapter Overview	28
Hardware Architecture	29
Mechanical Implementation	30
Front Panel	35
Keypad	38

## 3.2 HARDWARE ARCHITECTURE

The main components comprising devices based on the Multilin Agile platform are as follows:

- The housing, consisting of a front panel and connections at the rear
- The Main processor module consisting of the main CPU (Central Processing Unit), memory and an interface to the front panel HMI (Human Machine Interface)
- An I/O board consisting of output relay contacts and digital opto-inputs with optional redundant rear communications
- Power supply with rear communication connectors

All modules are connected by a parallel data and address bus, which allows the processor module to send and receive information to and from the other modules as required. There is also a separate serial data CAN bus for conveying sampled data from the modules to the CPU. These parallel and serial databuses are shown as a single interconnection module in the following figure, which shows typical modules and the flow of data between them.




Figure 4: Hardware design overview

### 3.2.1 MEMORY AND REAL TIME CLOCK

The IED contains flash memory for storing the following operational information:

- Fault, disturbance and motor records
- Events
- Alarms
- Measurement values
- Latched trips
- Latched contacts

Flash memory is non-volatile and therefore no backup battery is required.

A dedicated Supercapacitor keeps the on board real time clock operational for up to seven days after power down.

### 3.3 MECHANICAL IMPLEMENTATION

This equipment is suitable for mounting on the flat surface of a Type 1 Enclosure. All products based on the Multilin Agile platform have common hardware architecture. The hardware comprises two main parts; the cradle and the housing.

The cradle consists of the front panel which is attached to a carrier board into which all of the hardware boards and modules are connected. The products have been designed such that all the boards and modules comprising the product are fixed into the cradle and are not intended to be removed or inserted after the product has left the factory.

The housing comprises the housing metalwork, magnetic module and connectors at the rear into which the boards in the cradle plug into.

*Note:*

*The magnetic module remains attached to the chassis to avoid opening the current transformers circuit.*




Figure 5: Exploded view of IED - 20TE



Figure 6: Exploded view of IED - 30TE IEC version



Figure 7: Exploded view of IED - 30TE ANSI version

### 3.3.1 HOUSING VARIANTS

The Multilin Agile range of products are implemented in one case size. Case dimensions for industrial products usually follow modular measurement units based on rack sizes. These are: U for height and TE for width, where:

- 1U = 1.75 inches = 44.45 mm
- 1TE = 0.2 inches = 5.08 mm

The products are available in panel-mount or standalone versions. All products are nominally 4U high. This equates to 177.8 mm or 7 inches.

The cases are pre-finished steel with a black covering of hybrid epoxi-polyester powder. This provides good grounding at all joints, providing a low resistance path to earth that is essential for performance in the presence of external noise.

The case width depends on the product type and its hardware options. The case dimensions are as follows:

Case Width (TE)	Case Width (mm)
20TE	102.4 mm (4 inches)
30TE	154.2 mm (6.07 inches)

### 3.3.2 20TE REAR PANEL

The basic 20TE rear panel consists of one 16-pole terminal block connector and one 24-pole 45 degree connector. An optional I/O module can be ordered with an additional 16-pole 45 degree connector.




Figure 8: 20TE rear panel

### 3.3.3 30TE REAR PANEL

The basic 30TE rear panel consists of one 16-pole terminal block connector for PIN terminals options, one 24-pole 45 degree connector. In addition, an optional I/O module can be ordered with an additional 16-pole 45 degree connector. Up to two optional I/O modules can be ordered with an additional 24-pole 45 degree connector.

For RING terminals option, a 24-pole connector is available on slots C and F.




Figure 9: 30TE rear panel (PIN terminals)




Figure 10: 30TE rear panel (Hybrid PIN + RING terminals)

### 3.3.4 TERMINAL CONNECTIONS

#### 3.3.4.1 I/O OPTIONS (20TE)

Cortec I/O Option	Description
B	5 inputs (3 binary inputs + 2 Trip Circuit Supervision inputs) + 7 outputs configurable + 1 watchdog (critical fail)
C	8 inputs (6 binary inputs + 2 Trip Circuit Supervision inputs) + 5 outputs configurable + 1 watchdog (critical fail)
D	11 inputs (9 binary inputs + 2 Trip Circuit Supervision inputs) + 11 outputs configurable + 1 watchdog (critical fail)

Cortec I/O Option	Description
E	14 inputs (12 binary inputs + 2 Trip Circuit Supervision inputs) + 9 outputs configurable + 1 watchdog

### 3.3.4.2 I/O OPTIONS (30TE)

Cortec I/O Option	Description
D	11 inputs (9 binary inputs + 2 Trip Circuit Supervision inputs) + 11 outputs configurable + 1 watchdog (20TE/30TED)
E	14 inputs (12 binary inputs + 2 Trip Circuit Supervision inputs) + 9 outputs configurable + 1 watchdog (20TE/30TEE)
F, P (*1)	16 inputs (12 binary inputs + 4 Trip Circuit Supervision inputs) + 11 outputs configurable + 1 watchdog (30TEF, 30TEP (*1))
G, P (*2)	22 inputs (18 binary inputs + 4 Trip Circuit Supervision inputs) + 15 outputs configurable + 1 watchdog (30TEG, 30TER (*2))
H	30 inputs (24 binary inputs + 6 Trip Circuit Supervision inputs) + 21 outputs configurable + 1 watchdog (30TEH)
J	24 inputs (18 binary inputs + 6 Trip Circuit Supervision inputs) + 25 outputs configurable + 1 watchdog (30TEJ)

*Note:*  
All I/O options have (at least) two Trip Circuit Supervision (TCS) inputs.

*Note:*  
All I/O options have a Critical Fail NC output contact.

*Note:*  
For details of terminal connections, refer to the Wiring Diagrams Appendix.

*Note:*  
For details of inputs and output selections, refer to the Ordering Options Appendix

*Note:*  
For details of input and output boards and settings configuration, refer to the "I/O Population - Type of Boards (usage and configuration) Appendix

*Note:*  
(\*1): I/O Boards F and P have the same number of inputs and outputs, but board F has a Pin terminal option and board P has a Ring terminal option.

*Note:*  
(\*2): I/O Boards G and R have the same number of inputs and outputs, but board G has a Pin terminal option and board G has a Ring + Pin (Hybrid) terminal option.



## 3.4 FRONT PANEL

The IEDs front panel provides an interface that will vary depending on the Cortec option selected (\*). Features provided are a liquid crystal display (text based or graphical (\*)), LED status indicators (fixed and programmable (\*)), keypad with control keys (\*), function keys (\*), Local/Remote (L/R) key (\*), Start (I)/Stop (O) keys (\*) and a USB program port.

The display and status indicators show device information automatically. The control keys are used to select the appropriate menu to enter setpoints or display measured values. The function keys are available for custom use (\*). Local/Remote (L/R) key is used to select the local or remote mode (\*). Start (I)/Stop (O) keys (\*) are used to be able to control the motor (breaker/contactors) from the HMI. The USB program port is also provided for connection with a computer.

### 3.4.1 20TE FRONT PANEL



**Figure 11: Front panel (20TE)**

The figure shows the front panel for the 20TE variant.

It consists of:

- LCD display (text based) with 2 dedicated navigation keys
- Keypad
- USB port
- 4 x fixed function tri-colour LEDs
- 4 x programmable tri-colour LEDs

### 3.4.2 30TE FRONT PANEL

30TE front panel has two variants (IEC or ANSI) both including color graphical liquid crystal display, keypad, function keys, fixed and extended programmable LEDs, Local/Remote (L/R) key, Start (I)/Stop (O) keys.

A colour graphical HMI display (ANSI variant and IEC variant) can be ordered with or without added Bay Control functionality for multiple SLDs configuration. For a detailed explanation, refer to the Cortec in Appendix A Ordering Options.

Depending on the Cortec option selected (IEC or ANSI), the symbology used on the Graphical HMI will be IEC or ANSI and some of the control keys name and color may vary.

The functionality of the keys (Clear/Reset, Read/Home) remains the same in both variants (IEC/ANSI), besides the name or the color. It is the name and look and feel which varies from one to the other.

The functionality of the keys to start or stop the motor remain the same, but the name, color and position differ between IEC and ANSI variants.

- **IEC Start (I) key is the third key from the left** (closest to the Enter key), and **IEC Stop (O) key is the second key from the left** (closest to the L/R key). Both Start and Stop keys are blue.
- **ANSI Start key (in green) is the second key from the left** (closest to the L/R key), and **ANSI Stop key (in red) is the third key from the left** (closest to the Enter key). The Start key is green and the Stop key is red.

### 3.4.2.1 30TE IEC FRONT PANEL



**Figure 12: Front panel (30TE IEC variant)**

It consists of:

- LCD display (Graphical) with IEC symbols with 5 dedicated tab pushbuttons
- Keypad with Clear (C), Read, Enter and Up/Down/Left/Right selection keys
- USB port
- 4 x fixed function tri-colour LEDs
- 16 x programmable tri-colour LEDs
- 6 x programmable function keys with their corresponding 6 x programmable tri-colour LEDs
- Stop (O)/Start (I) Motor (breaker/contactors) control keys
- Open (O)/Close (I) breaker control keys

### 3.4.2.2 30TE ANSI FRONT PANEL



**Figure 13: Front panel (30TE ANSI variant)**

It consists of:

- LCD display (Graphical) with IEC symbols with 5 dedicated tab pushbuttons
- Keypad with Reset, Home, Enter and Up/Down/Left/Right selection keys
- USB port
- 4 x fixed function tri-colour LEDs
- 16 x programmable tri-colour LEDs
- 6 x programmable function keys with their corresponding 6 x programmable tri-colour LEDs
- Local/Remote (L/R) key to select Local/Remote
- Open (green)/Close (red) breaker control keys

## 3.5 KEYPAD

The keypad may vary depending on the Cortec option selected, either 20TE or 30TE IEC/30TE ANSI (Multilin Agile).

20TE and 30TE have a different navigation through the menus using the keypad, although some of the keys may remain the same (look and feel and functionality), others may vary. 30TE has a wider range of keys and a graphical display to access to the IED menus, dedicated motor switching device (Breaker/Contactor) control keys, Local/Remote key, SLD's. 20TE full navigation relies on the keypad and the text display, including breaker control for full navigation.

For 30TE, the functionality of the keys (Clear/Reset, Read/Home) remains the same in both variants (IEC/ANSI). Besides the name or the color, it is only the name and look and feel which varies from one to the other.

The functionality of the keys to Start (I) or Stop (O) the motor remain the same, but the name, color and position differ between IEC and ANSI variants.

- The **IEC Start (I) key is the third key from the left** (closest to the Enter key), and the **IEC Stop (O) key is the second key from the left** (closest to the L/R key). Both Start and Stop keys are blue.
- The **ANSI Start key (green) is the second key from the left** (closest to the L/R key), and the **ANSI Stop key (red) is the third key from the left** (closest to the Enter key). The Start key is green and the Stop key is red.

### 3.5.1 CLEAR/RESET KEY FUNCTIONALITY

Multilin Agile IEDs (20TE and 30TE) since 8A release onwards, provide the capability of selecting the primary functionality of the **Clear/Reset key** (either being Clear or Reset).

The **Clear/Reset Key** setting at **SETPOINTSDEVICEINSTALLATION** path defines the primary functionality of the Clear/Reset and the behaviour of Read/Home keys on the front panel.

The primary function of the key will be linked to the short pulsation of the key, and the secondary function of the key will be linked to the long pulsation of the key. The change on the functionality of the **Clear/Reset key** will affect the behaviour of the **Read/Home key**.

When the **Clear/Reset Key** setting is configured as Clear:





- The **short pulse** execution of the **Clear/Reset key** will issue a **Clear** command. In the 20TE model only, the **short pulse** execution can also be used for **setting confirmation**.
- The **long pulse** execution of the **Clear/Reset key** will issue a **Reset** command.
- The **short pulse** execution of the **Read/Home key** will show **Targets** (when Alarm LED is ON) and **Last Trip** data (when Trip LED is ON) for 20TE, and will navigate through **Home Screens** for 30TE.


When the **Clear/Reset Key** setting is configured as Reset:

- The **short pulse** execution of the **Clear/Reset key** will issue a **Reset** command.
- The **short pulse** execution of the **Read/Home key** will issue a **Clear** command. In the 20TE model only, the **short pulse** execution can also be used for **setting confirmation**.
- The **long pulse** execution of the **Read/Home key** will show **Targets** (when Alarm LED is ON) and **Last Trip** data (when Trip LED is ON) for 20TE, and will navigate through **Home Screens** for 30TE.

### 3.5.2 20TE KEYPAD

The 20TE keypad consists of the following keys:

Key Type	Key Description	20TE
<b>Standard Menu Navigation Keys</b>	Four arrow keys (Up, Down, Left, Right) to navigate the menus, for setpoints and Up/Down/Right/Left value selection (organised around the Enter key).	
<b>Enter Key</b>	An Enter key for executing the chosen option	
<b>Clear/Reset Key</b>	<p><b>06A and previous releases (*1)</b> A <b>Clear/Reset key</b> for clearing the last enter key execution (short pulsation). Short pulsation can also be used for settings confirmation. If maintained (long pulsation), it will issue a Reset command.</p>	
	<p><b>08A and further releases (*2)</b> When setting <b>Clear/Reset Key</b> is configured as <b>Clear</b>:</p> <ul style="list-style-type: none"> <li>The <b>short pulse</b> execution of Clear/Reset key will issue a <b>Clear</b> command. The short pulse execution can also be used for <b>setting confirmation</b>.</li> <li>The <b>long pulse</b> execution of Clear/Reset key will issue a <b>Reset</b> command.</li> </ul> <p>When setting <b>Clear/Reset Key</b> is configured as <b>Reset</b>:</p> <ul style="list-style-type: none"> <li>The <b>short pulse</b> execution of Clear/Reset key will issue a <b>Reset</b> command.</li> </ul>	
<b>Read/Home Key</b>	<p><b>06A and previous releases (*1)</b> A <b>Read key</b> for accessing <b>Targets</b> menu if the <b>Alarm LED</b> is on. And, for accessing <b>Last Trip</b> data if the <b>Trip LED</b> is on. (Arrow keys now used for scrolling).</p> <p>When setting <b>Clear/Reset Key</b> is configured as <b>Clear</b>:</p>	
	<p><b>08A and further releases (*2)</b></p> <ul style="list-style-type: none"> <li>The <b>short pulse</b> execution of <b>Read/Home</b> key will show <b>Targets</b> if the <b>Alarm LED</b> is on, and <b>Last Trip</b> data if the <b>Trip LED</b> is on (Arrow keys now used for scrolling).</li> </ul> <p>When setting <b>Clear/Reset Key</b> is configured as <b>Reset</b>:</p> <ul style="list-style-type: none"> <li>The <b>short pulse</b> execution of <b>Read/Home</b> key will issue a <b>Clear</b> command. The short pulse execution can also be used for <b>setting confirmation</b>.</li> <li>The <b>long pulse</b> execution of <b>Read/Home</b> key will show <b>Targets</b> if the <b>Alarm LED</b> is on, and <b>Last Trip</b> data if the <b>Trip LED</b> is on (Arrow keys now used for scrolling).</li> </ul>	






Key Type	Key Description	20TE
Hot Menu Navigation Keys (directly below LCD display)	Two x navigation keys (under LCD display). Two hot keys for accessing the Reset Command (Up) and CB Control (Down). These are situated directly below the LCD display.	










Note:

(\*1) For 06A and previous releases: the Clear/Reset functionality of the Clear/Reset key is fixed and can't be configured.  
 (\*2) For 08A and further releases: the Clear/Reset primary functionality for short pulsation (Clear or Reset) is configurable through a setting at **Setpoints\Device\Installation\Clear/Reset Key** path. The Clear/Reset Key setting selection affects both to the Clear/Reset and Read/Home short and long pulsation behaviour.

### 3.5.3 30TE KEYPAD (IEC, ANSI VARIANTS)

The 30TE keypad consists of the following keys:

Key Type	Key Description	30TE	
		IEC	ANSI
Standard Menu Navigation Keys	4 arrow keys (Up, Down, Left, Right) to navigate the menus, for setpoints and Up/Down/Right/Left value selection (organised around the Enter key).		
Enter Key	An Enter key for executing the chosen option.		
Clear/Reset Key	<p><b>06A and previous releases (*1)</b>                      A <b>Clear/Reset</b> key for clearing the last enter key execution (short pulsation). If maintained (long pulsation), it will issue a <b>Reset command</b>.                      When nested on an HMI menu by pressing with short pulsation, the <b>Clear/Reset</b> key will return to the last selected Home screen.</p>		
	<p><b>08A and further releases (*2)</b>                      When setting <b>Clear/Reset Key</b> is configured as <b>Clear</b>:</p> <ul style="list-style-type: none"> <li>The <b>short pulse</b> execution of Clear/Reset key will issue a <b>Clear</b> command.</li> <li>The <b>long pulse</b> execution of Clear/Reset key will issue a <b>Reset</b> command.</li> </ul> <p>When setting <b>Clear/Reset Key</b> is configured as <b>Reset</b>:                      The <b>short pulse</b> execution of Clear/Reset key will issue a <b>Reset</b> command.</p>		

Key Type	Key Description	30TE			
		IEC	ANSI		
Read/Home Key	<p><b>06A and previous releases (*1)</b>                      A <b>Read/Home</b> key for accessing and navigating through the up to 10 configurable <b>Home Screens</b> (at <b>Setpoint \Device\Front Panel\Home Screens</b> path).</p>				
	<p><b>08A and further releases (*2)</b>                      When setting <b>Clear/Reset Key</b> is configured as <b>Clear</b>:</p> <ul style="list-style-type: none"> <li>The <b>short pulse</b> execution of <b>Read/Home</b> key will navigate through the <b>Home Screens</b> (up to 10 Home Screens configurable at <b>Setpoint\Device\Front Panel\Home Screens</b> path).</li> </ul> <p>When setting <b>Clear/Reset Key</b> is configured as <b>Reset</b>:</p> <ul style="list-style-type: none"> <li>The <b>short pulse</b> execution of <b>Read/Home</b> key will issue a <b>Clear</b> command.</li> <li>The <b>long pulse</b> execution of <b>Read/Home</b> key will navigate through the <b>Home Screens</b> (up to 10 Home Screens configurable at <b>Setpoint \Device\Front Panel\Home Screens</b> path).</li> </ul>				
Hot Menu Navigation Keys (directly below LCD display)	<p>5 x <b>navigation keys/LCD tab pushbuttons</b> (under LCD display).                      5 keys for <b>quick menu accessing</b> to some of the menus displayed on the Graphical LCD. Also, can be used to select values using (&lt;, &gt;, v, ^ and select) when a virtual keypad may appear in certain menus. These are situated directly below the LCD Two hot keys for accessing the <b>Reset Command</b> (Up) and <b>CB Control</b> (Down). These are situated directly below the LCD display.</p>				
Functional Keys/ Programmable Pushbuttons	<p>6 <b>Function keys/programmable pushbuttons</b> for executing user programmable functions, with their corresponding 6 programmable tri-colour LEDs.</p>				
Local/Remote (L/R) Key	<p><b>Local/Remote (L/R) Key</b> to select Local/Remote.</p>				
Open (O)/Close (I) Keys	<p><b>Open (O)/ Close (I) keys</b> for breaker control.</p>	<p>Open</p> 	<p>Close</p> 	<p>Open</p> 	<p>Close</p> 

**Note:**

(\*1) **For 06A and previous releases:** the Clear/Reset functionality of the Clear/Reset key is fixed and can't be configured.  
 (\*2) **For 08A and further releases:** the Clear/Reset primary functionality for short pulsation (Clear or Reset) is configurable through a setting at **Setpoints\Device\Installation\Clear/Reset Key** path. The Clear/Reset Key setting selection affects both to the Clear/Reset and Read/Home short and long pulsation behaviour.

### 3.5.4 LIQUID CRYSTAL DISPLAY

20TE and 30TE case Cortec options have different LCD displays with different capabilities, the 20TE being a text display and the 30TE (both IEC and ANSI variants) a colour graphical one.

The 20TE is a high-resolution monochrome LCD display with 16 characters on 3 lines and a controllable back light.

The 30TE is a colour active matrix TFT (Thin Film Transistor) LCD (liquid crystal display) that uses amorphous silicon TFT as a switching device. This module is composed of a Transmissive type TFT- LCD Panel, driver circuit, back-light unit. The resolution of a 4.0" TFT-LCD contains 480 x 480 pixels, this being the active display area: 70 mm (H) x 70 mm (V).

30TE IEC and ANSI variants are customised to show either IEC or ANSI symbols for the Single Line Diagram (SLD) configuration. Depending on the Cortec selected, the IED will also have the capability to display either one or several (up to 6 configurable SLD's) in the Bay Control option.

### 3.5.5 USB PORT

Both 20TE and 30TE have a USB port situated at the bottom of the front panel. The differences between the 20TE and the 30TE USB port are:

- Placement: at the bottom left-hand corner for the 20TE, and the bottom right-hand corner for the 30TE
- Type of cover: a sliding cover for the 20TE and a rugged cover for the 30TE, with enclosure protection against dust and dripping water (front face) of IP52 for the 20TE and IP54 for the 30TE, as per IEC 60529:2013

The USB port is used to communicate with a locally connected PC. It has two main purposes:

- To transfer settings information to/from the PC from/to the device
- For downloading firmware updates and menu text editing

The port is intended for temporary connection during testing, installation and commissioning. It is not intended to be used for permanent SCADA communications. This port supports the MODBUS communication protocol only, to allow communication with a range of protection equipment, and between the device and the Windows-based support software package.

You can connect the unit to a PC with a USB cable up to 5 m in length.

The inactivity timer for the front port is set to 15 minutes. This controls how long the unit maintains its level of password access on the front port. If no messages are received on the front port for 15 minutes, any password access level that has been enabled is cancelled.

**Caution:**

**When not in use, always close the cover of the USB port to prevent contamination.**



### 3.5.6 FIXED FUNCTION LEDS

Four fixed-function LEDs on the left-hand side of the front panel indicate the following conditions:

- Trip (Red) LED can be triggered by the operation of protection, control, or monitoring elements with functions selected as "Trip" or "Latched Trip". This will be linked to Any Trip FlexOperand. This indicator always latches, and a reset command must be initiated to allow the latch to be reset
- Alarm (Orange) LED flashes when the IED registers an alarm, that can be triggered by operation of protection, control, or monitoring elements with functions selected as "Alarm" or "Latched Alarm", fault, event or maintenance record. This will be linked to Any Alarm FlexOperand. This indicator latches, or not, depending on the setting selected. If latched, a reset command must be initiated to allow the latch to be reset. For non-latched alarms the LED flashes until the alarm conditions disappear, then it switches OFF. For latched alarms the LED flashes until the alarm conditions disappear, then changes to constantly ON. When the alarms are cleared, the LED switches OFF
- Out of service (Red) is ON when the IEDs functions are unavailable
- Healthy (Green) is ON when the IED is in correct working order, and should be ON at all times. It goes OFF if the unit's self-tests show there is an error in the hardware or software. The state of the Out of Service and healthy LED is reflected by the watchdog contacts at the back of the unit

*Note:*

The reset of the Latched LEDs can be done through command or by continuing to press (long pulsation) the **Clear/Reset** key.

### 3.5.7 PROGRAMMABLE LEDS

The device has a number of programmable LEDs. All of the programmable LEDs on the unit are tri-colour and can be set to RED, ORANGE or GREEN.

In the 20TE case, four programmable LEDs are available.


In the 30TE case, sixteen programmable LEDs are available.

All programmable LEDs can be set on **SETPOINTS\DEVICE\FRONT PANEL\PROG.LED** menu.

*Note:*

For 30TE there are another 6 LEDs (besides the 16 listed here), that are also programmable and tri-colour, but these LEDs are dedicated to the Function keys, and they will be addressed in the Function keys section.

A template for the LEDs and programmable function keys (pushbuttons) can be found on the GE Grid solutions web page for this product. The LEDs labels are entered into the front panel through the upper part of the IED where the LEDs are placed. The programmable pushbutton labels are entered through the left side of the IED where the pushbuttons are placed.



**Figure 14: LED numbering for 20TE**




Figure 15: Typical LED indicator panel for 20TE




Figure 16: Typical LED indicator panel template for 30TE (programmable LEDs and pushbuttons)

### 3.5.8 PROGRAMMABLE FUNCTION KEYS/PUSHBUTTONS

The programmable function keys are available for custom use for certain models.

Adjacent to these function keys are programmable LEDs, which are usually set to be associated with their respective function keys.

30TE has six programmable function keys with their corresponding 6 programmable tri-colour LEDs.

Function keys can be programmed in **SETPOINTS\DEVICE\FRONT PANEL\PROGRAMMABLE PB's**.

The function keys programmable LEDs can be programmed in **SETPOINTS\DEVICE\FRONT PANEL\PROG.LED** from LED 21 until LED 26.

### **3.5.9 LOCAL/REMOTE KEY**

The Local/Remote (L/R) key is available for certain models.

30TE has one Local/Remote (L/R) key to select Local/Remote mode.

---

### **3.5.10 STOP (O)/START (I) MOTOR SWITCHING DEVICE (BREAKER/ CONTACTOR) CONTROL KEYS**

The Stop (O)/Start (I) Motor Switching device (Breaker/Contactor) 30TE.

The 30TE IEC variant has two blue keys for Stop (O)/Start (I).

The 30TE ANSI variant has one green key for Start and one red key for Stop.

## CHAPTER 4

# SOFTWARE DESIGN

---

## 4.1 CHAPTER OVERVIEW

---

This chapter describes the software design of the IED.

This chapter contains the following sections:


Chapter Overview	47
Software Design Overview	48
System Level Software	49
Platform Software	51
Protection and Control Functions	52

## 4.2 SOFTWARE DESIGN OVERVIEW

The range of products based on the Multilin Agile platform can be conceptually categorised into several elements as follows:

- The system level software
- The platform software
- The protection and control software

These elements are not distinguishable to the user, and the distinction is made purely for the purposes of explanation.



**Figure 17: Software structure**

The software can be divided into a number of functions as illustrated above. Each function is further broken down into a number of separate tasks. These tasks are then run according to a scheduler. They are run at either a fixed rate or they are event driven. The tasks communicate with each other as required.

---

## 4.3 SYSTEM LEVEL SOFTWARE

---

### 4.3.1 REAL TIME OPERATING SYSTEM

The real-time operating system is used to schedule the processing of the various tasks. This ensures that they are processed in the time available and in the desired order of priority. The operating system also plays a part in controlling the communication between the software tasks.

---

### 4.3.2 SYSTEM SERVICES SOFTWARE

The system services software provides the layer between the hardware and the higher-level functionality of the platform software and the protection and control software. For example, the system services software provides drivers for items such as the LCD display, the keypad and the remote communication ports. It also controls things like the booting of the processor and the downloading of the processor code into RAM at startup.

---

### 4.3.3 SELF-DIAGNOSTIC SOFTWARE

The device includes several self-monitoring functions to check the operation of its hardware and software while in service. If there is a problem with the hardware or software, it should be able to detect and report the problem.

If a problem is detected by the self-monitoring functions, the device attempts to store a record to allow the nature of the problem to be communicated to the user.

The self-monitoring is implemented in two stages: firstly a thorough diagnostic check which is performed on boot-up, and secondly a continuous self-checking operation, which checks the operation of the critical functions while the device is in service.

---

### 4.3.4 STARTUP SELF-TESTING

The self-testing takes a few seconds to complete, during which time the LEDs measurement, recording, control, and protection functions are unavailable. On a successful start-up and self-test, the 'Healthy' state LED on the front of the device is switched on. If a problem is detected during the start-up testing, the device remains out of service until it is manually restored to working order.

The operations that are performed at start-up are:

1. System boot
2. System software initialisation
3. Platform software initialisation and monitoring

#### 4.3.4.1 SYSTEM BOOT

The integrity of the Flash memory is verified using a checksum before the program code and stored data is loaded into RAM for execution by the processor. When the loading has been completed, the data held in RAM is compared to that held in the Flash memory to ensure that no errors have occurred in the data transfer and that the two are the same. The entry point of the software code in RAM is then called. This is the LEDs initialisation code.

#### 4.3.4.2 SYSTEM LEVEL SOFTWARE INITIALISATION

The initialisation process initialises the processor registers and interrupts, starts the watchdog timers (used by the hardware to determine whether the software is still running), starts the real-time operating system and creates and starts the supervisor task. In the initialisation process the device checks the following:

- The integrity of the non-volatile memory, which is used to store event, fault and disturbance records
- The operation of the LCD controller
- The watchdog operation

At the conclusion of the initialization software the supervisor task begins the process of starting the platform software.

#### 4.3.4.3 PLATFORM SOFTWARE INITIALISATION AND MONITORING

When starting the platform software, the IED checks the following:

- The integrity of the data held in non-volatile memory (using a checksum)
- The operation of the real-time clock
- The presence and condition of the input board
- The analog data acquisition system (it does this by sampling the reference voltage)

At the successful conclusion of all of these tests the unit is entered into service and the application software is started up.

---

#### 4.3.5 CONTINUOUS SELF-TESTING

When the IED is in service, it continually checks the operation of the critical parts of its hardware and software. The checking is carried out by the system services software and the results are reported to the platform software. The functions that are checked are as follows:

- The Flash memory containing all program code and language text is verified by a checksum
- The code and constant data held in system memory is checked against the corresponding data in Flash memory to check for data corruption
- The system memory containing all data other than the code and constant data is verified with a checksum
- The integrity of the digital signal I/O data from the opto-isolated inputs and the output relay coils is checked by the data acquisition function every time it is executed.
- The operation of the analogue data acquisition system is continuously checked by the acquisition function every time it is executed. This is done by sampling the reference voltages
- The operation of the optional Ethernet board is checked by the software on the main processor card. If the Ethernet board fails to respond an alarm is raised and the card is reset in an attempt to resolve the problem.
- The operation of the optional IRIG-B function is checked by the software that reads the time and date from the board

In the event that one of the checks detects an error in any of the subsystems, the platform software is notified and it attempts to log a maintenance record.

If the self-check detected is a minor error the IED continues in service and the cause of the error is displayed in the IED records as well as in the Targets menu. If the self-check is a major error, the device takes itself permanently out of service. In both cases the Alarm LED is active while the self-test error is active. This is indicated by the 'Healthy' state LED on the front of the device, which switches OFF, and the watchdog contact which switches ON.



---

## 4.4 PLATFORM SOFTWARE

---

The platform software has three main functions:

- To control the logging of records generated by the protection software, including alarms, events, faults, and maintenance records
- To store and maintain a database of all of the settings in non-volatile memory
- To provide the internal interface between the settings database and the user interfaces, using the front panel interface and the front and rear communication ports

---

### 4.4.1 RECORD LOGGING

The logging function is used to store all alarms, events, faults and maintenance records. The records are stored in non-volatile memory to provide a log of what has happened. The IED maintains several types of log on a first in first out basis (FIFO). These are:

- Targets
- Event records
- Disturbance records
- Data logger
- Motor specific records (motor start rec, mtr start stats, learned data)
- Fault records
- Circuit breaker health records
- Digital counter records
- Maintenance records

The logs are maintained such that the oldest record is overwritten with the newest record. The logging function can be initiated from the protection software. The platform software is responsible for logging a maintenance record in the event of an IED failure. This includes errors that have been detected by the platform software itself or errors that are detected by either the system services or the protection software function. See the Monitoring and Control chapter for further details on record logging.

---

### 4.4.2 SETTINGS DATABASE

The settings database contains all the settings and data, which are stored in non-volatile memory. The platform software manages the settings database and ensures that only one user interface can modify the settings at any one time. This is a necessary restriction to avoid conflict between different parts of the software during a setting change.

Changes to protection settings and disturbance recorder settings, are first written to a temporary location SRAM memory. This is sometimes called 'Scratchpad' memory. These settings are not written into non-volatile memory immediately. This is because a batch of such changes should not be activated one by one, but as part of a complete scheme. Once the complete scheme has been stored in SRAM, the batch of settings can be committed to the non-volatile memory where they will become active.

---

### 4.4.3 INTERFACES

The settings and measurements database must be accessible from all of the interfaces to allow read and modify operations. The platform software presents the data in the appropriate format for each of the interfaces (LCD display, keypad and all the communications interfaces).

## 4.5 PROTECTION AND CONTROL FUNCTIONS

The protection and control software processes all of the protection elements and measurement functions. To achieve this it has to communicate with the system services software, the platform software as well as organise its own operations.

The protection task software has the highest priority of any of the software tasks in the main processor board. This ensures the fastest possible protection response.

The protection and control software provides a supervisory task, which controls the start-up of the task and deals with the exchange of messages between the task and the platform software.

### 4.5.1 ACQUISITION OF SAMPLES

After initialisation, the protection and control task waits until there are enough samples to process. The acquisition of samples on the main processor board is controlled by a 'sampling function' which is called by the system services software.

The sampling rate is adapted to the frequency of the electrical power system to provide a fixed sampling acquisition rate of 64 samples/ cycle.

The sampling function waits until the reception of 8 consecutive samples, it calculates the DFT or RMS value of the last 64 samples,--8 consecutive blocks of 8 sample each-- and raises an interrupt to the rest of the system indicating a new measurement has been acquired. Thus, the sampling rate of the protection system is executed 8 times per electrical power cycle.

### 4.5.2 FREQUENCY TRACKING

The device provides a frequency tracking algorithm so that there are always 64 samples per cycle irrespective of frequency drift within a certain frequency range (see technical specifications). If the frequency falls outside this range, the sample rate reverts to its default rate of 3200 samples for 50 Hz or 3840 samples for 60 Hz.

Frequency measurement is accomplished by measuring the time between zero crossings of the composite signal of three-phase bus voltages. The signals are passed through a low pass filter to prevent false zero crossings.

Frequency tracking utilises the measured frequency to set the sampling rate for voltage which results in better accuracy for the Discrete Fourier Transform (DFT) algorithm for off nominal frequencies. The frequency tracking is switched automatically from main source to the low priority source by an algorithm, if the frequency detected from the main or high priority source input is declared invalid. If a stable frequency signal is not available from all sources, then the tracking frequency defaults to the nominal system frequency.

The following table shows high to low priority sources depending on the relay model type:

Priority	P24D	P24N
1st	3VT	CT
2nd	CT	None

The minimum voltage/current needed for frequency calculation is 6%  $V_n/I_n$ . The frequency is limited to the range between 15 Hz and 70 Hz.

### 4.5.3 FOURIER SIGNAL PROCESSING

When the protection and control task is re-started by the sampling function, it calculates the Fourier components for the analogue signals. Although some protection algorithms use some Fourier-derived harmonics (e.g. second harmonic for magnetising inrush), most protection functions are based on the Fourier-derived fundamental components of the measured analogue signals. The Fourier components of the input current and voltage signals are stored in memory so that they can be accessed by all of the protection elements' algorithms.

The Fourier components are calculated using single-cycle Fourier algorithm. This Fourier algorithm always uses the most recent 64 samples.

Most protection algorithms use the fundamental component. In this case, the Fourier algorithm extracts the power frequency fundamental component from the signal to produce its magnitude and phase angle. This can be represented in either polar format or rectangular format, depending on the functions and algorithms using it.

The Fourier function acts as a filter, with zero gain at DC and unity gain at the fundamental, but with good harmonic rejection for all harmonic frequencies up to the nyquist frequency. Frequencies beyond this nyquist frequency are known as alias frequencies, which are introduced when the sampling frequency becomes less than twice the frequency component being sampled. However, the alias frequencies are significantly attenuated by an anti-aliasing filter (low pass filter), which acts on the analogue signals before they are sampled. The ideal cut-off point of an anti-aliasing low pass filter would be set at:

$$(\text{samples per cycle}) \times (\text{fundamental frequency})/2$$

At 64 samples per cycle, this would be nominally 1600 Hz for a 50 Hz system, or 1920 Hz for a 60 Hz system.

---

#### 4.5.4 FLEXLOGIC EQUATION EDITOR

The purpose of the Flexlogic Equation Editor (Flexlogic Equation Editor & Logic Designer) is to allow you to configure your own protection schemes to suit your particular application. This is done with programmable logic gates and delay timers.

The input to the Flexlogic Equation Editor is any combination of the status of the digital input signals from the opto-isolators on the input board, virtual inputs, virtual outputs, output relays, remote inputs, remote GOOSEs, remote inputs DPS, the outputs of the protection elements such as protection starts and trips. The Flexlogic Equation Editor consists of software logic gates and timers. The logic gates can be programmed to perform a range of different logic functions and can accept any number of inputs. The timers are used either to create a programmable delay, and/or to condition the logic outputs, such as to create a pulse of fixed duration on the output regardless of the length of the pulse on the input. The outputs of the Flexlogic Equation Editor can be assigned to the LEDs, or function keys (for 30TE) on the front panel of the IED and the relay output contacts at the rear.

The Flexlogic Equation Editor can be configured to create complex schemes. Because of this, the Flexlogic Equation Editor design is achieved by means of Flexlogic Equation Editor & Logic Designer. This is available as part of the EnerVista Configuration settings application software.

*Note:*

*Flexlogic Equation Editor (Flexlogic Equation Editor & Logic Designer) is only available in offline mode. After configuring the logic offline it can be sent to the IED.*

---

#### 4.5.5 EVENT RECORDING

A change in any digital input signal or protection element output signal is used to indicate that an event has taken place. When this happens, the protection and control task sends a message to the supervisor task to indicate that an event is available to be processed and writes the event data to a fast buffer controlled by the supervisor task. When the supervisor task receives an event record, it instructs the platform software to create the appropriate log in non-volatile memory (flash memory). The operation of the record logging to RAM is slower than the supervisor buffer. This means that the protection software is not delayed waiting for the records to be logged by the platform software. However, in the rare case when a large number of records to be logged are created in a short period of time, it is possible that some will be lost.

Maintenance records are created in a similar manner, with the supervisor task instructing the platform software to log a record when it receives a maintenance record message. However, it is possible that a maintenance record may be triggered by a fatal error in the device, in which case it may not be possible to successfully store a maintenance record, depending on the nature of the problem.

For more information, see the Monitoring and Control chapter.

#### **4.5.6 DISTURBANCE RECORDER**

The disturbance recorder can record the waveforms of the calibrated analogue channels, plus the values of the digital signals. The number of records is user selectable up to 16 and the maximum length of one record at 8 samples/cycle is approximately 4895.125 cycles. The disturbance recorder is supplied with data by the protection and control task once per cycle, and collates the received data into the required length disturbance record. The disturbance records can be extracted using EnerVista Configuration software or the SCADA system, which can also store the data in COMTRADE format, allowing the use of other packages to view the recorded data.

For more information, see the Monitoring and Control chapter.

## CHAPTER 5

# CONFIGURATION

---

## 5.1 CHAPTER OVERVIEW

---

This chapter provides some general information about the technical manual and an introduction to the device(s) described in this technical manual.

This chapter contains the following sections:

Chapter Overview	56
Settings Application Software	57
Device	60
System	71

## 5.2 SETTINGS APPLICATION SOFTWARE

To configure this device you will need to use the Settings Application Software called EnerVista Configuration Software, which is used for setting up and managing the IED.

Although you can change many settings using the front panel HMI, some of the features cannot be configured without the Settings Application Software; for example the Flexlogic Equation Editor, or IEC 61850 communications.

If you do not already have a copy of the Settings Application Software, you can obtain it from GE Vernova at [www.gegridsolutions.com](http://www.gegridsolutions.com).

### 5.2.1 SETTING ENTRY METHODS

Before placing the IED in operation, settings defining system characteristics, inputs, IED outputs, and protection settings must be entered, using one of the following methods:

- Front panel, using the keypad and the display (used to configure all settings except Flexlogic Equation Editor and IEC61850).
- Front USB port, connected to a portable computer running the EnerVista Configuration software (used to configure all settings including Flexlogic Equation Editor and IEC61850).
- Rear Ethernet (copper or fiber ports connected to portable computer running the EnerVista Configuration software (used to configure all settings including Flexlogic Equation Editor and IEC61850).
- Rear RS485 ports and a SCADA system running user-written software. (used to configure all settings except Flexlogic Equation Editor and IEC61850)

Any of these methods can be used to enter most of the IED settings. A computer, running the EnerVista Configuration software is the preferred settings entry method as it makes entry much easier. Files can be stored and downloaded for fast, error free entry when a computer is used. The IED leaves the factory with settings programmed to default values, and it is these values that are shown in the setting message illustrations.

At a minimum, the **SETTINGS\SYSTEM** settings must be entered for the system to function correctly. To safeguard against the installation of a IED whose settings have not been entered, the Out-Of-Service self-test warning is displayed. In addition, the Critical Fail output relay is de-energized and the Healthy LED is OFF (red). Once the IED has been programmed for the intended application, the **SETTINGS\DEVICE\INSTALLATION\Device In Service** setting should be changed from 'Not Ready' (default value) to 'Ready' and the Healthy LED will turn ON (green). Before putting the IED in 'Ready' state, each setting should be worked through to ensure that proper device settings have been configured, entering values either by keypad or computer.

### 5.2.2 COMMON SETTINGS

To make the application of this device as simple as possible, similar methods of operation and similar types of settings are incorporated in various features. Rather than repeat operation descriptions for this class of setting throughout the manual, a general description is presented in this overview. Details that are specific to a particular feature are included in the discussion of the feature. The form and nature of these settings is described below.

**Function** setting: The **Function** setting determines the operational characteristic of each feature. The range for this setting is: 'Disabled', 'Trip', 'Latched Trip', 'Alarm', 'Latched Alarm', and 'Configurable'.

If the **Function** setting is selected as 'Disabled', then the feature is not operational.

If the **Function** setting is selected as 'Trip' or 'Latched Trip', then the feature is operational. When the 'Trip' or 'Latched Trip' function is selected and the feature operates, the output IED 'Trip' operates, and the LED 'TRIP' is lit. The LED 'TRIP' can be reset by issuing reset command or pressing 'Clear/Reset' key.

If the **Function** setting is selected as 'Alarm' or 'Latched Alarm', then the feature is operational. When this function is selected, and the feature operates, the LED 'ALARM' is lit, and any assigned auxiliary output IED operates. The 'Trip' output IED does not operate, and the LED 'TRIP' is not lit.

When **Alarm** function is selected and the feature operates, the LED 'ALARM' flashes, and it self-resets when the operating conditions are cleared.

When **Latched Alarm** function is selected, and the feature operates, the LED 'ALARM' will flash during the operating condition, and will be steady lit after the conditions are cleared. The LED 'ALARM' can be reset by issuing reset command or pressing the 'Clear/Reset' key.

If the **Function** setting is selected as 'Configurable', the feature is fully operational but outputs are not driving any action, such as TRIP IED , Alarm LED or anything else. The User has to program operands from this element to a desirable action which may be the auxiliary output IED from the list of available IEDs in the element itself, Flexlogic, etc.

**Note:**

*The FlexLogic operands generated by the operation of each feature are active, and available to assign to outputs, or use in FlexLogic equations in the Flexlogic Equation Editor, regardless of the selected function, except when the function is set to 'Disabled'.*

- **Current set/Voltage set:** This setting selects the threshold equal to or above (for over elements) or equal to or below (for under elements) which the measured parameter causes an output from the measuring element.
- **Time Delay:** This setting selects a fixed time interval to delay an input signal from appearing as an output.
- **tRESET (Dropout delay):** This setting selects a fixed time interval to delay dropping out the output signal after being generated.
- **Time Dial/TMS:** This setting provides a selection for Time Dial Multiplier which modifies the operating times per the selected inverse curve. For example, if an IEEE Extremely Inverse curve is selected with TDM=2, and the fault current is 5 times bigger than the PKP level, operation of the element can not occur before an elapsed time of 2.59 s from Pickup.
- **Relay O/P X:** The **Relay O/P X** setting selects the IEDs required to operate when the feature generates an output. The range is any combination of the Auxiliary output IEDs. The letter 'X' denotes the number of auxiliary output IEDs defined for the IEDs Cortec.
- **Direction:** The **Direction** setting is available for overcurrent features which are subject to control from a directional element. The range is 'Non-Directional', 'Forward', and 'Reverse'. If set to 'Non-Directional', the element is allowed to operate for current flow in any direction. There is no supervision from the directional element. If set to 'Forward', the OC element is allowed to operate when the fault is detected by the directional element in forward direction. In this mode, the OC element does not operate for fault in reverse direction. If set to 'Reverse', the OC element is allowed to operate when the fault is detected in reverse direction, and does not operate in forward direction.
- **Reset Char:** Selection of an Instantaneous DT or a Timed reset (Inverse) is provided by this setting. If Instantaneous reset (DT) is selected, the element resets instantaneously providing the quantity drops below the percentage or absolute value of the PKP (Start) level corresponding to each element before the time for operation is reached. More information on the dropout levels for each element can be found in the Technical Specifications chapter. If Timed reset (Inverse) is selected, the time to reset is calculated based on the reset equation for the selected inverse curve.
- **Inhibit:** The **Inhibit** setting selects an operand from the list of FlexLogic operands, which when active, blocks the feature from running.

### 5.2.3 SETTINGS TEXT ABBREVIATIONS

The following abbreviations are used in the settings pages.

- A: amperes
- kA: kiloamperes
- V: volts
- kV: kilovolts
- kW: kilowatts
- kvar: kilovars
- kVA: kilo-volt-amperes



- AUX: auxiliary
- COM, Comms: communications
- CT: current transformer
- GND: ground (earth)
- Hz: Hertz
- MAX: maximum
- MIN: minimum
- SEC, s: seconds
- UV: undervoltage
- OV: overvoltage
- VT: voltage transformer
- Ctrl: control
- Hr & hr: hour
- O/L: overload
- CT1 IN2: EF2 Derived Current
- CT1 IN1: EF1 Measured Current
- ISEF: Sensitive Earth Fault Current or SEF Current
- PTP: Precision Time Protocol
- PRP: Parallel Redundancy Protocol
- HSR: High-availability Seamless Redundancy
- LLA: Link Loss Alert functionality

## 5.3 DEVICE

The following diagram is an example of the Device settings display navigation, so it may not apply in its entirety to all IEDs. The actual display options available are dependant on the exact IED Cortec selection.




Figure 18: Device menu hierarchy

### 5.3.1 DATE AND TIME CONFIGURATION

The date and time setting will normally be updated automatically by the chosen UTC (Universal Time Co-ordination) time synchronisation mechanism when the device is in service. You can also set the date and time manually using the **Clock** setting under the path **SETPOINTS\DEVICE\DATE AND TIME**.

### 5.3.1.1 CLOCK

The Multilin Agile IED is capable of receiving a time reference from several time sources in addition to its own internal clock for the purpose of time-stamping events, disturbance records and other occurrences within the IED. The accuracy of the time stamp is based on the time reference that is used. The Multilin Agile IED supports an internal clock, SNTP, IRIG-B and PTP IEEE 1588, as potential time references.

If two or more time sources are available, the time source with the higher priority shown in Time Sources table is used where 1 is considered to be the highest priority.

**Note:**

The time source priority of PTP and IRIG-B can be swapped. If both PTP and IRIG-B are available to the Multilin Agile IED, by default the Multilin Agile IED clock syncs to PTP over IRIG-B. If PTP is not available, the IED syncs the internal clock to IRIG-B.

The following table shows the priority of each time source.

Time Source	Priority
PTP (IEEE1588)	1*
IRIG-B	2*
SNTP	3
Internal Clock	4

\*The priority of IRIG-B and PTP can be swapped in **SETTINGS\ DEVICE\ DATE AND TIME\ CLOCK\ SYNC SRC PRIO.** path by selecting either *PTP/IRIG B/OTHER* setting value.

Path: **SETTINGS\DEVICE\DATE AND TIME\CLOCK**

In the clock settings the date and time can be set manually or sync the IED to computer clock.

The System Clock (device date and time) and RTC Sync Source (Type of synchronization in place) are available at **DEVICE STATUS\ CLOCK** path

**Note:**

Synchronisation via communication protocols, IEC 60870-5-103, DNP3 Serial and DNP3oE, Modbus RTU and Modbus TCP, etc will not be accepted if the sync source is from IRIG-B, SNTP or PTP.

### 5.3.1.2 PTP PROTOCOL

The IED implements PTP functionality on each of its Ethernet ports independently, and automatically selects the port with the best time using the Best Master Clock Algorithm. Depending on the Cortec selection the device will have just one Ethernet port (ETH1) or three (ETH1 and ETH2, ETH3 for redundancy).

The PTP settings are placed under the path: **SETPOINT\ DEVICE\ DATE AND TIME\ PTP.**

The PTP status can be viewed in the at **DEVICE STATUS\ PTP**

### 5.3.1.3 IRIG-B

All models have the option of accepting a demodulated IRIG-B input through the rear serial port 1 (COM1)

To set the device to use IRIG-B, Set the IRIG-B setting under path, **SETPOINT\ DEVICE\ DATE AND TIME** to *Enabled*.

For more information, refer to Demodulated IRIG-B sub-chapter under Time Synchronisation in Communications chapter.

---

### 5.3.1.4 SNTP PROTOCOL

SNTP is used to synchronise the clocks of computer systems over packet-switched, variable-latency data networks, such as IP.

The device is synchronised by the main SNTP server. This is achieved by entering the IP address of the SNTP server into the IED.

SNTP settings are found under the path: **SETPOINTS\DEVICE\DATE AND TIME\SNTP**.

For more information, refer to SNTP sub-chapter under Time Synchronisation in Communications chapter.

---

## 5.3.2 SECURITY

The following security features are available:

- Basic Security – The basic security feature present in the default offering of the product.
- Advanced Cyber-security – The feature refers to the advanced security options available as a software option. When this option is purchased, it is automatically enabled and Basic Security is disabled.

Basic and Advanced Cyber-Security settings are found under the path: **SETPOINTS\DEVICE\SECURITY**.

For more information, refer to the Cyber-Security chapter.

---

## 5.3.3 COMMUNICATIONS

This product supports Substation Automation System (SAS), and Supervisory Control and Data Acquisition (SCADA) communication.

Communication settings are found under the path: **SETPOINTS\DEVICE\COMMUNICATIONS**.

Refer to the Communications chapter for more information.

---

## 5.3.4 DISTURBANCE RECORDER

The disturbance recorder feature allows to record the waveform capture of the calibrated analogue channels, together with selected values for the configurable digital and analogue channels available in the device. The disturbance recorder allows the user to configure up to 64 digital channels (up to 64) and up to 16 analogue channels.

The Disturbance Recorder settings are found under the path: **SETPOINTS\DEVICE\DISTURB RECORDER**.

For more information, refer to the Monitoring and Control chapter.

---

## 5.3.5 DATA LOGGER

The data logger samples and records up to 16 analogue parameters at rate defined by the user. All data is stored in non-volatile memory, where the information will be retained upon relay control power lost.

The data logger can be configured with a few channels over a long period of time, or with larger number of channels for a shorter period of time. The IED automatically partitions the available memory between the channels in use.

The selection of the rate for logging data also affects the duration of recorded data. The data logger will have longer duration for sampling rates at longer periods of time (e.g. '1 minute', '30 minutes', '1 hour', etc.), as compared to sampling rates at short periods (e.g. '1 cycle', or '1 second', etc.).

The recorded data can be downloaded to EnerVista Configuration software and displayed.

The data logger settings are found under the path: **SETPOINTS\DEVICE\DATA LOGGER**.

For more information, refer to the Monitoring and Control chapter.

---

### 5.3.6 FAULT RECORDS

The Multilin Agile IED supports up to 25 fault reports before overwriting the oldest one. The trigger conditions and the characteristics of the motor, as well as the analog quantities to be stored, are configured in this setting menu.

When enabled, this function monitors the pre-fault trigger. The pre-fault data are stored in the memory for prospective creation of the fault report on the rising edge of the pre-fault trigger. The element waits for the fault trigger as long as the pre-fault trigger is asserted, but not shorter than 1 second. When the fault trigger occurs, the fault data is stored, and the complete report is created. If the fault trigger does not occur within 1 second after the pre-fault trigger drops out, the element resets and no record is created.

The user programmable fault report contains a header with the following information:

- IED model
- Device name
- Firmware revision
- Date and time of trigger
- Name of pre-fault trigger operand
- Name of Fault trigger operand
- Active setting group at the time of pre-fault trigger
- Active setting group at the time of fault trigger

The fault report continues with the following information:

- All current and voltage phasors (four cycles after the fault trigger)
- Pre-fault values for all programmed analogue channels (one cycle before pre-fault trigger)
- Fault values of all programmed analogue channels (one cycle after the fault trigger)

Each Fault Report is created as a text file with flt extension that can be visualized and shared using the EnerVista Configuration software. The file name is numbered with sequential numbers showing which one is older than the other.

The Fault Records settings are found under the path: **SETPOINTS\DEVICE\FAULT RECORDS**.

For more information, refer to the Monitoring and Control chapter.

---

### 5.3.7 EVENT DATA

The Event Data feature stores 64 configurable analogue values each time an event occurs. The IED is able to capture a maximum of 2048 Event records. The Event Data behaviour matches that of the Event Recorder.

There is no Enabling/Disabling of the feature. It is always 'ON'.

When changes are made to the Event Data settings, the Event data is cleared and the Snapshot.txt file where the Event Data is stored internally in the IED is deleted. The Event Record remains as it is and is not cleared.

The data logger settings are found under the path: **SETPOINTS\DEVICE\EVENT DATA**.

For more information, refer to the Monitoring and Control chapter.

---

### 5.3.8 FLEX STATES

The Flex State feature provides a mechanism where any of 256 selected FlexLogic operand states or any inputs can be used for efficient monitoring.

The feature allows user-customised access to the FlexLogic operand states in the IED. The state bits are packed so that 16 states may be read out in a single Modbus register. The state bits can be configured so that all of the states which are of interest are available in a minimum number of Modbus registers.

There are 256 Flex State bits available. The status value indicates the state of the given Flex State bit.

The Flex States settings are found under the path: **SETPOINTS\DEVICE\FLEX STATES**.

For more information, refer to the Monitoring and Control chapter.

---

## 5.3.9 FRONT PANEL

### 5.3.9.1 DISPLAY PROPERTIES

The available language options in the IED include English (UK), English (US), Spanish, Russian and Turkish.

The **Display Property** setting in which the language can be selected is found under the path: **SETPOINTS\DEVICE\FRONT PANEL\DISPLAY PROPERTY**.

### 5.3.9.2 DEFAULT SCREENS

The default display screens show the measurement values. The sequence of displaying the screens starts after a time of inactivity, when no key has been pressed. The displaying sequence goes as follows:

First screen: System Currents, Voltages, Frequency, DC supply voltage.

Second screen: System Power Measurements and Power Factor.

Third screen: System Current & Voltage Negative, Positive and Zero sequence values.

Fourth screen: System Total Harmonic Distorsion.

All default screens show Date & Time data.

The measurement values shown in the default display screens and its configuration are fixed by default. The display time for the default screens is configurable.

The Display Time setting can be found under the path: **SETPOINTS\DEVICE\FRONT PANEL\DEFAULT SCREENS**.

---

## 5.3.10 RESETTING

Some events can be programmed to latch the front panel LEDs. Depending on the application some auxiliary relay outputs can be programmed to latch after the triggering event is cleared. Once set, the latching mechanism holds all the latched indicators, messages, and auxiliary relay outputs in the set state, after the initiating condition has cleared, until a **RESET** command is received to return these latches (except the FlexLogic NV latches) to the reset state.

The **RESET** command can be initiated by pressing the Cancel key for a few seconds, or by a configurable operand or by a remote device via a communication channel.

The Reset Input X setting (Being X from 1 to 3) under the path: **SETPOINTS\DEVICE\RESETTING**, allows to select an operand from the list of Flexlogic operands in the IED.

The targets, LEDs, and latched relay outputs will reset, upon assertion from any of the operand selected as Reset Inputs.

---

## 5.3.11 INSTALLATION

The Installation settings allow the user to:

Set the Device Name assigning an alphanumeric name to the device up to 13 alphanumeric characters.

Put the device in service or out of service. The relay is defaulted to the 'Not Ready' state when it leaves the factory. This safeguards against the installation of an IED whose settings have not been entered. The IED in the 'Not Ready' state blocks signaling of any relay output. These conditions remain until the IED is explicitly put in the 'Ready' state. When the IED is in 'Not Ready' state, the Out of Service LED is ON and the Healthy LED is OFF

Establish the Service Command for the IED.

Select the engineering units of temperature display to Celsius or Fahrenheit

Set the current and voltages cutoff levels.

The Installation settings can be found under the path: **SETPOINTS\DEVICE\INSTALLATION**.

**Note:**

*Lower the Voltage Cutoff and Current Cutoff levels with care as the IED will accept lower signals as valid measurements. The default IED cutoff settings are '0.020 pu' for current and '1.0 V' for voltage.'*

### 5.3.12 CLEAR RECORDS

The Clear Records commands are accessible from the front panel and from the EnerVista Configuration software.

The Clear Records commands available in the IED are: All Records, Event Records, Disturb Recorder, Data Logger, Fault Records, Max Cur Demand, Max P Demand, Max Q Demand, Energy Use Data, Reset Thermal, Digital Counters, CB1 Arc Current, CB1 Health Data, Security Records, Last Trip Data, Pwr Quality Data, Volt Interruption.

Each record clear command operand can be set under the path: **SETPOINTS\DEVICE\CLEAR RECORDS**.

Each record can be cleared either by assigning 'On' or a FlexLogic operand to the appropriate setting.

**Note:**


*The Clear Records commands are also available from the front panel under the path: **RECORDS\CLEAR RECORDS** and from the EnerVista Configuration software under the path: **MONITORING\CLEAR RECORDS**, however there the allowable settings are only 'ON' and 'OFF'. (FlexLogic operands cannot be used.)*






### 5.3.13 USING THE HMI PANEL

Using the HMI, you can:

- Display and modify settings
- View the digital I/O signal status
- Display measurements
- Display fault records
- Reset fault and alarm indications

The keypad provides full access to the device functionality using a range of menu options. The information is displayed on the LCD.

Keys	Description	Function
	Up and down cursor keys	To change the menu level or change between settings in a particular setting level, or changing values within a setting

Keys	Description	Function
	Left and right cursor keys	To navigate between default displays, and in the event of a text length longer than 16 characters, this keys can be used to display the whole text
	ENTER key	For accepting setting values changes
	Hotkeys	Shortcuts for executing Reset command and enter CB Control menu. Also, for confirming or not confirming changes when navigating through settings
	Clear key	To return to a higher level menu header from any lower level menu. To clear the insertion whilst inputting a setting. To ask for settings confirmation when changing a setting
	Read key	To read alarm messages and enter Last Trip data menu

**Note:**

As the LCD display has a resolution of 16 characters by 3 lines, some of the information is in a condensed mnemonic form.

### 5.3.13.1 NAVIGATING THE HMI PANEL

The cursor keys are used to navigate the menus. These keys have an auto-repeat function if held down continuously. This can be used to speed up the setting value changes and menu navigation. The longer the key is held pressed, the faster the rate of change or movement.

The navigation map below shows how to navigate the menu items.







Figure 19: Navigating the HMI

### 5.3.13.2 GETTING STARTED

When the IED first starts, it will go through its power up procedure. After a few seconds it will settle down into the default display menu.

Even though the device itself should be in full working order when it first starts, an alarm could still be present, for example, if there is no network connection for a device that has the Ethernet port physically connected with a copper cable. If this is the case, the orange Alarms LED will be flashing and the alarm can be read by pressing the 'Read' key.



If this is the case, the IED will need to be connected to an active Ethernet network to clear the alarm.

If there are other alarms present, these must also be cleared to set the Alarm LED OFF.

### 5.3.13.3 DEFAULT DISPLAY

The HMI display provides Date, Time and Measurements for the system voltages, currents, power, and frequency, depending on the device model.

#### Date and time, and Metering values

For example (P24D):

```
Ia 0.0 A Va 0.0 V
Ib 0.0 A Vb 0.0 V
Ic 0.0 A Vc 0.0 V
```

```
In 0.0 A Vn 0.0 V
f 0.00 Hz DC 0.0 V
```

#### 5.3.13.4 DEFAULT DISPLAY NAVIGATION

The following diagram is an example of the default display navigation. This is an example only and may not apply in its entirety to all models. The actual display options available depend on the exact model.

Use the horizontal cursor keys to step through from one display to the next.




Figure 20: Default display navigation

#### 5.3.13.5 PASSWORD ENTRY AND ROLE BASED ACCESS CONTROL (RBAC)

#### 5.3.13.6 PASSWORD ENTRY AND ROLE BASED ACCESS CONTROL (RBAC)

##### Role Based Access Control (RBAC)

Role based access control, RBAC, is the core of session management. Every login attempt will connect to the RBAC service and it will allow or deny the login of the user.

In IEDs with Basic Cyber-Security (default option), the default connection is done as Viewer, without any password requirement. Basic Cyber-Security IEDs support 4 fixed roles: Administrator, Engineer, Operator and Viewer. Administrator, Engineer and Operator are password protected roles. The default password for those roles is 0.

In IEDs with Advanced Cyber-Security (see ordering options for more detail), a username and password always will be required. If the login is successful, the access level will correspond to the role defined to this user.

The maximum number of concurrent sessions is only one for all roles, except of Viewer role, which has the limit of 5 sessions.

Only Administrator can change other user's passwords. All IED users can change their own passwords. For password reset/recovery procedure the Administrator role will be required.

There is a session timeout adjustable by settings. This timeout means that open sessions are automatically closed if they remain inactive till the timer elapses. This inactivity timer defines the period that IED waits in idleness before a logged in user will be automatically logged out. This timeout is different for HMI interface and other interfaces (serial, Ethernet, etc.).

For more detailed information regarding Basic and Advanced Cyber-Security Implementation (Cortec dependant), please refer to the Cyber-Security chapter.

### Password entry

When configuring the default display or any other settings modification, the user will be prompted for a Role and a password before any changes can be made in the IED. The default Viewer Role is not password protected (select Viewer as role and press Enter), Viewer role just allows settings visualisation. For any other role a password will be required as follows.

```

LOGIN
Role:
Administrator
  
```

```

LOGIN
Password
A*****
  
```

1. Select the Role in the Role login screen using the up or down cursor keys and press Enter key to confirm it.
2. A Password screen will be prompted, a fix cursor shows which character field of the password can be changed. Press the up or down cursor keys to change each character.
3. Use the left and right cursor keys to move between the character fields of the password.
4. Press the **Enter** key to confirm the password. If you enter an incorrect password, an invalid password message followed by an **AUTH FAILED** message is displayed. The display then reverts to **PASSWORD**. On entering a valid password, if this Role is sufficient to edit the selected setting, the display returns to the setting screen to allow the edit to continue. If the correct level of password has not been entered, the password prompt screen appears again.
5. To escape from this password prompt, press the **Clear** key. If the keypad is inactive for a number of minutes, the password protection of the front panel user interface reverts to the default access level.

#### 5.3.13.7 PROCESSING ALARMS AND RECORDS

If there are any alarm messages, they will appear on the Target Messages display and the orange alarm LED will flash. The alarm messages can either be self-resetting or latched. If they are latched, they must be cleared manually.

1. To view the alarm messages, press the **Read** key.
2. Scroll through the pages of the latest fault record, using the cursor keys.

#### 5.3.13.8 MENU STRUCTURE

IED display messages are organized into a main menu, menus and different levels of sub-menus.. The five main menu headers are Targets, Device Status, Measurements, Settings and Records.

Pressing the **Down** key scrolls through the Main Menu.

Pressing the **Enter** key from the main menu headers displays the corresponding menus. Use the **Up** and **Down** keys to scroll through the available menus and sub-menus.

### 5.3.13.9 CHANGING THE SETTINGS

Starting at the default display, press the **Down** cursor key to show the Setpoint heading.

1. Use the **Enter** key to access to the settings menus and sub-menus.
2. Use the **Up** and **Down** keys to scroll through the available menus and press the **Enter** key to select the menu required. Repeat this sequence to access to the subsequent sub-menus.
3. To return to the previous menu level press the **Clear** key.
4. To return to the default display, press the **Clear** key repeatedly from any of the menus and sub-menus.
5. To change the value of a setting, go to the relevant Setting in the menu, then press the **Enter** key to change the setting value. A marking cursor on the LCD shows that the value can be changed. You may be prompted for a password first.
6. To change the setting value, use the **Up** and **Down** keys to select the required value to be changed.
7. Press the **Enter** key to confirm the new setting value or the **Clear** key to discard it. The new setting is automatically discarded if it is not confirmed within 15 seconds.
8. The changes must be confirmed before they are used. When all required changes have been entered, press the **Clear** key. Before returning to the previous menu level, the following prompt appears.

CONFIRM CHANGES? NO YES
----------------------------

9. Press the relevant hotkey to accept or discard the new settings.

## 5.4 SYSTEM




Figure 21: System menu hierarchy

### 5.4.1 CT RATIO

The CT RATIO menu provides the setup menu for the Current Transformers (CTs) connected to the Multilin Agile IED terminals. The setup of the three-phase CTs, the Earth CT, and the Sensitive Earth CT requires a selection of primary and secondary CT ratings.

The Multilin Agile IED has three inputs for phase currents A, B, and C, and one input for earth/residual current.

For PHASE CT PRIMARY settings, enter the primary rating of the three-phase feeder CTs wired to the IED phase CT terminals. With the phase CTs connected in wye (star), the calculated phasor sum of the three phase currents ( $I_a + I_b + I_c = \text{Neutral Current} = 3I_0$ ) is used as the input for the neutral.

For PHASE CT SEC'y, the EARTH CT PRIMARY and SEC'Y settings are displayed only if the Earth input is installed.

The SENSITIVE EARTH CT PRIMARY and SEC'Y settings are displayed only if the Sensitive Earth input is installed.

For both cases, and depending on the Earth or Sensitive Earth input selected, enter the primary rating of the Earth / Sensitive Earth CT wired to the relay Earth / Sensitive Earth CT terminals. When the Earth input is used for measuring the residual 3I0 current, the primary current must be the same as the one selected for the phase CTs.

The CT Ratio settings can be found under the path: **SETPOINTS\SYSTEM\CT RATIO\CT RATIO**.

For more information regarding ranges and default values, refer to the Settings and Signal appendix.

### 5.4.2 VT RATIO

The VT RATIO menu provides the setup for all VTs (PTs) connected to the IED voltage terminals

**Note:**

The nominal **MAIN VT SEC'Y** voltage settings are the voltages across the phase VT terminals when nominal voltage is applied.

For example, on a system of 13.8kV nominal primary voltage, and a 14400:120 volt VT in a Delta connection, the secondary voltage would be 115V, i.e.  $(13800/14400)*120$ . For a Wye connection, the voltage value entered must be the phase to neutral voltage which would be  $115/\sqrt{3} = 66.4$  V.

On a 14.4 kV system with a Delta connection and a VT primary to secondary turns ratio of 14400:120, the voltage value entered would be 120 V, i.e. 14400/120.

The VT Ratio settings can be found under the path: **SETPOINTS\SYSTEM\VT RATIO\VT RATIO**.

For more information regarding ranges and default values, refer to the Settings and Signal appendix .

**PH VT INPUT** Selects the type of phase VT connection to match the VTs (PTs) connected to the IED.

**MAIN VT PRIMARY** Selects the phase VT ratio to match the ratio of the VTs connected to the VT bank.

**MAIN VT SEC'Y** Selects the output secondary voltage for phase VTs connected to the VT bank.

**Note:**

*VT Ratio functionality is only available for products with VT inputs (P24D).*

### 5.4.3 POWER SENSING

The power computation in the Multilin Agile IED is performed using the voltage and current inputs from the PH VT1 BANK-A and CT1 BANK-B. In cases when the connected VTs and CTs have opposite polarity, the power sensing menu allows for inverting the power measurement.

The Power Sensing settings can be found under the path: **SETPOINTS\SYSTEM\POWER SENSING**.

For more information regarding ranges and default values, refer to the Settings and Signal Appendix B.

**PHASE CT&VT POLARITY** Selects the polarity of phase VT connection and Phase CT connection connected to the IED, Same or Reverse. When Reverse is selected, this setpoint inverts (multiplies phase currents by "-1") the CT polarity for the phase currents from CT1 BANK-B, with respect to the phase voltages from the PH VT1 BANK-A.

**Note:**

*The setpoint for inversion of the power metering will be useful to avoid the physical inversion of the CT connections on the relay. As the power metering will affect the power directional elements, the user must determine the correct forward and reverse direction of the power before setup.*

**RESET EVENT ENERGY** Selects the Flexlogic operand to log, and resets to Zero all energy metering values.

At the rising edge of the FlexLogic operand selected under **RESET EVENT ENERGY** setpoint, all energy metering values under **MEASUREMENTS\ENERGY 1\ENERGY**, are logged and reset to zero, and **RST ENERGY D/T** is recorded and displayed.

The logged values are displayed as the **LAST EVENT (+/-) WHR** and **LAST EVENT (+/-) VARHR** under **MEASUREMENTS\ENERGY 1\ENERGY LOG**. Today and yesterday energy events are also provided.

An application example could be monitoring of the total energy accumulated at the end of an event or a shift interval. An event/shift interval can be defined, e.g. per the breaker status operand (open or closed).

### 5.4.4 POWER SYSTEM

The Power System menu allows the user to set the system nominal frequency (**Nom. Frequency**), phase sequence (**Phase Sequence**) and reverse phase sequence rotation for CTs and VTs (**Rev Ph Seq - CT** and **Rev Ph Seq - VT**).

The Power System settings can be found under the path: **SETPOINTS\SYSTEM\POWER SYSTEM**.

Settings descriptions are provided in the following subsections. For more information regarding ranges and default values, refer to the Settings and Signals Appendix B.

### 5.4.4.1 NOMINAL FREQUENCY AND PHASE SEQUENCE

The **Nom. Frequency** setting is used as a default to set the digital sampling rate if the system frequency cannot be measured from available AC signals. This may happen if the signals selected for frequency tracking are not present, or a valid frequency is not detected. Before reverting to the nominal frequency, the frequency tracking algorithm holds the last valid frequency measurement for a safe period of time while waiting for the signals to reappear or for the distortions to decay.

The selection of the **Phase Sequence** setting shall match the power system phase rotation. This setting is required to properly calculate sequence components and power parameters.

This setting informs the IED of the actual system phase sequence, either ABC or ACB. CT and VT inputs on the IED corresponding to a, b, and c, must be connected to system phases A, B, and C for correct operation.

### 5.4.4.2 REVERSE PHASE SEQUENCE ROTATION

The device provides the flexibility of dynamically reversing the phase rotation (ABC <-> ACB) of both current and voltage phases. These setpoints can be used to reverse phase rotation of CT bank(s) and VT bank independent of each other. There may be a reverse motor application when only current phase rotation is reversed (ABC <-> ACB) while voltage phase rotation remains the same. An example of such an application is illustrated in the figure below.




Figure 22: Reverse motor application, current phase rotation reversed

**Note:**

VT Inputs only apply to P24D models.

#### 5.4.4.2.1 REVERSE PHASE SEQUENCE ROTATION IMPLEMENTATION

Reverse phase sequence rotation settings (**Rev Ph Seq - CT**, **Rev Ph Seq - VT** (\*)) can be found at: **SETPOINTS \SYSTEMPOWER SYSTEM** path.

These settings dynamically reverse the phase rotation of all currents (**Rev Ph Seq - CT** setting) and voltages (**Rev Ph Seq - VT** setting) (\*). For example, if the nominal phase rotation is ABC but the condition (FlexLogic operand configured at the corresponding setting) becomes true (high), then the phase rotation switches to ACB.

The reverse phase rotation feature is only intended for use in special applications such as pumped storage schemes, reverse motor application, etc. As soon as the reverse phase rotation condition (FlexLogic operand)

status becomes false (low), the phase rotation returns to the nominal value set at Phase Sequence setting at: **SETPOINTS\SYSTEM\POWER SYSTEM**.

Flexlogic Operands	
Operand	Description
Ph Seq Inhibit	Reverse to forward or forward to reverse (ABC <-> ACB) phase rotation of either current or voltage (*) or both has initiated. This operand remains high for 3 cycles after initiation.
Rev Ph Seq - CT	Currents phase rotation is switched from forward to reverse.
Rev Ph Seq - VT (*)	Voltages phase rotation is switched from forward to reverse.

*Note:*

(\*) Voltages, settings and Flexlogic operands are only available for P24D models.

*Note:*

Dynamic switching of the phase rotation (ABC <-> ACB) using this feature, blocks all relay functions that use current and voltage measurements for 3 cycles as soon as phase rotation switches from forward to reverse or reverse to forward.



**Caution:**

Any FlexElement that uses FlexAnalog values (current, voltage, power, impedance) must be blocked using the FlexLogic operands ' Ph Seq Inhibit' in order to secure element operation during the phase rotation switching process.

**Caution:**

In applications when only the current phase rotation reverses while the voltage phase rotation remains the same. Illustrated by the figure below, different CT and VT phase rotations may result in unexpected operation of the functions that use power, power factor, and impedance. It is recommended to block these functions.



5.4.4.2.2 REVERSE PHASE SEQUENCE ROTATION LOGIC




Figure 23: Reverse phase sequence rotation logic

5.4.5 MOTOR SETUP CONFIGURATION

MAGile Motor IED setup configuration is performed through the *SETUP* and *VFD* menus, placed at **SETPOINTS\SYSTEMMOTOR** path.

5.4.5.1 MOTOR SETUP

5.4.5.1.1 MOTOR SETUP IMPLEMENTATION

The Motor **Setup** settings reflect the design and configuration of the motor that the device will protect.

*Note:*  
Some protection elements are dependant on these settings for correct operation.

Motor Setup settings can be found at **SETPOINTS\SYSTEMMOTOR\SETUP** path.

Motor Setup feature provides several Flexlogic operands as per the following table:

Flexlogic Operands	
Operand	Description
Speed2 Tr 2-1 OP	Motor is transferring from high speed (speed 2) to low speed (speed 1)
Motor Speed 2	Motor is running at high speed (speed 2)

The Motor Setup settings are as follows:

### Motor FL Amps

This setting represents the full load current (FLA) of the motor. FLA is a standard motor parameter that can be found on the motor nameplate.

### Motor OL Factor

This setting defines the current level at which the motor is considered to be overloaded. If the motor current exceeds the **Motor OL Factor** threshold, the Thermal Model reacts by accumulating thermal capacity. Normally, this factor is set slightly above the motor service factor to account for inherent load measuring errors (CTs and limited relay accuracy). The typical total inaccuracy factor is 8 to 10%; for motors with a thermal capability at a rated service factor of 1 or 1.15, the **Motor OL Factor** must be set to 1.1 or 1.25 respectively.

### Motor Rated Volt

This setting represents the rated phase-to-phase motor voltage. The **Motor Rated Volt** setting is used as a reference for the voltage dependant thermal overload curve feature and indicates a 100% voltage starting condition.

### Rated Speed

This setting defines the rated speed of the motor in RPM.

**Note:**

*In 2 Speed motor application, when the **2-Spd Mtr Prot** setting is set to *Enabled* and **Spd2 Motor Sw** setting is set to *On*, the setting **Spd2 Rated Spd**, programmed under **SETPOINTS\SYSTEM\MOTOR\SETUP**, will be used by the Second Speed Protection as the rated value.*

### Emergency Restart

The Emergency Restart feature must only be used in an emergency, as it defeats the purpose of the device, which is to protect the motor. The input selected by this setting, when asserted, is used to reset the motor thermal capacity used from its current value to 0%, so that a hot motor may be restarted. The selected input also sets the Start Inhibit block functions lockout time to zero. These Start Inhibit functions are: **Thermal Inhibit**, **Max Starting Rate** (Maximum Starting Rate) and **Time Bet Starts** (Time Between Starts). However, a **Restart Delay** inhibit lockout will remain active and any trip condition that remains will still cause a trip.

In the event of a real emergency, the **Emergency Restart** input must remain asserted until the emergency is over. All the associated output relays reset until the **Emergency Restart** input is removed. However, the TCU does not remain reset to zero if the **Emergency Restart** input remains asserted, the thermal model continues calculating the TCU.

The **Emrg Restart Alm** operand is asserted if the Emergency Restart input remains asserted for 10 seconds.

The Flexlogic operands related to the Emergency Restart are calculated in the Thermal Model feature and are as follows (for motor details refer to the Thermal Model section in the Motor Protection chapter).

Flexlogic Operands	
Operand	Description
Emrg Restart	Emergency restart command has been initiated
Emrg Restart Alm	Emergency restart alarm initiated

### Nb of Str to Lr

This **Nb of Str to Lr** (Number of Starts to Learn) setting selects the number of motor start and stop records to calculate learned data presented under **RECORDS\LEARNED DATA** path.

### Load Avg Cal Prd

This **Load Avg Cal Prd** (Load Average Calculation Period) setting adjusts the period of time over which the average motor load is calculated. The calculation is a sliding window and is ignored during motor starting.

### Switch Dev Type

This setting specifies the type of switching device installed (Breaker or Contactor), to stop or start the motor.

### Mtr Ld Filt Int

This motor load filter interval setting defines the window size (when the setting is set to a non-zero value) of the averaging filter applied to current and voltage signals. The averaging filter is intended for use on driving reciprocating loads or variable frequency drives (VFD).

With the reciprocating load application, the number of cycles to average can be determined from current waveform capture using the Disturbance Recorder or Datalogger features. The second way to determine this setpoint is by using the following equation:

$$N = P/2$$

Where N is the number of cycles to average, and P is the number of poles on the motor.

Example of settings: **Mtr Ld Filt Int** setting to be set to 3 cycles, for a motor driving reciprocating load with 6 poles.

**Note:**

The latter approach of determining the cyclic load only applies to applications where loads are coupled directly to the motor (with no gear box).

**Note:**

When set greater than one cycle, Motor Load Filter Interval may increase trip/alarm times for the following protection elements: **Thermal Model, Current Unbalance, Mechanical Jam, Undercurrent, Overload Alarm, Acceleration Time** configurable at **SETPOINTS\PROTECTION\GROUP [1-6]\MOTOR** path. **Power Factor** configurable at **SETPOINTS\MONITORING\FUNCTIONS** path and **Overpower** and **Underpower** configurable at **SETPOINTS\PROTECTION\GROUP [1-6]\POWER PROT.** path. No other elements are affected. Trip/alarm times increase 16.7 ms at 60 Hz (or 20msec at 50Hz) for each additional cycle in the filter interval.

**Note:**

A logic diagram for Motor Load Averaging Filter for VFD and Cyclic Load Motor Applications using **Mtr Ld Filt Int** setting, is available in the Motor Setup Logic section below.

### Max Accel Time

This setting specifies the maximum acceleration time. This setting is used by the **Accel Time** element (configurable under **SETPOINTS\PROTECTION\GROUP [1-6]\MOTOR**), and by the **Mtr Start Stats** feature (available under **RECORDS**).

This setting can be estimated experimentally by starting a given motor several times under various load and electrical conditions, and measuring the starting time. Some security margin should be applied.

The **Accel Time** element operates if the motor is not in the *Motor Running* state when this time expires.

Regardless of whether the **Accel Time** element is *Enabled* or *Disabled*, this **Max Accel Time** setting is also required to calculate the **Mtr Start Stats** when the motor doesn't go in the *Motor Running* state from the *Motor Starting* state, i.e. unsuccessful motor start. For a successful motor start, *Motor Starting* and *Motor Running* states are used to calculate the motor start statistics.

## 2-Spd Mtr Prot

This setting is used to enable the two-speed motor function. This function provides proper protection for a two-speed motor where there are two different full load values. The two-speed functionality is required for motors having two windings wound into one stator. One winding, when energized, provides one of the speeds. When the second winding is energized, the motor takes on the speed determined by the second winding. The algorithm integrates the heating at each speed into one thermal model using a common thermal capacity used register value for both speeds.

Using the device for such applications provides several options, allowing the removal of traditional wiring and interlocking:

- Use the device front panel pushbuttons (applicable for 30TE models) to provide the necessary operate and interlock logics using FlexLogic.
- Use external pushbuttons to the device, to provide the necessary operate and interlock logic using FlexLogic.
- Use a traditional external control schematic with some connections to the device for control and protection.

## Spd2 Motor Sw

If the two-speed motor feature is used (**2-Spd Mtr Prot** set to *Enabled*), this setting specifies a FlexLogic operand to indicate the current motor speed. This is typically an indication that the contactor at speed 2 is energized. When the FlexLogic operand assigned to **Spd2 Motor Sw** setting (typically a contact input operand) is asserted, the algorithm switches to speed 2 (high speed), Motor Speed 2 Flexlogic operand is asserted. If the FlexLogic operand assigned to **Spd2 Motor Sw** setting is de-asserted, the algorithm switches to speed 1 (low speed), Motor Speed 2 Flexlogic operand is de-asserted. This allows the device to determine which settings must be active at any given time.

## Spd2 Sw 2-1 Dly

This setting specifies the time delay to transfer from high (Speed 2) to low speed (Speed 1). This allows the motor to slow down before energizing at low speed. When the motor is switched from high speed to low speed, the *Speed2 Tr 2-1 OP* FlexLogic operand is asserted for time length defined by the **Spd2 Sw 2-1 Dly** setting, to allow inputs for control logic of contactors and breakers at both speeds. FlexLogic operands required for contactor and breaker control are provided.

## Spd2 Accel Time

This setting specifies the maximum acceleration time for the Speed 2 Motor protection. This setting is used by the **Speed2 Acceleration element** (configurable under **SETPOINTS\PROTECTION\GROUP [1-6]\MOTOR\2-SPEED MOTOR**), and by the **Mtr Start Stats** feature (available under **RECORDS**).

When the motor is directly started at Speed2 (high speed), the Speed2 Acceleration element operates if the motor is not in the *Motor Running* state when this time expires.

When the **2-Spd Mtr Prot** setpoint is programmed as *Enabled*, regardless of the **Speed2 Acceleration element** (configurable at **SETPOINTS\PROTECTION\GROUP [1-6]\MOTOR\2-SPEED MOTOR** path) being *Enabled* or *Disabled*, this setting is also required to calculate the motor start statistics (under **RECORDS\MTR START STATS**) when the motor doesn't go into the *Motor Running* state from the *Motor Starting* state, i.e. unsuccessful motor start. Otherwise, in the successful motor start case, *Motor Starting* and *Motor Running* states are used to calculate the motor start statistics.

## Spd2 CT Prmry

This setting specifies the primary rating of the three-phase CTs installed at the speed 2 stator winding terminals.

## Spd2 Motor FLA

This setting specifies the motor full load current for speed 2.

### Spd2 Rated Spd

This setting specifies the motor rated speed for speed 2.

### Spd2 Ph Rotation

The **Spd2 Ph Rotation** setting (*Standard ABC, Reverse ACB*) can be programmed to accommodate the reversed motor rotation at Speed2 and is seen only if **2-Spd Mtr Prot** is set to *Enabled*.

#### 5.4.5.1.2 MOTOR SETUP LOGIC





Figure 24: Motor load averaging filter for VFD and Cyclic load motor applications



#### 5.4.5.2 VARIABLE FREQUENCY DRIVE (VFD)

Some Variable Frequency Drives (VFD), for example pulse width modulated drives, generate significant distortion in voltages introducing harmonics. However, distortion due to these harmonics is not as significant in currents as in voltages. The functionality of various protection elements is made adaptive to the VFD motor applications depending on the system configurations.

The possible system configurations can be:

1. Motor start and run through the VFD only.
2. VFD with Bypass (BP) Switch (i.e., the motor runs through the bypass switch without VFD, but the VFD is required for starting).




Figure 25: Typical motor applications with VFD and bypass switch

5.4.5.2.1 VARIABLE FREQUENCY DRIVE (VFD) IMPLEMENTATION

Variable Frequency Drive (VFD) settings can be found at **SETPOINTS\SYSTEM\MOTOR\VFD** path. The VFD feature provides several operands (depending on the asserted/non-asserted status of the signal configured at **Bypass Switch** setting). These operands are:

Flexlogic Operands	
Operand	Description
VFD Bypassed	The VFD is bypassed by the switch
VFD Not Bypassed	The VFD is not bypassed by the switch

The VFD settings are as follows:

**Function**

This setting enables the VFD configuration support in the device.

**Bypass Switch**

This setting defines the operand (typically a digital input) to determine (when asserted) if the motor is powered by the VFD or directly from the AC source through the bypass switch. The VFD Bypassed operand will be asserted when VFD is bypassed (i.e., the motor is directly powered by the AC system or the utility). This operand can be

used to block (inhibit) the voltage based elements via the **Inhibit** setting of the desired elements if this operand is not asserted i.e. VFD is not bypassed.

**Note:**

We recommend blocking (inhibiting) the voltage based elements via the **Inhibit** setting of the desired elements if "VFD Not Bypassed" Flexlogic operand is asserted.

## Starting Freq

This setting defines the starting frequency, which provides faster tracking to the frequency once the motor is energized. For example, in the motor application, when the VFD is required at the starting and normally the starting frequency is 25 Hz, then the **Starting Freq** setting should be set to 25 Hz rather than to the nominal system frequency. If this value of starting frequency is not known, then set this setting to a value equal to the system nominal frequency (as per **Nom. Frequency** at **SETPOINTS\SYSTEM\POWER SYSTEM**).

The **VFD Function** must be *Enabled* in order to ensure proper performance of the device for motor applications with VFD. In the motor application when VFD can be bypassed via the Bypass Switch (see option (2) of the "Typical motor application with VFD and Bypass Switch" figure), the status of the bypass switch must be configured as a selected input under the **Bypass Switch** setting. When the input configured at the **Bypass Switch** setting is asserted, **VFD Bypassed** operand is asserted and **VFD Not Bypassed** operand is de-asserted, and vice versa, when the signal configured at the **Bypass Switch** setting is not asserted, **VFD Bypassed** operand is de-asserted and **VFD Not Bypassed** operand is asserted.


See below the behaviour of the device depending on the **VFD Function** setting and **Bypass Switch** operand asserting status:

If the **VFD Function** is *Enabled* and the **Bypass Switch** operand is not asserted (i.e., bypass switch is open) then the device algorithms adopt the following changes:

- Multilin Agile Motor protection can be ordered with both current and voltage inputs (P24D), or with just current inputs (P24N). Independently of which ordering options are selected, when it comes to frequency tracking, the current inputs will always have the highest priority or main source to frequency tracking. For the case where currents are not available, or system frequency cannot be measured from the available AC signals, then the power system nominal frequency (**Nom. Frequency** setting value (50 Hz or 60 Hz) at **SETPOINTS\SYSTEM\POWER SYSTEM** path) is used as a default. All elements will function properly for a frequency range of 40-72 Hz.
- Thermal Model Voltage Dependant (VD) function (**VD Function** at **SETPOINT\PROTECTION\GROUP [1-6]MOTOR\THERMAL MODEL**) is blocked automatically.
- **VFD Not Bypassed** operand will be asserted and **VFD Bypassed** operand will be de-asserted. **VFD Not Bypassed** operand can be used to block(inhibit) the voltage elements via the **Inhibit** setting of the elements.
- To mitigate oscillations, all motor current functions except Short Circuit and Ground Fault will use Motor Filtered Currents with a Motor Load Averaging Filter of length according to the value set at the **Mtr Ld Filt Int** setting under **SETPOINTS\SYSTEM\MOTOR\SETUP**.
- If the **VFD Function** is *Enabled* and the **Bypass Switch** operand is asserted (i.e. bypass switch is closed) then the frequency tracking source will be switched from currents to voltages for P24D models. All voltages elements will work as normal, **VFD Not Bypassed** operand will be de-asserted, while **VFD Bypassed** operand will be asserted, and all motor functions will then be using the normal RMS currents (not filtered).

**Note:**

To ensure proper working of the voltage related functions and measurements, CTs and VTs must be on the motor side of the VFD. In case the voltage inputs to the IED are measured at the busbar side of the VFD and there is a frequency difference between the bus and motor sides of the VFD, then voltage functions must not be used or must be blocked (inhibited). In case the voltage inputs to the IED are measured at the motor side of the VFD, voltages may or may not be sinusoidal and highly distorted depending on the VFD type. It is recommended to block (inhibit) voltage functions if VFD output voltages are not sinusoidal and highly distorted. If VFD output voltages are substantially sinusoidal, which can be verified from the measurements, disturbance recorder and data logger, then the blocking (inhibition) of the voltage elements is not required.



**Figure 26: Possible VT locations: busbar or motor side of the VFD**

With the VFD motor application, the motor protection device uses the running average technique (see the **Mtr Ld Filt Int** setting description in the Motor Setup section for more details of this technique) to smooth out the phasor's ripple due to the distortion generated by the VFD. When the **Mtr Ld Filt Int** setting is set to non-zero cycles, the Motor Load Averaging Filter can increase Trip or Alarm times for the following protection elements:

- Acceleration Time
- Current Unbalance
- Mechanical Jam
- Overload
- Thermal Model
- Undercurrent
- Power Factor
- Under Power
- Reduced Voltage Start

No other elements are affected. The exceptions to this increased time are the short circuit elements such as Short Circuit, Ground Fault, TOC/IOC, which will trip as per the specification.

**Note:**

When using this filter for the VFD motor application running at a low frequency, it will result in very long time delays for Trip or Alarm. For example, if the **Mtr Ld Filt Int** setting is set to 10 cycles and the motor is running at 40Hz (tracking frequency), the Trip/Alarm delay will be increased by 0.5 sec.



In order to avoid long Trip/Alarm delays, especially when the motor is running at low frequencies, the Trip/Alarm delay is limited internally to the number of cycles equal to the minimum of the maximum delay at nominal frequency and average filter delay at tracking frequency, as follows:

$$\text{Min} \left( \frac{1}{F_n} \times 16 \text{ cycles}, \frac{1}{F} \times N \text{ in cycles} \right)$$

where:

$N$  = **Mtr Ld Filt Int** setting value of the motor load filter interval for the number of cycles in the range of 0 to 32

$F_n$  = Nominal system frequency in Hz (50 or 60 Hz)

$F$  = Tracking frequency in Hz

This adjustment to the filter length, to avoid large Trip/Alarm delay is only applicable when the VFD **Function** is *Enabled*, and the **Bypass Switch** operand is not asserted. This adjustment is not applicable when this filter is applied to motor applications with reciprocating load. The following examples show the Trip/Alarm time delay calculation with the above-mentioned adjustment to the filter length, when the average filter of length **Mtr Ld Filt Int** setting is applied to the VFD applications:

Example 1:

- **Mtr Ld Filt Int** setting (at **SETPOINTS\SYSTEM\MOTOR\SETUP**),  $N = 20$  cycles
- Tracking frequency,  $F = 40\text{Hz}$
- **Nom. Frequency** setting (at **SETPOINTS\SYSTEM\POWER SYSTEM**),  $F_n = 60\text{Hz}$
- Maximum time delay at nominal frequency =  $(1/F_n) \times 16 \text{ cycles} \times 1000 = \sim 270 \text{ msec}$
- Actual time delay at actual or tracking frequency =  $(1/F) \times 20 \text{ cycles} \times 1000 = \sim 500 \text{ msec}$
- Trip/Alarm time delay is then =  $\text{Min} (270, 500) = 270 \text{ msec}$

Example 2:

- **Mtr Ld Filt Int** setting (at **SETPOINTS\SYSTEM\MOTOR\SETUP**),  $N = 4$  cycles
- Tracking frequency,  $F = 70\text{Hz}$
- **Nom. Frequency** setting (at **SETPOINTS\SYSTEM\POWER SYSTEM**),  $F_n = 60\text{Hz}$
- Maximum time delay at nominal frequency =  $(1/F_n) \times 16 \text{ cycles} \times 1000 = \sim 270 \text{ msec}$
- Actual time delay at actual or tracking frequency =  $(1/F) \times 4 \text{ cycles} \times 1000 = \sim 60 \text{ msec}$
- Trip/Alarm time delay is then =  $\text{Min} (270, 60) = 60 \text{ msec}$

For the VFD motor application, the value for the **Mtr Ld Filt Int** setting (configurable at **SETPOINTS\SYSTEM\MOTOR\SETUP**) can be determined from the captured load waveforms obtained from the Datalogger or Disturbance Recorder features, by following the steps below:


**Step 1:** Capture the pre-filtered load analog value from the Datalogger/Disturbance Recorder. This analog value is defined as *Motor Load* in the Thermal Model analog values (at **MEASUREMENTS\MOTOR LOAD**). *Motor Load* is the average of the three RMS input currents and is applied at the input of the Motor Load Averaging Filter (see the "Motor Load Averaging Filter for VFD and Cyclic Load Motor Applications Logic" figure in the "Motor Setup Logic" section, for more details about VFD and Motor Load Averaging Filter).

**Step 2:** By analyzing the captured waveform in Step 1, the length of oscillation that repeats itself at regular intervals can be estimated. Estimation of length must be done in nominal power cycles.

**Step 3:** Set the Motor Load Filter Interval (**Mtr Ld Filt Int** setting) equal to the value estimated in Step 2 plus a recommended margin of 1 cycle.

**Step 4:** Capture the *Filt Motor Load* analog value from the Datalogger/Disturbance Recorder. *Filt Motor Load* is the motor load current after filtration of oscillations due to VFD.

**Step 5:** Analyze the captured waveform in Step 4, to see if the estimated value from Step 2 is appropriate enough to mitigate the oscillations. If needed, repeat Steps 1-4 in order to achieve the appropriate value of the Motor Load Filter Interval (**Mtr Ld Filtr Int** setting) until oscillations become negligible.



5.4.5.2.2 VARIABLE FREQUENCY DRIVE (VFD) LOGIC




Figure 27: VFD logic

5.4.6 PRESET VALUES

Multilin Agile Motor IEDs provide the possibility to preset several actual values accumulators, such as Motor Running Hours and Energy counters (Positive and Negative Watt Hours and Var Hours). See the list below:

Actual Value Accumulator	Description	Path
Mtr Running Hrs	Running hours of the motor	<b>DEVICE STATUS\SUMMARY\MOTOR</b>
+Whr	Positive Watt Hours of the motor	<b>MEASUREMENTS\ENERGY</b>
-Whr	Negative Watt Hours of the motor	

When the accumulator is preset with a new value, the device overwrites the previous value and continues the accumulation starting from the new value. The accumulated value is displayed in either Device Status or Measurements, depending on the type of value. The displayed actual values are the accumulated real-time values starting from the Preset Values.

There are two ways to store the preset values on its corresponding accumulators. By directly updating the setting value, this will apply to the specific setting that has been modified, or, in the case of the Energy values, by also clearing the Energy Use Data by a direct command when connected to the device, or by asserting the operand configured at **Energy Use Data** setting at **SETPOINTS\DEVICE\CLEAR RECORDS** path. Clearing the Energy Use Data will set the Energy values to their configured preset values. There is no clear command for Motor Running Hours. Motor Running Hours value is only preset by updating the value of its **Mtr Running Hrs** setting.

The Preset Values settings can be found at **SETPOINTS\SYSTEM\PRESET VALUES** path, and are as follows:

### Mtr Running Hrs

This setting allows the user to set the running hours value of the existing motor. The accumulated Motor Running Hours is shown in **DEVICE STATUS\SUMMARY\MOTOR\MTR RUNNING HRS**. Updating the setting sets the displayed value to its preset value.

### Pwr1 Pos WattHrs

This setting allows the user to set the preset value for Positive Watt Hours. The accumulated Positive Watt Hours are shown in **MEASUREMENTS\ENERGY+WHR**. Clearing the Energy Use Data sets the displayed value to its preset value.

### Pwr1 Neg WattHrs

This setting allows the user to set the preset value for Negative Watt Hours. The accumulated Negative Watt Hours are shown in **MEASUREMENTS\ENERGY-WHR**. Clearing the Energy Use Data sets the displayed value to its preset value.

### Pwr1 Pos VarHrs

This setting allows the user to set the preset value for Positive Var Hours. The accumulated Positive Var Hours are shown in **MEASUREMENTS\ENERGY+VARHR**. Clearing the Energy Use Data sets the displayed value to its preset value.

### Pwr1 Neg VarHrs

This setting allows the user to set the preset value for Negative Var Hours. The accumulated Negative Var Hours are shown in **MEASUREMENTS\ENERGY-VARHR**. Clearing the Energy Use Data sets the displayed value to its preset value.

## 5.4.7 SWITCHING DEVICES

The IED supports two types of motor switching devices: breakers and contactors. A breaker operation is controlled by two coils labeled "Trip" and "Close". Each of them has to be separately energized with a short pulse in order to change the state of the breaker. A contactor operation is controlled by a single coil. When the coil is energized, the main contacts are closed and when the coil is de-energized, the main contacts are open.

To configure the Switching Device on this IED, the user needs to select either *Breaker* or *Contactor* in the **Switch Dev Type** setting at **SETPOINTS\SYSTEM\MOTOR\SETUP** path and ensure that the selection matches the actual device type used.

### 5.4.7.1 BREAKER

#### 5.4.7.1.1 BREAKER IMPLEMENTATION

If **Switch Dev Type** setting is selected as *Breaker* at **SETPOINTS\SYSTEM\MOTOR\SETUP**, the user will have access to the Breaker settings under **SETPOINTS\SYSTEM\CB SETUP** path.

The breaker detection is performed on the IED by monitoring the state/states of either one, or preferably two, contact inputs. It is highly recommended to monitor the status of the breaker using both breaker auxiliary contacts 52a, and 52b. However, using only one of them is also acceptable.

The breaker status can be checked at *Position* status under **DEVICE STATUS\CIRCUIT BREAKER\CB STATUS** path. *Position* will show one of the following operands corresponding to the breaker status:

Flexlogic Operands	
Operand	Description
CB Open 3 ph	Breaker state is detected opened

Flexlogic Operands	
Operand	Description
CB Closed 3 ph	Breaker state is detected closed
CB State Unknown	Close or Open breaker state cannot be detected
CB NotConfigured	No input 52a or 52b is programmed to reflect the status of the breaker

The Breaker settings are as follows:

### Status Input

The **Status Input** setting selects the CB input configuration with one contact (*52A* or *52B*) or two contacts (Both *52A* and *52B*). Form A contacts match the status of the circuit breaker primary contacts, form B are opposite to the breaker status. In case the setting is left as *None*, or any of the **Aux 3ph (52A)** or **Aux 3ph (52B)** settings are set to *Off*, the device will show breaker status *CB NotConfigured*.

### Aux 3ph (52A) and Aux 3ph (52B)

The **Aux 3ph (52A)** and **Aux 3ph (52B)** settings select the Input connected to the breaker auxiliary contacts 52a and 52b. These settings will be displayed when the **Status Input** setting is set to any value other than *None*. Depending on the value selected, *52A*, *52B* or Both *52A* and *52B*, one of the two settings or both will be available for the user to configure.

The logic for Breaker configuration and the Open, and Close status is shown in the tables below:

#### Breaker status depending on availability of contacts 52a and 52b:

Status Input	52a Contact Configured	52b Contact Configured	Breaker Status	
			Open	Close
Both 52A and 52B	Yes	Yes	52a contact open 52b contact closed	52a contact closed 52b contact open
	Yes	No	Breaker not configured	
	No	Yes		
	No	No		
52A	Yes	-	52a contact open	52a contact closed
	No	-	Breaker not configured	
52B	-	Yes	52b contact closed	52b contact open
	-	No	Breaker not configured	

#### Breaker status with both contacts 52a and 52b configured:

52a Contact Status	52b Contact Status	Breaker Status
Off	On	Breaker Opened
On	Off	Breaker Closed
On	On	Breaker Unknown State
Off	Off	Breaker Unknown State

### 5.4.7.1.2 BREAKER LOGIC




Figure 28: Breaker state detection logic

### 5.4.7.2 CONTACTOR

#### 5.4.7.2.1 CONTACTOR IMPLEMENTATION

If **Switch Dev Type** setting is selected as *Contactor* **SETPOINTS\SYSTEM\MOTOR\SETUP**, the user will have access to the Contactor settings under **SETPOINTS\SYSTEM\CONTACTOR** path.

The contactor states are as follows:

Flexlogic Operands	
Operand	Description
Contactor Opened (Cnct Open 3 ph)	Contactor state is detected open
Contactor Closed (Cnct Closed 3 ph)	Contactor state is detected closed
Contactor Unkwn Stat (Cnct State Unkwn)	Closed or Open Contactor state cannot be detected
Contactor Not Config (Cnct Not Config)	Contactor status contacts not configured

The Contactor settings are as follows:

#### Status Input

The **Status Input** setting selects the contactor input configuration with one contact (*52A* or *52B*) or two contacts (Both *52A* and *52B*). Form A contacts match the status of the contactor primary contacts, form B are opposite to the contactor status. In case the setting is left as *None*, or any of the **Aux 3ph (52A)** or **Aux 3ph (52B)** settings are set to *OFF*, the device will show contactor status *Contactor Not Config* (Cnct Not Config).

#### Aux 3ph (52A) and Aux 3ph (52B)

The **Aux 3ph (52A)** and **Aux 3ph (52B)** settings select the Input connected to the contactor auxiliary contacts 52a and 52b. These settings will be displayed when the **Status Input** setting is set to any value other than *None*.

Depending on the value selected, 52A, 52B or Both 52A and 52B, one of the two settings or both will be available for the user to configure.

The logic for Contactor configuration and the Open, and Close status is shown in the tables below:


**Contactor status depending on availability of contacts 52a and 52b:**

Status Input	52a Contact Configured	52b Contact Configured	Breaker Status	
			Open	Close
Both 52A and 52B	Yes	Yes	52a contact open 52b contact closed	52a contact closed 52b contact open
	Yes	No	Contactor not configured	
	No	Yes		
	No	No		
52A	Yes	-	52a contact open	52a contact closed
	No	-	Contactor not configured	
52B	-	Yes	52b contact closed	52b contact open
	-	No	Contactor not configured	

**Contactor status with both contacts 52a and 52b configured:**

52a Contact Status	52b Contact Status	Breaker Status
Off	On	Contactor Opened
On	Off	Contactor Closed
On	On	Contactor Unknown State
Off	Off	Contactor Unknown State

**5.4.7.2.2 CONTACTOR LOGIC**



**Figure 29: Contactor state detection logic**

### 5.4.7.3 USER CURVES

The IED incorporates five programmable User Curves - User Curve 1, 2, 3, 4 and User Curve OL.

The points for the User Curves 1 through 4 are defined by the user in the EnerVista Configuration software. User-defined curves can be used for Time Overcurrent protection in the same way as IEEE, IAC, ANSI and IEC curves. Each of the four User Curves (1, 2, 3 and 4) has 128-point settings for entering times to reset and operate, 40 points for reset (from 0 to 0.98 times the Pickup value) and 88 for operate (from 1.03 to 20 times the Pickup). These data are converted into two continuous curves by linear interpolation between data points.

The User Curves Data settings for User Curves 1, 2, 3, 4 can be found under the path: **SETPOINTS\SYSTEM\USER CURVES DATA\USER CURVE X**, where X is 1 to 4.

The User Curve Data settings for User Curve OL can be found under the path: **SETPOINTS\SYSTEM\USER CURVE OL**.

For more information regarding ranges and default values, refer to the Settings and Signals appendix.

*Note:*

Use the EnerVista Configuration software to select, design or modify any of the User Curves' data.

#### 5.4.7.3.1 USER CURVES 1, 2, 3, 4

The IED incorporates four programmable User Curves: User Curve 1, 2, 3 and 4. The points for these curves are defined in the EnerVista Configuration software. User-defined curves can be used for Time Overcurrent protection in the same way as IEEE, IAC, ANSI, and IEC curves. Each of the four User Curves (1, 2, 3 and 4) has 128-point settings for entering times to reset and operate, 40 points for reset (from 0 to 0.98 times the Pickup value) and 88 for operate (from 1.03 to 20 times the Pickup). The data is converted into two continuous curves by linear interpolation between data points.

*Note:*

Use the EnerVista Configuration software to select, design or modify any of the User Curves' data.

The following table, for User Curves 1 to 4, details the 128 configurable points as well as the characteristic for each of them, and a blank cell where the user can write the time value when the operation (for  $I > I_{pickup}$ ) or the reset (for  $I < I_{pickup}$ ) is required.

Reset Time at (x PKP)	Time Value (ms)	Reset Time at (x PKP)	Time Value (ms)	Operate Time at (x PKP)	Time Value (ms)	Operate Time at (x PKP)	Time Value (ms)	Operate Time at (x PKP)	Time Value (ms)	Operate Time at (x PKP)	Time Value (ms)	Operate Time at (x PKP)	Time Value (ms)
0.00		0.68		1.03		2.1		4.1		6.5		16.5	
0.05		0.70		1.05		2.2		4.2		7.0		17.0	
0.10		0.72		1.07		2.3		4.3		7.5		17.5	
0.15		0.74		1.09		2.4		4.4		8.0		18.0	
0.20		0.76		1.1		2.5		4.5		8.5		18.5	
0.25		0.78		1.125		2.6		4.6		9.0		19.0	
0.30		0.80		1.15		2.7		4.7		9.5		19.5	
0.35		0.82		1.175		2.8		4.8		10.0		20.0	
0.40		0.84		1.2		2.9		4.9		10.5			
0.45		0.86		1.25		3.0		5.0		11.0			
0.48		0.88		1.3		3.1		5.1		11.5			
0.50		0.90		1.35		3.2		5.2		12.0			




0.52	0.91	1.4	3.3	5.3	12.5			
0.54	0.92	1.45	3.4	5.4	13.0			
0.56	0.93	1.5	3.5	5.5	13.5			
0.58	0.94	1.6	3.6	5.6	14.0			
0.60	0.95	1.70	3.7	5.7	14.5			
0.62	0.96	1.8	3.8	5.8	15.0			
0.64	0.97	1.9	3.9	5.9	15.5			
0.66	0.98	2.0	4.0	6.0	16.0			

**User Curves 1, 2, 3, 4 Configuration using EnerVista Configuration Software**

EnerVista Configuration software allows for easy configuration and management of User Curves and their associated data points. Prospective User Curves can be configured from a selection of standard curves to provide the best approximate fit, then specific data points can be edited afterwards. Alternately, curve data can be imported from a specified file (.csv format) by selecting the **Import Data From** setting.

*Note:*  
The pickup multiples start at zero (implying the "reset time"), operating time below Pickup, and operating time above Pickup.

Curves and data can be exported, viewed, and cleared by clicking the appropriate buttons. User Curves 1, 2, 3 and 4 are customized by editing the operating time (ms) values at pre-defined per-unit current multiples.



**Figure 30: User curve 1 EnerVista configuration example**

**5.4.7.3.2 USER CURVE OL**

The User Curve OL is customized by editing the operating time(s) values as well as the operate quantity, which is multiple of FLA.

The following table shows the configurable operating quantity (x FLA) and operating times (in seconds) for the configurable range of a maximum 30 points and a minimum range 10 points.

**Example of User Curve OL table with 30 operating points**

Trip Time At		Value (Time in sec.)		Trip Time At		Value (Time in sec.)
1.01	x FLA	17414.380		3.75	x FLA	26.780
1.05	x FLA	3414.840		4.00	x FLA	23.320
1.10	x FLA	1666.720		4.25	x FLA	20.500
1.20	x FLA	795.440		4.50	x FLA	18.170
1.30	x FLA	507.210		4.75	x FLA	16.220
1.40	x FLA	364.540		5.00	x FLA	14.570
1.50	x FLA	279.960		5.50	x FLA	11.960
1.75	x FLA	169.660		6.00	x FLA	9.990
2.00	x FLA	116.630		6.50	x FLA	8.480
2.25	x FLA	86.120		7.00	x FLA	7.290
2.50	x FLA	66.640		7.50	x FLA	6.330
2.75	x FLA	53.310		8.00	x FLA	5.550
3.00	x FLA	43.730		10.00	x FLA	5.550
3.25	x FLA	36.580		15.00	x FLA	5.550
3.50	x FLA	31.090		20.00	x FLA	5.550

**Note:**

For FlexCurve OL to properly work, it is important to enter the current pickup levels (x FLA) in ascending order, while the trip times can be entered in descending or ascending order.

EnerVista will create the final curve by means of a linear interpolation from the points defined by the user. The definition of these points is performed in a separate module from the IED, using a configuration program included in EnerVista, which incorporates a graphical environment for viewing the curve, and making it easy for the user to create.

The graphical environment to configure User Curve OL in EnerVista is similar to the one described for User Curves 1 to 4, with the following differences:

- For User Curve OL, the number of operational points is configurable at the **Nb of Op Points** setting, with a minimum of 10 up to a maximum of 30 (only Trip Times), while in the User Curves 1 to 4, the number of configurable points is fixed to 128 points (40 for Reset Time, and 88 for Trip time).
- For User Curve OL, the **Select Curve** setting only allows the *Standard Curve* value as a selectable option, while for User Curves 1 to 4, that setting shows the full range of curves available for the device.




Figure 31: User curve OL EnerVista configuration example

## CHAPTER 6

# MOTOR PROTECTION FUNCTIONS

---

## 6.1 MOTOR PROTECTION FUNCTIONS

---

This chapter contains the following sections:

Motor Protection Functions	95
Motor Protection Functions Menu Hierarchy	96
Motor Protection Functions	97

## 6.2 MOTOR PROTECTION FUNCTIONS MENU HIERARCHY

The following diagram is an example of the motor protection functions settings display navigation.

The protection elements are organized in six (6) identical setpoint groups: Setpoint Group 1 to Setpoint Group 6. Each Setpoint Group has the same protection functions, depending on the relay order code.




Figure 32: Motor protection functions menu hierarchy

## 6.3 MOTOR PROTECTION FUNCTIONS

Multilin Agile Motor IEDs provide a wide range of motor protection elements, such as:

- Thermal Model (\*1)
- Current Unbalance
- Mechanical Jam
- Undercurrent
- Overload Alarm
- Mechanical Jam
- Undercurrent (\*1)
- Overload Alarm
- Short Circuit
- Ground Fault
- Acceleration Time (\*1)
- Underpower (\*2)

*Note:*

*(\*1) Some of these elements have a 2-Speed associated features, such as Thermal Model, Undercurrent and Acceleration Time. The 2-Speed features are described in a separate section under this chapter.*

*Note:*

*(\*2) Underpower motor feature is described under Power Protection functions chapter.*

### 6.3.1 THERMAL MODEL

Thermal model is the primary protective function of the P24D and P24N Motor Multilin Agile IEDs.

#### 6.3.1.1 THERMAL MODEL IMPLEMENTATION

The Thermal Model consists of five key elements:

- Thermal model curve (overload)
- Overload pickup level
- Unbalance biasing of the motor current while the motor is running
- Motor cooling time constants
- Biasing of the thermal model based on hot/cold information

The algorithm integrates both stator and rotor heating into a single model. The motor heating level is maintained in the Thermal Capacity Used (TCU) register. If the motor has been stopped for a long time, it will be at ambient temperature and the Thermal Capacity Used will be zero. If the motor is in overload, the output operand is set once the thermal capacity used reaches 100%.

Once the motor load current exceeds the overload level (FLA x overload factor), it enters an overload phase; that is, the heat accumulation becomes greater than the heat dissipation. The thermal model reacts by incrementing the Thermal Capacity Used at a rate dependant on the selected thermal curve and overload level. When the thermal capacity reaches 100%, the Thermal Trip OP operand (typically configured to trip the motor) is set.

Resetting of Thermal OP and output relays depends on the selection of Trip Function.

- When the **Trip Function** is set to *Trip* or *Configurable*, thermal model outputs (output relay(s) and operand Thermal OP) reset automatically as soon as the TCU level drops to 97%.
- When the **Trip Function** is set as *Latched Trip*, the Thermal OP and output relays remain asserted until the current drops below OL\*FLA level and a Reset command is initiated or Emergency Restart input is asserted.

In the event of a loss of control power to the relay while the motor status is not Motor Stopped or Tripped, the thermal capacity will remain unchanged when control power is restored.

If the motor status is Motor Stopped or Tripped when control power is lost, the thermal capacity will decay for the duration of the loss of control power, based on the stopped motor cooling rate if the real time clock (RTC) was working properly during the power loss. However, if the clock was not working properly, the TCU value will remain unchanged when the relay power is restored.

The Thermal Model feature has two functions, Trip and Alarm. Trip is managed by the **Trip Function** setting and all the subsequent settings after trip. Alarm is managed by the **Alarm Function**, **Alarm Pickup** and **Alrm O/P Rly [X]** settings. **Inhibit** setting works both for Trip and Alarm features. Trip feature has its own relays to signal Trip through **Trip O/P Rly [X]** settings. Alarm feature has its own relays to signal Alarm through **Alrm O/P Rly [X]** settings. Thermal Model settings can be found at: **SETPOINTPROTECTION\GROUP [1-6]\MOTOR\THERMAL MODEL** path.

Thermal Model function provides several Flexlogic operands and Motor Status that are the following:

Flexlogic Operands		Motor Status (Multi Status Operand) (*)	
Operand	Description	Operand	Description
Thermal PKP	The thermal model element has started (picked up).	Motor Tripped	The motor is tripped
Thermal OP	The thermal model trip element has operated (trip).	Motor Stopped	The motor is stopped
Thermal Alarm OP	The thermal model alarm element has operated.	Motor Starting	The motor is starting
Emrg Restart	Emergency restart command has been initiated.	Motor Running	The motor is running
Emrg Restart Alm	Emergency restart alarm initiated.	Motor Overload	A motor overload condition has occurred

**Note:**

(\*) These messages describe the motor status at any given point in time. All motor status operands are mutually exclusive.

**Note:**

For detailed information about Motor Status and Emergency Restart signals, go to the Motor Status subsection in the Device Status section of the Monitoring and Control chapter.

The Thermal Models settings are as follows:

### Trip Function

This setting enables the Thermal Model Trip functionality if set to *Trip*, *Latched Trip* or *Configurable*. If this setting is set to *Disabled*, the Thermal Model Trip functionality is disabled and will not operate.



### Overload Curve

This setting specifies the thermal curve selected to determine the thermal limit overload conditions that can damage the motor.

The thermal model curve determines the thermal limit overload conditions that can damage the motor. This curve accounts for motor heating in both the stator and rotor during stall, acceleration, and running conditions. The overload curve can take one of six formats: *Motor*, *User Curve 1*, *User Curve 2*, *User Curve 3*, *User Curve 4*, *User Curve OL* or *IEC*. The selected curve (except IEC) can also serve as a base for a voltage dependant overload curve if the **VD Function** (Voltage Dependant Function) setting is set to *Enabled*.

The selected curve (except IEC) can also serve as a base for a voltage dependant overload curve if the **Voltage Dependant Function** setting is set to *Enabled*. The algorithm uses memory in the form of a register called Thermal Capacity Used. This register is updated every power cycle using the following equation:

$$TC_{used(t)} = TC_{used(t-1)} + \frac{T_{system}}{t_{trip}} \times 100\%$$

where:

- $t_{trip}$  represents the time coordinate on the time-current overload curve, corresponding to the equivalent motor current detected within any power cycle period of motor overload. Also specified as time to trip.
- $T_{system}$  represents the period in seconds corresponding to the nominal power system frequency.

When the **Overload Curve** is selected as *Motor*, the trip time is then calculated using the following equation:

$$t_{trip} = \frac{TDM \times 2.2116623}{0.02530337 \times \left(\frac{I_{motor}}{FLA} - 1\right)^2 + 0.05054758 \times \left(\frac{I_{motor}}{FLA} - 1\right)}$$

**Note:**

Always set the overload curve slightly lower than the thermal limits provided by the motor manufacturer. This ensures that the motor is tripped before the thermal limit is reached.

The Motor curve is based on typical motor thermal limit curves and is normally used for standard motor applications (see the following Standard Motor Curve TD Multipliers table below). The pickup level for the Motor curve is calculated as **Motor OL Factor** setting (OL) times the **Motor FL Amps** setting (FLA). Both **Motor OL Factor** and **Motor FL Amps** settings can be found at **SETPOINTS\SYSTEMMOTOR\SETUP** path.

### Pickup Level vs. Standard “Motor” Curve TD Multipliers

Pickup Level	STANDARD “Motor” Curve TD MULTIPLIERS														
	x 1	x 2	x 3	x 4	x 5	x 6	x 7	x 8	x 9	x 10	x 11	x 12	x 13	x 14	x 15
1.01	4353.6	8707.2	13061	17414	21768	26122	30475	34829	39183	43536	47890	52243	56597	60951	65304
1.05	853.7	1707.4	2561.1	3414.9	4268.6	5122.3	5976.0	6829.7	7683.4	8537.1	9390.8	10245	11098	11952	12806
1.10	416.68	833.36	1250.0	1666.7	2083.4	2500.1	2916.8	3333.5	3750.1	4166.8	4583.5	5000.2	5416.9	5833.6	6250.2
1.20	198.86	397.72	596.58	795.44	994.30	1193.2	1392.0	1590.9	1789.7	1988.6	2187.5	2386.3	2585.2	2784.1	2982.9
1.30	126.80	253.61	380.41	507.22	634.02	760.82	887.63	1014.4	1141.2	1268.0	1394.8	1521.6	1648.5	1775.3	1902.1
1.40	91.14	182.27	273.41	364.55	455.68	546.82	637.96	729.09	820.23	911.37	1002.5	1093.6	1184.8	1275.9	1367.0
1.50	69.99	139.98	209.97	279.96	349.95	419.94	489.93	559.92	629.91	699.90	769.89	839.88	909.87	979.86	1049.9

Pickup Level	STANDARD "Motor" Curve TD MULTIPLIERS														
	x 1	x 2	x 3	x 4	x 5	x 6	x 7	x 8	x 9	x 10	x 11	x 12	x 13	x 14	x 15
1.75	42.42	84.83	127.24	169.66	212.07	254.49	296.90	339.32	381.73	424.15	466.56	508.98	551.39	593.81	636.22
2.00	29.16	58.32	87.47	116.63	145.79	174.95	204.11	233.26	262.42	291.58	320.74	349.90	379.05	408.21	437.37
2.25	21.53	43.06	64.59	86.12	107.65	129.18	150.72	172.25	193.78	215.31	236.84	258.37	279.90	301.43	322.96
2.50	16.66	33.32	49.98	66.64	83.30	99.96	116.62	133.28	149.94	166.60	183.26	199.92	216.58	233.24	249.90
2.75	13.33	26.66	39.98	53.31	66.64	79.96	93.29	106.62	119.95	133.27	146.60	159.93	173.25	186.58	199.91
3.00	10.93	21.86	32.80	43.73	54.66	65.59	76.53	87.46	98.39	109.32	120.25	131.19	142.12	153.05	163.98
3.25	9.15	18.29	27.44	36.58	45.73	54.87	64.02	73.16	82.31	91.46	100.60	109.75	118.89	128.04	137.18
3.50	7.77	15.55	23.32	31.09	38.87	46.64	54.41	62.19	69.96	77.73	85.51	93.28	101.05	108.83	116.60
3.75	6.69	13.39	20.08	26.78	33.47	40.17	46.86	53.56	60.25	66.95	73.64	80.34	87.03	93.73	100.42
4.00	5.83	11.66	17.49	23.32	29.15	34.98	40.81	46.64	52.47	58.30	64.13	69.96	75.79	81.62	87.45
4.25	5.13	10.25	15.38	20.50	25.63	30.75	35.88	41.00	46.13	51.25	56.38	61.50	66.63	71.75	76.88
4.50	4.54	9.09	13.63	18.17	22.71	27.26	31.80	36.34	40.88	45.43	49.97	54.51	59.05	63.60	68.14
4.75	4.06	8.11	12.17	16.22	20.28	24.33	28.39	32.44	36.50	40.55	44.61	48.66	52.72	56.77	60.83
5.00	3.64	7.29	10.93	14.57	18.22	21.86	25.50	29.15	32.79	36.43	40.08	43.72	47.36	51.01	54.65
5.50	2.99	5.98	8.97	11.96	14.95	17.94	20.93	23.91	26.90	29.89	32.88	35.87	38.86	41.85	44.84
6.00	2.50	5.00	7.49	9.99	12.49	14.99	17.49	19.99	22.48	24.98	27.48	29.98	32.48	34.97	37.47
6.50	2.12	4.24	6.36	8.48	10.60	12.72	14.84	16.96	19.08	21.20	23.32	25.44	27.56	29.67	31.79
7.00	1.82	3.64	5.46	7.29	9.11	10.93	12.75	14.57	16.39	18.22	20.04	21.86	23.68	25.50	27.32
7.50	1.58	3.16	4.75	6.33	7.91	9.49	11.08	12.66	14.24	15.82	17.41	18.99	20.57	22.15	23.74
8.00	1.39	2.78	4.16	5.55	6.94	8.33	9.71	11.10	12.49	13.88	15.27	16.65	18.04	19.43	20.82
10.00	1.39	2.78	4.16	5.55	6.94	8.33	9.71	11.10	12.49	13.88	15.27	16.65	18.04	19.43	20.82
15.00	1.39	2.78	4.16	5.55	6.94	8.33	9.71	11.10	12.49	13.88	15.27	16.65	18.04	19.43	20.82
20.00	1.39	2.78	4.16	5.55	6.94	8.33	9.71	11.10	12.49	13.88	15.27	16.65	18.04	19.43	20.82

Pickup Level	STANDARD "Motor" Curve TD MULTIPLIERS (x16 to x25)									
	x 16	x 17	x 18	x 19	x 20	x 21	x 22	x 23	x 24	x 25
1.01	69658	74011	78365	82719	87072	91426	95779	100133	104487	108840
1.05	13659	14513	15367	16221	17074	17928	18782	19635	20489	21343
1.10	6666.92	7083.60	7500.28	7916.96	8333.64	8750.33	9167.01	9583.69	10000	10417
1.20	3181.78	3380.64	3579.50	3778.36	3977.22	4176.08	4374.94	4573.80	4772.66	4971.52
1.30	2028.86	2155.67	2282.47	2409.28	2536.08	2662.88	2789.69	2916.49	3043.30	3170.10
1.40	1458.18	1549.32	1640.46	1731.59	1822.73	1913.87	2005.00	2096.14	2187.28	2278.41
1.50	1119.84	1189.83	1259.82	1329.81	1399.80	1469.79	1539.78	1609.77	1679.76	1749.75
1.75	678.63	721.05	763.46	805.88	848.29	890.71	933.12	975.54	1017.95	1060.37
2.00	466.53	495.69	524.84	554.00	583.16	612.32	641.48	670.63	699.79	728.95
2.25	344.49	366.02	387.55	409.08	430.62	452.15	473.68	495.21	516.74	538.27

Pickup Level	STANDARD "Motor" Curve TD MULTIPLIERS (x16 to x25)									
	x 16	x 17	x 18	x 19	x 20	x 21	x 22	x 23	x 24	x 25
2.50	266.56	283.22	299.88	316.54	333.20	349.86	366.52	383.18	399.84	416.50
2.75	213.24	226.56	239.89	253.22	266.55	279.87	293.20	306.53	319.86	333.18
3.00	174.91	185.85	196.78	207.71	218.64	229.57	240.51	251.44	262.37	273.30
3.25	146.33	155.47	164.62	173.76	182.91	192.06	201.20	210.35	219.49	228.64
3.50	124.38	132.15	139.92	147.70	155.47	163.24	171.02	178.79	186.56	194.34
3.75	107.11	113.81	120.50	127.20	133.89	140.59	147.28	153.98	160.67	167.37
4.00	93.28	99.11	104.94	110.77	116.60	122.43	128.26	134.08	139.91	145.74
4.25	82.00	87.12	92.25	97.37	102.50	107.62	112.75	117.87	123.00	128.12
4.50	72.68	77.22	81.76	86.31	90.85	95.39	99.93	104.48	109.02	113.56
4.75	64.88	68.94	72.99	77.05	81.11	85.16	89.22	93.27	97.33	101.38
5.00	58.29	61.94	65.58	69.22	72.87	76.51	80.15	83.80	87.44	91.08
5.50	47.83	50.82	53.81	56.80	59.79	62.78	65.76	68.75	71.74	74.73
6.00	39.97	42.47	44.97	47.46	49.96	52.46	54.96	57.46	59.96	62.45
6.50	33.91	36.03	38.15	40.27	42.39	44.51	46.63	48.75	50.87	52.99
7.00	29.14	30.97	32.79	34.61	36.43	38.25	40.07	41.89	43.72	45.54
7.50	25.32	26.90	28.48	30.07	31.65	33.23	34.81	36.40	37.98	39.56
8.00	22.20	23.59	24.98	26.37	27.76	29.14	30.53	31.92	33.31	34.69
10.00	22.20	23.59	24.98	26.37	27.76	29.14	30.53	31.92	33.31	34.69
15.00	22.20	23.59	24.98	26.37	27.76	29.14	30.53	31.92	33.31	34.69
20.00	22.20	23.59	24.98	26.37	27.76	29.14	30.53	31.92	33.31	34.69

Note:  
The IEC motor curve is described in the IEC CURVE k FACTOR setting.

### Curve Effect


The **Curve Effect** setting for P24D and P24N is defaulted to *Cutoff* and is not available for the users to be modified.

This setting affects the trip time thermal curves when the **Overload Curve** is selected as *Motor*. This setting takes into account the design of the machine with respect to overload capability as determined by the overload (service) factor. **Curve Effect** being defaulted to *Cutoff* applies for motor designs where temperature rise above ambient is based on full load current, and for conservative approaches for other motor designs, the trip time is then calculated using the following equation:.

$$t_{trip} = \frac{TDM \times 2.2116623}{0.02530337 \times \left( \frac{I_{motor}}{FLA} - 1 \right)^2 + 0.05054758 \times \left( \frac{I_{motor}}{FLA} - 1 \right)}$$

In the above equation, both the **motor stator current**  $I_{motor} = I_{eq}$  as defined by the equation (6) at **UB Bias K Factor** (Unbalance Bias K Factor) setting description, and the **motor rated current** (FLA) configurable at **Motor FL Amps** setting at **SETPOINTS\SYSTEM\MOTOR\SETUP** path, are expressed in Amps.

The following figure illustrates the impact of the **Curve Effect** as *Cutoff* on the time to trip thermal curves.



**Figure 33: Impact of thermal model curve effect setting**

**Note:**

*P24D and P24N have available only Cutoff Curve Effect.*

### Curve k Factor

This setting defines the overload factor that is applicable when the **Overload Curve** setting is configured to *IEC*.

This setting applies only to the **IEC motor curve** and is applied as described below. Refer to the IEC 255-8 standard for additional details on its application.

The IEC 255-8 cold curve trip time is defined as follows:

$$t_{trip} = \tau \times \ln \left( \frac{I_{motor}^2}{I_{motor}^2 - (k \times FLA)^2} \right)$$

The IEC 255-8 hot curve trip time is defined as follows:

$$t_{trip} = \tau \times \ln \left( \frac{I_{motor}^2 - I_p^2}{I_{motor}^2 - (k \times FLA)^2} \right)$$

where:

- $t_{trip}$  = time to trip
- $\tau$  = IEC time constant defined by **IEC Curve TC1** and **IEC Curve TC 2** settings
- $I_{motor}$  =  $I_{eq}$  measured motor load current as defined in equation (6) at **UB Bias K Factor** setting description
- $I_p$  = Motor load current before overload occurs
- $k$  = k-factor (overload factor) defined by IEC **Curve k Factor** setting applied to FLA
- $FLA$  = Motor rated current specified by the **Motor FL Amps** setting at SETPOINTS\SYSTEM\MOTOR path.

The square of the motor load current ( $I_p^2$ ), in equation (5), represents the thermal capacity of the motor before overload occurs, as determined by equation (8) shown in the description for the **Cool TC Running** setting, TC (Time Constant). The trip time obtained from the IEC hot curve takes into account a percent of the thermal capacity that has already been used. The motor thermal model automatically determines the hot and cold states of the motor based on the motor state prior to overload and thermal capacity used (TCU) as per the following table.

### Selection of IEC Hot/Cold Curve Characteristic

Prior to Overload Condition		Upon Overload Condition	Selection of IEC Curve Characteristic
Motor Status	TC Used	Motor Status	
Stopped	Less than 5%	Starting	Cold
Stopped	Greater than or equal to 5%	Starting	Hot
Running	Less than 5%	Overload	Hot
Running	Greater than or equal to 5%	Overload	Hot

### IEC Curve TC 1(2)

The thermal model specifies two IEC thermal time constants defined by **IEC Curve TC 1** and **IEC Curve TC 2** settings. These settings specify thermal time constants for IEC motor curves in the preceding equations as per the IEC 255-8 standard.

Motor during starting ( $I_{eq} > 2 \times k \times FLA$ ) is rotor-limited, and subjected to extensive heating. The thermal model requires a separate heating constant specified by **IEC Curve TC 2** in order to properly reflect the rotor heating. However, during running overload ( $k \times FLA < I_{eq} \leq 2 \times k \times FLA$ ) the motor is stator-limited, and the thermal model uses the stator heating time constant specified by **IEC Curve TC 1**.

Thermal model automatically selects the **IEC Curve TC 1** or **IEC Curve TC 2** based on the motor load current as per the following table.

### Selection of IEC Curve Time Constant 1 or 2

IEC Time Constant	Selection Criteria
IEC Curve TC 1	$(k \times FLA) < I_{eq} \leq (2 \times k \times FLA)$
IEC Curve TC 2	$I_{eq} > (2 \times k \times FLA)$

When the IEC motor curves are selected, the device calculates the time to trip using the IEC 255-8 cold curve and IEC 255-8 hot curve equations and increases Thermal Capacity Used as defined by the Thermal Capacity Used equation. If the overload disappears or the motor is tripped (stopped), then the Thermal Capacity Used decreases as per the equation described in the **Cool TC Running** setting description, to simulate motor cooling, depending on the motor status and the values programmed for the **Cool TC Running** and **Cool TC Stopped** settings.

If the **IEC** curve is selected in the Overload Curve setting, then the following applies:

- For two-speed motor applications, the **IEC Curve TC 1(2)** settings are used at both speeds
- Voltage dependant overload curves are not applicable
- The motor status is evaluated using motor FLA and the IEC **Curve k Factor** setting


### Time Dial

This setting defines the curve time dial multiplier. This setting is applicable when the Overload Curve setting is selected as *Motor*, *User Curve 1*, *User Curve 2*, *User Curve 3*, *User Curve 4*, or *User Curve OL*.

The time dial multiplier is used to shift the overload curve on the time axis to create a family of the different curves. The **Time Dial** value is used to select the curve that best matches the thermal characteristics of the protected motor.

**Note:**

If **Overload Curve** is selected as *Motor*, then the **Time Dial** setting range can be specified between 1.00 and 25.00 as indicated in the Standard Motor Curves diagram.



**Figure 34: Standard motor curves**

*Note:*

*During the interval of discontinuity, the longer of the two trip times is used to reduce the chance of nuisance tripping during motor starts.*

### User Curve 1/2/3/4 and User Curve OL

In some applications, the shape of the motor thermal damage curve substantially deviates from the standard. Furthermore, the characteristics of the starting (locked rotor and acceleration) and running thermal damage curves may not correspond smoothly. In these cases, it may be necessary to use a custom curve so the motor can be started successfully and used to its full potential without compromising protection. For these conditions, it is recommended that the **Overload Curve** setting set as *User Curve 1*, *User Curve 2*, *User Curve 3*, *User Curve 4*, or *User Curve OL* curves be used.

EnerVista Configuration software allows easy configuration and management of User Curves 1, 2, 3, 4 and User Curve OL and their associated data points. Prospective curves can be configured from a selection of standard curves to provide the best approximate fit, then specific data points can be edited afterwards. Alternately, curve data can be imported from a specified file (.csv format) by selecting the Import Data From setting at SETPOINTS \SYSTEM\USER CURVES DATA path if configuring User Curves 1, 2, 3, 4 or at SETPOINTS\SYSTEM\USER CURVE OL path if configuring User Curve OL.

### User Curve 1/2/3/4

The relay incorporates four programmable **User Curves 1, 2, 3 and 4** that allow the programming of selected trip times for pre-determined current levels. These curves can be configured at **SETPOINTS\SYSTEM\USER CURVES**

**DATA** path in the EnerVista Configuration software. User-defined curves can be used for Thermal Model protection in the same way as standard Motor Curves and IEC curves. Each of the four User Curves has 128-point settings for entering times to reset and operate; 40 points for reset (from 0 to 0.98 times the Pickup value) and 88 for operate (from 1.03 to 20 times the Pickup), whereas Pickup equals OL x FLA. However, when these curves are used as an **Overload Curve** in Thermal Model protection, the 40 points for reset are not required.

The thermal model applies User Curve (1 to 4) to estimate TCU% until the current drops below  $0.97 \times I_{pickup}$  (97% hysteresis). Therefore, special care must be taken when setting the points close to a Pickup multiple of 1; that is,  $0.97 \times I_{pickup}$  and  $0.98 \times I_{pickup}$  should be set to a similar value as  $1.03 \times I_{pickup}$ , whereas  $I_{pickup}$  equals OL x FLA. Otherwise, the thermal model may incorrectly estimate the TCU% level resulting in undesired behaviour.

### Flexcurve OL

User Curve OL, on the other hand, provides the flexibility of choosing the number of operating points, including programmable trip time values as well as operate quantity values as multiple of FLA. The following Table shows the comparison between User Curves (1, 2, 3 and 4) and User Curve OL. **User Curve OL** can be configured at **SETPOINTS\SYSTEM\USER CURVE OL** path.

### Comparison between User Curves 1, 2, 3 and 4 and User Curve OL

Features	User Curve 1, 2, 3, 4	User Curve OL
Total Number of Operating Points:	128 (Fixed)	10 to 30 (Configurable)
Number of Reset and Trip Points:	40 Reset and 88 Trip points	Maximum 30 points for Trip only (no reset curve)
Operating Current Quantities are:	Fixed (multiple of PKP)	Configurable (multiple of FLA)
Operating Trip Times are:	Configurable (units msec)	Configurable (units seconds)
Operating Current Quantities are:	Fixed	Configurable
Can be Initialization by:	Various Curves including Standard Motor Curves	Only Standard Motor Curves

**Note:**

If thermal model curve at **Overload Curve** setting is selected as User Curve (1/2/3/4) or User Curve OL, then the **Time Dial Multiplier** can be specified between 0.00 and 600.00. The **Time Dial** setting allows the selection of a multiple of the base curve shape (where the time dial multiplier = 1) with the curve shape setting. For example, all times for a **Time Dial** = 10 are ten times the multiplier 1 or base curve values.

Example of user curves need:

As can be seen in the following figure, if the running (2) and the locked rotor thermal limit curves were smoothed into one standard overload curve, the motor could not start at 80% line voltage, thus a custom curve (1) is required.

For high inertia load applications (when the Voltage Dependant function, **VD Function** setting at **SETPOINTS\PROTECTION\GROUP [X]\THERMAL MODEL** path, is set to *Enabled*), the locked rotor thermal limit section of the programmed motor or the User Curve overload curve is modified and becomes dynamically adaptive to system voltage changes. A detailed explanation of the Voltage Dependant function is given later in this section at the **VD Function** setting description.




Figure 35: User curve example

### UB Bias K Factor

This setting defines the biasing factor of current unbalance. If a value of  $K = 0$  is entered, unbalance biasing is defeated, and the overload curve will time out against the measured per unit motor positive sequence current.

Unbalanced phase currents cause rotor heating that is not shown in the motor thermal damage curve. When the motor is running, the rotor rotates in the direction of the positive sequence current at near synchronous speed. Negative sequence current, which has a phase rotation that is opposite to the positive sequence current, and hence opposite to the direction of rotor rotation, generates a rotor voltage that produces a substantial current in the rotor. This current has a frequency that is approximately twice the line frequency: 100 Hz for a 50 Hz system or 120 Hz for a 60 Hz system. Skin effect in the rotor bars at this frequency causes a significant increase in rotor resistance and therefore, a significant increase in rotor heating. This extra heating is not accounted for in the thermal limit curves supplied by the motor manufacturer as these curves assume positive sequence currents from a perfectly balanced supply voltage and motor design.

The thermal model may be biased to reflect the additional heating that is caused by negative sequence current when the motor is running. This biasing is done by creating an equivalent motor heating current rather than simply using the average current. This equivalent current is calculated using the equation shown below.

$$I_{eq} = \sqrt{I_{avg}^2 \left( 1 + K \left( \frac{I_2}{I_1} \right)^2 \right)}$$



where:

- $I_{eq}$  = Thermal model biased motor load current
- $I_{avg}$  = Average of the three RMS currents
- $I_1$  = Positive sequence current
- $I_2$  = Negative sequence current
- $K$  = Constant

The motor derating as a function of voltage unbalance as recommended by NEMA (National Electrical Manufacturers Association) is shown below. Assuming a typical induction motor with an inrush of 6 x FLA and a negative sequence impedance of 0.167, voltage unbalances of 1, 2, 3, 4, and 5% equals current unbalances of 6, 12, 18, 24, and 30% respectively. Based on this assumption, the amount of motor derating for different values of  $K$  entered for **UB Bias K Factor** setting is shown in the following figure.

Note:

The curve created when  $K = 8$  is almost identical to the NEMA derating curve.




Figure 36: Medium motor derating factor due to unbalanced voltage

The following equations can be used to calculate  $K$ :

$$K = \frac{175}{I_{LR}^2} \text{ (typical estimate); } K = \frac{230}{I_{LR}^2} \text{ (conservative estimate)}$$

Where  $I_{LR}$  is the per unit locked rotor current.

### Cool TC Running

This setting defines the cooling time constant when the motor is running.

The thermal capacity used value (TCU) is reduced in an exponential manner when the motor current is below the **full load amps** times **overload factor** ( $OL \times FLA$ ) settings, at **SETPOINTS\SYSTEM\MOTOR\SETUP** path, to simulate motor cooling. The motor **Cool TC Running** should be entered for running case. Motor cooling is calculated as follows:

$$TCU = (TCU_{start} - TCU_{end}) (e^{-t/T_{cool}}) + TCU_{end}$$

$$TCU_{end} = \left( \frac{I_{eq}}{OL \times FLA} \right) \left( 1 - \frac{hot}{cold} \right) \times 100\%$$

where:

- $TCU$  = Thermal capacity used
- $TCU_{start}$  = TCU value caused by overload condition
- $TCU_{end}$  = TCU value dictated by the hot/cold curve ratio when the motor is running. This value is 0 when the motor is stopped
- $t$  = Time in minutes
- $t_{cool}$  = **Cool TC Running** setting
- $I_{eq}$  = Equivalent motor heating current (also defined as Thermal Model Biased Motor Load Current)
- $OL$  = Overload factor specified by the **Motor OL Factor** setting
- $FLA$  = Motor rated current specified by the **Motor FL Amps** setting
- hot/cold = Hot/Cold curve ratio

For the case when the motor is running cyclic or reciprocating load of small load cycle, it is recommended to calculate the value of **Cool TC Running** using the following equation:

$$T = \frac{87.4 \times TDM}{60} \text{ (min)}$$

Where  $TDM$  is the Time Dial Multiplier (**Time Dial** setting).

However, **Cool TC Running** can be only selected using the above equation when **Overload Curve** is set to *Motor*.

### **Cool TC Stopped**

This setting defines the cooling time constant when the motor is stopped.

The Thermal Capacity Used value is reduced in an exponential manner when the motor current is stopped after running rated load or tripped due to overload. The motor **Cool TC Stopped** setting must be entered for the stopped cases. A stopped motor normally cools significantly slower than a running motor.

For the motor stopped case, motor cooling is also calculated using the same equation above, however; the value of the cool time constant ( $t_{cool}$ ) is now **Cool TC Stopped** and  $TCU_{end}$  is now 0.




Figure 37: Thermal model cooling

### HC Safe Stall Rt

This setting defines the hot by cold safe stall ratio.

The motor manufacturer sometimes provides thermal limit information for a hot/cold motor. The algorithm uses this data if this setting is programmed. The value entered for the setting dictates the level at which Thermal Capacity Used settles for current that is below the motor overload factor (OL) times FLA. When the motor is running at a level that is below this limit, Thermal Capacity Used rises or falls to a value based on  $I_{eq}$  (Thermal Model Biased Motor Load Current).

$$TCU_{end} = \left( \frac{I_{eq}}{OL \times FLA} \right) \left( 1 - \frac{\text{hot}}{\text{cold}} \right) \times 100\%$$

where:

- $TCU_{end}$  = Thermal Capacity Used, if  $I_{eq}$  remains steady state
- $I_{eq}$  = Equivalent motor heating current (also defined as Thermal Model Biased Motor Load Current)

OL = Overload factor specified by the **Motor OL Factor** setting

- FLA = Motor rated current specified by the **Motor FL Amps** setting
- hot/cold = **HC Safe Stall Rt** setting

### VD Function

This setting enables or disables the Voltage Dependant feature and modifies the locked rotor portion of the programmed IED overload curve with respect to the acceleration thermal limits. These thermal limits are typically available from the machine specifications provided by the motor manufacturer.

If the motor is called upon to drive a high inertia load, it is quite possible and acceptable for the acceleration time to exceed the safe stall time (keeping in mind that a locked rotor condition is different than an acceleration condition). The voltage dependant overload curve feature is tailored to protect these types of motors. This curve is composed of the three characteristics of thermal limit curve shapes as determined by the stall or locked rotor condition, acceleration, and running overload. The following figure presents the typical thermal limit curve for high inertia application.

In this instance, each distinct portion of the thermal limit curve must be known, and protection coordinated against that curve. The IED protecting the motor must be able to distinguish between a locked rotor condition (curve 4) and an accelerating condition for different levels of the system voltage (curves 2 and 3). Voltage is continually monitored during motor starting and the acceleration thermal limit portion of the relay overload curve is dynamically adjusted based on motor voltage variations.

The acceleration thermal limit is a function of motor speed during the start. The dynamically shifted voltage dependant overload curve inherently accounts for the change in motor speed as a function of motor impedance. The change in impedance is reflected by the motor terminal voltage and line current. This method aids in dynamically setting the appropriate value of the thermal limit time for any given line current at any given terminal voltage.

**Note:**

Variable frequency drives (VFD) generates significant distortion in voltage input, therefore, Voltage Dependant Function is blocked when operand *VFD Not Bypassed* is asserted. *VFD Not Bypassed* is asserted when **VFD FUNCTION** (at **SETPOINTSYSTEMMOTOR\VFD** path) is set to *Enabled*, and operand *Bypass Switch* is not asserted. More detail can be found in the Variable Frequency Drives section in the System settings description for Motor section.




Figure 38: High inertia load overload curves

### VD Min Volts

This setting defines the minimum allowable line voltage applied to the motor during acceleration if the **VD Function** setting is set to *Enabled*. This voltage is expressed as a percentage of the **Motor Rated Volt** setting value set at **SETPOINTS\SYSTEM\MOTOR** path. If the measured line voltage drops below this **VD Min Volts** setting during acceleration, the thermal curve is switched to one based on the programmed minimum voltage thermal limit:

$$t_{trip} = \frac{I_1^2 \times t_1}{I^2}$$

where:

- $I=I_{eq}$  = Equivalent motor heating current (also defined as Thermal Model Biased Motor Load Current)
- $I_1$  = **VD St Cur@MinV** setting (VD Stall Current at Minimum Voltage described further on this section)
- $t_1$  = **VD St Time@MinV** setting (VD Stall Time at Minimum Voltage described further on this section)

### VD Voltage Loss

This setting is used to address situations when the voltage input into thermal model has been lost. In this case, the voltage dependant algorithm re-adjusts the voltage dependant curve to avoid an inadequate thermal protection response. The VT fuse failure function (VT SUPERVISION at **SETPOINTS\CONTROL** path) is typically used to detect a voltage loss condition. If a voltage loss has been detected while the motor accelerates, the thermal curve is switched to one based on the programmed 100% voltage thermal limit:

$$t_{trip} = \frac{I_3^2 \times t_3}{I^2}$$

where:

- $I=I_{eq}$  = Equivalent motor heating current (also defined as Thermal Model Biased Motor Load Current)
- $I_3$  = **VD St Cur@100%V** setting (VD Stall Current at Rated Motor Voltage described further on this section)
- $t_3$  = **VD St Time@100%V** setting (VD Stall Time at Rated Motor Voltage described further on this section)

### VD St Cur@MinV

This setting defines the locked rotor current level at minimum motor voltage ( $I_1$ ).

### VD St Time@MinV

This setting defines the maximum time that the motor is allowed to withstand the locked rotor current at minimum motor voltage ( $t_1$ ).

### VD Acc Int@MinV

This setting defines the starting current level corresponding to the crossing point between the acceleration thermal limit at minimum voltage and the programmed IED overload curve ( $I_2$ ). This value can be typically determined from motor acceleration curves. The value at the breakdown torque for the minimum voltage start is recommended for this setting.

### VD St Cur@100%V

This setting defines the locked rotor current level at the rated motor voltage ( $I_3$ ).

### VD St Time@100%V

This setting defines the maximum time the motor is allowed to withstand the locked rotor current at rated motor voltage ( $t_3$ ).

### VD Acc Int@100%V

This setting defines the starting current level corresponding to the crossing point between the acceleration thermal limit at rated voltage and the programmed IED overload curve ( $I_4$ ). The value can be typically determined from the motor acceleration curves. The current value at the breakdown torque for the 100% voltage start is recommended for this setting. The voltage dependant overload curves are shown in the following figure.




Figure 39: Voltage dependant overload curves

### Alarm Function

This setting enables the Thermal Model alarm functionality.

This setting enables the Thermal Model Alarm functionality if set to *Alarm*, or *Latched Alarm*. If this setting is set to *Disabled*, the Thermal Model Alarm functionality is disabled and will not operate.

### Alarm Pickup

This setting specifies a pickup threshold of the Thermal Capacity Used (TCU) for the alarm function.

### Alarm O/P Rly [X]

Selection of Relay Outputs to signal Alarm operation.

### Trip O/P Rly [X]

Selection of Relay Outputs to signal Trip operation.

### Events

Setting introduced in 8A release to allow the user to enable or disable the events related to the Thermal Model feature. By default, this setting is set to *Enabled*.

### Targets

Setting introduced in 8A release to allow the user to disable or set to *Latched* or *Self-Reset* the targets related to the Thermal Model feature. By default, this setting is set to *Latched*.

### Inhibit (Thermal Model Inhibit)

This setting defines the FlexLogic operand to inhibit (block) the thermal model, when asserted.

The thermal model can be blocked by any asserted FlexLogic operand. While the blocking signal is applied, the element remains running and updates the thermal memory, but the states of the *Thermal Trip OP* and *Thermal Alarm OP* operands will reset. When the element blocking signal is removed, the element logic is based on the new value of the thermal capacity and updates the status of the *Thermal Trip OP* and *Thermal Alarm OP* operands.

The following procedure, along with the previous figure (Voltage Dependant Overload Curves), illustrates the construction of the voltage overload curves.

1. Draw a curve for the running overload thermal limit. The curve is one that has been selected in the IED as an Overload Curve in the **Overload Curve** setting (*Motor, User Curve 1, User Curve 2, User Curve 3, User Curve 4, User Curve OL or IEC.*).
2. Determine the point of intersection between the Overload Curve and the vertical line corresponding to the per-unit current value of **VD Acc Int@MinV** setting value (see point 2 of the voltage dependant overload curves figure).
3. Determine the locked rotor thermal limit point for the minimum voltage motor start. The coordinates of this point are the per-unit current value of **VD St Cur@MinV** setting value and the time value of **VD St Time@MinV** setting value (see point 1 of the voltage dependant overload curves figure).
4. The line connecting points 1 and 2 constructs the acceleration curve for the system voltage level defined by the **VD Min Volts** setting. The acceleration time-current curve for the minimum voltage starting is calculated from the following equation:

$$t_{trip} = A_{Factor} \times e^{-I/\sigma}$$

where

$$\sigma = \frac{I_1 - I_2}{\ln(t_2 / t_1)} \text{ and } A_{Factor} = t_1 \times e^{I_1/\sigma}$$

where:

- $I$  = Is a variable multiplier of the motor rated current (values between  $I_1$  and  $I_2$ )
  - $I_1$  = is a multiplier of the rated motor current (FLA) specified by the **VD St Cur@MinV** setting
  - $t_1$  = is a time value specified by the **VD St Time@MinV** setting
  - $I_2$  = is a multiplier of the rated motor current (FLA) specified by the **VD Acc Int@MinV** setting
  - $t_2$  = is a time coordinate of the intersection point between the thermal model curve and the vertical line corresponding to the per-unit current value of the **VD Acc Int@MinV** setting
5. Determine the point of intersection between the Overload Curve and the vertical line corresponding to the multiplier of the rated current value of the **VD Acc Int@100%V** setting (see point 4 of the voltage dependant overload curves figure).
  6. Draw the locked rotor thermal limit point for the 100% voltage motor start. The coordinates of this point are the multiplier of the rated current value (FLA) of the **VD St Cur@100%V** setting and the time value of the **VD St Time@100%V** setting (see point 3 of the voltage dependant overload curves figure).
  7. The line connecting points 3 and 4 constructs the acceleration curve for the motor rated system voltage. The acceleration time-current curve for the rated voltage starting is calculated from the same equations, but the setpoints associated with the 100% voltage starting are applied.
  8. The line connecting points 1, 3 and 5 represent the motor safe stall conditions for any system voltage from the minimum to 110% of rated. Ideally, all the points on this line are characterized by the same thermal limit ( $I^2t$ ), but the equivalent starting impedance at reduced voltage is greater than the impedance at full voltage. So, the higher terminal voltages tend to reduce  $I^2t$ . The rate of  $I^2t$  reduction is dictated by the **VD Stall Current** and **VD St Time** setpoints for rated (**@100%V**) and minimum voltage (**@MinV**) conditions. For voltage conditions above rated, the locked rotor thermal limit and acceleration curve are extrapolated up to

110% of the terminal voltage. The point coordinates ( $I_s$ ,  $T_s$ ) for 110% are extrapolated based on the  $I_1$ ,  $t_1$ ,  $I_3$ , and  $t_3$  values. For starting currents at voltages higher than 110%, the trip time computed from 110% V thermal limit value is used.


- The voltage dependant curve for current values above 8 times pickup ( $OL \times FLA$ ) are clamped, and the time to trip is frozen at the level calculated for the 8 times pickup current.

**Note:**

The voltage dependant curve for current values above 8 times pickup ( $OL \times FLA$ ) are clamped and the time to trip is frozen at the level calculated for the 8 times pickup current.

The following three figures (a), (b) and (c) on the Voltage Dependant Overload Curve Protection figure, illustrate the resultant overload protection curve for minimum, 100%, and maximum line voltages. For voltages between these limits, the relay shifts the acceleration curve linearly and constantly, based on the measured line voltage during a motor start. Figures (d), (e) and (f) illustrate the motor starting curves for the following abnormal conditions: line voltages below the minimum, above 110%, and the situation for voltage los.

For the Voltage Dependant Overload Curve Protection figure: (a) At Minimum Voltage, (b) At 100% Voltage, (c) At 110% Voltage, (d) At Less Than Minimum Voltage, (e) At Voltage Loss Condition, (f) At More Than 110% Voltage.



**Figure 40: Voltage dependant overload curve protection (a to f)**

**Note:**

For the three abnormal voltage situations, the device makes a transition from the acceleration curve to Motor or User Curve when the Motor Running or Motor Overload operands are asserted.



6.3.1.2 THERMAL MODEL LOGIC




Figure 41: Voltage dependant overload curve selection logic




Figure 42: Thermal model logic

### 6.3.2 CURRENT UNBALANCE

Unbalance current, also known as negative sequence current or  $I_2$ , results in disproportionate rotor heating.

### 6.3.2.1 CURRENT UNBALANCE IMPLEMENTATION

If the thermal overload protection's unbalance bias feature has been enabled, by setting a non-zero value for the Unbalance Bias K Factor under **SETPOINT\PROTECTION\GROUP [1-6] \MOTOR\THERMAL MODEL**. The Thermal Model protection will protect the motor against unbalance by tripping when the motor's thermal capacity is exhausted.

However, the Current Unbalance protection can detect this unbalance condition and issue an alarm or trip before the motor has heated substantially.

Unbalance is defined as the ratio of negative-sequence to positive-sequence current:

$$Unbal = \frac{I_2}{I_1} \times A_{Factor} \times 100\%$$

where:

- $I_2$  = Negative sequence current
- $I_1$  = Positive sequence current
- $A_{factor}$  = Adjustment factor used to prevent nuisance trip and/or alarm at light loads

If the motor is operating at an average current level ( $I_{avg}$ ) equal to or greater than the programmed full load current (FLA), as selected at **Motor FL Amps** setpoint configurable at **SETPOINTS\SYSTEM\MOTOR\SETUP**, the adjustment factor ( $A_{factor}$ ) is one. However, if the motor is operating at an average current level ( $I_{avg}$ ) less than FLA then the adjustment factor ( $A_{factor}$ ) is the ratio of average current to full load current.

If this element is enabled, a trip and/or alarm occur(s) once the unbalance level equals or exceeds the set pickup for the set period of time. If the unbalance level exceeds 40% or when  $I_{avg} \geq 25\%$  FLA and current in any one phase is less than the cutoff current, the motor is considered to be single phasing and a trip occurs within 2 seconds. Single phasing protection is disabled if the unbalance trip feature is disabled when **I2/I1> Trip** setting is set to *Disabled*.

**Note:**

*Unusually high unbalance levels can be caused by incorrect phase CT wiring.*

The Current Unbalance feature has two functions, Trip and Alarm. Trip is managed by the **I2/I1> Trip** setting and all the subsequent settings after trip. Alarm is managed by the **I2/I1> Alarm** and all the subsequent settings after alarm. **I2/I1 Inhibit** setting works both for Trip and Alarm features. Trip feature has its own relays to signal Trip through **Trip O/P Rly [X]** settings. Alarm feature has its own relays to signal Alarm through **Alrm O/P Rly [X]** settings. Current Unbalance settings can be found at **SETPOINT\PROTECTION\GROUP [1-6] \MOTOR\CURRENT UNBALANCE** path.

Current Unbalance function provides several Flexlogic operands as per the following table:

Flexlogic Operands	
Operand	Description
I2/I1> Trip Strt	Current Unbalance trip stage picks up (starts)
I2/I1> Trip OP	Current Unbalance trip stage operates (trips)
Sgl Phasing Trip	Single Phasing operates (trips)
I2/I1> Alrm Strt	Current Unbalance alarm stage picks up (starts)
I2/I1> Alrm OP	Current Unbalance alarm stage operates (trips)

Unbalance settings are the following:

**I2/I1> Trip**

This setting enables the Current Unbalance Trip functionality.

**I2/I1> Input**

This setting can be selected either as *I2/I1* or as *Lookup Table*.

**Note:**

This setpoint is applicable only when the **VFD Function** setting is *Enabled* at **SETPOINTSYSTEMMOTORVFD** path.

In VFD driven motor applications, measurement of the sequence components (I1, I2) from currents Phasors may not be accurate depending on the VFD output current signatures. The device provides calculation of unbalance current (%) using the Lookup table method.

So, when setting **VFD Function** setting is set to *Enabled*, the device, can use unbalance current (%) determination from the Lookup Table by setting the **I2/I1> Input** setting as *Lookup Table*.

The Lookup Table is established from the graph shown below. The ratio of negative to positive-sequence current is calculated from 0 to 30%, not 50%.

Unbalance (%) is calculated as:

$$\text{when } \frac{I_{\min}}{I_{\max}} \geq 0.70 \text{ then } I2/I1 = (I2/I1\_lookup) \times A_{factor}$$

$$\text{when } \frac{I_{\min}}{I_{\max}} < 0.70 \text{ then } I2/I1 = 40\% \times A_{factor}$$

where:

$I_{\min}$  and  $I_{\max}$  are the minimum and maximum of the three phase filtered RMS currents.

$$A_{factor} = \frac{I_{avg}}{FLA} \text{ if } I_{avg} < FLA$$

$$A_{factor} = 1 \text{ if } I_{avg} \geq FLA$$

$$A_{factor} = 1 \text{ if } I_{avg} \geq FLA$$

The ratio of negative sequence to positive sequence current ( $I_2/I_1$ ) for any magnitude of phase current may be displayed on a graph as shown below (providing the supply is a true three phase supply and there is no zero-sequence current flowing, no ground fault).




Figure 43: Negative to positive sequence current ratio

#### ***I2/I1***> Strt Dly

This Start Inhibit/Block Delay setting specifies the length of time to block the current unbalance function when the motor is starting. The element is active only when the motor is running, and it is blocked upon the initiation of a motor start for a period specified by this setting. A value of 0 specifies that the feature is not blocked from start. For values other than 0, the feature is disabled when the motor is stopped and from the time a start is detected until the time entered expires.

#### ***I2/I1***> Trip Set

This setting is defaulted to 15% and its range goes from 4.0 to 50.0% if **VFD Function** is set to *Disabled* at **SETPOINT\SYSTEM\MOTOR\VFD** path, or if **VFD Function** is set to *Enabled* and ***I2/I1***> Input setting is set to *I2/I1*. If **VFD Function** is set to *Enabled* and ***I2/I1***> Input is set to *Lookup Table*, ***I2/I1***> Trip Set range goes from 4.0 to 40.0 %.

This setting specifies a pickup threshold for the Trip function. When setting the pickup level, note that a 1% voltage unbalance typically translates into a 6% current unbalance. To prevent nuisance trips or alarms, the pickup level must not be set too low. Also, since short term unbalances are common, a reasonable delay must be set to avoid nuisance trips or alarms. This setting must be greater than the corresponding setting for the alarm stage.

**Note:**

This setting is defaulted to 15% and its range goes from 4.0 to 50.0% if **VFD Function** is set to *Disabled* at **SETPOINT \SYSTEMMOTOR\VFD** path, or if **VFD Function** is set to *Enabled* and **I2/I1> Input** setting is set to *I2/I1*. If **VFD Function** is set to *Enabled* and **I2/I1> Input** is set to *Lookup Table*, **I2/I1> Trip Set** range goes from 4.0 to 40.0 %.

**I2/I1> Trip Crv**

This setting can be selected either as *DT* (*Definite Time*) or as *IDMT* (*Inverse Time*).

*DT* (*Definite Time*)

When the curve is programmed as definite time (*DT*), the trip element operates when the operating quantity exceeds the pickup level (**I2/I1> Trip Set** setting) for longer than the set time delay (**I2/I1> Trip Dly** setting).

*IDMT* (*Inverse Time*)

When the curve is programmed as inverse time (*IDMT*), the trip element operates following the *IDMT* curve for the unbalance current as defined below:

$$T = \frac{TDM}{[Unbal]^2}$$

Where:

- Unbal = is defined by the equation, described at the beginning of this section
- T = Time in seconds when  $I_2 >$  pickup (minimum and maximum times are defined by **I2/I1> Trp MnDly** and **I2/I1> Trp MxDly** settings).
- TDM = Time dial multiplier (**I2/I1> Trip TMS** setting)

**I2/I1> Trip TMS**

This setting provides a selection for Time Dial Multiplier (TMS) which modifies the operating times per the inverse curve (*IDMT*).

**Note:**

This setting is only applicable when **I2/I1> Trip Crv** setting is programmed as *IDMT* (*Inverse Time*).

**I2/I1> Trp MxDly**

The Unbalance maximum time (**I2/I1> Trp MxDly**) setting defines the maximum time that any value of negative sequence current in excess of the pickup value (**I2/I1> Trip Set**) will be allowed to persist before a trip is issued. This setting can be applied to limit the maximum tripping time for low level unbalances.

This setting is only applicable when **I2/I1> Trip Crv** setting is programmed as *IDMT* (*Inverse Time*).

**I2/I1> Trp MnDly**

The Unbalance minimum time (**I2/I1> Trp MnDly**) setting defines the minimum time setting that can be applied to limit the minimum tripping time. Small power system transients or switching device operation can generate spurious negative sequence current that can result in the false operation of the Current Unbalance element. Unbalance minimum time must be set in order to prevent false operation of the element.


**Note:**

This setting is only applicable when **I2/I1> Trip Crv** setting is programmed as *IDMT* (*Inverse Time*).

**I2/I1> Tr tRESET**

When **I2/I1> Trip Crv** setting is programmed as *IDMT* (*Inverse Time*):

This setting defines the linear reset time of the trip element time accumulator. It is the maximum reset time from the threshold of tripping, based on the motor unbalance inverse curve. The reset time has an accumulator/integrator to represent the thermal memory counter which increments linearly if the motor unbalance current is above the threshold, and decrements linearly if it is below the threshold.



**Figure 44: Unbalance inverse time curves**

When **I2/I1> Trip Crv** setting is programmed as *DT* (Definite Time):

This setting specifies a time delay to reset the trip element operation. This delay must be set long enough to allow the breaker or contactor to disconnect the motor.

#### **Trip O/P Rly [X]**

Selection of Relay Outputs to signal Trip operation.

#### **I2/I1> Alarm**

This setting enables the Current Unbalance Alarm functionality if set to *Alarm*, or *Latched Alarm*. If this setting is set to *Disabled*, the Current Unbalance Alarm functionality is disabled and will not operate.

#### **I2/I1> Alarm Set**

**Note:**

This setting is defaulted to 10% and its range goes from 4.0 to 50.0% if **VFD Function** is set to *Disabled* at **SETPOINT \SYSTEMMOTOR\VFD** path, or if **VFD Function** is set to *Enabled* and **I2/I1> Input** setting is set to *I2/I1*.

If **VFD Function** is set to *Enabled* and **I2/I1> Input** is set to *Lookup Table*, **I2/I1> Alarm Set** range from 4.0 to 40.0%.

This setting specifies a pickup threshold for the Alarm function.

For example, if the supply voltage is normally unbalanced up to 2%, the current unbalance seen by a typical motor is  $2 \times 6 = 12\%$ . In this case, set the current unbalance alarm pickup (**I2/I1> Alarm Set**) setting to 15% and the current unbalance trip pickup (**I2/I1> Trip Set**) setting to 20% to prevent nuisance tripping; 5 or 10 seconds is a reasonable delay.

### **I2/I1> Alarm Dly**

The setting specifies a time delay for the Alarm function.

### **I2/I1> AI tRESET**

This setting specifies a time delay to reset the alarm element operation.

### **Alrm O/P Rly [X]**

Selection of Relay Outputs to signal Alarm operation.

### **I2/I1> Inhibit**

This setting defines the FlexLogic operand to inhibit (block), when asserted, the Current Unbalance feature.

### **Events**

Setting introduced in 8A release to allow the user to enable or disable the events related to Current Unbalance feature. By default, this setting is set to *Enabled*.

### **Targets**

Setting introduced in 8A release to allow the user to disable or set to Latched or Self-Reset the targets related to Current Unbalance feature. By default, this setting is set to Latched.



### 6.3.2.2 CURRENT UNBALANCE LOGIC




Figure 45: Current unbalance logic

### 6.3.3 MECHANICAL JAM

A motor load can become constrained (mechanical jam) during starting or running. The starting current magnitude alone cannot provide a definitive indication of a mechanical jam; however, the running current magnitude can. Therefore, the Mechanical Jam element is specially designed to operate for running load jams. Starting load jams are detected by monitoring acceleration time and speed.

#### 6.3.3.1 MECHANICAL JAM IMPLEMENTATION

After a motor has started and reached the running state, a trip or alarm occurs if the magnitude of any phase current exceeds the **I>[X] MJam Set** setting for a period of time specified by the **I>[X] MJam Delay** setting.

The thermal element also operates during mechanical jams but after a delay when the thermal capacity reaches 100%. Not only does the Mechanical Jam protect the motor by tripping it quicker than the thermal protection, it can also prevent or limit damage to the driven equipment in the event of a locked rotor during running.

The Mechanical Jam is armed as long as the motor status is not Motor Starting or Motor Stopped; So it will be armed when the motor status is either Motor Running or Motor Overload. As soon as any phase current exceeds the user-selectable threshold (**I>[X] MJam Set**), the element picks up (starts) and operates (trips) after the programmed time delay (**I>[X] MJam Delay**). The element uses currents (phasor, RMS) and motor status asserted by the Thermal Model element. Thermal Model protection and 2-Speed Motor protection must be configured properly in order for the Mechanical Jam protection to operate.

When the 2-Speed Motor Protection functionality is employed, the device will block (inhibit) Mechanical Jam Protection during the acceleration time from Speed 1 to Speed 2 until the motor current has dropped below overload pickup level (OL x FLA) (configurable at **Motor OL Factor** and **Motor FL Amps** settings at **SETPOINTS\SYSTEM\MOTOR\SETUP** path) or the **Acc Time Spd 1-2** (configurable at **SETPOINT\PROTECTION\GROUP [1-6]\2-SPEED MOTOR\SPEED2 ACCELERATION** path) has expired. At a point in time when the motor has reached the Speed 2 running stage, the Mechanical Jam will be re-enabled using the **Spd2 Motor FLA** setpoint set under **SETPOINTS\SYSTEM\MOTOR\SETUP**. The Pickup level (**I>[X] MJam Set**) should be set higher than the motor loading during normal operation, but lower than the motor stall level for both speeds. Normally the delay is set to the minimum time delay or set so that no nuisance trips occur due to momentary load fluctuations.

Mechanical Jam feature has two stages, each of them with its corresponding settings are described below. Mechanical Jam settings can be found at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\MECHANICAL JAM** path.

Mechanical Jam function provides several Flexlogic operands as per the following table:

Flexlogic Operands	
Operand	Description
I>[X] MJam Start	The Mechanical Jam element has picked up (start)
I>[X] MJam Trip	The Mechanical Jam element has operated (trip)

Mechanical Jam settings are as follows:

#### **I>[X] MJam Funct**

This setting enables the Mechanical Jam functionality.

#### **I>[X] MJam Set**

This setting defines the excessive current condition that identifies a mechanical jam. As the element is not armed during start conditions, this threshold can be set below the starting current. Since the element is armed during overload conditions, this setting must be higher than the maximum overload current. The setting is entered in multiplies of FLA (**Motor FL Amps** (FLA) setting is programmed under at **SETPOINTS\SYSTEM\MOTOR\SETUP** menu).

**I>[X] MJam Delay**

This setting specifies the pickup delay of the element. In the case of large motors that could feed close-in feeder faults, this setting can co-ordinate with feeder protection to avoid false tripping due to excessive fault currents fed by the motor.

**I>[X] MJam tRESET**

This setting defines the reset delay of the element. Typical application includes time seal-in of the tripping signal.

**I>[X] MJam Inhibit**

The mechanical jam can be blocked (inhibited) by any asserted FlexLogic operand.

**Relay O/P [X]**

Any assignable output relay can be selected to operate upon Mechanical Jam operation.

**Events**

Setting introduced in 8A release to allow the user to enable or disable the events related to the Mechanical Jam feature. By default, this setting is set to *Enabled*.

**Targets**

Setting introduced in 8A release to allow the user to disable or set to Latched or Self-Reset the targets related to the Mechanical Jam feature. By default, this setting is set to *Latched*.

6.3.3.2 CURRENT UNBALANCE LOGIC




Figure 46: Mechanical jam logic

## 6.3.4 UNDERCURRENT

### 6.3.4.1 UNDERCURRENT IMPLEMENTATION

The device provides one Undercurrent element per protection group. The element responds to a per-phase current. When the motor is in the running state, an alarm occurs if the magnitude of any phase current falls below the undercurrent alarm pickup level (**I<1 Alarm Set** setting) for the time specified by the undercurrent alarm delay (**I<1 Alarm Delay** setting). Furthermore, a trip occurs if the magnitude of any phase current falls below the undercurrent trip pickup level (**I<1 Trip Set** setting) for the time specified by the undercurrent trip delay (**I<1 Trip Delay** setting). The alarm and trip pickup levels must be set lower than the lowest motor loading during normal operations.

The Undercurrent element is active only when the motor is running and is blocked (inhibited) upon the initiation of a motor start for a period of time defined by the **I<1 Strt Blk Dly** setting. This block may be used to allow pumps to build up head before the undercurrent element trips or alarms.

A second independent Undercurrent protection element is provided for Speed 2. If 2 speed functionality is enabled (at **SETPOINTS\SYSTEMMOTOR\SETUP** path), the device relies on the motor speed indication; so, the main Undercurrent protection element (configurable at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR UNDERCURRENT** path) is only active when the motor is running at speed 1 (low speed), and the Speed2 Undercurrent protection element (configurable at **SETPOINT\PROTECTION\GROUP [1-6]\2-SPEED MOTOR SPEED2 UNDERCURRENT** path) is only active when the motor is running at high speed (speed 2).

**Note:**

For motor applications the operating per-phase current parameter can be phasor or RMS. Phasor is always used but in VFD application where the **VFD Function** setting is set to *Enabled* at **SETPOINTS\SYSTEMMOTOR\VFD** path and **VDF Flex operand VFD Not Bypassed** is asserted, in that case the per-phase currents are switched from Phasor to RMS.

The Undercurrent element has Trip and Alarm functionality. Trip is managed by the **I<1 Trip** setting and all the subsequent settings after trip. Alarm is managed by the **I<1 Alarm** setting and all the subsequent settings after alarm. **I<1 Inhibit** setting works both for Trip and Alarm features. Trip feature has its own relays to signal Trip through Trip **O/P Rly [X]** settings. Alarm feature has its own relays to signalize Alarm through **Alrm O/P Rly [X]** settings.

Undercurrent settings can be found at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR UNDERCURRENT** path.

The Undercurrent function provides several Flexlogic operands as per the following table:

Flexlogic Operands	
Operand	Description
I<1 Trip Start	The Undercurrent Trip has picked up (start)
I<1 Trip OP	The Undercurrent Trip has operated (trip)
I<1 Alarm Start	The Undercurrent Alarm has picked up (start)
I<1 Alarm OP	The Undercurrent Alarm has operated (trip)

The Undercurrent settings are as follows:

#### **I<1 Trip**

This setting enables the Undercurrent Trip functionality.

#### **I<1 Strt Blk Dly**

The Undercurrent element is active only when the motor is running, and it is blocked (inhibited) upon the initiation of a motor start for a period of time defined by the **I<1 Strt Blk Dly** setting (e.g., this block can be used to allow pumps to build up head before the undercurrent element trips or alarms).

***I<1 Trip Set***

This setting specifies a pickup threshold for the Trip function.

***I<1 Trip Delay***

This setting specifies a time delay for the Trip function.

***I<1 Trip tRESET***

This setting specifies a time delay to reset the trip signal. This delay should be set long enough to allow the breaker or contactor to disconnect the motor.

***Trip O/P Rly [X]***

This setting allows the selection of any assignable output relay to operate upon Undercurrent Trip function operation.

***I<1 Alarm***

This setting enables the Undercurrent Alarm functionality.

***I<1 Alarm Set***

This setting specifies a pickup threshold for the Alarm function.

***I<1 Alarm Delay***

This setting specifies a time delay for the Alarm function.

***I<1 Alarm tRESET***

This setting specifies a time delay to reset the alarm signal.

***Alrm O/P Rly [X]***

This setting allows the selection of any assignable output relay to operate upon Undercurrent Alarm function operation.

***I<1 Inhibit***

This setting defines the FlexLogic operand to inhibit (block) the Undercurrent feature, when asserted,

***Events***

Setting introduced in 8A release to allow the user to enable or disable the events related to the Undercurrent feature. By default, this setting is set to *Enabled*.

***Targets***

Setting introduced in 8A release to allow the user to disable or set to Latched or Self-Reset the targets related to the Undercurrent feature. By default, this setting is set to *Latched*.

### 6.3.4.2 UNDERCURRENT LOGIC




Figure 47: Undercurrent logic

## 6.3.5 OVERLOAD ALARM

### 6.3.5.1 OVERLOAD ALARM IMPLEMENTATION

The device provides one Overload Alarm element per protection group. The Overload Alarm is used to alarm abnormal load increases that can indicate problems with the process. An alarm is enabled only after the acceleration stage is complete and the motor has entered the running or overload stage. Once enabled, the alarm is generated when the biased motor load current ( $I_{eq}$ ) exceeds the **lavg>1 Set** setting for the time delay specified by the **lavg>1 Time Dly** setting. When the current has subsided, the alarm stays active for the time specified by the **lavg>1 Rst Time** setting.

The biased motor average load current ( $I_{eq}$ ) is the equivalent heating current calculated from the average of three RMS currents with ( $I2/I1$ ) bias, as follows:

$$I_{eq} = \sqrt{I_{avg}^2 \cdot \left(1 + k \cdot \left(\frac{I2}{I1}\right)^2\right)}$$

where:

- $I_{eq}$  Biased motor average load current. This value is displayed as *THR MOD BIAS LD* under **MEASUREMENT\MOTOR LOAD** path.
- $I_{avg}$  Average of three phase RMS currents
- $I2$  Negative-sequence current
- $I1$  Positive-sequence current
- $k$  Biasing factor configured under Path: **Setpoints\Protection\Motor\Therma Model**

Overload Alarm settings can be found at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\OVERLOAD ALARM** path.

The Overload Alarm function provides several Flexlogic operands as per the following table:

Flexlogic Operands	
Operand	Description
$I_{avg}>1$ Alm Start	The Overload alarm element has picked up (start)
$I_{avg}>1$ Alm OP	The Overload alarm element has operated (trip)

The Overload settings are as follows:

### ***I<sub>avg</sub>>1 Function***

This setting enables the Overload Alarm functionality when set to *Alarm*, *Latched Alarm* or *Configurable*. A detailed explanation of the **Function** setting behaviour can be found at the COMMON SETTINGS subsection of the SETTINGS APPLICATION SOFTWARE section under the CONFIGURATION chapter.

### ***I<sub>avg</sub>>1 Set***

This setting specifies a pickup threshold for the Overload Alarm function.

### ***I<sub>avg</sub>>1 Time Dly***

This setting specifies a time delay for the Overload Alarm function.

### ***I<sub>avg</sub>>1 Rst Time***

This setting specifies a time delay to reset the Overload Alarm signal.

### ***I<sub>avg</sub>>1 Inhibit***

This setting defines the FlexLogic operand to inhibit (block), the Overload Alarm feature, when asserted.

### ***Relay O/P [X]***

This setting allows the selection of any assignable output relay to operate upon Overload Alarm function operation.

### ***Events***

Setting introduced in 8A release to allow the user to enable or disable the events related to the Overload Alarm feature. By default, this setting is set to *Enabled*.



**Targets**

Setting introduced in 8A release to allow the user to disable or set to Latched or Self-Reset the targets related to the Overload Alarm feature. By default, this setting is set to *Latched*.

**6.3.5.2 OVERLOAD ALARM LOGIC**




Figure 48: Overload alarm logic

**6.3.6 SHORT CIRCUIT**

**6.3.6.1 SHORT CIRCUIT IMPLEMENTATION**

The device provides two Short Circuit elements (**Short Circuit [X]**) per protection group. If Short Circuit is enabled, a trip or alarm occurs once the magnitude of any phase current exceeds the **I>[X] SC Curr Set** setting for the time specified by the **I>[X] SC Delay** setting.

**Note:**

Care must be taken when turning on this feature. If the interrupting device (contactor or circuit breaker) is not rated to break the fault current, the function of this feature must not be configured as *Trip*. Alternatively, this feature may be programmed as *Alarm* or *Latched Alarm* and assigned to an auxiliary relay connected to an upstream device which is capable of breaking the fault current.

Short Circuit settings can be found at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\SHORT CIRCUIT** path.

The Short Circuit function provides several Flexlogic operands as per the following table:

Flexlogic Operands	
Operand	Description
I>[X] SC Start	The short circuit [X] element has picked up (start)
I>[X] SC Trip	The short circuit [X] element has operated (trip)

The Short Circuit settings are as follows:

### **I>[X] SC Function**

This setting enables the Short Circuit functionality. Any assignable output relays can be selected to operate when the function is enabled.

If the operating condition is satisfied when *Trip* is selected as **I>[X] SC Function**, the logic operands **I>[X] SC Start** and **I>[X] SC Trip** are asserted, which in turn operates the LED trip and trip output relay.

If *Alarm* is selected, the LED alarm flashes on Short Circuit operation, and it automatically resets when the activating condition clears.

If *Latched Alarm* is selected, the LED alarm flashes on Short Circuit operation, and stays on after the condition clears, until a reset command is initiated. The TRIP output relay (Relay 1-Trip) does not operate if *Latched Alarm* or *Alarm function* is selected.

If the **Function** setting is selected as *Configurable*, the feature is fully operational, but outputs are not driving any specific action, such as Relay 1-Trip and Trip LED activation, Alarm LED activation or anything else. The User should program operands from this element to a desirable action which may be to drive an auxiliary output from the list of available relay outputs in the element itself, Flexlogic, etc.

### **I>[X] SC OvrFtr**

When a motor starts, the starting current (typically  $6 \times \text{FLA}$  for an induction motor) has an asymmetrical component. This asymmetrical current may cause one phase to see as much as 1.6 times the normal RMS starting current. If the pickup value (**I>[X] SC Curr Set**) is set at 1.25 times the symmetrical starting current, it is probable that there will be nuisance trips during motor starting. A rule of thumb has been developed over time, that short circuit protection is at least 1.6 times the symmetrical starting current value. This allows the motor to start without nuisance tripping.

The overreach filter removes the DC component from the asymmetrical current present at the moment of fault or during motor starting. This filter eliminates overreach due to DC component and secure the element from nuisance tripping.

In VFD application, when setpoint **VFD Function** is *Enabled* (at **SETPOINTS\SYSTEMMOTOR\VFD** path) and operand VFD Not Bypassed is asserted, phase currents are switched from RMS (IA/B/C RMS) to Peak (IA/B/C Peak) and Overreach Filter is bypassed. Peak currents are available at **MEASUREMENTS\CT1 BANK-B\CT1 IA/B/C PEAK**.

### **I>[X] SC Curr Set**

This setting specifies a pickup threshold for the Short Circuit element.

If 2-Speed Motor Protection functionality is employed, then the CT primary used is the value set on the **Spd2 CT Prmry** setting that can be found under **SETPOINTS\SYSTEMMOTOR\SETUP** path.

**Note:**

*Special care must be taken when setting the pickup (**I>[X] SC Curr Set**) for motor applications with low and high-speed windings. Pickup must be set with enough margin that short circuit elements do not malfunction when switching from one speed to another.*

### **I>[X] SC Delay**

This setting specifies the pickup time delay for the Short Circuit element, to secure the element from nuisance tripping in various situations (e.g. charging a long line to the motor, or power factor correction capacitors, or DC component from the asymmetrical current present at the moment of fault) that may cause an increase in the current above pickup level (**I>[X] SC Curr Set**) for a very short period of time.

The **I>[X] SC Delay** setting is adjustable in increments of 10 milliseconds (ms). This delay can be fine-tuned to an application, so it still responds quickly but rides through normal operational disturbances. Normally, the **I>[X] SC Delay** is set as quickly as possible, 0 ms. This time may be increased if nuisance tripping occurs.

**Note:**

When overreach filter is used (**I>[X] SC OvrFltr** setting set to *On*) it is recommended to program the **I>[X] SC Delay** setting to 1 cycle minimum to override the response time of the overreach filter.

### **I>[X] SC tRESET**

This setting defines the reset delay of the element.

### **I>[X] SC Inhibit**

This setting defines the FlexLogic operand to inhibit (block) the Short Circuit element.

### **Relay O/P [X]**

This setting allows the selection of any assignable output relay to operate upon Short Circuit element operation.

### **Events**

Setting introduced in 8A release to allow the user to enable or disable the events related to the Short Circuit element. By default, this setting is set to *Enabled*.

### **Targets**

Setting introduced in 8A release to allow the user to disable or set to *Latched* or *Self-Reset* the targets related to Short Circuit element. By default, this setting is set to *Latched*.

The Short Circuit function provides *SC IA CURRENT*, *SC IB CURRENT* and *SC IC CURRENT* measurements. These measurements will be available at **MEASUREMENTS\MOTOR\SHORT CIRCUIT** path, when any of the two Short Circuit elements available at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\SHORT CIRCUIT\SHORT CIRCUIT[X]** path are enabled (this is set to either *Trip*, *Latched Trip*, *Alarm*, *Latched Alarm* or *Configurable*).

### 6.3.6.2 SHORT CIRCUIT LOGIC




Figure 49: Short circuit logic

## 6.3.7 GROUND FAULT

### 6.3.7.1 GROUND FAULT IMPLEMENTATION

Special care must be taken when the ground input is wired to the phase CTs in a residual connection. When a motor starts, the starting current (typically  $6 \times \text{FLA}$  for an induction motor) has an asymmetrical or DC component. This momentary DC component causes each of the phase CTs to react differently, and cause a net current into the ground input of the relay. A 20 ms block of the ground fault element when the motor starts normally enables the relay to ride through this momentary ground current signal.

The device provides two Ground Fault elements (**Ground Fault [X]**) per protection group, with Trip and Alarm functionality per element.

When motor stator windings become wet or suffer insulation deterioration, low magnitude leakage currents often precede complete failure and resultant destructive fault currents. This ground fault protection provides early detection of such leakage current, so that the motor can be taken off line (tripped) in time to limit motor damage.

However, if a high magnitude ground fault occurs, which is too high for the contactor to interrupt, it is best to set the Ground Fault function as *Configurable* to signal an upstream device or wait for the fuses to do the interruption.

Various situations (e.g. contactor bounce) can cause transient ground currents during motor starting, which can exceed the pickup level (**IN1>[X] GF Tr Set**) for a very short period of time. The **IN1>[X] GF Tr Dly** setting can be fine-tuned to an application such that it still responds very quickly, but rides through normal operational disturbances. Normally, the Ground Fault time delays are set as short as possible (0 seconds). However, time to trip might have to be increased if nuisance tripping occurs.

**Note:**

*Special care must be taken when the ground input is wired to the phase CTs in a residual connection. When a motor starts, the starting current (typically 6 × FLA for an induction motor) has an asymmetrical or DC component. This momentary DC component causes each of the phase CTs to react differently and cause a net current into the ground input of the relay. A 20 millisecond block of the Ground Fault element when the motor starts, normally enables the relay to ride through this momentary ground current signal.*

**Note:**

*The operating magnitude is the measured ground/earth current. Depending on the Cortec selected for the device, the ground/earth current measured will come from a Standard CT (EF) for Cortec 6-1 or a Sensitive CT (SEF) for Cortec 6-2.*

Ground Fault elements have Trip and Alarm functionality (this is two stages, Trip and Alarm, per element). Trip is managed by the **IN1>[X] GF Trip** setting and all the subsequent settings after trip. Alarm is managed by the **IN1>[X] GF Alarm** setting and all the subsequent settings after alarm. **IN1>[X] GF Inhibit** setting works for both Trip and Alarm features. Trip feature has its own relays to signal Trip through **Trip O/P Rly [X]** settings. The Alarm feature has its own relays to signal Alarm through **Alrm O/P Rly [X]** settings.

Ground Fault settings can be found at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\GROUND FAULT** path.

Ground Fault function provides several Flexlogic operands as per the following table:

Flexlogic Operands	
Operand	Description
IN1>[X] GF Trip St	Ground Fault [X] trip stage picks up (start)
IN1>[X] GF Trip OP	Ground Fault [X] trip stage operates (trip)
IN1>[X] GF Alrm St	Ground Fault [X] alarm stage picks up (start)
IN1>[X] GF Alrm OP	Ground Fault [X] alarm stage operates (trip)

### **IN1>[X] GF Trip**

This setting enables the Ground Fault Trip functionality.

### **IN1>[X] GF Tr Set**

This setting specifies a pickup threshold for the Trip function.

### **IN1>[X] GF Tr Dly**

This setting specifies the amount of time that the motor ground current must exceed the pickup (**IN1>[X] GF Tr Set**) to generate a trip when the motor is in a running or overload condition.

***IN1>[X] GF Tr tRST***

This setting specifies a time delay to reset the trip signal. This delay must be set long enough to allow the breaker or contactor to disconnect the motor.

***Trip O/P Rly [X]***

This setting allows the selection of any assignable output relay to operate upon Ground Fault Trip function operation.

***IN1>[X] GF Alarm***

This setting enables the Ground Fault Alarm functionality.

***IN1>[X] GF AI Set***

This setting specifies a pickup threshold for the Alarm function.

***IN1>[X] GF AI Dly***

This setting specifies the amount of time the motor ground current must exceed the pickup (***IN1>[X] GF Tr Set***) to generate an alarm.

***IN1>[X] GF AI tRST***

This setting specifies a time delay to reset the alarm signal.

***Alrm O/P Rly [X]***

This setting allows the selection of any assignable output relay to operate upon Ground Fault Alarm function operation.

***IN1>[X] GF Inhibit***

This setting defines the FlexLogic operand to inhibit (block), the Ground Fault element, when asserted.

***Events***

Setting introduced in 8A release to allow the user to enable or disable the events related to the Ground Fault element. By default, this setting is set to *Enabled*.

***Targets***

Setting introduced in 8A release to allow the user to disable or set to Latched or Self-Reset the targets related to the Ground Fault element. By default, this setting is set to *Latched*.

### 6.3.7.2 GROUND FAULT LOGIC




Figure 50: Ground fault logic

## 6.3.8 ACCELERATION TIME

### 6.3.8.1 ACCELERATION TIME IMPLEMENTATION

The device provides one Acceleration Time element per protection group. The Thermal Model protects the motor under both starting and overload conditions. The Acceleration Time trip may be used to complement this protection. For example, if the motor always starts in 2 seconds, but the safe stall time is 8 seconds, there is no point letting the motor remain in a stall condition for 7 or 8 seconds because that is when the Thermal Model would take it off line. Furthermore, the starting torque applied to the driven equipment for that period of time could cause severe damage.

It is advantageous to detect stalling during a start as early as possible, to minimize re-starting delays once the cause of the stall is remedied, e.g. neglecting to release a fan brake.

The Acceleration Time element compares actual starting time with a pre-determined time setting (defined under **SETPOINTS\SYSTEM\MOTOR\SETUP** as **Max Accel Time**) and operates when it is exceeded. This element has the functionality to adapt the tripping time for starts with lower starting current, and it stores the acceleration time and current of the last five starts.

**Note:**

In both *Definite Time* and *Adaptive Mode*, if the motor remains in Starting state for more than two times the set **Max Accel Time**, the element de-asserts the asserted operating flag, and resets the timer to zero so that thermal protection operates according to the set thermal limits.


The element uses currents and motor status asserted by the Thermal Model element. Thermal Model protection and 2-Speed Motor protection must be configured properly for the Acceleration Time protection to operate.

The following figure shows examples of constant and variable acceleration currents and explains measurement of the acceleration time and current. Part "a" represents a constant current start and part "b" represents a variable current start.

The element stores the basic statistics for the last five successful starts. The following values are retained, are available for display, and accessible on the HMI or via communications at **RECORDSMTR START STATSMOTOR START [X]** path:

- Start Date/Time: Date and time of starting
- Start Accel Time: Acceleration time (seconds)
- Start Effect Curr: Effective acceleration current (multiplies of FLA)
- Start Peak Curr: Peak acceleration current (multiplies of FLA)

Recorded effective acceleration current and time could be used for fine-tuning of the device settings.



**Figure 51: Sample acceleration currents: (a) Constant current start and (b) Variable current start**

Acceleration Time settings can be found at **SETPOINTPROTECTION\GROUP [1-6]\MOTOR\ACCEL TIME** path.

Acceleration Time function provides one Flexlogic operand as per the following table:

Flexlogic Operands	
Operand	Description
Accel Time Trip	The Acceleration Time element has operated (trip).

The Acceleration Time settings are as follows:

**Function**

This setting enables the Acceleration Time functionality.



### Current

This setting is only used in the Adaptive mode. This setting defines a constant current that when applied to the motor would accelerate the motor within the normal acceleration time, and it is used to adapt the tripping action when the current is changing significantly during the start, such as due to voltage dips.

### Mode

This setting defines the operating mode of the Acceleration Time element.

When set to *Definite Time*, the element times the duration of the motor start and operates when the starting time exceeds the **Max Accel Time** (defined under **SETPOINTS\SYSTEM\MOTOR\SETUP**).

When set to *Adaptive*, the element uses the effective accelerating current to adapt to the starting conditions. The operating equation assumes that the accelerating power is proportional to the square of the current and neglects any current unbalance or impact of the rotor slip. Consequently, in the *Adaptive* mode, the element operates when the square of the current integrated from the beginning of the start up to a given time exceeds the product of acceleration current<sup>2</sup> x **Max Accel Time**.

### Relay O/P [X]

This setting allows the selection of any assignable output relay to operate upon Acceleration Time function operation.

### Inhibit

This setting defines the FlexLogic operand to inhibit (block), the Acceleration Time feature, when asserted.

### Events

Setting introduced in 8A release to allow the user to enable or disable the events related to Acceleration Time feature. By default, this setting is set to *Enabled*.

### Targets

Setting introduced in 8A release to allow the user to disable or set to Latched or Self-Reset the targets related to Acceleration Time feature. By default, this setting is set to *Latched*.

### 6.3.8.2 ACCELERATION TIME LOGIC




Figure 52: Acceleration time logic

### 6.3.9 2-SPEED MOTOR PROTECTION

The two-speed motor feature provides proper protection for a two-speed motor where there will be two different full load values. If the two-speed motor feature is used, setpoint **2-Speed Motor Protection** must be set to *Enabled* under **Setpoints > System > Motor > Setup**). And an assignable input under setpoint **Speed2 Motor Switch** under **Setpoints > System > Motor > Setup** must monitor for a contact closure. Contact closure signifies that the motor is in Speed 2; if the input is open, it signifies that the motor is in Speed 1. This allows the device to determine which settings should be active at any given point in time.

### 6.3.9.1 2-SPEED THERMAL MODEL

#### 6.3.9.1.1 2-SPEED THERMAL MODEL IMPLEMENTATION

When two-speed motor functionality is used, these settings allow selection of the proper parameters for the thermal model when motor is switched to the second speed. There is one thermal model in the device, and it has inputs for overload conditions from calculations at both speeds. The accumulated thermal capacity is calculated from overload contributions at each speed.

The algorithm integrates the heating at each speed into one thermal model using a common thermal capacity used register value for both speeds.

Refer to the Thermal model sub-section for details on settings for thermal model at the second motor speed.

#### 6.3.9.1.2 2-SPEED THERMAL MODEL LOGIC




Figure 53: 2 Speed thermal mode logic

### 6.3.10 2-SPEED ACCELERATION TIME

#### 6.3.10.1 2-SPEED ACCELERATION TIME IMPLEMENTATION

Speed 2 Acceleration Time functionality is enabled when the motor is switched from speed 1 to speed 2 and 2-Speed Motor Protection (set under **Setpoints/System/Motor/Setup**) is *enabled*.

**Note:**

Speed2 Acceleration **Current** and **Mode** settings and functionality at speed 2 are identical to those of speed 1 and are described in the Acceleration Time element.

Two additional settings define the transition between speeds. A two-speed motor is usually started at a low speed (speed 1) and then switched to a higher speed (speed 2) when required. When the motor starts directly at high speed, then the Speed 2 **Max. Accel. Time** setting (defined under **Setup > Motor**) specifies the maximum acceleration time at speed 2. When the motor is switched from a low-to-high speed setting, the speed 2 **Accel Time Fr. Spd 1-2** setting specifies the acceleration time. When the motor is switched from high speed to low speed, the Speed 2 Trans 2-1 Op FlexLogic operand is set for a time defined by the Speed 2 **Switch 2-1 Delay** setting (defined under **Setpoints/System/Motor/Setup**) to allow inputs for control logic of contactors and breakers at both speeds.

The acceleration time at speed 2 becomes functional only if the acceleration time at speed 1 is enabled. When the acceleration time at any speed is not required, it can be permanently blocked.

### 6.3.10.2 2-SPEED ACCELERATION TIME LOGIC




Figure 54: 2-Speed acceleration time logic

---

## 6.3.11 2-SPEED UNDERCURRENT

### 6.3.11.1 2-SPEED UNDERCURRENT IMPLEMENTATION

If the Speed2 Undercurrent function is enabled, trip or alarm are initiated once the IA, IB or IC current magnitude falls below the pickup level for a period of time specified by the delay. For example, undercurrent may be used to detect loss-of load conditions. This may be especially useful for detecting process related problems. This element is active if the motor is running at Speed 2. The undercurrent function at speed 2 becomes functional only if undercurrent at speed 1 is enabled. When the undercurrent function at any speed is not required, it can be permanently blocked.

Start Block Delay under **SETPOINTPROTECTION\GROUP [1-6]MOTOR\2-SPEED MOTOR\SPEED2 UNDERCURRENT** specifies a time to block the undercurrent function when the motor is starting directly at speed 2. Prior to starting, the motor state is determined from the Motor Stopped operand. Refer to the Motor Status section for additional information on the motor stopped state determination. The speed 2 undercurrent element is active only when the motor is running at speed 2 and is blocked upon the initiation of a motor start for a period of time defined by the **Start Block DLY** setting (for example, this block may be used to allow pumps to build up head before the undercurrent element trips or alarms). A value of 0 specifies that the feature is not blocked from start. For values other than 0, the feature is disabled when the motor is stopped, and also from the time a start is detected until the time entered expires. A one second delay is added to prevent wrong operation of the element when the motor is switched from speed 1 to speed 2.

6.3.11.2 2-SPEED UNDERCURRENT LOGIC




Figure 55: 2-Speed undercurrent logic

## CHAPTER 7

# CURRENT PROTECTION FUNCTIONS

---

## 7.1 CHAPTER OVERVIEW

---

The P24D and P24N provide a wide range of current protection functions. This chapter describes the operation of these functions including the principles, logic diagrams and applications.

This chapter contains the following sections:

Chapter Overview	146
Overcurrent Protection Principles	147
Phase Overcurrent Protection	157
Voltage Dependant Overcurrent Element	166
Earth Fault Protection	170
Sensitive Earth Fault Protection	174
Blocked Overcurrent Protection	177

*Note:*

*For any protection element setting set below 0.02xCT value, the Current Cutoff setting under the **DEVICE\INSTALLATION** path must be taken into account and set accordingly, as the default value is 0.020.*



## 7.2 OVERCURRENT PROTECTION PRINCIPLES

Most electrical power system faults result in an overcurrent of one kind or another. It is the job of protection devices, formerly known as 'relays' but now known as Intelligent Electronic Devices (IEDs) to protect the power system from faults. The general principle is to isolate the faults as quickly as possible to limit the danger and prevent fault currents flowing through systems, which can cause severe damage to equipment and systems. At the same time, we wish to switch off only the parts of the power grid that are absolutely necessary, to prevent unnecessary blackouts. The protection devices that control the tripping of the power grid's circuit breakers are highly sophisticated electronic units, providing an array of functionality to cover the different fault scenarios for a multitude of applications.

The described products offer a range of overcurrent protection functions including:

- Phase Overcurrent protection
- Earth Fault Overcurrent protection
- Sensitive Earth Fault protection

To ensure that only the necessary circuit breakers are tripped and that these are tripped with the smallest possible delay, the IEDs in the protection scheme need to co-ordinate with each other. Various methods are available to achieve correct co-ordination between IEDs in a system. These are:

- By means of time alone
- By means of current alone
- By means of a combination of both time and current.

Grading by means of current alone is only possible where there is an appreciable difference in fault level between the two locations where the devices are situated. Grading by time is used by some utilities but can often lead to excessive fault clearance times at or near source substations where the fault level is highest.

For these reasons the most commonly applied characteristic in co-ordinating overcurrent devices is the IDMT (Inverse Definite Minimum Time) type.

### 7.2.1 FUNCTION SETTING APPLICATION

The Function setting has an enumeration of *Disabled*, *Trip*, *Latched Trip*, *Alarm*, *Latched Alarm* or *Configurable* and is available in most of the elements. Selection of *Trip*, *Latched Trip*, *Alarm*, *Latched Alarm* or *Configurable* enables the element.

When the **Alarm** function is selected, and the element operates, the LED "ALARM" will flash, and will self-reset, when the operating conditions are cleared.

When the **Latched Alarm** function is selected, and the element operates, the LED "ALARM" will flash during the element operating condition and will be steady lit after the conditions are cleared. The LED "ALARM" can be cleared by issuing reset command. The output relay #1 "Trip" will not operate if Latched Alarm or Alarm setting is selected. The Output relay #1 "Trip" can be configured to operate using the element output operands and the Flexlogic Equation Editor.

The output relay #1 "Trip" will operate only when the **Trip** or **Latched Trip** function is selected, and the element operates. The LED "ALARM" will not turn on, if the element operates when set to function **Trip** or **Latched Trip**.


When the **Configurable** function is selected, neither the trip output, nor the ALARM LED will turn on automatically. They need be configured using their own menus, FlexLogic operands and Flexlogic Equation Editor.

### 7.2.2 PRINCIPLES OF IMPLEMENTATION

The range of protection products provides a very wide range of protection functionality. Despite the diverse range of functionality provided, there is some commonality between the way many of the protection functions are

implemented. It is important to describe some of these basic principles before going deeper into the individual protection functions.

A simple representation of protection functionality is shown in the following diagram:



**Figure 56: Principle of protection function implementation**

An energising quantity is either a voltage input from a system voltage transformer, a current input from a system current transformer or another quantity derived from one or both of these. The energising quantities are extracted from the power system. The signals are converted to digital quantities where they can be processed by the IEDs internal processor.

In general, an energising quantity, be it a current, voltage, power, frequency, or phase quantity, is compared with a threshold value, which may be settable, or hard-coded depending on the function. If the quantity exceeds (for overvalues) or falls short of (for undervalues) the threshold, a signal is produced, which when gated with the various inhibit functions becomes the Start signal for that protection function. This Start signal is generally made available to the Flexlogic Equation Editor for further processing. It is also passed through a timer function to produce the Trip signal. The timer function may be an IDMT curve, or a Definite Time delay, depending on the function. The timer can be configured by a range of settings to define such parameters as the type of curve, The Time Multiplier Setting, the IDMT constants, the Definite Time delay etc.

In GE Vernova products, there are usually several independent stages for each of the functions, and for three-phase functions, there are usually independent stages for each of the three phases.

PTOC protection elements use an Inverse Definite Minimum Time (IDMT) timer function, and a Definite Time timer (DT) function. If the DT time delay is set to '0', then the function is known to be "instantaneous". In many instances, the term "instantaneous protection" is used loosely to describe Definite Time protection stages, even when the stage may not theoretically be instantaneous.

Many protection functions require a direction-dependant decision. Such functions can only be implemented where both current and voltage inputs are available. For such functions, a directional check is required, whose output can block the Start signal should the direction of the fault be wrong.

**Note:**

*In the logic diagrams and descriptive text, it is usually sufficient to show only the first stage, as the design principles for subsequent stages are usually the same (or at least very similar). Where there are differences between the functionality of different stages, this is clearly indicated.*

### 7.2.2.1 TIMER HOLD FACILITY

The Timer Hold facility is available for stages with IDMT functionality, and is controlled by the timer reset settings for the relevant stages (e.g.  $I>1 tReset$ ,  $I>2 tReset$ ). These values are not visible for the IEEE/US curves if an inverse time reset characteristic has been selected, because in this case the reset time is determined by the time dial setting (TDS).

This feature may be useful in certain applications, such as when grading with upstream electromechanical overcurrent relays, which have inherent reset time delays. If you set the hold timer to a value other than zero, the resetting of the protection element timers will be delayed for this period. This allows the element to behave in a similar way to an electromechanical relay. If you set the hold timer to zero, the overcurrent timer for that stage will reset instantaneously as soon as the current falls below a specified percentage of the current setting (typically 95%).

Another situation where the timer hold facility may be used to reduce fault clearance times is for intermittent faults. An example of this may occur in a plastic insulated cable. In this application it is possible that the fault energy melts and reseals the cable insulation, thereby extinguishing the fault. This process repeats to give a succession of fault current pulses, each of increasing duration with reducing intervals between the pulses, until the fault becomes permanent.

When the reset time is instantaneous, the device will repeatedly reset and not be able to trip until the fault becomes permanent. By using the Timer Hold facility the device will integrate the fault current pulses, thereby reducing fault clearance time.

---

## 7.2.3 IDMT CHARACTERISTICS

There are two basic requirements to consider when designing protection schemes:

- All faults should be cleared as quickly as possible to minimise damage to equipment
- Fault clearance should result in minimum disruption to the electrical power grid.

The second requirement means that the protection scheme should be designed such that only the circuit breaker(s) in the protection zone where the fault occurs, should trip.

These two criteria are actually in conflict with one another, because to satisfy (1), we increase the risk of shutting off healthy parts of the grid, and to satisfy (2) we purposely introduce time delays, which increase the amount of time a fault current will flow. With IDMT protection applied to radial feeders, this problem is exacerbated by the nature of faults in that the protection devices nearest the source, where the fault currents are largest, actually need the longest time delay.

IDMT characteristics are described by operating curves. Traditionally, these were defined by the performance of electromechanical relays. In numerical protection, equations are used to replicate these characteristics so that they can be used to grade with older equipment.

The old electromechanical relays countered this problem somewhat due to their natural operate time v. fault current characteristic, whereby the higher the fault current, the quicker the operate time. The characteristic typical of these electromechanical relays is called Inverse Definite Minimum Time or IDMT for short.

### 7.2.3.1 IEC 60255 IDMT CURVES

There are seven well-known variants of this characteristic:

- Standard Inverse
- Very Inverse
- Extremely Inverse
- UK Long Time Inverse
- Rectifier
- FR Short Time Inverse
- Standard Inverse (1.3s)

These equations and corresponding curves governing these characteristics are very well known in the power industry.

### Standard Inverse

This characteristic is commonly known as the 3/10 characteristic, i.e. at ten times setting current and TMS of 1, the IED will operate in 3 seconds.

The characteristic curve can be defined by the mathematical expression:

$$t_{op} = T \frac{0.14}{\left(\frac{I}{I_s}\right)^{0.02} - 1}$$

The standard inverse time characteristic is widely applied at all system voltages – as back up protection on EHV systems and as the main protection on HV and MV distribution systems.

In general, the standard inverse characteristics are used when:

- There are no co-ordination requirements with other types of protective equipment further out on the system, e.g. Fuses, thermal characteristics of transformers, motors etc.
- The fault levels at the near and far ends of the system do not vary significantly.
- There is minimal inrush on cold load pick up. Cold load inrush is that current which occurs when a feeder is energised after a prolonged outage. In general the IED cannot be set above this value but the current should decrease below the IED setting before the IED operates.

### Very Inverse

This type of characteristic is normally used to obtain greater time selectivity when the limiting overall time factor is very low, and the fault current at any point does not vary too widely with system conditions. It is particularly suitable, if there is a substantial reduction of fault current as the distance from the power source increases. The steeper inverse curve gives longer time grading intervals. Its operating time is approximately doubled for a reduction in setting from 7 to 4 times the IED current setting. This permits the same time multiplier setting for several IEDs in series.

The characteristic curve can be defined by the mathematical expression:

$$t_{op} = T \frac{13.5}{\left(\frac{I}{I_s}\right) - 1}$$

### Extremely Inverse

With this characteristic the operating time is approximately inversely proportional to the square of the current. The long operating time of the IED at peak values of load current make the IED particularly suitable for grading with fuses and also for protection of feeders which are subject to peak currents on switching in, such as feeders supplying refrigerators, pumps, water heaters etc., which remain connected even after a prolonged interruption of supply.

For cases where the generation is practically constant and discrimination with low tripping times is difficult to obtain, because of the low impedance per line section, an extremely inverse configured IED can be very useful since only a small difference of current is necessary to obtain an adequate time difference.

This characteristic is also widely used for protecting plant against overheating since overheating is usually an I2t function.

This characteristic curve can be defined by the mathematical expression:

$$t_{op} = T \frac{80}{\left(\frac{I}{I_s}\right)^2 - 1}$$

### UK Long Time Inverse

This type of characteristic has a long time characteristic and may be used for protection of neutral earthing resistors (which normally have a 30 second rating). The IED operating time at 5 times current setting is 30 seconds at a TMS of 1.

This can be defined by:

$$t_{op} = T \frac{120}{\left(\frac{I}{I_s}\right) - 1}$$

### Rectifier

This characteristic curve can be defined by the mathematical expression:

$$t_{op} = T \frac{45900}{\left[\frac{I}{I_s}\right]^{5.6} - 1}$$

### FR Short Time Inverse

This characteristic curve can be defined by the mathematical expression:

$$t_{op} = T \frac{0.05}{\left[\frac{I}{I_s}\right]^{0.04} - 1}$$

### Standard Inverse (1.3S)

This characteristic curve can be defined by the mathematical expression:

$$t_{op} = T \frac{0.00607}{\left[\frac{I}{I_s}\right]^{0.02} - 1}$$

In the above equations:

- $t_{op}$  is the operating time
- $T$  is the time multiplier setting
- $I$  is the measured current

$I_s$  is the current threshold setting.

The ratio  $I/I_s$  is sometimes defined as 'M' or 'PSM' (Plug Setting Multiplier).

These curves are plotted as follows:




Figure 57: IEC 60255 IDMT curves

### 7.2.3.2 EUROPEAN STANDARDS

The IEC 60255 IDMT Operate equation is:

$$t_{op} = T \left( \frac{\beta}{M^\alpha - 1} + L \right) + C$$

and the IEC 60255 IDMT Reset equation is:

$$t_r = T \left( \frac{\beta}{1 - M^\alpha} \right)$$

where:

- $t_{op}$  is the operating time
- $t_r$  is the reset time
- T is the Time Multiplier setting
- M is the ratio of the measured current divided by the threshold current ( $I/I_n$ )
- $\beta$  is a constant, which can be chosen to satisfy the required curve characteristic
- $\alpha$  is a constant, which can be chosen to satisfy the required curve characteristic
- C is a constant for adding Definite Time (Definite Time adder)
- L is a constant (usually only used for ANSI/IEEE curves)

The constant values for the IEC IDMT curves are as follows:

Curve Description	$\beta$ Constant	$\alpha$ Constant	L Constant
IEC Standard Inverse Operate	0.14	0.02	0
IEC Standard Inverse Reset	8.2	6.45	0

Curve Description	$\beta$ Constant	$\alpha$ Constant	L Constant
IEC Very Inverse Operate	13.5	1	0
IEC Very Inverse Reset	50.92	2.4	0
IEC Extremely Inverse Operate	80	2	0
IEC Extremely Inverse Reset	44.1	3.03	0
UK Long Time Inverse Operate*	120	1	0
Rectifier Operate*	45900	5.6	0
FR Short Time Inverse Operate*	0.05	0.04	0
Standard Inverse (1.3s) Operate	0.0607	0.02	0
Standard Inverse (1.3s) Reset	3.55	6.45	0

Note:

\* When using UK Long Time Inverse, Rectifier or FR Short time Inverse for the Operate characteristic, DT (Definite Time) is always used for the Reset characteristic.

### Rapid Inverse (RI) characteristic

The RI operate curve is represented by the following equation:

$$t_{op} = K \left( \frac{1}{0.339 - \frac{0.236}{M}} \right)$$

where:

- $t_{op}$  is the operating time
- K is the Time Multiplier setting
- M is the ratio of the measured current divided by the threshold current ( $I/I_s$ )

Note:

\* When using RI for the Operate characteristic, DT (Definite Time) is always used for the Reset characteristic.

### 7.2.3.3 NORTH AMERICAN STANDARDS

The IEEE IDMT Operate equation is:

$$t_{op} = TD \left( \frac{\beta}{M^\alpha - 1} + L \right) + C$$

and the IEEE IDMT Reset equation is:

$$t_r = TD \left( \frac{\beta}{1 - M^\alpha} \right)$$

where:

- $t_{op}$  is the operating time
- $t_r$  is the reset time

- TD is the Time Dial setting
- M is the ratio of the measured current divided by the threshold current ( $I/I_s$ )
- $\beta$  is a constant, which can be chosen to satisfy the required curve characteristic
- $\alpha$  is a constant, which can be chosen to satisfy the required curve characteristic
- C is a constant for adding Definite Time (Definite Time adder)
- L is a constant (usually only used for ANSI/IEEE curves)

The constant values for the IEEE curves are as follows:

Curve Description	$\beta$ Constant	$\alpha$ Constant	L Constant
IEEE Moderately Inverse Operate	0.0515	0.02	0.114
IEEE Moderately Inverse Reset	4.85	2	0
IEEE Very Inverse Operate	19.61	2	0.491
IEEE Very Inverse Reset	21.6	2	0
IEEE Extremely Inverse Operate	28.2	2	0.1217
IEEE Extremely Inverse Reset	29.1	2	0
CO8 US Inverse Operate	5.95	2	0.18
CO8 US Inverse Reset	5.95	2	0
CO2 US Short Time Inverse Operate	0.16758	0.02	0.11858
CO2 US Short Time Inverse Reset	2.261	2	0

### 7.2.3.3.1 ANSI CURVES

The ANSI Operate equation is:

$$T = TD \times \left[ A + \frac{B}{(I/I_{pickup}) - C} + \frac{D}{((I/I_{pickup}) - C)^2} + \frac{E}{((I/I_{pickup}) - C)^3} \right]$$

$$t_r = TD \left( \frac{\beta}{1 - M^\alpha} \right)$$

And the ANSI Reset equation is:

$$T_{RESET} = TD \times \left[ \frac{t_r}{1 - (I/I_{pickup})^2} \right]$$

where:

- T = operate time (in seconds)
- TD = Time Dial setting
- I = measured current
- Ipickup = threshold Current
- A to E = constants
- tr = characteristic constant
- TRESET = reset time in seconds

The constant values for the ANSI curves are as follows:



Curve Description	A Constant	B Constant	C Constant	D Constant	E Constant	tr Constant
ANSI Extremely Inverse	0.0399	0.2294	0.5000	3.0094	0.7222	5.67
ANSI Very Inverse	0.0615	0.7989	0.3400	-0.2840	4.0505	3.88
ANSI Normally Inverse	0.0274	2.2614	0.3000	-4.1899	9.1272	5.95
ANSI Moderately Inverse	0.1735	0.6791	0.8000	-0.0800	0.1271	1.08

### 7.2.3.4 IAC CURVES

The IAC Operate equation is:

$$T = TD \times \left[ A + \frac{B}{\left( I / I_{pickup} \right) - C} + \frac{D}{\left( \left( I / I_{pickup} \right) - C \right)^2} + \frac{E}{\left( \left( I / I_{pickup} \right) - C \right)^3} \right]$$

And the IAC Reset equation is:

$$T_{RESET} = TD \times \left[ \frac{t_r}{1 - \left( I / I_{pickup} \right)^2} \right]$$

where:

- T = operate time (in seconds)
- TD = time dial setting
- I = measured current
- I<sub>pickup</sub> = threshold current
- A to E = constants
- tr = characteristic constant, and
- TRESET = reset time in seconds

The constant values for the IAC curves are as follows:

Curve Description	A Constant	B Constant	C Constant	D Constant	E Constant	tr Constant
IAC Extremely Inverse	0.0040	0.6379	0.6200	1.7872	0.2461	6.008
IAC Very Inverse	0.0900	0.7965	0.1000	-1.2885	7.9586	4.678
IAC Normally Inverse	0.2078	0.8630	0.8000	-0.4180	0.1947	0.990
IAC Moderately Inverse	0.0428	0.0609	0.6200	-0.0010	0.0221	0.222

### 7.2.3.5 I2T CURVES

The I2T Operate equation is:

$$T = TD \times \left[ \frac{100}{\left( I / I_{pickup} \right)^2} \right]$$

And the I2T Reset equation is:

$$T_{RESET} = TD \times \left[ \frac{100}{(I / I_{pickup})^{-2}} \right]$$

where:

- T = operate time (in seconds)
- TD = time dial setting
- I = measured current
- Ipickup = threshold current and
- TRESET = reset time in seconds

### 7.2.3.6 I4T CURVES

The I4T Operate equation is:

$$T = TD \times \left[ \frac{100}{(I / I_{pickup})^4} \right]$$

And the I4T Reset equation is:

$$T_{RESET} = TD \times \left[ \frac{100}{(I / I_{pickup})^{-4}} \right]$$

where:

- T = operate time (in seconds)
- TD = time dial setting
- I = measured current
- Ipickup = threshold current and
- TRESET = reset time in seconds

### 7.2.3.7 DIFFERENCES BETWEEN THE NORTH AMERICAN AND EUROPEAN STANDARDS

The IEEE and US curves are set differently to the IEC/UK curves, with regard to the time setting. A time multiplier setting (TMS) is used to adjust the operating time of the IEC curves, whereas a time dial setting is used for the IEEE/US curves. The menu is arranged such that if an IEC/UK curve is selected, the **I>1 Time Dial** setting is not visible and vice versa for the TMS setting.

### 7.2.3.8 PROGRAMMABLE CURVES

In addition to the standard curves as defined by various countries and standardising bodies, it is possible to program custom curves using User Curves, which can be programmed either through the IED front panel or through the EnerVista Configuration software (preferred option). There are 4 User Curves available. Each User Curve can be configured at the **User Curve (n)** menu available at **SETPOINTS\SYSTEM\USER CURVES DATA**. The EnerVista Configuration software allows the creation of curves either by formula or by entering data points, allowing the user to have a standard curve as a reference. If the mode of entry selected is the IEDs front panel, the curve is created just by entering manually the curve data points.

User Curves help match more closely the withstand characteristics of the electrical equipment than the standard curves.

## 7.3 PHASE OVERCURRENT PROTECTION

Phase current faults are faults where fault current flows between two or more phases of a power system. The fault current may be between the phase conductors only or, between two or more phase conductors and earth.

Although not as common as earth faults (single phase to earth), phase faults are typically more severe.

### 7.3.1 PHASE OVERCURRENT PROTECTION IMPLEMENTATION

Phase Time Overcurrent Protection (PTOC) is configured under the path **SETPOINTS\PROTECTION\GROUP [1-6]\CURRENT PROT.\PHASE TOC**

Phase Instantaneous Overcurrent Protection (PIOC) is configured under the path **SETPOINTS\PROTECTION \GROUP [1-6]\CURRENT PROT.\PHASE IOC**

The product provides segregated three-phase time overcurrent protection and six-phase instantaneous overcurrent protection, each with independent time delay characteristics. The settings are independent for each stage, but for each stage, the settings apply to all phases.

Each stage of PTOC provides a choice of operate and reset characteristics, where you can select between:

- A range of IDMT (Inverse Definite Minimum Time) curves based on IEC, IEEE, ANSI and IAC standards
- A range of programmable user-defined curves
- DT (Definite Time) characteristic

For PTOC stage 1, this is achieved using the following settings:

- **I>1 Curve** for the overcurrent operate characteristic
- **I>1 Reset Char** if available, according to the **I>1 Curve** setting selection, for the overcurrent reset characteristic


The setting names for other stages follow the same principles.

For PIOC stage 1, there are no operate or reset characteristics but there are current pickup levels (current set), reset time and time delays:

- **I>1 Current Set** for the overcurrent pickup level
- **I>1 tRESET** for the overcurrent reset time
- **I>1 Time Delay** for the overcurrent time delay

The setting names for other stages follow the same principles.

### 7.3.2 NON-DIRECTIONAL OVERCURRENT LOGIC



V80065

**Figure 58: Non-directional overcurrent logic**

Phase Overcurrent Modules are level detectors that detect when the current magnitude exceeds a set threshold. When this happens, a Start signal is generated unless it is inhibited by a blocking signal. This Start signal initiates the timer module, which can be configured as an IDMT timer or DT timer, for PTOC, or DT timer for PIOC respectively. The Start signal is also available for use in the Flexlogic Equation Editor. For each stage, there are three Phase Overcurrent Modules, one for each phase. The three Start signals from each of these phases are combined to form a 3-phase Start signal.

The timer can be configured with several settings depending on which type of curve is selected.

Taking stage 1 as an example:

**I>1 Time Dial** setting is the Time Multiplier Setting to adjust the operate time of IEEE M/V/E Inverse OR US Inverse/ Short Time OR ANSI E/V/N/M Inverse OR IAC E/V/N/S Inverse OR I2T OR I4T curves.

*Note:*

*The I>1 Time Dial setting can be made visible from setting management, only when Curve setting is selected as IEEE/US/ ANSI/IAC/I2T/I4T IDMT curves*

**I>1 TMS** setting is the Time Multiplier Setting to adjust the operate time of IEC S/V/E Inverse OR UK Long Time Inverse OR FR Short Time OR Rectifier OR Standard Inverse (1.3s).

*Note:*

*The I>1 TMS setting can be made visible from setting management, only when the Curve setting is selected as IEC/UK IDMT, Rectifier/Standard inverse curves.*

**I>1 k (RI)** setting defines the TMS constant to adjust the operate time of the RI curve.

*Note:*

*The I>1 k (RI) setting can be made visible from setting management, only when the Curve setting is selected as RI curves.*

**I>1 MRT** setting is the Minimum Response Time setting to set the minimum operating time for the Phase TOC element. If **I>1 MRT** setting is selected with a value different from zero, the Phase TOC element minimum operating time will be fixed by this setting, ensuring the operating time of the element never falls below this setting. The minimum operating time selected will be the maximum value between the curve value and the **I>1 MRT** setting, whichever is greater.

*Note:*

*The I>1 MRT setting can be made visible from the setting management, only when the Curve setting is selected as any type of curve (all curves but DT selection).*

*Note:*

*If I>1 MRT setting is set to zero, the setting is disabled and just the curve time will apply.*

**I>1 DT Adder** setting adds an additional fixed time delay to the curve operate characteristics.

*Note:*

*The I>1 DT Adder setting can be made visible from the setting management, only when the Curve setting is selected as any type of curve but FlexCurves.*

**I>1 Time Delay** setting sets the definite Time delay for the Phase TOC element, when operate time is selected as Definite Time.

*Note:*

*The I>1 Time Delay setting can be made visible from setting management, only when the Curve setting is selected as DT (Definite Time).*

**I>1 Reset Char** setting allows the selection of an Definite Time (DT) or Inverse reset time. If **DT** reset is selected, the Phase TOC element will reset after a time delay provided by **tRESET** setting. If **Inverse** reset is selected, the time to reset is calculated based on the reset equation for the selected inverse curve.

When using UK Long Time Inverse, Rectifier, FR Short Time Inverse, RI curves for the Operate characteristic, it is always recommended to use DT for the Reset characteristic.

The outputs of the timer modules are the single-phase trip signals. These trip signals are combined to form a 3-phase Trip signal. The Trip signal is also available for use in the Flexlogic Equation Editor.

For close up three-phase faults, all three voltages will collapse to zero and no healthy phase voltages will be present. For this reason, the device includes a polarisation feature that stores the pre-fault voltage information and continues to apply this to the directional overcurrent elements for a period of 3 cycles. This ensures that either instantaneous or time-delayed directional overcurrent elements will be allowed to operate, even with a three-phase voltage collapse.

### 7.3.3 DIRECTIONAL ELEMENT

If fault current can flow in both directions through a protected location, you will need to use a directional overcurrent element to determine the direction of the fault. Once the direction has been determined the device can decide whether to allow tripping or to block tripping. To determine the direction of a phase overcurrent fault, the device must compare the phase angle of the fault current with that of a known reference quantity. The phase angle of this known reference quantity must be independent of the faulted phase. Typically this will be the line voltage between the other two phases.

The phase fault elements of the IEDs are internally polarised by the quadrature phase-phase voltages, as shown in the table below:

Phase of Protection	Operate Current	Polarising Voltage
A Phase	IA	VBC
B Phase	IB	VCA
C Phase	IC	VAB

Under system fault conditions, the fault current vector lags its nominal phase voltage by an angle depending on the system X/R ratio. The IED must therefore operate with maximum sensitivity for currents lying in this region. This is achieved using the relay characteristic angle (RCA) setting. The RCA is the angle by which the current applied to the IED must be displaced from the voltage applied to the IED to obtain maximum sensitivity.

The characteristic angle can be set independently for each stage. For PTOC stage 1, for example, this would be the setting **I>1 Char Angle**. It is possible to set characteristic angles anywhere in the range 0° to + 359°.




Figure 59: Directional trip angles

### 7.3.4 DIRECTIONAL OVERCURRENT LOGIC




Figure 60: Directional overcurrent logic (Phase A only)


*Note:*  
Directional functionality is available for P24D only.

*Note:*  
The Multilin Agile Motor IED has one stage of the Phase Directional Overcurrent element.



## 7.3.5 APPLICATION NOTES

### 7.3.5.1 PARALLEL FEEDERS



**Figure 61: Typical distribution system using parallel transformers**

In the application shown in the diagram, a fault at 'F' could result in the operation of both R3 and R4 resulting in the loss of supply to the 11 kV busbar. Hence, with this system configuration, it is necessary to apply directional protection devices at these locations set to 'look into' their respective transformers. These devices should coordinate with the non-directional devices, R1 and R2, to ensure discriminative operation during such fault conditions.


In such an application, R3 and R4 may commonly require non-directional overcurrent protection elements to provide protection to the 11 kV busbar, in addition to providing a back-up function to the overcurrent devices on the outgoing feeders (R5).

For this application, stage 1 of the R3 and R4 overcurrent protection would be set to non-directional and time graded with R5, using an appropriate time delay characteristic. Stage 2 could then be set to directional (looking back into the transformer) and also have a characteristic which provides correct co-ordination with R1 and R2. Directionality for each of the applicable overcurrent stages can be set in the directionality setting (***I>1 Direction***) as *FWD* or *REV*. The directional settings (RCA angle, etc.) are to be set at the different Dir OC menus available for each of the overcurrent stages. The direction for each overcurrent stage (Non-directional, Forward (FWD), Reverse(REV)) is set at each of the overcurrent protection function settings (***I>1 Direction***).

**Note:**

*The principles outlined for the parallel transformer application are equally applicable for plain feeders that are operating in parallel.*

### 7.3.5.2 RING MAIN ARRANGEMENTS



**Figure 62: Typical ring main with associated overcurrent protection**

In a ring main arrangement, current may flow in either direction through the various device locations, therefore directional overcurrent devices are needed to achieve correct discrimination.

The normal grading procedure for overcurrent devices protecting a ring main circuit is to consider the ring open at the supply point and to grade the devices first clockwise and then anti-clockwise. The arrows shown at the various device locations depict the direction for forward operation of the respective devices (i.e. the directional devices are set to look into the feeder that they are protecting).

The diagram shows typical time settings (assuming definite time co-ordination is used), from which it can be seen that any faults on the interconnections between stations are cleared discriminatively by the devices at each end of the feeder.

Any of the overcurrent stages may be configured to be directional and co-ordinated, but bear in mind that IDMT characteristics are not selectable on all the stages.

### 7.3.5.3 SETTING GUIDELINES

Standard principles should be applied in calculating the necessary current and time settings. The example detailed below shows a typical setting calculation and describes how the settings are applied.

This example is for a device feeding a LV switchboard and makes the following assumptions:

- CT Ratio = 500/1
- Full load current of circuit = 450A
- Slowest downstream protection = 100A Fuse

The current setting on the device must account for both the maximum load current and the reset ratio, therefore:

$I_{\text{P}}$  must be greater than:  $450/\text{dropout} = 450/0.95 = 474\text{A}$ .

The required setting is 475A in terms of primary current.

A suitable time delayed characteristic will now need to be chosen. When co-ordinating with downstream fuses, the applied characteristic should be closely matched to the fuse characteristic. Therefore, assuming IDMT co-ordination is to be used, an Extremely Inverse (EI) characteristic would normally be chosen. This is found under the ***I>1 Curve*** setting as *IEC E Inverse*.

Finally, a suitable time multiplier setting (TMS) must be calculated and entered in setting ***I>1 TMS***.

#### 7.3.5.4 SETTING GUIDELINES (DIRECTIONAL ELEMENT)

The applied current settings for directional overcurrent devices are dependant upon the application in question. In a parallel feeder arrangement, load current is always flowing in the non-operate direction. Hence, the current setting may be less than the full load rating of the circuit.

You need to observe some setting constraints when applying directional overcurrent protection at the receiving-end of parallel feeders. These minimum safe settings are designed to ensure that there is no possibility of undesired tripping during clearance of a source fault. For a linear system load, these settings are as follows:

We recommend the following settings to ensure that there is no possibility of malaoperation:

- Parallel plain feeders: Set to 50% pre-fault load current
- Parallel transformer feeders: Set to 87% pre-fault load current

In a ring main application, the load current can flow in either direction. The current setting must be above the maximum load current.

The required characteristic angle settings for directional devices depend on the application. We recommend the following settings:

- Plain feeders, or applications with an earthing point behind the device location, should use a +30° RCA setting
- Transformer feeders, or applications with a zero sequence source in front of the device location, should use a +45° RCA setting

Although it is possible to set the RCA to exactly match the system fault angle, we recommend that you adhere to the above guidelines, as these settings provide satisfactory performance and stability under a wide range of system conditions.

---

## 7.4 VOLTAGE DEPENDANT OVERCURRENT ELEMENT

---

An overcurrent protection scheme is co-ordinated throughout a system such that cascaded operation is achieved. This means that if for some reason a downstream circuit breaker fails to trip for a fault condition, the next upstream circuit breaker should trip.

However, where long feeders are protected by overcurrent protection, the detection of remote phase-to-phase faults may prove difficult due to the fact that the current pick-up of phase overcurrent elements must be set above the maximum load current, thereby limiting the minimum sensitivity.

If the current seen by a local device for a remote fault condition is below its overcurrent setting, a voltage dependant element may be used to increase the sensitivity to such faults. As a reduction in system voltage will occur during overcurrent conditions, this may be used to enhance the sensitivity of the overcurrent protection by reducing the pick up level.

Voltage dependant overcurrent devices are often applied in generator protection applications in order to give adequate sensitivity for close up fault conditions. The fault characteristic of this protection must then co-ordinate with any of the downstream overcurrent devices that are responsive to the current decrement condition. It therefore follows that if the device is to be applied to an outgoing feeder from a generator station, the use of voltage dependant overcurrent protection in the feeder device may allow better co-ordination with the Voltage Dependant device on the generator.

*Note:*

*Voltage Dependant Overcurrent element is available in P24D only.*

---

### 7.4.1 VOLTAGE DEPENDANT OVERCURRENT PROTECTION IMPLEMENTATION


Voltage Dependant Overcurrent Protection (**V Dep OC**) is set in **Phase TOC**.

The function is available for each stage of **PTOC**. When **I>1 V Dep OC** is enabled, the overcurrent setting is modified when the voltage falls below the thresholds set in the voltage dependant overcurrent settings.

If voltage dependant overcurrent operation is selected, the element can be set in one of two modes, voltage controlled overcurrent or voltage restrained overcurrent.

#### 7.4.1.1 VOLTAGE CONTROLLED OVERCURRENT PROTECTION

In Voltage Controlled Operation (VCO) mode of operation, the under voltage detector is used to produce a step change in the current setting, when the voltage falls below the voltage setting **V Dep OC V<1**. The operating characteristic of the current setting when voltage controlled mode is selected is as follows:



**Figure 63: Modification of current pickup level for voltage controlled overcurrent protection**

### 7.4.1.2 VOLTAGE RESTRAINED OVERCURRENT PROTECTION

In Voltage Restrained Operation (VRO) mode the effective operating current of the protection element is continuously variable as the applied voltage varies between two voltage thresholds. This protection mode is considered to be better suited to applications where the generator is connected to the system via a generator transformer.

With indirect connection of the generator, a solid phase-phase fault on the local busbar will result in only a partial phase-phase voltage collapse at the generator terminals.

The voltage-restrained current setting is related to measured voltage as follows:

- If  $V$  is greater than  $V<1$ , the current setting ( $I_s$ ) =  $I>$
- If  $V$  is greater than  $V<2$  but less than  $V<1$ , the current setting ( $I_s$ ) =

$$KI > + (I > - KI) \frac{V - V < 2}{V < 1 - V < 2}$$

- If  $V$  is less than  $V<2$ , the current setting ( $I_s$ ) =  $K \cdot I >$

where:

- $I >$  = Over current stage setting
- $I_s$  = Current setting at voltage  $V$
- $V$  = Voltage applied to IED element
- $V < 1$  = V Dep OC  $V < 1$
- $V < 2$  = V Dep OC  $V < 2$




Figure 64: Modification of current pickup level for voltage restrained overcurrent protection

### 7.4.1.3 VOLTAGE DEPENDANT OVERCURRENT LOGIC




Figure 65: Voltage dependant overcurrent logic (Phase A to phase B)

The current threshold setting for the Overcurrent function is determined by the voltage.

If the voltage is greater than ***I>1 V Dep OC V<1*** setting, the normal overcurrent setting ***I>1 Current Set*** is used. this applies to both VCO and VRO modes.

If the voltage is less than the ***I>1 V Dep OC V<1*** setting AND it is in VCO mode, the overcurrent setting ***I>1 Current Set*** is multiplied by the factor set in the ***I>1 V Dep OC k*** setting.

If the voltage is less than the ***I>1 V Dep OC V<2*** setting AND it is in VRO mode, the overcurrent setting ***I>1 Current Set*** is multiplied by the factor set in the ***I>1 V Dep OC k*** setting.

If the voltage is between **I>1 V Dep OC V<1** and **I>1 V Dep OC V<2** settings AND it is in VRO mode, the overcurrent setting is multiplied by a functional operator to determine the setting.

## 7.4.2 APPLICATION NOTES

### 7.4.2.1 SETTING GUIDELINES

The **I>1 V Dep OC k** setting should be set low enough to allow operation for remote phase-to-phase faults, typically:

$$k = \frac{I_F}{1.2I >}$$

where:

- $I_F$  = Minimum fault current expected for the remote fault
- $I >$  = Phase current setting for the element to have VCO control

#### Example

If the overcurrent device has a setting of 160%  $I_n$ , but the minimum fault current for the remote fault condition is only 80%  $I_n$ , then the required k factor is given by:

$$k = \frac{0.8}{1.6 \times 1.2} = 0.42$$

The voltage threshold, **I>1 V Dep OC V<(n)** setting would be set below the lowest system voltage that may occur under normal system operating conditions, whilst ensuring correct detection of the remote fault.

## 7.5 EARTH FAULT PROTECTION

Earth faults are overcurrent faults where the fault current flows to earth. Earth faults are the most common type of fault.

Earth faults can be measured directly from the system by means of:

- A separate current Transformer (CT) located in a power system earth connection
- A separate Core Balance Current Transformer (CBCT), usually connected to the SEF transformer input
- A residual connection of the three line CTs, where the Earth faults can be derived mathematically by summing the three measured phase currents

Depending on the device model, it will provide one or more of the above means for Earth fault protection.

### 7.5.1 EARTH FAULT PROTECTION ELEMENTS

Earth Fault Time Overcurrent protection is implemented under the **SETPOINTS\PROTECTION\GROUP [1-4]\CURRENT PROT\ (EF1 TOC, EF2 TOC)**.

Earth Fault Instantaneous Overcurrent protection is implemented under the **SETPOINTS\PROTECTION\GROUP [1-4]\CURRENT PROT\ (EF1 IOC, EF2 IOC)**.

**EARTH FAULT 1 (EF1)** is used for earth fault current that is measured directly from the system (measured). **EARTH FAULT 2 (EF2)** uses quantities derived internally from summing the three-phase currents.

The EF2 TOC protection element computes the neutral current (IN) using the following formula:

$$|IN| = |IA + IB + IC|$$

$$IN2\ TOC\ pickup = |IN|$$

The EF2 IOC protection element computes the neutral current (IN) using the following formula:

$$|IN| = |IA + IB + IC|$$

The element essentially responds to the magnitude of a neutral current fundamental frequency phasor calculated from the phase currents. A positive-sequence restraint is applied for better performance. A small portion (6.25%) of the positive-sequence current magnitude (I1) is subtracted from the zero-sequence current magnitude (I0) when forming the operating quantity of the element as follows:

$$IN2\ IOC\ pickup = 3 * (|I0| - K * |I1|) \text{ where } K = 1/16 \text{ and } |I0| = 1/3 * |IN|$$

The P24D and P24N provide Earth Fault protection with independent time delay characteristics.

Each Earth Fault Time Overcurrent stage provides a choice of operate and reset characteristics, where you can select between:

- A range of IDMT (Inverse Definite Minimum Time) curves
- A range of User-defined curves
- DT (Definite Time)

For the EF1 TOC element, this is achieved using the following settings:

- **IN1>(n) Curve** for the overcurrent operate characteristics
- **IN1>(n) Reset Char** if available, depending on the **I>1 Curve** setting selection, for the overcurrent reset characteristic

For the EF2 TOC element, this is achieved using the following settings:

- **IN2>(n) Curve** for the overcurrent operate characteristics
- **IN2>(n) Reset Char** if available, depending on the **I>1 Curve** setting selection, for the overcurrent reset characteristic where (n) is the number of the stage



The fact that both EF1 and EF2 elements may be enabled at the same time leads to a number of applications advantages. For example, some applications may require directional earth fault protection for upstream equipment and backup earth fault protection for downstream equipment. This can be achieved with a single IED, rather than two.

**Note:**


EF/SEF protection availability in the IED settings is depending on the Cortec selection for Current/Voltage Types:

**Note:**

EF2/EF1 protection functions available for option 1 (Standard Earth CT)

EF2/SEF protection functions available for option 2 (Sensitive Earth Fault CT)

## 7.5.2 NON-DIRECTIONAL EARTH FAULT LOGIC



**Note:**

\*1The CTS blocking is not applicable for IN1, however this can be achieved using the IED settings

**Figure 66: Non-directional EF logic (single stage)**

The Earth Fault current is compared with a set threshold (**IN2>(n) Current**) for each stage (TOC/IOC). If it exceeds this threshold, a Start signal is triggered, providing it is not blocked. This can be blocked by an Inhibit signal configured in the **IN2>(n) Inhibit** setting.

Earth Fault Time Overcurrent protection can follow a subset of the IDMT characteristics as described in the Overcurrent Protection Principles section. Please refer to that section for details of IDMT characteristics.

The timer settings can be configured with several settings depending on which type of curve is selected.

Taking stage 1 as an example:

**IN2>1 Time Dial** setting is the **Time Multiplier** Setting to adjust the operate time of IEEE M/V/E Inverse OR US Inverse/Short Time OR ANSI E/V/N/M Inverse OR IAC E/V/N/S Inverse OR I2T OR I4T curves.

**Note:**

The **IN2>1 Time Dial** setting can be made visible from setting management, only when **Curve** setting is selected as IEEE/US/ANSI/IAC/I2T/I4T IDMT curves.

**IN2>1 TMS** setting is the **Time Multiplier** Setting to adjust the operate time of IEC S/V/E Inverse OR UK Long Time Inverse OR FR Short Time OR Rectifier OR Standard Inverse (1.3s).

**Note:**

The **IN2>1 TMS** setting can be made visible from setting management, only when the **Curve** setting is selected as IEC/UK IDMT, Rectifier/Standard inverse curves.

**IN2>1 k (RI)** setting defines the TMS constant to adjust the operate time of the RI curve.

The **IN2>1 k (RI)** setting can be made visible from setting management, only when the **Curve** setting is selected as RI curves.

**IN2>1 MRT** setting is the **Minimum Response Time** setting to set the minimum operating time for the Earth Fault TOC element. If **IN2>1 MRT** setting is selected with a value different from zero, the Earth Fault TOC element minimum operating time will be fixed by this setting, ensuring the operating time of the element never falls below this setting. The minimum operating time selected will be the maximum value between the curve value and the **IN2>1 MRT** setting, whichever is greater.

**Note:**

The **IN2>1 MRT** setting can be made visible from setting management, only when the **Curve** setting is selected as any type of curve (all curves but DT selection).

**Note:**

If **IN2>1 MRT** setting is set to zero, the setting is disabled and just the curve time will apply.

**IN2>1 DT Adder** setting adds an additional fixed time delay to the curve operate characteristics.

**Note:**

The **IN2>1 DT Adder** setting can be made visible from setting management, only when the **Curve** setting is selected as any type of curve but FlexCurves.

**IN2>1 Time Delay** setting sets the definite Time delay for the Earth Fault TOC element, when operate time is selected as Definite Time.

**Note:**

The **IN2>1 Time Delay** setting can be made visible from setting management, only when the **Curve** setting is selected as DT (Definite Time).

**IN2>1 Reset Char** setting allows the selection of a Definite Time (DT) or Inverse reset time. If **DT** reset is selected, the Earth Fault TOC element will reset after a time delay provided by **tRESET** setting. If **Inverse** reset is selected, the time to reset is calculated based on the reset equation for the selected inverse curve.

When using UK Long Time Inverse, Rectifier, FR Short Time Inverse, RI curves for the Operate characteristic, it is always recommended to use DT for the Reset characteristic.

The diagram and description also applies to the Earth Fault 1 element (IN1).

**Note:**

*Multilin Agile Motor IED has one stage of Earth Fault Time Overcurrent and one stage of Earth Fault Instantaneous Overcurrent.*

## 7.6 SENSITIVE EARTH FAULT PROTECTION

With some earth faults, the fault current flowing to earth is limited by either intentional resistance (as is the case with some HV systems) or unintentional resistance (e.g. in very dry conditions and where the substrate is high resistance, such as sand or rock).

To provide protection in such cases, it is necessary to provide an earth fault protection system with a setting that is considerably lower than for normal line protection. Such sensitivity cannot be provided with conventional CTs, therefore the SEF input would normally be fed from a core balance current transformer (CBCT) mounted around the three phases of the feeder cable. The SEF transformer should be a special measurement class transformer.

### 7.6.1 SEF PROTECTION IMPLEMENTATION

SEF Time Overcurrent Protection is implemented under the path **SETPOINTS\PROTECTION\GROUP [1-6]\CURRENT PROT.\SEF TOC**

SEF Instantaneous Overcurrent Protection is implemented under the path **SETPOINTS\PROTECTION\GROUP [1-6]\CURRENT PROT.\SEF IOC**

The product provides **SEF TOC** protection with independent time delay characteristics:

- A range of IDMT (Inverse Definite Minimum Time) curves
- A range of User-defined curves
- DT (Definite Time)

For **SEF TOC** this is achieved using the following setpoints:

- **ISEF>(n) Curve** for the overcurrent operate characteristic
- **ISEF>(n) Reset Chr** if available, depending on the **I>1 Curve** setting selection, for the overcurrent reset characteristic

where (n) is the number of the stage.

For **SEF IOC** there are no operate or reset characteristic settings but current pickup levels (current) and reset time:


- **ISEF>(n) Current** for the SEF overcurrent pickup level
- **ISEF>(n) tReset** for the SEF overcurrent reset time
- **ISEF>(n) Time Delay** for the overcurrent time delay

where (n) is the number of the stage.

**Note:**

The Current Cutoff setting configured under **SETPOINTS\DEVICE\INSTALLATION\CURRENT CUTOFF** is set to 0.020 p.u. as default factory value, so the SEF measurement starts metering from 20 mA on. If currents under 20 mA need to be measured, the **CURRENT CUTOFF** setting should be set to 0 p.u. or to whichever value meets the customer's requirement.

## 7.6.2 NON-DIRECTIONAL SEF LOGIC



**Figure 67: Non-directional SEF logic**

The SEF current is compared with a set threshold (**ISEF>(n) Current**) for each stage. If it exceeds this threshold, a Start signal is triggered, providing it is not blocked. This can be blocked by an Inhibit signal configured at **ISEF>(n) Inhibit** setting.

SEF Time Overcurrent protection can follow a subset of the IDMT characteristics as described in the Overcurrent Protection Principles section. Please refer to this section for details of the relevant IDMT characteristics.

The timer settings can be configured with several settings depending on which type of curve is selected.

Taking stage 1 as an example:

**ISEF>1 Time Dial** setting is the **Time Multiplier** Setting to adjust the operate time of IEEE M/V/E Inverse OR US Inverse/Short Time OR ANSI E/V/N/M Inverse OR IAC E/V/N/S Inverse OR I2T OR I4T curves.

*Note:*

The **ISEF>1 Time Dial** setting can be made visible from setting management, only when **Curve** setting is selected as IEEE/US/ANSI/IAC/I2T/I4T IDMT curves.

**ISEF>1 TMS** setting is the **Time Multiplier** Setting to adjust the operate time of IEC S/V/E Inverse OR UK Long Time Inverse OR FR Short Time OR Rectifier OR Standard Inverse (1.3s).

*Note:*

The **ISEF>1 TMS** setting can be made visible from setting management, only when the **Curve** setting is selected as IEC/UK IDMT, Rectifier/Standard inverse curves.

**ISEF>1 k (RI)** setting defines the TMS constant to adjust the operate time of the RI curve.

*Note:*

The **ISEF>1 k (RI)** setting can be made visible from setting management, only when the **Curve** setting is selected as RI curves.

**ISEF>1 MRT** setting is the **Minimum Response Time** setting to set the minimum operating time for the Sensitive Earth Fault TOC element. If **ISEF>1 MRT** setting is selected with a value different from zero, the Sensitive Earth Fault TOC element minimum operating time will be fixed by this setting, ensuring the operating time of the element never falls below this setting. The minimum operating time selected will be the maximum value between the curve value and the **ISEF>1 MRT** setting, whichever is greater.

**Note:**

The **ISEF>1 MRT** setting can be made visible from setting management, only when the **Curve** setting is selected as any type of curve (all curves but DT selection).

**Note:**

If **ISEF>1 MRT** setting is set to zero, the setting is disabled and just the curve time will apply.

**ISEF>1 DT Adder** setting adds an additional fixed time delay to the curve operate characteristics.

**Note:**

The **ISEF>1 DT Adder** setting can be made visible from setting management, only when the **Curve** setting is selected as any type of curve but FlexCurves.

**ISEF>1 Time Delay** setting sets the definite Time delay for the Sensitive Earth Fault TOC element, when operate time is selected as Definite Time.

**Note:**

The **ISEF>1 Time Delay** setting can be made visible from setting management, only when the **Curve** setting is selected as DT (Definite Time).

**ISEF>1 Reset Char** setting allows the selection of a Definite Time (DT) or Inverse reset time. If **DT** reset is selected, the Sensitive Earth Fault TOC element will reset after a time delay provided by **tRESET** setting. If **Inverse** reset is selected, the time to reset is calculated based on the reset equation for the selected inverse curve.

When using UK Long Time Inverse, Rectifier, FR Short Time Inverse, RI curves for the Operate characteristic, it is always recommended to use DT for the Reset characteristic.

## 7.7 BLOCKED OVERCURRENT PROTECTION

With Blocked Overcurrent schemes, the start contacts from downstream IEDs are connected to the blocking inputs of upstream IEDs. This allows identical current and time settings to be used on each of the IEDs in the scheme, as the device nearest to the fault does not receive a blocking signal and so trips discriminatively. This type of scheme therefore reduces the number of required grading stages, and consequently fault clearance times.

The principle of Blocked Overcurrent protection may be extended by setting fast-acting overcurrent elements on the incoming feeders to a substation, which are then arranged to be blocked by start contacts from the devices protecting the outgoing feeders. The fast-acting element is thus allowed to trip for a fault condition on the busbar, but is stable for external feeder faults due to the blocking signal.

This type of scheme provides much reduced fault clearance times for busbar faults than would be the case with conventional time-graded overcurrent protection. The availability of multiple overcurrent and earth fault stages in GE Vernova's IED's allows additional time-graded overcurrent protection for back-up purposes.

### 7.7.1 BLOCKED OVERCURRENT IMPLEMENTATION

Blocked Overcurrent schemes can be implemented using the IEDs settings or the Flexlogic Equation Editor. The start outputs, available from each stage of the overcurrent and earth fault elements (including the sensitive earth fault element) can be mapped to output relay contacts. These outputs can then be connected to the relevant block inputs of the upstream IEDs via opto-inputs.

### 7.7.2 APPLICATION NOTES

#### 7.7.2.1 BUSBAR BLOCKING SCHEME





Figure 68: Simple busbar blocking scheme



**Figure 69: Simple busbar blocking scheme characteristics**

For further guidance on the use of blocked busbar schemes, refer to GE Vernova.



## CHAPTER 8

# RESTRICTED EARTH FAULT PROTECTION

---

## 8.1 CHAPTER OVERVIEW

---

The device provides extensive Restricted Earth Fault functionality. This chapter describes the operation of this function including the principles of operation, logic diagrams and applications.

This chapter contains the following sections:


Chapter Overview	180
REF Protection Principles	181
Restricted Earth Fault Protection Implementation	187
Application Notes	190

## 8.2 REF PROTECTION PRINCIPLES

Winding-to-core faults in a transformer can be caused by insulation breakdown. Such faults can have very low fault currents, but they still need to be picked up. If such faults are not identified, this could result in extreme damage to very expensive equipment.

Often the associated fault currents are lower than the nominal load current. Neither overcurrent nor percentage differential protection is sufficiently sensitive in this case. We therefore require a different type of protection arrangement. Not only should the protection arrangement be sensitive, but it must create a protection zone, which is limited to each transformer winding. Restricted Earth Fault protection (REF) is the protection mechanism used to protect individual transformer winding sets.


The following figure shows a REF protection arrangement for protecting the delta side of a delta-star transformer.



**Figure 70: REF protection for delta side**

The current transformers measuring the currents in each phase are connected in parallel. The currents from all three phases are summed to form a differential current, sometimes known as a spill current. Under normal operating conditions the currents of the three phases add up to zero resulting in zero spill current. A fault on the star side will also not result in a spill current, as the fault current would simply circulate in the delta windings. However, if any of the three delta windings were to develop a fault, the impedance of the faulty winding would change and that would result in a mismatch between the phase currents, resulting in a spill current. If the spill current is large enough, it will trigger a trip command.

The following figure shows a REF protection arrangement for the star side of a delta-star transformer.



**Figure 71: REF protection for star side**

Here we have a similar arrangement of current transformers connected in parallel. The difference is that we need to measure the zero sequence current in the neutral line as well. An external unbalanced fault causes zero sequence current to flow through the neutral line, resulting in uneven currents in the phases, which could cause the protection to maloperate. By measuring this zero sequence current and placing it in parallel with the other three, the currents

are balanced, resulting in stable operation. Now only a fault inside the star winding can create an imbalance sufficient to cause a trip.

### 8.2.1 RESISTANCE-EARTHED STAR WINDINGS

Most distribution systems use resistance-earthed systems to limit the fault current. Consider the diagram below, which depicts an earth fault on the star winding of a resistance-earthed Dyn transformer (Dyn = Delta-Star with star-point neutral connection).




Figure 72: REF protection for resistance-earthed systems

The value of fault current ( $I_F$ ) depends on two factors:

- The value of earthing resistance (which makes the fault path impedance negligible)
- The fault point voltage (which is governed by the fault location)

Because the fault current ( $I_F$ ) is governed by the resistance, its value is directly proportional to the location of the fault.

A restricted earth fault element is connected to measure  $I_F$  directly. This provides very sensitive earth fault protection. The overall differential protection is less sensitive, since it only measures the HV current  $I_S$ . The value of  $I_S$  is limited by the number of faulty secondary turns in relation to the HV turns.

### 8.2.2 SOLIDLY-EARTHED STAR WINDINGS

Most transmission systems use solidly-earthed systems. Consider the diagram below, which depicts an earth fault on the star winding of a solidly-earthed Dyn transformer.




Figure 73: REF protection for solidly earthed system

In this case, the fault current  $I_F$  is dependant on:

- The leakage reactance of the winding
- The impedance in the fault path
- The fault point voltage (which is governed by the fault location)

In this case, the value of fault current ( $I_F$ ) varies with the fault location in a complex manner.

A restricted earth fault element is connected to measure  $I_F$  directly. This provides very sensitive earth fault protection.

For solidly earthed systems, the operating current for the transformer differential protection is still significant for faults over most of the winding. For this reason, independent REF protection may not have been previously considered, especially where an additional device would have been needed. But with this product, it can be applied without extra cost.

---

### 8.2.3 THROUGH FAULT STABILITY

In an ideal world, the CTs either side of a differentially protected system would be identical with identical characteristics to avoid creating a differential current. However, in reality CTs can never be identical, therefore a certain amount of differential current is inevitable. As the through-fault current in the primary increases, the discrepancies introduced by imperfectly matched CTs is magnified, causing the differential current to build up. Eventually, the value of the differential current reaches the pickup current threshold, causing the protection element to trip. In such cases, the differential scheme is said to have lost stability. To specify a differential scheme's ability to restrain from tripping on external faults, we define a parameter called 'through-fault stability limit', which is the maximum through-fault current a system can handle without losing stability.

---

### 8.2.4 RESTRICTED EARTH FAULT TYPES

There are two different types of Restricted Earth Fault; Low Impedance REF (also known as Biased REF) and High Impedance REF. Each method compensates for the effect of through-fault errors in a different manner.

With Low Impedance REF, the through-fault current is measured and this is used to alter the sensitivity of the REF element accordingly by applying a bias characteristic. So the higher the through fault current, the higher the differential current must be for the device to issue a trip signal, Often a transient bias component is added to improve stability during external faults.

Low impedance protection used to be considered less secure than high impedance protection. This is no longer true as numerical IEDs apply sophisticated algorithms to match the performance of high-impedance schemes. Some advantages of using Low Impedance REF are listed below:

- There is no need for dedicated CTs. As a result CT cost is substantially reduced
- The wiring is simpler as it does not require an external resistor or Metrosil
- Common phase current inputs can be used
- It provides internal CT ratio mismatch compensation. It can match CT ratios up to 1:40 resulting flexibility in substation design and reduced cost
- Advanced algorithms make the protection secure

With High Impedance REF, there is no bias characteristic, and the trip threshold is set to a constant level. However, the High Impedance differential technique ensures that the impedance of the circuit is sufficiently high such that the differential voltage under external fault conditions is lower than the voltage needed to drive differential current through the device. This ensures stability against external fault conditions so the device will operate only for faults occurring inside the protected zone.

High Impedance REF protection responds to a voltage across the differential junction points. During external faults, even with severe saturation of some of the CTs, the voltage does not rise above certain level, because the other

CTs will provide a lower-impedance path compared with the device input impedance. The principle has been used for more than half a century. Some advantages of using High Impedance REF are listed below:

- It provides a simple proven algorithm, which is fast, robust and secure
- It is less sensitive to CT saturation

### 8.2.4.1 LOW IMPEDANCE REF PRINCIPLE

Low Impedance REF can be used for either delta windings or star windings in both solidly grounded and resistance grounded systems. The connection to a modern IED is as follows:




Figure 74: Low impedance REF connection

#### 8.2.4.1.1 LOW IMPEDANCE BIAS CHARACTERISTIC

Usually, a triple slope biased characteristic is used as follows:




Figure 75: Three-slope REF bias characteristic

The flat area of the characteristic is the minimum differential current required to cause a trip (operate current) at low bias currents. From the first kneepoint onwards, the operate current increases linearly with bias current, as shown by the lower slope on the characteristic. This lower slope provides sensitivity for internal faults. From the second knee point onwards, the operate current further increases linearly with bias current, but at a higher rate. The second slope provides stability under through fault conditions.

Note:

In Restricted Earth Fault applications, Bias Current Compensation is also known as Low Impedance REF.

### 8.2.4.2 HIGH IMPEDANCE REF PRINCIPLE

This scheme is very sensitive and can protect against low levels of fault current, typical of winding faults.

High Impedance REF protection is based on the differential principle. It works on the circulating current principle as shown in the following diagram.




Figure 76: High impedance REF principle

When subjected to heavy through faults the line current transformer may enter saturation unevenly, resulting in imbalance. To ensure stability under these conditions a series connected external resistor is required, so that most of the unbalanced current will flow through the saturated CT. As a result, the current flowing through the device will be less than the setting, therefore maintaining stability during external faults.


Voltage across REF element  $V_s = I_F (R_{CT2} + R_{L3} + R_{L4})$

Stabilising resistor  $R_{ST} = V_s / I_s - R_R$

where:

- $I_F$  = maximum secondary through fault current
- $R_R$  = device burden
- $R_{CT}$  = CT secondary winding resistance
- $R_{L2}$  and  $R_{L3}$  = Resistances of leads from the device to the current transformer
- $R_{ST}$  = Stabilising resistor

High Impedance REF can be used for either delta windings or star windings in both solidly grounded and resistance grounded systems. The connection to a modern IED are as follows:

**Figure 77: High impedance REF connection**



## 8.3 RESTRICTED EARTH FAULT PROTECTION IMPLEMENTATION

### 8.3.1 RESTRICTED EARTH FAULT PROTECTION SETTINGS

Restricted Earth Fault Protection is implemented in the Restricted E/F menu of the relevant settings group. It is here that the constants and bias currents are set.

The REF protection may be configured to operate as either a high impedance or biased element.

### 8.3.2 LOW IMPEDANCE REF

#### 8.3.2.1 SETTING THE BIAS CHARACTERISTIC

Low impedance REF uses a bias characteristic for increasing sensitivity and stabilising for through faults. The current required to trip the differential IED is called the Operate current. This Operate current is a function of the differential current and the bias current according to the bias characteristic.

The differential current is defined as follows:

$$I_{diff} = (\bar{I}_A + \bar{I}_B + \bar{I}_C) + K\bar{I}_N$$

The bias current is as follows:

$$I_{bias} = \frac{1}{2} \left\{ \max [ |I_A|, |I_B|, |I_C| ] + K |I_N| \right\}$$

where:


- K = Neutral CT ratio / Line CT ratio
- $I_N$  = current measured by the neutral CT

The allowable range for K is:

$$0.05 < K < 15 \text{ for standard CTs}$$

$$0.05 < K < 20 \text{ for sensitive CTs}$$

The operate current is calculated according to the following characteristic:



**Figure 78: REF bias characteristic**

The following settings are provided to define this bias characteristic:

- **IREF> Is1**: sets the minimum trip threshold
- **IREF> Is2**: sets the bias current kneepoint whereby the required trip current starts increasing
- **IREF> k1**: defines the first slope
- **IREF> k2**: defines the second slope

*Note:*

*Is1 and Is2 are relative to the line CT, which is always the reference CT.*

*Note:*

*In order to obtain the graphic above, Is2 should be Is1/K1. Do not set K1 = 0 (as in that case the unit will always trip when the operating current is over Is1). However, if Is2 = Is1/K1, then the second kneepoint moves to the first kneepoint, the lower slope that spans Is1/K1 to Is2 becomes non-existent and the restrain characteristic applied is that of the higher slope, K2).*

### 8.3.3 HIGH IMPEDANCE REF

The device provides a high impedance restricted earth fault protection function. An external resistor is required to provide stability in the presence of saturated line current transformers. Current transformer supervision signals do not block the high impedance REF protection. The appropriate logic must be configured in Flexlogic Equation Editor to block the high impedance REF when any of the above signals is asserted.

### 8.3.3.1 HIGH IMPEDANCE REF CALCULATION PRINCIPLES

The primary operating current ( $I_{op}$ ) is a function of the current transformer ratio, the device operate current ( $IREF > I_s$ ), the number of current transformers in parallel with a REF element ( $n$ ) and the magnetizing current of each current transformer ( $I_e$ ) at the stability voltage ( $V_s$ ). This relationship can be expressed in three ways:

1. The maximum current transformer magnetizing current to achieve a specific primary operating current with a particular operating current:

$$I_e < \frac{1}{n} \left( \frac{I_{op}}{CT \text{ ratio}} - [IREF > I_s] \right)$$

2. The maximum current setting to achieve a specific primary operating current with a given current transformer magnetizing current:

$$[IREF > I_s] < \left( \frac{I_{op}}{CT \text{ ratio}} - nI_e \right)$$

3. The protection primary operating current for a particular operating current with a particular level of magnetizing current:

$$I_{op} = (CT \text{ ratio}) ([IREF > I_s] + nI_e)$$

To achieve the required primary operating current with the current transformers that are used, you must select a current setting for the high impedance element, as shown in item 2 above. The value of the stabilising resistor ( $R_{st}$ ) can be calculated in the following manner.

$$R_{st} = \frac{V_s}{[IREF > I_s]} = \frac{I_F (R_{CT} + 2R_L)}{[IREF > I_s]}$$

where:

- $R_{CT}$  = the resistance of the CT winding
- $R_L$  = the resistance of the lead from the CT to the IED

*Note:*


*The above formula assumes negligible IED burden.*

We recommend a stabilising resistor, which is continuously adjustable up to its maximum declared resistance.

## 8.4 APPLICATION NOTES

### 8.4.1 STAR WINDING RESISTANCE EARTHED

Consider the following resistance earthed star winding below.



**Figure 79: Star winding, resistance earthed**

An earth fault on such a winding causes a current which is dependant on the value of earthing impedance. This earth fault current is proportional to the distance of the fault from the neutral point since the fault voltage is directly proportional to this distance.

The ratio of transformation between the primary winding and the short circuited turns also varies with the position of the fault. Therefore the current that flows through the transformer terminals is proportional to the square of the fraction of the winding which is short circuited.

The earthing resistor is rated to pass the full load current  $I_{FLC} = V1/\sqrt{3}R$


Assuming that  $V1 = V2$  then  $T2 = \sqrt{3}T1$

For a fault at  $x$  PU distance from the neutral, the fault current  $I_f = xV1/\sqrt{3}R$

Therefore the secondary fault current referred to the primary is  $I_{primary} = x^2 \cdot I_{FLC}/\sqrt{3}$

If the fault is a single end fed fault, the primary current should be greater than 0.2 pu ( $I_{s1}$  default setting) for the differential protection to operate. Therefore  $x^2/\sqrt{3} > 20\%$

The following diagram shows that 41% of the winding is protected by the differential element.



**Figure 80: Percentage of winding protected**

## 8.4.2 LOW IMPEDANCE REF PROTECTION APPLICATION

### 8.4.2.1 SETTING GUIDELINES FOR BIASED OPERATION


Two bias settings are provided in the REF characteristic. The K1 level of bias is applied up to through currents of  $I_{s2}$ , which is normally set to the rated current of the transformer. K1 is normally be set to 0% to give optimum sensitivity for internal faults. However, if any CT mismatch is present under normal conditions, then K1 may be increased accordingly, to compensate. We recommend a setting of 20% in this case.

K2 bias is applied for through currents above  $I_{s2}$  and would typically be set to 150%.

According to ESI 48-3 1977, typical settings for the  $I_{s1}$  thresholds are 10-60% of the winding rated current when solidly earthed and 10-25% of the minimum earth fault current for a fault at the transformer terminals when resistance earthed.

### 8.4.2.2 LOW IMPEDANCE REF SCALING FACTOR

The three line CTs are connected to the three-phase CTs, and the neutral CT is connected to the neutral CT input. These currents are then used internally to derive both a bias and a differential current quantity for use by the low impedance REF protection. The advantage of this mode of connection is that the line and neutral CTs are not differentially connected, so the neutral CT can also be used to provide the measurement for the Standby Earth Fault Protection. Also, no external components such as stabilizing resistors or Metrosils are required.



**Figure 81: Low impedance REF scaling factor**

Another advantage of Low Impedance REF protection is that you can use a neutral CT with a lower ratio than the line CTs in order to provide better earth fault sensitivity. In the bias calculation, the device applies a scaling factor to the neutral current. This scaling factor is as follows:

$$\text{Scaling factor} = K = \text{Neutral CT ratio} / \text{Line CT ratio}$$

This results in the following differential and bias current equations:

$$I_{diff} = (\bar{I}_A + \bar{I}_B + \bar{I}_C) + K\bar{I}_N$$

$$I_{bias} = \frac{1}{2} \left\{ \max[|I_A|, |I_B|, |I_C|] + K|I_N| \right\}$$

### 8.4.2.3 PARAMETER CALCULATIONS

Consider a solidly earthed 90 MVA 132 kV transformer with a REF-protected star winding. Assume line CTS with a ratio of 400:1.

**I<sub>s1</sub>** is set to 10% of the winding nominal current:

$$\begin{aligned} &= (0.1 \times 90 \times 10^6) / (\sqrt{3} \times 132 \times 10^3) \\ &= 39 \text{ Amps primary} \\ &= 39/400 = 0.0975 \text{ Amps secondary (approx 0.1 A)} \end{aligned}$$

**I<sub>s2</sub>** is set to the rated current of the transformer:

$$\begin{aligned} &= 90 \times 10^6 / (\sqrt{3} \times 132 \times 10^3) \\ &= 390 \text{ Amps primary} \\ &= 390/400 = 0.975 \text{ Amps secondary (approx 1 A)} \end{aligned}$$

Set **K1** to 0% and **K2** to 150%

## 8.4.3 HIGH IMPEDANCE REF PROTECTION APPLICATION

### 8.4.3.1 HIGH IMPEDANCE REF OPERATING MODES

In the examples below, the respective Line CTS and measurement CTs must have the same CT ratios and similar magnetising characteristics.




Figure 82: Hi-Z REF protection for a grounded star winding




Figure 83: Hi-Z REF protection for a delta winding




Figure 84: Hi-Z REF protection for autotransformer configuration


#### 8.4.3.2 SETTING GUIDELINES FOR HIGH IMPEDANCE OPERATION

This scheme is very sensitive and can protect against low levels of fault current in resistance grounded systems. In this application, the ***IREF>Is*** settings should be chosen to provide a primary operating current less than 10-25% of the minimum earth fault level.

This scheme can also be used in a solidly grounded system. In this application, the ***IREF>Is*** settings should be chosen to provide a primary operating current between 10% and 60 % of the winding rated current.

The following diagram shows the application of a high impedance REF element to protect the LV winding of a power transformer.





**Figure 85: High impedance REF for the LV winding**

#### 8.4.3.2.1 STABILITY VOLTAGE CALCULATION

The transformer full load current,  $I_{FLC}$ , is:

$$I_{FLC} = (90 \times 10^6) / (32 \times 10^3 \times \sqrt{3}) = 394 \text{ A}$$

To calculate the stability voltage the maximum through fault level should be considered. The maximum through fault level, ignoring the source impedance,  $I_F$ , is:

$$I_F = I_{FLC} / TX = 394 / 0.05 = 7873 \text{ A}$$

The required stability voltage,  $V_s$ , and assuming one CT saturated is:

$$V_s = K I_F (R_{CT} + 2R_L)$$

The following figure can be used to determine the K factor and the operating time. The K factor is valid when:

- $5 \leq X/R \leq 120$

and

- $0.5 I_n \leq I_f \leq 40 I_n$

We recommend a value of  $VK/V_s = 4$ .

With the transformer at full load current and percentage impedance voltage of 394A and 5% respectively, the prospective fault current is 7873 A and the required stability voltage  $V_s$  (assuming that one CT is saturated) is:

$$V_s = 0.9 \times 7873 \times (0.5 + 2 \times 0.98) / 400 = 45.5 \text{ V}$$

The CTs knee point voltage should be at least 4 times  $V_s$  so that an average operating time of 40 ms is achieved.

#### 8.4.3.2.2 PRIMARY CURRENT CALCULATION

The primary operating current should be between 10 and 60 % of the winding rated current. Assuming that the IED effective setting or primary operating current is approximately 30% of the full load current, the calculation below shows that a setting of less than 0.3 A is required.

Effective setting =  $0.3I_{FLC}/CT \text{ Ratio} = 0.3 \times 394/400 = \text{approximately } 0.3 \text{ A}$

#### 8.4.3.2.3 STABILISING RESISTOR CALCULATION

Assuming that a setting of 0.1A is selected the value of the stabilizing resistor,  $R_{ST}$ , required is

$$R_{ST} = V_s / (I_{REF} > I_{s1} \text{ (HV)}) = 45.5/0.1 = 455 \text{ ohms}$$

To achieve an average operating time of 40 ms,  $V_k/V_s$  should be 3.5.

The Kneepoint voltage is:

$$V_K = 4V_s = 4 \times 45.5 = 182 \text{ V.}$$

If the actual  $V_K$  is greater than 4 times  $V_s$ , then the K factor increases. In this case,  $V_s$  should be recalculated.

*Note:*  
K can reach a maximum value of approximately 1.

#### 8.4.3.2.4 CURRENT TRANSFORMER CALCULATION

The effective primary operating current setting is:

$$I_p = N(I_s + nI_e)$$

By re-arranging this equation, you can calculate the excitation current for each of the current transformers at the stability voltage. This turns out to be:

$$I_e = (0.3 - 0.1)/4 = 0.05 \text{ A}$$

In summary, the current transformers used for this application must have a kneepoint voltage of 182 V or higher (note that maximum  $V_k/V_s$  that may be considered is 16 and the maximum K factor is 1), with a secondary winding resistance of 0.5 ohms or lower and a magnetizing current at 45.5 V of less than 0.05 A.

Assuming a CT kneepoint voltage of 200 V, the peak voltage can be estimated as:

$$V_p = 2\sqrt{2}V_K(V_F - V_K) = 2\sqrt{2}(200)(9004 - 200) = 3753 \text{ V}$$

This value is above the peak voltage of 3000 V and therefore a non-linear resistor is required.

*Note:*  
The kneepoint voltage value used in the above formula should be the actual voltage obtained from the CT magnetizing characteristic and not a calculated value.

## CHAPTER 9

# CB FAIL PROTECTION

---

## 9.1 CHAPTER OVERVIEW

---

The device provides a Circuit Breaker Fail Protection function. This chapter describes the operation of this function including the principles, logic diagrams and applications.

This chapter contains the following sections:

Chapter Overview	198
Circuit Breaker Fail Protection	199
Circuit Breaker Fail Implementation	200
Circuit Breaker Fail Logic	202
Circuit Breaker Mapping	203
Application Notes	204

---

## 9.2 CIRCUIT BREAKER FAIL PROTECTION

---

When a fault occurs, one or more protection devices will operate and issue a trip command to the relevant circuit breakers. Operation of the circuit breaker is essential to isolate the fault and prevent, or at least limit, damage to the power system. For transmission and sub-transmission systems, slow fault clearance can also threaten system stability.

For these reasons, it is common practice to install Circuit Breaker Failure protection (CBF). CBF protection monitors the circuit breaker and establishes whether it has opened within a reasonable time. If the fault current has not been interrupted following a set time delay from circuit breaker trip initiation, the CBF protection will operate, whereby the upstream circuit breakers are back-tripped to ensure that the fault is isolated.

*Note:*  
*CBF protection is available in the P24D and P24N.*

---

## 9.3 CIRCUIT BREAKER FAIL IMPLEMENTATION

---

Circuit Breaker Failure Protection is implemented under the **SETPOINTS\CONTROL\CB FAIL\CB1 FAIL**.

The circuit breaker failure element determines that a breaker signaled to trip has not cleared a fault within a definite time. The circuit breaker failure scheme must Trip all breakers that can supply current to the faulted zone. Operation of a circuit breaker failure element causes clearing of a larger section of the power system than the initial Trip. As circuit breaker failure can result in tripping a large number of breakers, which can affect system safety and stability, a very high level of security is required.

The circuit breaker failure function monitors phase and neutral currents and/or status of the breaker while the protection trip or external initiation command exists. If circuit breaker failure is declared, the function operates the selected output relays, and raises signals.

The operation of a circuit breaker failure element consists of three stages: initiation, determination of a failure condition, and outputs.

---

### 9.3.1 CIRCUIT BREAKER FAILURE INITIATION

The protection signals initially sent to the breaker or external initiation (signal that initiates circuit breaker failure) initiates the circuit breaker failure scheme. The initiating signal should be sealed-in if primary fault detection can reset before the breaker failure timers have finished timing. The seal-in is supervised by current level, so it is reset when the fault is cleared. If required, an incomplete sequence seal-in reset can be implemented by using the initiating operands to initiate a FlexLogic timer, set longer than any breaker failure time, whose output operand is selected to block the breaker failure scheme.

When the scheme is initiated, it sends a Trip signal, after a pickup delay, to the circuit breaker initially signalled to trip (this function is configured as Re-Trip and phase and neutral overcurrent condition is satisfied). This reduces the possibility of widespread tripping that can result from a declaration of a failed circuit breaker.

---

### 9.3.2 CIRCUIT BREAKER FAILURE DETERMINATION

The schemes determine a circuit breaker failure condition supervised by one of the following:

- Current supervision only
- Circuit breaker status only
- Both (current and circuit breaker status)

Each type of supervision is equipped with a time delay, after which a failed circuit breaker is declared and trip signals are sent to all breakers required to clear the zone. The delays are associated with breaker failure timers 1, 2, and 3.

Timer 1 logic is supervised by current level only. If fault current is detected after the delay interval, an output is issued. The continued presence of current indicates that the breaker has failed to interrupt the circuit. This logic detects a breaker that opens mechanically but fails to interrupt fault current.

Timer 2 logic is supervised by both current supervision and circuit breaker status. If the circuit breaker is still closed (as indicated by the auxiliary contact) and fault current is detected after the delay interval, an output is issued.

Timer 3 logic is supervised by a circuit breaker auxiliary contact only. There is no current level check in this logic as it is intended to detect low magnitude faults. External logic may be created to include the control switch contact used to indicate that the circuit breaker is in out-of-service mode, disabling this logic when the circuit breaker is out-of-service for maintenance.

Timer 1 and 2 logic provide two levels of current supervision - high-set and low-set - that allow the supervision level to change (for example: from a current which flows before a circuit breaker inserts an opening resistor into the faulted circuit to a lower level after resistor insertion). The high-set detector is enabled after the timeout of timer 1 or 2, along with a timer low-set delay that enables the low-set detector after its delay interval. The delay interval between high-set and low-set is the expected breaker opening time. Both current detectors provide a fast operating

time for currents at small multiples of the pickup value. The overcurrent detectors are required to operate after the circuit breaker failure delay interval to eliminate the need for very fast resetting overcurrent detectors.

---

### 9.3.3 CIRCUIT BREAKER FAILURE OUTPUTS

The outputs from the circuit breaker failure schemes are:

- Re-trip of the protected breaker
- FlexLogic operand that reports on the operation of the portion of the scheme where high-set or low-set current supervision is used
- FlexLogic operand that reports on the operation of the portion of the scheme where 52b status supervision is used only
- FlexLogic operand that initiates tripping required to clear the faulted zone. The Breaker Failure output can be sealed-in for an adjustable period

## 9.4 CIRCUIT BREAKER FAIL LOGIC





Figure 86: Circuit Breaker fail logic



---

## 9.5 CIRCUIT BREAKER MAPPING

---



**Figure 87: Circuit Breaker mapping**

## 9.6 APPLICATION NOTES

### 9.6.1 RESET MECHANISMS FOR CB FAIL TIMERS

It is common practise to use low set undercurrent elements to indicate that circuit breaker poles have interrupted the fault or load current. This covers the following situations:

- Where circuit breaker auxiliary contacts are defective, or cannot be relied on to definitely indicate that the breaker has tripped.
- Where a circuit breaker has started to open but has become jammed. This may result in continued arcing at the primary contacts, with an additional arcing resistance in the fault current path. Should this resistance severely limit fault current, the initiating protection element may reset. Therefore, reset of the element may not give a reliable indication that the circuit breaker has opened fully.

For any protection function requiring current to operate, the device uses operation of undercurrent elements to detect that the necessary circuit breaker poles have tripped and reset the CB fail timers. However, the undercurrent elements may not be reliable methods of resetting CBF in all applications. For example:

- Where non-current operated protection, such as under/overvoltage or under/overfrequency, derives measurements from a line connected voltage transformer. Here, I< only gives a reliable reset method if the protected circuit would always have load current flowing. In this case, detecting dropoff of the initiating protection element might be a more reliable method.
- Where non-current operated protection, such as under/overvoltage or under/overfrequency, derives measurements from a busbar connected voltage transformer. Again using I< would rely on the feeder normally being loaded. Also, tripping the circuit breaker may not remove the initiating condition from the busbar, and so dropoff of the protection element may not occur. In such cases, the position of the circuit breaker auxiliary contacts may give the best reset method.

### 9.6.2 SETTING GUIDELINES (CB FAIL TIMER)

The following timing chart shows the CB Fail timing during normal and CB Fail operation. The maximum clearing time should be less than the critical clearing time which is determined by a stability study. The CB Fail back-up trip time delay considers the maximum CB clearing time, the CB Fail reset time plus a safety margin. Typical CB clearing times are 1.5 or 3 cycles. The CB Fail reset time should be short enough to avoid CB Fail back-trip during normal operation.




Figure 88: CB fail timing

The following examples consider direct tripping of a 2-cycle circuit breaker. Typical timer settings to use are as follows:

CB Fail Reset Mechanism	tBF Time Delay	Typical Delay For 2 Cycle Circuit Breaker
Initiating element reset	CB interrupting time + element reset time (max.) + error in tBF timer + safety margin	$50 + 50 + 10 + 50 = 160$ ms
CB open	CB auxiliary contacts opening/closing time (max.) + error in tBF timer + safety margin	$50 + 10 + 50 = 110$ ms
Undercurrent elements	CB interrupting time + undercurrent element (max.) + safety margin operating time	$50 + 25 + 50 = 125$ ms

## CHAPTER 10

# CURRENT TRANSFORMER REQUIREMENTS

---

## 10.1 CHAPTER OVERVIEW

---

This chapter contains the following sections:

Chapter Overview	207
CT requirements	208

## 10.2 CT REQUIREMENTS

The current transformer requirements are based on a maximum fault current of 50 times the rated current ( $I_n$ ) with the device having an instantaneous overcurrent setting of 25 times the rated current. The current transformer requirements are designed to provide operation of all protection elements.

Where the criteria for a specific application are in excess of this, or the lead resistance exceeds the limiting lead resistance shown in the following table, the CT requirements may need to be modified according to the formulae in the subsequent sections:

Nominal Rating	Nominal Output	Accuracy Class	Accuracy Limited Factor	Limiting Lead Resistance
1A	2.5 VA	10P	20	1.3 ohms
5A	7.5 VA	10P	20	0.11 ohms

The formula subscripts used in the subsequent sections are as follows:

$K$  = A constant affected by the dynamic response of the IED

$I_{cn}$  = Maximum prospective secondary earth fault current or 31 times  $I>$  setting (whichever is lower) (amps)

$I_{cp}$  = Maximum prospective secondary phase fault current or 31 times  $I>$  setting (whichever is lower) (amps)

$I_f$  = Maximum through-fault current level (amps)

$I_{fn}$  = Maximum prospective secondary earth fault current (amps)

$I_{fp}$  = Maximum prospective secondary phase fault current (amps)

$I_n$  = Rated secondary current (amps)

$I_s$  = Current setting of REF elements (amps)

$I_{sn}$  = Stage 2 & 3 earth fault setting (amps)

$I_{sp}$  = Stage 2 and 3 setting (amps)

$I_{st}$  = Motor start up current referred to CT secondary side (amps)

$R_{CT}$  = Resistance of current transformer secondary winding (ohms)

$R_L$  = Resistance of a single lead from IED to current transformer (ohms)

$R_n$  = Impedance of the neutral current input at  $30I_n$  (ohms)

$R_p$  = Impedance of the phase current input at  $30I_n$  (ohms)

$R_{st}$  = Value of stabilising resistor for REF applications (ohms)

$V_K$  = Required CT knee-point voltage (volts)

$V_S$  = Required stability voltage

## 10.2.1 PHASE OVERCURRENT PROTECTION

### 10.2.1.1 DIRECTIONAL ELEMENTS

Time-delayed phase overcurrent elements

$$V_K = \frac{I_{cp}}{2} (R_{CT} + R_L + R_p)$$

Instantaneous phase overcurrent elements

$$V_K = \frac{I_{fp}}{2} (R_{CT} + R_L + R_p)$$

### 10.2.1.2 NON-DIRECTIONAL ELEMENTS

Time-delayed phase overcurrent elements

$$V_K = \frac{I_{cp}}{2} (R_{CT} + R_L + R_p)$$

Instantaneous phase overcurrent elements

$$V_K = I_{sp} (R_{CT} + R_L + R_p)$$

## 10.2.2 EARTH FAULT PROTECTION

### 10.2.2.1 DIRECTIONAL ELEMENTS

Instantaneous earth fault overcurrent elements

$$V_K = \frac{I_{fn}}{2} (R_{CT} + 2R_L + R_p + R_n)$$

### 10.2.2.2 NON-DIRECTIONAL ELEMENTS

Time-delayed earth fault overcurrent elements

$$V_K = \frac{I_{cn}}{2} (R_{CT} + 2R_L + R_p + R_n)$$

Instantaneous earth fault overcurrent elements

$$V_K = I_{sn} (R_{CT} + 2R_L + R_p + R_n)$$

## 10.2.3 SEF PROTECTION (RESIDUALLY CONNECTED)

### 10.2.3.1 DIRECTIONAL ELEMENTS

#### Time delayed SEF protection

$$V_K \geq \frac{I_{cn}}{2} (R_{CT} + 2R_L + R_p + Rn)$$

#### Instantaneous SEF protection

$$V_K \geq \frac{I_{fn}}{2} (R_{CT} + 2R_L + R_p + Rn)$$

### 10.2.3.2 NON-DIRECTIONAL ELEMENTS

#### Time delayed SEF protection

$$V_K \geq \frac{I_{cn}}{2} (R_{CT} + 2R_L + R_p + Rn)$$

#### Instantaneous SEF protection

$$V_K \geq \frac{I_{sn}}{2} (R_{CT} + 2R_L + R_p + Rn)$$

## 10.2.4 SEF PROTECTION (CORE-BALANCED CT)

### 10.2.4.1 DIRECTIONAL ELEMENTS

#### Instantaneous element

$$V_K \geq \frac{I_{fn}}{2} (R_{CT} + 2R_L + Rn)$$

**Note:**

Ensure that the phase error of the applied core balance current transformer is less than 90 minutes at 10% of rated current and less than 150 minutes at 1% of rated current.

### 10.2.4.2 NON-DIRECTIONAL ELEMENTS

#### Time delayed element

$$V_K \geq \frac{I_{cn}}{2} (R_{CT} + 2R_L + Rn)$$

#### Instantaneous element

$$V_K \geq I_{sn} (R_{CT} + 2R_L + Rn)$$



**Note:**

Ensure that the phase error of the applied core balance current transformer is less than 90 minutes at 10% of rated current and less than 150 minutes at 1% of rated current.

## 10.2.5 LOW IMPEDANCE REF PROTECTION

For  $X/R < 40$  and  $I_f < 15I_n$

$$V_K \geq 24I_n(R_{CT} + 2R_L)$$

For  $40 < X/R < 120$  and  $15I_n < I_f < 40I_n$

$$V_K \geq 48I_n(R_{CT} + 2R_L)$$

**Note:**

Class x or Class 5P CTs should be used for low impedance REF applications.

## 10.2.6 HIGH IMPEDANCE REF PROTECTION

The high impedance REF element will maintain stability for through-faults and operate in less than 40ms for internal faults, provided the following equations are met:

$$R_{st} = \frac{I_f(R_{CT} + 2R_L)}{I_s}$$

$$V_K \geq 4I_s R_{st}$$

**Note:**

Class x CTs should be used for high impedance REF applications.

## 10.2.7 HIGH IMPEDANCE BUSBAR PROTECTION

The high impedance bus bar protection element will maintain stability for through faults and operate for internal faults. You should select  $V_k/V_s$  based on the  $X/R$  of the system. The equation is:

$$V_s = K * I_f * (R_{CT} + R_L)$$

For  $X/R \leq 40$

$$V_k/V_s \geq 2$$

Typical operating time = 25 ms

For  $X/R > 40$

$$V_k/V_s \geq 4$$

Typical operating time = 30 ms

*Note:*

*K is a constant affected by the dynamic response of the device. K is always equal to 1.*

## 10.2.8 USE OF METROSIL NON-LINEAR RESISTORS

Current transformers can develop high peak voltages under internal fault conditions. Metrosils are used to limit these peak voltages to a value below the maximum withstand voltage (usually 3 kV).

You can use the following formulae to estimate the peak transient voltage that could be produced for an internal fault. The peak voltage produced during an internal fault is a function of the current transformer kneepoint voltage and the prospective voltage that would be produced for an internal fault if current transformer saturation did not occur.

$$V_p = 2\sqrt{(2VK(V_F - V_K))}$$

$$V_f = I_f(R_{CT} + 2R_L + R_{ST})$$

where:

- $V_p$  = Peak voltage developed by the CT under internal fault conditions
- $V_k$  = Current transformer kneepoint voltage
- $V_f$  = Maximum voltage that would be produced if CT saturation did not occur
- $I_f$  = Maximum internal secondary fault current
- $R_{CT}$  = Current transformer secondary winding resistance
- $R_L$  = Maximum lead burden from current transformer to IED
- $R_{ST}$  = IED stabilising resistor

You should always use Metrosils when the calculated values are greater than 3000 V. Metrosils are connected across the circuit to shunt the secondary current output of the current transformer from the device to prevent very high secondary voltages.

Metrosils are externally mounted and take the form of annular discs. Their operating characteristics follow the expression:

$$V = CI^{0.25}$$

where:

- $V$  = Instantaneous voltage applied to the Metrosil
- $C$  = Constant of the Metrosil
- $I$  = Instantaneous current through the Metrosil

With a sinusoidal voltage applied across the Metrosil, the RMS current would be approximately 0.52 x the peak current. This current value can be calculated as follows:

$$I_{RMS} = 0.52 \left( \frac{\sqrt{2}V_{S(RMS)}}{C} \right)^4$$

where:

- $V_{S(RMS)}$  = RMS value of the sinusoidal voltage applied across the metrosil.

This is due to the fact that the current waveform through the Metrosil is not sinusoidal but appreciably distorted.

The Metrosil characteristic should be such that it complies with the following requirements:

- The Metrosil current should be as low as possible, and no greater than 30 mA RMS for 1 A current transformers or 100 mA RMS for 5 A current transformers.
- At the maximum secondary current, the Metrosil should limit the voltage to 1500 V RMS or 2120 V peak for 0.25 second. At higher device voltages it is not always possible to limit the fault voltage to 1500 V rms, so higher fault voltages may have to be tolerated.

The following tables show the typical Metrosil types that will be required, depending on IED current rating, REF voltage setting etc.

### Metrosils for devices with a 1 Amp CT

The Metrosil units with 1 Amp CTs have been designed to comply with the following restrictions:

- The Metrosil current should be less than 30 mA rms.
- At the maximum secondary internal fault current the Metrosil should limit the voltage to 1500 V rms if possible.

The Metrosil units normally recommended for use with 1Amp CTs are as shown in the following table:

Device Voltage Setting	Nominal Characteristic		Recommended Metrosil Type	
	C	$\beta$	Single Pole IED	Triple Pole IED
Up to 125 V RMS	450	0.25	600A/S1/S256	600A/S3/1/S802
125 to 300 V RMS	900	0.25	600A/S1/S1088	600A/S3/1/S1195

*Note:*

*Single pole Metrosil units are normally supplied without mounting brackets unless otherwise specified by the customer.*

### Metrosils for devices with a 5 Amp CT

These Metrosil units have been designed to comply with the following requirements:

- The Metrosil current should be less than 100 mA rms (the actual maximum currents passed by the devices shown below their type description).
- At the maximum secondary internal fault current the Metrosil should limit the voltage to 1500 V rms for 0.25secs. At the higher IED settings, it is not possible to limit the fault voltage to 1500 V rms so higher fault voltages have to be tolerated.

The Metrosil units normally recommended for use with 5 Amp CTs and single pole IEDs are as shown in the following table:

Secondary Internal Fault Current	Recommended Metrosil Types for Various Voltage Settings			
Amps RMS	Up to 200 V RMS	250 V RMS	275 V RMS	300 V RMS
50A	600A/S1/S1213 C = 540/640 35 mA RMS	600A/S1/S1214 C = 670/800 40 mA RMS	600A/S1/S1214 C = 670/800 50 mA RMS	600A/S1/S1223 C = 740/870 50 mA RMS
100A	600A/S2/P/S1217 C = 470/540 70 mA RMS	600A/S2/P/S1215 C = 570/670 75 mA RMS	600A/S2/P/S1215 C = 570/670 100 mA RMS	600A/S2/P/S1196 C = 620/740 100 mA RMS
150A	600A/S3/P/S1219 C = 430/500 100 mA RMS	600A/S3/P/S1220 C = 520/620 100 mA RMS	600A/S3/P/S1221 C = 570/670 100 mA RMS	600A/S3/P/S1222 C = 620/740 100 mA RMS

In some situations single disc assemblies may be acceptable, contact GE Vernova for detailed applications.

**Note:**

*The Metrosils recommended for use with 5 Amp CTs can also be used with triple pole devices and consist of three single pole units mounted on the same central stud but electrically insulated from each other. To order these units please specify "Triple pole Metrosil type", followed by the single pole type reference. Metrosil for higher voltage settings and fault currents are available if required.*

**10.2.9 USE OF ANSI C-CLASS CTS**

Where American/IEEE standards are used to specify CTs, the C class voltage rating can be used to determine the equivalent knee point voltage according to IEC. The equivalence formula is:

$$V_k = 1.05(C \text{ rating in volts}) + 100R_{CT}$$

## CHAPTER 11

# VOLTAGE PROTECTION FUNCTIONS

---

## 11.1 CHAPTER OVERVIEW

---

The device provides a wide range of voltage protection functions. This chapter describes the operation of these functions including the principles, logic diagrams and applications.

This chapter contains the following sections:

Chapter Overview	216
Phase Reversal Protection	217
Undervoltage Protection	220
Overvoltage Protection	224
Residual Overvoltage Protection	227
Negative Sequence Overvoltage Protection	231
Positive Sequence Undervoltage Protection	233

## 11.2 PHASE REVERSAL PROTECTION

### 11.2.1 PHASE REVERSAL IMPLEMENTATION

The IED can detect the phase sequence rotation of the three phase voltages.

When all three Phase-to-Phase Voltages ( $V_{ab}$ ,  $V_{bc}$  and  $V_{ca}$ ) are greater than 50% of  $V_T$  (\*1) and, if the phase rotation of the three phase voltages is not the same as the **Phase Sequence** or **Rev Ph Seq - VT** (\*2) settings (programmed at **SETPOINTS\SYSTEM\POWER SYSTEM** path), and there is no fuse failure (*VTS Fast Block* operand is not asserted) and the function is not Inhibit by any other operand (configured at **Inhibit** setting), either an Alarm or a Trip (depending on the setting value configured at the **Function** setting) will occur within the programmed **Delay** setting time.

**Note:**

(\*1)  $V_T$  is the secondary voltage programmed at **Main VT Sec'y** setting at **SETPOINTS\SYSTEM\VT RATIO** path.  $VT\ Ratio = \text{Main VT Primary/Main VT Sec'y}$ .

**Note:**

(\*2) For details about **Phase Sequence**, **Rev Ph Seq - VT** and **Rev Ph Seq - CT** settings and Reverse Phase Sequence Rotation implementation, refer to Reverse Phase Sequence Rotation under Power System in the System sub-chapter of the Configuration chapter.

Phase Reversal Current Mode (\*3) calculation option (when **Enable Curr Mode** setting is set to *Yes*) is provided to detect phase reversal using currents when voltages are less than 50% of  $V_T$  or voltages are not available.

When all three Phase Current ( $I_A$ ,  $I_B$  and  $I_C$ ) are greater than 5% of FLA, if the phase rotation of the three phase currents is not the same as the **Phase Sequence** or **Rev Ph Seq - CT** (\*2) settings (programmed at **SETPOINTS\SYSTEM\POWER SYSTEM** path), and the function is not Inhibited (operand configured at **Inhibit** setting not asserted), either an Alarm or a Trip (depending on the setting value configured at the **Function** setting) will occur within the programmed **Delay** setting time.

Upon detection of the phase reversal, this element will also issue a *Ph Rev Inhibit* operand to inhibit the starting of the motor. The *Ph Rev Inhibit* operand is part of the *Start Inhibit* operand logic. For more information about *Start Inhibit* refer to the Start Supervision sub section under the Motor Control Functions section in the Monitoring and Control chapter.

The Phase Reversal element will be blocked automatically (inhibited) by the IED for three cycles when voltage or current phase rotation dynamically switches from forward to reverse or from reverse to forward. Dynamic switching of the phase rotation (ABC $\leftrightarrow$ ACB) can be achieved using the **Rev Ph Seq - VT** or **Rev Ph Seq - CT settings** (\*2).

**Note:**

In 2-Speed Motor applications, when 2-Speed Motor Protection is enabled (**2-Spd Mtr Prot** setting set to *Enabled*), and the Speed2 Motor Switch is true (operand assigned to **Spd2 Motor Sw** setting is asserted), then the **Spd2 Ph Rotation** setting (Standard ABC, Reverse ACB) is used to accommodate the reversed motor rotation at Speed2.

**Note:**

Speed2 settings are available at **SETPOINTS\SYSTEM\MOTOR\SETUP** path. For more details about Speed 2 configuration refer to Motor Setup Implementation under the Motor Setup Configuration in the System sub-chapter of the Configuration chapter.

The Phase Reversal function provides the following FlexLogic operands:

Flexlogic Operands	
Operand	Description
Ph Rev Start	The Phase Reversal element has picked up (start)
Ph Rev Trip	The Phase Reversal element has operated (trip)
Ph Rev Inhibit	The Phase Reversal start inhibit occurs

Phase Reversal settings can be found at **SETPOINT\PROTECTION\GROUP [1-6]\VOLTAGE PROT\PHASE REVERSAL** path.

The settings are as follows:

### Function

This setting enables the Phase Reversal functionality.

### Enable Curr Mode

When this setting is set to *No*, the Phase Reversal detection algorithm uses three phase voltages only when voltages are greater than 50% of VT.

When this setting is programmed as *Yes*, currents are used to detect phase reversal when voltages are less than 50% of VT or voltages are not available. The current based method is only activated after the measured currents are above 5% of the motor FLA.

### Delay

This setting specifies the pickup time delay of the element.

### tRESET

This setting defines the reset delay of the element.

### Inhibit

The Phase Reversal feature can be blocked (inhibited) by any FlexLogic operand configured on this setting when that operand is asserted.

### Rly OP[X]

Any assignable relay output contact can be selected to operate upon Phase Reversal operation.

### Events

Setting introduced in 8A release to allow the user to enable or disable the events related to this feature. By default, this setting is set to *Enabled*.

### Targets

Setting introduced in 8A release to allow the user to disable or set to *Latched* or *Self-Reset* the targets related to this feature. By default, this setting is set to *Self-Reset*.



### 11.2.2 PHASE REVERSAL LOGIC




Figure 89: Phase reversal logic

## 11.3 UNDERVOLTAGE PROTECTION

Undervoltage conditions may occur on a power system for a variety of reasons, some of which are outlined below:

- Undervoltage conditions can be related to increased loads, whereby the supply voltage will decrease in magnitude. This situation would normally be rectified by voltage regulating equipment such as AVRs (Auto Voltage Regulators) or On Load Tap Changers. However, failure of this equipment to bring the system voltage back within permitted limits leaves the system with an undervoltage condition, which must be cleared.
- If the regulating equipment is unsuccessful in restoring healthy system voltage, then tripping by means of an undervoltage element is required.
- Faults occurring on the power system result in a reduction in voltage of the faulty phases. The proportion by which the voltage decreases is dependant on the type of fault, method of system earthing and its location. Consequently, co-ordination with other voltage and current-based protection devices is essential in order to achieve correct discrimination.
- Complete loss of busbar voltage. This may occur due to fault conditions present on the incomer or busbar itself, resulting in total isolation of the incoming power supply. For this condition, it may be necessary to isolate each of the outgoing circuits, such that when supply voltage is restored, the load is not connected. Therefore, the automatic tripping of a feeder on detection of complete loss of voltage may be required. This can be achieved by a three-phase undervoltage element.
- Where outgoing feeders from a busbar are supplying induction motor loads, excessive dips in the supply may cause the connected motors to stall, and should be tripped for voltage reductions that last longer than a pre-determined time.

### 11.3.1 UNDERVOLTAGE PROTECTION IMPLEMENTATION

Undervoltage Protection is implemented under the path **SETPOINTS/PROTECTION/GROUP [1-6]/VOLTAGE PROT/PHASE UV**.

The product provides four stages of Undervoltage protection with independent time delay characteristics.

Each stage provides a choice of operate characteristics, where you can select between:

- An IDMT characteristic
- A range of user-defined curves
- DT (Definite Time)

You set this using the **V<(n) Curve**, depending on the stage.

The IDMT characteristic is defined by the following formula:

$$T = D / (1 - V/V_{pkp})$$

where:

- T = Operating time in seconds
- D = Undervoltage Pickup Time Delay setpoint (for D = 0.00 operates instantaneously)
- V = Voltage as a fraction of the nominal VT Secondary Voltage
- V<sub>pkp</sub> = Undervoltage Pickup Level

If FlexCurves are selected, the operating time is determined based on the following equation:

- T = Flexcurve(V<sub>pkp</sub>/V)


The drop time detection can be delayed using **V<[X] Reset Time**. The Reset Mode is based on IEC 60255-151 reset characteristics, and can be configured to Definite or Dependant time.

The undervoltage stages can be configured either as phase-to-neutral or phase-to-phase voltages in the setting **V< [n] Meas Mode**.

Additional stages are included in order to provide multiple output types, such as alarm and trip stages. Alternatively, different time settings may be required depending upon the severity of the voltage dip. For example, motor loads will be able to cope with a small voltage dip for a longer time than a major one.

Outputs are available for single, double or three phase conditions via the **V< (n) Operate Mode** setting for each stage.

### 11.3.2 UNDERVOLTAGE PROTECTION LOGIC



**Figure 90: Undervoltage - single and three phase tripping mode (single stage)**

The Undervoltage protection function detects when the voltage magnitude for a certain stage falls short of a set threshold. If this happens a **Start** signal, signifying the "Start of protection", is produced. This Start signal can be blocked by the **VTS Fast Block** signal and a  **$V < (n)$  Min Voltage** threshold setting. This **Start** signal is applied to the timer module to produce the **Trip** signal. For each stage, there are three Phase undervoltage detection modules,

one for each phase. The three **Start** signals from each of these phases are OR'd together to create a 3-phase Start signal (**V<(n) Start**), which can be activated when any of the three phases start (Any Phase), or when all three phases start (Three Phase), depending on the chosen **V<(n) Operate Mode** setting.

The outputs of the timer modules are the trip signals which are used to drive the tripping output relay. These tripping signals are also OR'd together to create a 3-phase Trip signal, which are also controlled by the **V<(n) Operate Mode** setting.

In some cases, we do not want the undervoltage element to trip; for example, when the protected feeder is de-energised, or the circuit breaker is opened, an undervoltage condition would obviously be detected, but we would not want to start protection. To cater for this, a **V<(n) Min Voltage** threshold setting blocks the **Start** signal for each phase.

---

### 11.3.3 APPLICATION NOTES

#### 11.3.3.1 UNDERVOLTAGE SETTING GUIDELINES

In most applications, undervoltage protection is not required to operate during system earth fault conditions. If this is the case you should select phase-to-phase voltage measurement, as this quantity is less affected by single-phase voltage dips due to earth faults.

The voltage threshold setting for the undervoltage protection should be set at some value below the voltage excursions that may be expected under normal system operating conditions. This threshold is dependant on the system in question but typical healthy system voltage excursions may be in the order of 10% of nominal value.

The same applies to the time setting. The required time delay is dependant on the time for which the system is able to withstand a reduced voltage.

If motor loads are connected, then a typical time setting may be in the order of 0.5 seconds.

## 11.4 OVERVOLTAGE PROTECTION

Overvoltage conditions are generally related to loss of load conditions, whereby the supply voltage increases in magnitude. This situation would normally be rectified by voltage regulating equipment such as AVRs (Auto Voltage Regulators) or On Load Tap Changers. However, failure of this equipment to bring the system voltage back within permitted limits leaves the system with an overvoltage condition which must be cleared.

**Note:**

During earth fault conditions on a power system there may be an increase in the healthy phase voltages. Ideally, the system should be designed to withstand such overvoltages for a defined period of time.

### 11.4.1 OVERVOLTAGE PROTECTION IMPLEMENTATION

Overvoltage Protection is implemented under the path **SETPOINTS/PROTECTION/GROUP [1-6]/VOLTAGE PROT/PHASE OV**.

The product provides overvoltage protection with independent time delay characteristics.

Each stage provides a choice of operate characteristics, where you can select between:

- An IDMT characteristic
- A range of user-defined curves
- DT (Definite Time)

You set this using the **V>(n) Curve**.

The IDMT characteristic is defined by the following formula:

The operating time is defined by the following formula:

$$T = \frac{D}{\left(\frac{V}{V_{pickup}} - 1\right)}$$

when  $V > V_{pickup}$

Where:


- T = trip time in seconds
- D = Overvoltage Pickup Delay setpoint
- V = actual phase-phase voltage
- Vpickup = Overvoltage Pickup setpoint

The overvoltage stages can be configured either as phase-to-neutral or phase-to-phase voltages in the **V>(n) Meas Mode** setting.

Additional stages are included in order to provide multiple output types, such as alarm and trip stages. Alternatively, different time settings may be required depending upon the severity of the voltage increase.

Outputs are available for single, double or three-phase conditions via the **V>(n) Operate Mode** setting for each stage.

## 11.4.2 OVERVOLTAGE PROTECTION LOGIC



**Figure 91: Overvoltage - single and three phase tripping mode (single stage)**

The Overvoltage protection function detects when the voltage magnitude for a certain stage exceeds a set threshold. If this happens a **Start** signal, signifying the "Start of protection", is produced. This Start signal can be blocked by the **Inhibit** signal. This start signal is applied to the timer module to produce the **Trip** signal. For each stage, there are three Phase overvoltage detection modules, one for each phase. The three **Start** signals from each of these phases are OR'd together to create a 3-phase Start signal (**V>(n) Start**), which can then be activated when any of the three phases start (Any Phase), or when all three phases start (Three Phase), depending on the chosen **V>(n) Operate Mode** setting.

The outputs of the timer modules are the trip signals which are used to drive the tripping output relay. These tripping signals are also OR'd together to create a 3-phase Trip signal, which are also controlled by the **V>(n) Operate Mode** setting.

---

### 11.4.3 APPLICATION NOTES

#### 11.4.3.1 OVERVOLTAGE SETTING GUIDELINES

The provision of multiple stages and their respective operating characteristics allows for a number of possible applications:

- Definite Time can be used for both stages to provide the required alarm and trip stages.
- Use of the IDMT characteristic allows grading of the time delay according to the severity of the overvoltage. As the voltage settings for both of the stages are independent, the second stage could then be set lower than the first to provide a time-delayed alarm stage.
- If only one stage of overvoltage protection is required, or if the element is required to provide an alarm only, the remaining stage may be disabled.

This type of protection must be co-ordinated with any other overvoltage devices at other locations on the system.



## 11.5 RESIDUAL OVERVOLTAGE PROTECTION

On a healthy three-phase power system, the sum of the three-phase to earth voltages is nominally zero, as it is the vector sum of three balanced vectors displaced from each other by 120°. However, when an earth fault occurs on the primary system, this balance is upset and a residual voltage is produced. This condition causes a rise in the neutral voltage with respect to earth. Consequently this type of protection is also commonly referred to as 'Neutral Voltage Displacement' or NVD for short.

This residual voltage may be derived (from the phase voltages) or measured (from a measurement class open delta VT). Derived values will normally only be used where the model does not support measured functionality (a dedicated measurement class VT). If a measurement class VT is used to produce a measured Residual Voltage, it cannot be used for other features such as Check Synchronisation.

This offers an alternative means of earth fault detection, which does not require any measurement of current. This may be particularly advantageous in high impedance earthed or insulated systems, where the provision of core balanced current transformers on each feeder may be either impractical, or uneconomic, or for providing earth fault protection for devices with no current transformers.

### 11.5.1 RESIDUAL OVERVOLTAGE PROTECTION IMPLEMENTATION

Residual Overvoltage Protection is implemented under the paths **SETPOINTS/PROTECTION/GROUP [1-6]/VOLTAGE PROT/RESIDUAL OV(D)**--for derived values.

Some applications require more than one stage. For example an insulated system may require an alarm stage and a trip stage. It is common in such a case for the system to be designed to withstand the associated healthy phase overvoltages for a number of hours following an earth fault. In such applications, an alarm is generated soon after the condition is detected, which serves to indicate the presence of an earth fault on the system. This gives time for system operators to locate and isolate the fault. The second stage of the protection can issue a trip signal if the fault condition persists.

The product provides Residual Overvoltage protection with independent time delay characteristics.

Each stage provides a choice of operate characteristics, where you can select between:

- An IDMT characteristic
- A range of user-defined curves
- DT (Definite Time)

The operating time is given by:

$$T = \frac{D}{\left(\frac{V}{V_{pickup}} - 1\right)}$$

when  $V > V_{pickup}$

Where:


- T = trip time in seconds
- D = overvoltage Pickup Delay setpoint
- V = measured or derived phase-phase voltage
- Vpickup = overvoltage Pickup setpoint

You set this and all others in this section using the **VN(x)>(n) Curve** technically.

The residual voltage is derived from the phase voltages ( $V_{res} = V_a + V_b + V_c$ ).

The device derives the residual voltage internally from the three-phase voltage inputs supplied from either a 5-limb VT or three single-phase VTs. These types of VT design provide a path for the residual flux and consequently permit the device to derive the required residual voltage. In addition, the primary star point of the VT must be earthed. Three-limb VTs have no path for residual flux and are therefore unsuitable for this type of protection.

## 11.5.2 RESIDUAL OVERVOLTAGE LOGIC




**Figure 92: Residual overvoltage logic**

The Residual Overvoltage module (VN>) is a level detector that detects when the voltage magnitude exceeds a set threshold, for each stage. When this happens, the comparator output produces a **Start** signal (**VN>(n) Start**), which signifies the "Start of protection". This can be blocked by a **VTS Fast block** signal (in P24D only). This **Start** signal is applied to the timer module. The output of the timer module is the **VN> (n) Trip** signal which is used to drive the tripping output relay.

## 11.5.3 APPLICATION NOTES

### 11.5.3.1 CALCULATION FOR SOLIDLY EARTHED SYSTEMS

Consider a Phase-A to Earth fault on a simple radial system.




**Figure 93: Residual voltage for a solidly earthed system**

As can be seen from the above diagram, the residual voltage measured on a solidly earthed system is solely dependant on the ratio of source impedance behind the protection to the line impedance in front of the protection, up to the point of fault. For a remote fault far away, the  $Z_S/Z_L$ : ratio will be small, resulting in a correspondingly small residual voltage. Therefore, the protection only operates for faults up to a certain distance along the system. The maximum distance depends on the device setting.

**11.5.3.2 CALCULATION FOR IMPEDANCE EARTHED SYSTEMS**

Consider a Phase-A to Earth fault on a simple radial system.



**Figure 94: Residual voltage for an impedance earthed system**

An impedance earthed system will always generate a relatively large degree of residual voltage, as the zero sequence source impedance now includes the earthing impedance. It follows then that the residual voltage generated by an earth fault on an insulated system will be the highest possible value (3 x phase-neutral voltage), as the zero sequence source impedance is infinite.

### 11.5.3.3 SETTING GUIDELINES

The voltage setting applied to the elements is dependant on the magnitude of residual voltage that is expected to occur during the earth fault condition. This in turn is dependant on the method of system earthing employed.

Also, you must ensure that the protection setting is set above any standing level of residual voltage that is present on the system.

## 11.6 NEGATIVE SEQUENCE OVERVOLTAGE PROTECTION

Where an incoming feeder is supplying rotating plant equipment such as an induction motor, correct phasing and balance of the supply is essential. Incorrect phase rotation will result in connected motors rotating in the wrong direction. For directionally sensitive applications, such as elevators and conveyor belts, it is unacceptable to allow this to happen.

Imbalances on the incoming supply cause negative phase sequence voltage components. In the event of incorrect phase rotation, the supply voltage would effectively consist of 100% negative phase sequence voltage only.

### 11.6.1 NEGATIVE SEQUENCE OVERVOLTAGE IMPLEMENTATION


Negative Sequence Overvoltage Protection is implemented under the path **SETPOINTS\PROTECTION\GROUP [1-6]\VOLTAGE PROT\NEG SEQ OV**.

The device includes one Negative Phase Sequence Overvoltage element with multiple stages. Only Definite time is possible.

This element monitors the input voltage rotation and magnitude (normally from a bus connected voltage transformer) and may be interlocked with the motor contactor or circuit breaker to prevent the motor from being energised whilst incorrect phase rotation exists.

The element is enabled using the **V2>1 Function** setting.

### 11.6.2 NEGATIVE SEQUENCE OVERVOLTAGE LOGIC



**Figure 95: Negative sequence overvoltage logic**

The Negative Voltage Sequence Overvoltage module detects when the voltage magnitude exceeds a set threshold. When this happens, the comparator output Overvoltage Module produces a **Start** signal (e.g. for stage 1: **V2>1 Start**), which signifies the "Start of protection". This can be blocked by a **V2>1 Inhibit** signal. This **Start** signal is applied to the DT timer module. The output of the DT timer module is the trip signal which is used to drive the tripping output relay.

### 11.6.3 APPLICATION NOTES

#### 11.6.3.1 SETTING GUIDELINES

The primary concern is usually the detection of incorrect phase rotation (rather than small imbalances), therefore a sensitive setting is not required. The setting must be higher than any standing NPS voltage, which may be present due to imbalances in the measuring VT, device tolerances etc.

A setting of approximately 15% of rated voltage may be typical.

*Note:*  
Standing levels of NPS voltage ( $V_2$ ) are displayed in the **V2 Magnitude** setting under **MEASUREMENTS**.

The operation time of the element depends on the application, but a typical setting would be in the region of 5 seconds.

## 11.7 POSITIVE SEQUENCE UNDERVOLTAGE PROTECTION

### 11.7.1 POSITIVE SEQUENCE UNDERVOLTAGE IMPLEMENTATION

Positive Sequence Undervoltage Protection is implemented under the path **SETPOINTS\PROTECTIONGROUP [1-6]\VOLTAGE PROT\POS SEQ UV**.

The product provides Positive Sequence Undervoltage protection with independent time delay characteristics.

Each stage provides a choice of operate characteristics, where you can select between:

- An IDMT characteristic
- DT (Definite Time)

You set this using the **V1<1 Curve**

The IDMT characteristic is defined by the following formula:

$$T = \text{TMS} / (1 - V/V_{\text{pkp}})$$

where:

- T = Operating time in seconds
- TMS = Time Multiplier Setting
- V = Measured positive sequence voltage
- Vpkp = Undervoltage Pickup Level

Additional stages are included in order to provide multiple output types, such as alarm and trip stages.

### 11.7.2 POSITIVE SEQUENCE UNDERVOLTAGE LOGIC




Figure 96: Positive sequence undervoltage logic

## CHAPTER 12

# FREQUENCY PROTECTION FUNCTIONS



---

## 12.1 CHAPTER OVERVIEW

---

The device provides a range of frequency protection functions. This chapter describes the operation of these functions including the principles, logic diagrams and applications.

This chapter contains the following sections:

Chapter Overview	235
Frequency Protection Overview	236
Underfrequency Protection	237

---

## 12.2 FREQUENCY PROTECTION OVERVIEW

---

Power generation and utilisation needs to be well balanced in any industrial, distribution or transmission network. These electrical networks are dynamic entities, with continually varying loads and supplies, which are continually affecting the system frequency. Increased loading reduces the system frequency and generation needs to be increased to maintain the frequency of the supply. Conversely decreased loading increases the system frequency and generation needs to be reduced. Sudden fluctuations in load can cause rapid changes in frequency, which need to be dealt with quickly.

Unless corrective measures are taken at the appropriate time, frequency decay can go beyond the point of no return and cause widespread network collapse, which has dire consequences.

Protection devices capable of detecting low frequency conditions are generally used to disconnect unimportant loads in order to re-establish the generation-to-load balance. However, with such devices, the action is initiated only after the event and this form of corrective action may not be effective enough to cope with sudden load increases that cause large frequency decays in very short times. In such cases a device that can anticipate the severity of frequency decay and act to disconnect loads before the frequency reaches dangerously low levels, are very effective in containing damage. This is called instantaneous rate of change of frequency protection (ROCOF).

---

### 12.2.1 FREQUENCY PROTECTION IMPLEMENTATION

Frequency Protection is implemented under the path **SETPOINTS\PROTECTION\GROUP [1-6]\FREQUENCY PROT.**

The device includes multiple stages for the following frequency protection methods:

- Underfrequency Protection: abbreviated to  $F<(n)$
- Overfrequency Protection: abbreviated to  $F>(n)$
- Independent Rate of Change of Frequency Protection: abbreviated to  $df/dt>(n)$

Each stage can be disabled or enabled with the **Function** setting. The frequency protection can also be blocked by an undervoltage condition if required.

---

### 12.2.2 FREQUENCY PROTECTION COMMON SETUP

There are common settings that are applied to Under and Over Frequency elements when the Hi-Speed Frequency is enabled.

Hi-Speed Freq: Enables the Hi-Speed algorithm

Semicycles Set: Number of semi-cycles used for frequency estimation.

Semicycle Reset: Number of semi-cycles used for frequency estimation to evaluate the reset conditions.

---

## 12.3 UNDERFREQUENCY PROTECTION

---

A reduced system frequency implies that the net load is in excess of the available generation. Such a condition can arise, when an interconnected system splits, and the load left connected to one of the subsystems is in excess of the capacity of the generators in that particular subsystem. Industrial plants that are dependant on utilities to supply part of their loads will experience underfrequency conditions when the incoming lines are lost.

Many types of industrial loads have limited tolerances on the operating frequency and running speeds (e.g. synchronous motors). Sustained underfrequency has implications on the stability of the system, whereby any subsequent disturbance may damage equipment and even lead to blackouts. It is therefore essential to provide protection for underfrequency conditions.

---

### 12.3.1 UNDERFREQUENCY PROTECTION IMPLEMENTATION

Under Frequency Protection is implemented under the path **SETPOINTS\PROTECTION\GROUP [1-6]\FREQUENCY PROT.\UNDER FREQUENCY**.


The following settings are relevant for underfrequency:

- **F<(n) Function:** Determines whether the stage is underfrequency or disabled
- **F<(n) Freq Set:** Defines the frequency pickup setting
- **F<(n) Time Delay:** Sets the time delay
- **F<(n) Freq IP:** Normal or high-speed frequency can be selected as an input to detect under frequency

**Note:**

*When the source input for tracking frequency differs from that used for the Under Frequency function, due to frequency variations, you may encounter notable voltage measurement errors as the frequency of input signal moves away from the tracking frequency source input. For instance, when the setting 'Frequency Input' is configured to auxiliary voltage (from the 4th VT), while the tracking frequency comes from the main source's three-phase voltages, any difference between the frequency of the auxiliary voltage (Vx) and the three-phase voltages (3VT) leads to a magnitude measurement error in Vx, caused by the deviation of Vx frequency from the main frequency.*

### 12.3.2 UNDERFREQUENCY PROTECTION LOGIC



**Figure 97: Underfrequency logic (single stage)**

If the frequency is below the setting and not blocked the DT timer is started. If the frequency cannot be determined, the function is blocked.

### 12.3.3 APPLICATION NOTES

#### 12.3.3.1 SETTING GUIDELINES

In order to minimise the effects of underfrequency, a multi-stage load shedding scheme may be used with the plant loads prioritised and grouped. During an underfrequency condition, the load groups are disconnected sequentially, with the highest priority group being the last one to be disconnected.

The effectiveness of each load shedding stage depends on the proportion of power deficiency it represents. If the load shedding stage is too small compared with the prevailing generation deficiency, then there may be no improvement in the frequency. This should be taken into account when forming the load groups.

Time delays should be sufficient to override any transient dips in frequency, as well as to provide time for the frequency controls in the system to respond. These should not be excessive as this could jeopardize system stability. Time delay settings of 5 - 20 s are typical.

An example of a four-stage load shedding scheme for 50 Hz systems is shown below:

Stage	Element	Frequency Setting (Hz)	Time Setting (Sec)
1	F>1 Freq Set	49.0	20 s
2	F>2 Freq Set	48.6	20 s
3	F>3 Freq Set	48.2	10 s
4	F>4 Freq Set	47.8	10 s

The relatively long time delays are intended to provide sufficient time for the system controls to respond. This will work well in a situation where the decline of system frequency is slow. For situations where rapid decline of frequency is expected, this load shedding scheme should be supplemented by rate of change of frequency protection elements.

### 12.3.3.2 OVERFREQUENCY PROTECTION

An increased system frequency arises when the mechanical power input to a generator exceeds the electrical power output. This could happen, for instance, when there is a sudden loss of load due to tripping of an outgoing feeder from the plant to a load centre. Under such conditions, the governor would normally respond quickly to obtain a balance between the mechanical input and electrical output, thereby restoring normal frequency. Overfrequency protection is required as a backup to cater for cases where the reaction of the control equipment is too slow.

#### 12.3.3.2.1 OVERFREQUENCY PROTECTION IMPLEMENTATION

Over Frequency Protection is implemented under the path **SETPOINTS\PROTECTION\GROUP [1-6]\FREQUENCY PROT.\OVER FREQUENCY**.

The following settings are relevant for overfrequency:

- **F>(n) Function:** Determines whether the stage is overfrequency or disabled
- **F>(n) Freq Set:** Defines the frequency pickup setting
- **F>(n) Time Delay:** Sets the time delay
- **F>(n) Freq IP:** Normal or high-speed frequency can be selected as an input to detect over frequency

**Note:**

When the source input for tracking frequency differs from that used for the Over Frequency function, due to frequency variations, you may encounter notable voltage measurement errors as the frequency of input signal moves away from the tracking frequency source input. For instance, when the setting 'Frequency Input' is configured to auxiliary voltage (from the 4th VT), while the tracking frequency comes from the main source's three-phase voltages, any difference between the frequency of the auxiliary voltage (Vx) and the three-phase voltages (3VT) leads to a magnitude measurement error in Vx, caused by the deviation of Vx frequency from the main frequency.

12.3.3.2.2 OVERFREQUENCY PROTECTION LOGIC




Figure 98: Overfrequency logic (single stage)

If the frequency is above the setting and not blocked, the DT timer is started and after this has timed out, the trip is produced. If the frequency cannot be determined, the function is blocked.

12.3.3.2.3 APPLICATION NOTES

12.3.3.2.3.1 SETTING GUIDELINES

Following changes on the network caused by faults or other operational requirements, it is possible that various subsystems will be formed within the power network. It is likely that these subsystems will suffer from a generation/load imbalance. The "islands" where generation exceeds the existing load will be subject to overfrequency conditions. Severe over frequency conditions may be unacceptable to many industrial loads, since running speeds of motors will be affected. The overfrequency element can be suitably set to sense this contingency.


An example of two-stage overfrequency protection is shown below using stages 5 and 6. However, settings for a real system will depend on the maximum frequency that equipment can tolerate for a given period of time.

Stage	Element	Frequency Setting (Hz)	Time Setting (Sec.)
1	F>5 Freq Set	50.5	30
2	F>6 Freq Set	51.0	20

The relatively long time delays are intended to provide time for the system controls to respond and will work well in a situation where the increase of system frequency is slow.

For situations where rapid increase of frequency is expected, the protection scheme above could be supplemented by rate of change of frequency protection elements.

In the system shown below, the generation in the MV bus is sized according to the loads on that bus, whereas the generators linked to the HV bus produce energy for export to utility. If the links to the grid are lost, the generation will cause the system frequency to rise. This rate of rise could be used to isolate the MV bus from the HV system.



**Figure 99: Power system segregation based upon frequency measurements**

## CHAPTER 13

# POWER PROTECTION FUNCTIONS



---

## 13.1 CHAPTER OVERVIEW

---

Power protection applies to the P24D only.

This chapter contains the following sections:

Chapter Overview	243
Overpower Protection	244
Underpower Protection	247

## 13.2 OVERPOWER PROTECTION

With Overpower, we should consider two distinct conditions: Forward Overpower and Reverse Overpower.

A forward overpower condition occurs when the system load becomes excessive. A generator is rated to supply a certain amount of power and if it attempts to supply power to the system greater than its rated capacity, it could be damaged. Therefore overpower protection in the forward direction can be used as an overload indication. It can also be used as back-up protection for failure of governor and control equipment. Generally the Overpower protection element would be set above the maximum power rating of the machine.

A reverse overpower condition occurs if the generator prime mover fails. When this happens, the power system may supply power to the generator, causing it to motor. This reversal of power flow due to loss of prime mover can be very damaging and it is important to be able to detect this with a Reverse Overpower element.

### 13.2.1 OVERPOWER PROTECTION IMPLEMENTATION

Overpower Protection is implemented under the path **SETPOINTS\PROTECTIONGROUP [1-6]\POWER PROT. \OVERPOWER.**

The Overpower Protection element provides two stages of directional overpower for both active and reactive power. The directional element can be configured as forward or reverse and can activate single-phase or three-phase trips.

The elements use three-phase power and single phase power measurements as the energising quantities. A Start condition occurs when measurements exceed the setting threshold. A trip condition occurs if the Start condition is present for the set time delay. This can be inhibited by the VTS Slow Block and Pole Dead logic if desired.

The Start and Trip timer resets if the power falls below the dropout level or if an inhibit condition occurs. The reset mechanism is similar to the overcurrent functionality for a pecking fault condition, where the percentage of elapsed time for the operate timer is memorised for a set reset time delay. If the Start condition returns before the reset timer has timed out, the operate time initialises from the memorised travel value. Otherwise the memorised value is reset to zero after the reset time times out.

### 13.2.2 OVERPOWER LOGIC




Figure 100: Overpower logic

## 13.2.3 APPLICATION NOTES

### 13.2.3.1 FORWARD OVERPOWER SETTING GUIDELINES

The relevant power threshold settings should be set greater than the full load rated power.

The operating mode should be set to Forward.

A time delay setting ( $P>(n)$  *TimeDelay*) should be applied. This setting is dependant on the application. The delay on the reset timer ( $P>(n)$  *tRESET*), would normally be set to zero.

### 13.2.3.2 REVERSE POWER CONSIDERATIONS

A generator is expected to supply power to the connected system in normal operation. If the generator prime mover fails, it will begin to take motoring power from the power system (if the power system to which it is connected has other generating sources). The consequences of this reversal of power and the level of power drawn from the power system will be dependant on the type of prime mover.

Typical levels of motoring power and possible motoring damage that could occur for various types of generating plant are given in the following table.

Prime Mover	Motoring Power	Possible Damage (Percentage Rating)
Diesel Engine	5% - 25%	Risk of fire or explosion from unburned fuel
Motoring level depends on compression ratio and cylinder bore stiffness. Rapid disconnection is required to limit power loss and risk of damage.		
Gas Turbine	10% - 15% (Split-shaft) >50% (Single-shaft)	With some gear-driven sets, damage may arise due to reverse torque on gear teeth.
Compressor load on single shaft machines leads to a high motoring power compared to split-shaft machines. Rapid disconnection is required to limit power loss or damage.		
Hydraulic Turbines	0.2 - >2% (Blades out of water) >2.0% (Blades in water)	Blade and runner damage may occur with a long period of motoring
Power is low when blades are above tail-race water level. Hydraulic flow detection devices are often the main means of detecting loss of drive. Automatic disconnection is recommended for unattended operation.		
Steam Turbines	0.5% - 3% (Condensing sets) 3% - 6% (Non-condensing sets)	Thermal stress damage may be inflicted on low-pressure turbine blades when steam flow is not available to dissipate losses due to air resistance.
Damage may occur rapidly with non-condensing sets or when vacuum is lost with condensing sets. Reverse power protection may be used as a secondary method of detection and might only be used to raise an alarm.		

In some applications, the level of reverse power in the case of prime mover failure may fluctuate. This may be the case for a failed diesel engine. To prevent cyclic initiation and reset of the main trip timer, an adjustable reset time delay is provided. You will need to set this time delay longer than the period for which the reverse power could fall below the power setting. This setting needs to be taken into account when setting the main trip time delay.

**Note:**

A delay in excess of half the period of any system power swings could result in operation of the reverse power protection during swings.

### 13.2.3.3 REVERSE OVERPOWER SETTING GUIDELINES

Each stage of power protection can be selected to operate as a reverse power stage by setting  $P>(n)$  *Direction* to *Reverse*.

The relevant power threshold settings should be set to less than 50% of the motoring power.

The operating mode should be set to Reverse.

The reverse power protection function should be time-delayed to prevent false trips or alarms being given during power system disturbances or following synchronisation.

A time delay setting, of approximately 5 s would be typically applied.

The delay on the reset timer, ***P>1 tRESET*** or ***P>2 tRESET***, would normally be set to zero.

When settings of greater than zero are used for the reset time delay, the pickup time delay setting may need to be increased to ensure that false tripping does not result in the event of a stable power swinging event.

Reverse overpower protection can also be used for loss of mains applications. If the distributed generator is connected to the grid but not allowed to export power to the grid, it is possible to use reverse power detection to switch off the generator. In this case, the threshold setting should be set to a sensitive value, typically less than 2% of the rated power. It should also be time-delayed to prevent false trips or alarms being given during power system disturbances, or following synchronisation. A typical time delay is 5 seconds.

## 13.3 UNDERPOWER PROTECTION

Although the Underpower protection is directional and can be configured as forward or reverse, the most common application is for Low Forward Power protection.

When a machine is generating and the circuit breaker connecting the generator to the system is tripped, the electrical load on the generator is cut off. This could lead to overspeeding of the generator if the mechanical input power is not reduced quickly. Large turbo-alternators, with low-inertia rotor designs, do not have a high over speed tolerance. Trapped steam in a turbine, downstream of a valve that has just closed, can rapidly lead to over speed. To reduce the risk of over speed damage, it may be desirable to interlock tripping of the circuit breaker and the mechanical input with a low forward power check. This ensures that the generator circuit breaker is opened only after the mechanical input to the prime mover has been removed, and the output power has reduced enough such that overspeeding is unlikely. This delay in tripping the circuit breaker may be acceptable for non-urgent protection trips (e.g. stator earth fault protection for a high impedance earthed generator). For urgent trips however (e.g. stator current differential protection), this Low Forward Power interlock should not be used.

### 13.3.1 UNDERPOWER PROTECTION IMPLEMENTATION

Underpower Protection is implemented under the path **SETPOINTS\PROTECTION\GROUP [1-6]\POWER \UNDERPOWER\UNDERPOWER 1**.

The **UNDERPOWER** Protection element provides multiple stages of directional underpower for both active and reactive power. The directional element can be configured as forward or reverse and can activate single-phase or three-phase trips.

The elements use three-phase power and single phase power measurements as the energising quantity. A start condition occurs when two consecutive measurements fall below the setting threshold. A trip condition occurs if the start condition is present for the set trip time. This can be inhibited by the VTS slow block and pole dead logic if desired.

The Start and Trip timer resets if the power exceeds the dropout level or if an inhibit condition occurs. The reset mechanism is similar to the overcurrent functionality for a pecking fault condition, where the percentage of elapsed time for the operate timer is memorised for a set reset time delay. If the Start condition returns before the reset timer has timed out, the operate time initialises from the memorised travel value. Otherwise the memorised value is reset to zero after the reset time times out.

### 13.3.2 UNDERPOWER LOGIC




Figure 101: Underpower logic

### 13.3.3 APPLICATION NOTES

#### 13.3.3.1 LOW FORWARD POWER CONSIDERATIONS

The Low Forward Power protection can be arranged to interlock 'non-urgent' protection tripping using the Flexlogic Equation Editor. It can also be arranged to provide a contact for external interlocking of manual tripping. To prevent unwanted alarms and flags, a Low Forward Power protection element can be disabled when the circuit breaker is opened via Pole Dead logic.

The Low Forward Power protection can also be used to provide loss of load protection when a machine is motoring. It can be used for example to protect a machine which is pumping from becoming unprimed, or to stop a motor in the event of a failure in the mechanical transmission.

A typical application would be for pump storage generators operating in the motoring mode, where there is a need to prevent the machine becoming unprimed which can cause blade and runner damage. During motoring conditions, it is typical for the protection to switch to another setting group with the low forward power enabled and correctly set and the protection operating mode set to *Reverse*.

A low forward power element may also be used to detect a loss of mains or loss of grid condition for applications where the distributed generator is not allowed to export power to the system.

#### 13.3.3.2 LOW FORWARD POWER SETTING GUIDELINES

Each stage of power protection can be selected to operate as a forward power stage by setting ***P<(n) Direction*** to *Forward*.

When required for interlocking of non-urgent tripping applications, the threshold setting of the low forward power protection function should be less than 50% of the power level that could result in a dangerous overspeed condition on loss of electrical loading.

When required for loss of load applications, the threshold setting of the low forward power protection function, is system dependant, however, it is typically set to 10 - 20% below the minimum load. The operating mode should be set to operate for the direction of the load current, which would typically be reverse for a pump storage machine application where *Forward* is the Generating direction and *Reverse* is the motoring direction.

For interlocking non-urgent trip applications the time delay associated with the low forward power protection function could be set to zero. However, some delay is desirable so that permission for a non-urgent electrical trip is not given in the event of power fluctuations arising from sudden steam valve/throttle closure. A typical time delay is 2 seconds.

For loss of load applications the pickup time delay is application dependant but is normally set in excess of the time between motor starting and the load being established. Where rated power cannot be reached during starting (for example where the motor is started with no load connected) and the required protection operating time is less than the time for load to be established then it will be necessary to inhibit the power protection during this period. This can be done in the Flexlogic Equation Editor using AND logic and a pulse timer triggered from the motor starting to block the power protection for the required time.

When required for loss of mains or loss of grid applications where the distributed generator is not allowed to export power to the system, the threshold setting of the reverse power protection function, should be set to a sensitive value, typically <2% of the rated power.

The low forward power protection function should be time-delayed to prevent false trips or alarms being given during power system disturbances or following synchronisation. A time delay setting, of 5 s should be applied typically.

The delay on the reset timers would normally be set to zero.

To prevent unwanted alarms and flags, the protection element can be disabled when the circuit breaker is open via Pole Dead logic.

## CHAPTER 14

# MONITORING AND CONTROL

---

## 14.1 CHAPTER OVERVIEW

---

As well as providing a range of protection functions, the product includes comprehensive monitoring and control functionality.

This chapter contains the following sections:

Chapter Overview	250
Motor Records	251
Event Records	256
Disturbance Recorder	258
Data Logger	260
Fault Records	262
Event Data	263
Flex States	264
Flex Elements	265
Device Status	267
Measured Quantities	273
Opto-input Time Stamping	275
Power Factor	276
Breaker Arcing Current	281
CB Health Monitoring	284
CB State Monitoring	288
Setpoint Group	290
Motor Control Functions	291
Select Before Operate	312
Circuit Breaker/Contactor Control	317
Switch Status and Control	330
Harmonic Detection	334
Demand	336
Digital Counters	338
Loss Of Communications	339
Trip Bus	340
Digital Elements	342



## 14.2 MOTOR RECORDS

### 14.2.1 MOTOR START RECORDS

When a motor start status is detected by the P24x relay, a start data record is triggered and begins to sample and record the following parameters at a rate of 1 sample every 100ms.

Motor Start Record Values	Type
True RMS values of the phase A current (Ia)	FlexAnalog
True RMS values of the phase B current (Ib)	
True RMS values of the phase C current (Ic)	
Average of true RMS values of the three-phase currents (Iavg)	
True RMS value of the ground current (Ig)	
Current unbalance (%)	
True RMS values of the phase A-N, B-N, and C-N voltages (Van, Vbn, and Vcn) if VT is Wye connected or phase A-B, B-C and C-A voltages (Vab, Vbc, and Vca) if VT is delta connected)	
Average of the three-phase Voltage (V Avg L-N if VT is Wye Connected or V Avg L-L if VT is Delta Connected)	
Three-phase real power	
Three-phase reactive power	
Three-phase power factor	
Thermal capacity used (%)	
Frequency	
Motor Status (Stopped, Starting, Running, Overload, Tripped)	FlexLogic Operand

**Note:**

Voltage, power and frequency parameters are only available in P24D with voltage inputs.

1-second pre-trigger data and 59-second post-trigger data are recorded. The data record ignores all subsequent triggers and continues to record data until the active record is finished.

A total of 6 records are stored in the relay. Record #1 is the baseline record; it is written to, only by the first start that occurs after the user clears the motor start records. Records #2 to 6 are a rolling buffer of the last 5 motor starts. A new record automatically shifts the rolling buffer and overwrites the oldest record, #2.

The record files are formatted using the COMTRADE file format. The files can be downloaded and displayed via EnerVista D&I Setup software. All the files are stored in non-volatile memory, so that information is retained when power to the relay is lost.

The viewing, customizing, and saving of the Motor Start Records is the same as the Transient Records.

Clearing start records (**Records > Clear Records > Motor Start Records**) clears the stored files. The date and time will be recorded when clearing. An event 'Clear Start Rec' will be sent to the Event Record. The records can also be cleared using EnerVista D&I Setup.

### 14.2.2 MOTOR START STATISTICS

**Path: Records > Motor Start Statistics**

**START DATE/TIME**

Range: mm/dd/yy and hh:mm:ss Default: 01/01/08 and 00:00:00

**START ACCEL TIME**

Range: 0.000 to 250.000 s in steps of 0.001

Default: 0.000 s

**START EFFEC CURR**

Range: 0.00 to 20.00 x FLA in steps of 0.01 Default: 0.00 x FLA

**START PEAK CURR**

Range: 0.00 to 20.00 x FLA in steps of 0.01 Default: 0.00 x FLA

Up to five starts are reported. When the buffer is full the newest record overwrites the oldest one.

---

**14.2.3 LEARNED DATA**

The relay measures and records individual data records, all from actual motor operation, as indicated below. The latest individual data record can be viewed using the Learned Data feature on the relay. The data, when input cumulatively to the Learned Data Recorder (see below), can be used to evaluate changes/trends over time.

*Note:*

*Learned values are calculated even when features requiring them are disabled.*

The Learned Data recorder measures and records up to 250 data record "sets," all from actual motor operation. The data can be used to evaluate changes/trends over time. All available stored motor learned data records can only be retrieved using the EnerVista D&I Setup software from the menu **Records > Learned Data Records**.

Clearing learned data (**Records > Clear Records > Learned Data**) resets all these values to their minimum values and clears the stored file. The date and time is recorded when clearing. An event **Clear Learned Rec** is sent to the Event Record. The next record will be captured after N successful starts.

*Note:*

*Each of the learned features discussed below must not be used until at least N successful motor starts and stops have occurred, where N is defined by the setting in **Setpoints > System > Motor > Nb of Str to Lr**.*

The last stored Motor Learned Data records can be viewed from the following menu:

**Path: Records > Learned Data**

**Rec Since Clear**

This value shows the number of records since the last clear.

**Last Clear D/T**

Range: MM/DD/YY HH:MM:SS

This value is the date and time at which the record was cleared.

**Lrnd Accel Time**

Range: 0.000 to 250.000 s in steps of 0.001 s

The learned acceleration time is the longest acceleration time measured over the last N successful starts, where N is defined by the setting in Path: **Setpoints\System\Motor\Nb of Str to Lr**. Acceleration time is the amount of time the motor takes to reach the Running state. A successful motor start is one in which the motor reaches the running state.

If acceleration time is relatively consistent, the learned acceleration time plus suitable margin may be used to manually fine-tune the acceleration protection setting. The learned acceleration time should not be used until several successful motor starts have been measured.

### Lrnd Start Curr

*Range: 0.00 to 20.00 x FLA in steps of 0.01 x FLA*

The learned starting current is the average starting current measured over the last N successful starts, where N is defined by the setting in Path: **Setpoints\System\Motor\Nb of Str to Lr**. The effective current is used as starting current, as defined in the element of 'Acceleration Time'.

### Lrnd Start TCU

*Range: 0 to 100% in steps of 1%*

The learned start thermal capacity is the largest start thermal capacity used value calculated by the thermal model over the last N successful. Start thermal capacity used is the amount of thermal capacity used during starting.

If the thermal capacity used during starting is relatively consistent, the learned start thermal capacity used value plus suitable margin may be used to manually fine-tune the thermal start inhibit margin. See the Start Supervision section of this manual for a description of how the learned start thermal capacity used is calculated. The learned start thermal capacity used value should not be used until at least N successful motor starts have occurred.

P24 uses sliding window of length N successful motor starts to calculate the learned start TCU that is the largest TCU value from the N most recent successful starts.

All the values needed to make a relay power interruption transparent to last/learned acceleration time calculations, to last/learned last start TCU calculations, and to last/learned starting current calculations are maintained in non-volatile memory. (E.g. the N most recent "last" values).

### Last Accel Time

*Range: 0.000 to 250.000 s in steps of 0.001 s*

The last acceleration time is measured after a successful motor start.

### Last Start Curr

*Range: 0.00 to 20.00 x FLA in steps of 0.01 x FLA*

The last starting current is measured after a successful motor start.

### Last Start TCU

*Range: 0 to 100% in steps of 1%*

The last start thermal capacity used is measured after a successful motor start.

### Last Start D/T

*Range: MM/DD/YY HH:MM:SS*

This value specifies the date and time of the last start.

### Lrnd Avg Load

*Range: 0.00 to 20.00 x FLA in steps of 0.01 x FLA*

Learned average load is the average motor current, expressed as a multiple of FLA over a period of time, when the motor status is Running. The period of data window is  $t_{\text{AVER}}$ , specified in Path: **Setpoints\System\Motor\Load Avg Cal Prd**. If the run time of a start/stop sequence is less than  $t_{\text{AVER}}$ , the Learned Average Load will average all available samples. The calculation is ignored during motor starting. The data will be updated every  $t_{\text{AVER}}$  minutes once the motor status is Running. In the case of two-speed motors with different FLA values for the two speeds, the FLA used for each current sample is the one in effect at the time that sample was taken.

### Lrnd Avg kW

Learned average kW is the average motor real power when the motor status is Running. The period of data window is  $t_{\text{AVER}}$ , specified in Path: **Setpoints\System\Motor\Load Avg Cal Prd**. If the run time of a start/stop sequence is less than  $t_{\text{AVER}}$ , the Learned Average kW will average all available samples. The calculation is ignored during motor starting. The data will be updated every  $t_{\text{AVER}}$  minutes once the motor status is Running.

### Lrnd Avg kvar

*Range: 0.0 to 100000.0 kvar in steps of 0.1 x kvar*

Learned average kvar is the average motor reactive power when the motor status is Running. The mechanism is the same as the Learned Average kW.

### Lrnd Avg PF


*Range: -0.99 to 1.00 in steps of 0.01*

Learned average PF is the average motor power factor when the motor status is Running. The mechanism is the same as the Learned Average kW.

### Av Runtime (Days/Hr/Min)

*Range: 0 to 100000 Days; 0 to 23 Hours; 0 to 59 Minutes*

The average Run Time of the last N starts at the time the record was saved. If the amount of minutes exceeds 59, the Average Run Time (Hours) is increased by one, and this value rolls over to zero and continues. If the amount of hours exceeds 23, the Average Run Time (Days) is increased by one, and this value rolls over to zero and continues.



V80069

Figure 102: Motor learned data functionality

## 14.3 EVENT RECORDS

Multilin Agile IED's record events in an event log. This allows the user to establish the sequence of events that led up to a particular situation. For example, a change in a digital input signal or protection element output signal would cause an event record to be created and stored in the event log. This could be used to analyse how a particular power system condition was caused. These events are stored in the IEDs non-volatile memory. Each event is time tagged.

The event records can be displayed on an IEDs front panel but it is easier to view them through the EnerVista Configuration software.

The event records (Events) are available and always enabled for device, inputs, outputs, protection, monitoring and control features.

For Virtual Inputs and Virtual Outputs, the events can be **Enabled/Disabled** at the Events setting under the **SETPOINTS\INPUTS\VIRTUAL INPUTS\VIRTUAL I/P (n)** path for Virtual Inputs, and **SETPOINTS\INPUTS \VIRTUAL OUTPUTS\VIRTUAL O/P (n)** path for Virtual Outputs, where (n) is the number of Virtual Inputs and Outputs (1 to 128).

The Events (and their associated Event Data) can be accessed, either through the IEDs front panel (for Events and Event Data visualization with no file retrieval) at the **RECORDS\EVENTS** menu, or through the EnerVista Configuration software (for Events and Event Data visualization and file retrieval) by double clicking on the Evt file available at the **Browse Data** sub tab under the **Records** tab. The event file (\*.evt) can be exported and saved in a computer. This file contains some information for each event: event number, date and time, cause of event, and the values of the analogue parameters corresponding to the Event Data (if configured). All the events are displayed chronologically. The first event shown is always the latest event.

The device is capable of storing up to 2048 event records.

The Events can be deleted using the **Clear Events** command accessible through the Commands window on the **Monitor** tab on EnerVista Configuration software. The Events can also be deleted using the Clear All Records command (take into account that the Clear All Records command will clear all the records in the device, not just the Events). The Events can be also deleted by accessing to the same commands but under the **SETPOINT\DEVICE \CLEAR RECORDS** path, either directly through the IEDs front panel or through the EnerVista Configuration software **Setting** tab.

### 14.3.1 EVENT TYPES

There are several different types of event:

- Opto-input events (Change of state of opto-input)
- Relay output events (Change of state of output relay contact)
- Alarm and self-test error events
- Fault record events
- Standard events
- Security events

Standard events are further sub-categorised internally to include different pieces of information. These are:

- Protection events (starts and trips)
- Platform events

**Note:**

*The first event in the list is the most recent event to have occurred.*

### 14.3.1.1 OPTO-INPUT EVENTS

If one or more of the opto-inputs has changed state since the last time the protection algorithm ran (which runs at several times per cycle), a new event is created, which logs the logic states of the opto-inputs that have changed their status.

The opto-inputs status is also shown under the **DEVICE STATUS/OPTO INPUTS** path. The opto-inputs status is checked and updated at every protection algorithm run, whereas the information in the event log, although checked at every protection run, it is a snapshot at the time when the change of status of the opto-input takes place.

### 14.3.1.2 RELAY OUTPUT EVENTS

If one or more of the relay output contacts has changed state since the last time the protection algorithm ran (which runs at several times per cycle), a new event is created, which logs the logic states of the relay outputs that have changed their status.

The relay outputs status is also shown under the **DEVICE STATUS/RELAY OUTPUTS** path. The relay outputs status is checked and updated at every protection algorithm run, whereas the information in the event log, although checked at every protection run, it is a snapshot at the time when the change of status of the relay outputs takes place.

### 14.3.1.3 ALARM AND SELF-TEST ERROR EVENTS

The IED monitors itself on power up and continually thereafter. If it notices any problems, it will register an alarm event.

The same information is also shown in the **Targets** menu. This information is updated continuously, whereas the information in the event log is a snapshot at the time when the event was created.

### 14.3.1.4 FAULT RECORD EVENTS

An event record is created for every fault the IED detects. If the protection function that will operate for that fault is set to trip, the IED will record the trip event associated to that fault in the event recorder and its corresponding Last Trip Data information in a separate 'LastTripData' file containing the values of the parameters set in **Event Data** menu under the **SETPOINTS\DEVICE\EVENT DATA** path. For more details, refer to the Event Data and Last Trip Data sections.

The Last Trip Data file will only be available if the protection function is set to trip. If the protection function is not set to trip, the trip timestamp data and event data will be available in the event recorder but the 'LastTripData' file will not be created.

### 14.3.1.5 SECURITY EVENTS

An event record is generated each time a setting that requires an access level is executed.

### 14.3.1.6 PROTECTION EVENTS

The IED logs protection starts and trips as individual events. Protection events are special types of standard events.

Not all signals can generate an event. Those that can are shown in the **RECORD/EVENTS** menu when an event takes place.

## 14.4 DISTURBANCE RECORDER

The Disturbance Recorder feature allows the waveform capture of the calibrated analogue channels, together with selected values for the configurable digital and analogue channels available in the device. The configurable digital channels (up to 64) may be inputs, outputs, or internal digital signals (FlexLogic). The configurable analogue channels (up to 16) may be any analogue signal (FlexAnalog) available in the IED. The disturbance records can be extracted using the EnerVista Configuration software or using the SCADA system. The disturbance record file can be stored in COMTRADE format. This allows the use of other software packages other than EnerVista Configuration software to view the recorded data.

The user can configure how disturbance records are handled in case the available memory has reached capacity by selecting one of the options in the **Trigger mode** setting (*Overwrite* or *Protected* mode).

When *Overwrite* mode is selected, the new records overwrite the old ones, meaning the IED will always keep the newest records as per the selected number of records.

When *Protected* mode is selected, the IED will keep the maximum number of records corresponding to the value selected in the **Number of Record** setting, without saving further records beyond the value.

The number of cycles captured in a single disturbance record varies based on the **Number of Records** and **Sample per Cycle** setting values selected.

There is a fixed amount of data storage for the Disturbance Recorder: the higher the sampler rate, the less number of cycles captured per record. The number of records is user selectable up to 16 and the sampling rate can be selected from 8 up to 128 samples/cycle (8/16/32/64/128). The 128 samples/cycle used in the Disturbance Recorder is an interpolation from the 64 samples/cycle used for protection purposes.

To calculate the length in time corresponding to the length in cycles for a disturbance record the frequency of the system should be considered:  $Length\ in\ seconds = Length\ in\ cycles * 1/System\ frequency$ . For example, if the number of records is 1 and the sample rate is 8, the length in cycles would be 4895.125 and the length in time would be 81.47 seconds at a system frequency of 60 Hz and 97.77 seconds at 50 Hz.

The cycles per record (approximated values) for certain configuration of settings are shown in the following table:

Number of Records	Sample Rate	Length-Cycles
1	128	1064.125
1	64	1826.5
1	32	2846
1	16	3947.625
1	8	4895.125
5	128	354.625
5	64	608.75
5	32	948.625
5	16	1315.875
5	8	1631.625
16	128	125.125
16	64	214.875
16	32	334.75
16	16	464.375
16	8	575.875

The **Trigger Position** setting sets the value of pre-fault and post-fault within a disturbance record. If set to 20%, 20% of the stored file would be pre-fault data and 80% would be fault and post-fault data.



The disturbance record file can be generated upon change of state of at least one of the assigned triggers: **Trigger Source**, **Trigger on Start**, **Trigger on Oper.**, **Trigger on Alarm** or **Trigger on Trip**.

The Disturbance Recorder is supplied with data by the protection and control task once per cycle and collates the received data into the required length disturbance record.

It is not possible to view the disturbance records locally via the front panel LCD. The disturbance records should be extracted from the IED using suitable setting application software such as EnerVista Configuration or via SCADA system.

The Disturbance Recorder setting configuration can be made at the **SETPOINTS\DEVICE\DISTURB RECORDER** path accessing directly through the IEDs front panel, or through the EnerVista Configuration software **Setting** tab.

The Disturbance Recorder files can be visualized using the EnerVista Configuration software by double clicking on the **Osc(n)** file available at the **Browse Data** sub tab under the **Records** tab, where (n) is the number of the disturbance record file. The file in Comtrade format (\*.cfg, \*.dat, \*.hdr) can be exported and saved on a computer. A summary of the data contained in the file is also provided and can be accessed by double clicking on the **View Summary** icon for each file.

Basic Disturbance Recorder information, such as: records since last clear, total number of records, last clear date time and date and time of the record, can be also accessed through the IEDs front panel at **RECORDS \DISTURBANCE**, but the recommended way of accessing to the Disturbance Recorder data is using the EnerVista Configuration software.

The Disturbance Recorder files can be deleted using the **Clear Transient Records (Disturb Recorder)** command accessible through the **Commands** window on the **Monitor** tab on EnerVista Configuration software. The files can also be deleted using the **Clear All Records** command (this command will clear all the records in the device, not just those in the Disturbance Recorder). The Clear Records commands are also available at the **SETPOINT \DEVICE\CLEAR RECORDS** path, directly through the IEDs front panel, or through the EnerVista Configuration software **Setting** tab.

A **Trigger Waveform (Disturb Recorder)** command is also available in EnerVista Configuration **Commands** menu in **Monitor** tab. This command allows to create a Disturbance Record by user command. For more detail information regarding the Disturbance Recorder configuration refer to the dedicated Disturbance Recorder section in this chapter.

**Note:**

Use **Any Trip** Flexlogic operand for selecting the Relay 1 Trip behaviour for any setting using Flexlogic.

## 14.5 DATA LOGGER

The Data Logger samples and records up to 16 analogue parameters at a configured rate defined by the user. All data is stored in non-volatile memory as a 1 MB file, where the information is retained upon an IED control power loss.

The Data Logger can be configured with a few channels over a long period of time, or with larger number of channels for a shorter period of time. The IED automatically partitions the available memory between the channels in use.

The selection of the rate for logging data also affects the duration of recorded data. The Data Logger has longer duration for sampling rates at longer periods of time (i.e. *1 minute, 30 minutes, 1 hour*), as compared to sampling rates at short periods (i.e. *1 cycle, or 1 second*).

The length covered by the Data Logger record can be estimated with the following formula (being 0x100000 1MB in hexadecimal):

$$\text{Data Logger Record Length} = \frac{0x100000}{8 + \text{Actual Number of Configure Analogue Channels} \cdot 2} \cdot \text{Rate}$$

The Data Logger record length (approximated values) for certain configuration of settings are shown in the following table:

File Size	Sampling Rate [ sec ]		Number of Channels	Time-Window Covered			
				[sec]	[min]	[hour]	[day]
1048576	1 cycle	60 Hz (0.0167 s)	1	1747.6	29.1	0.5	0.0
			8	728.2	12.1	0.2	0.0
			16	436.9	7.3	0.1	0.0
		50 Hz (0.0200 s)	1	1498.0	25.0	0.4	0.0
			8	624.1	10.4	0.2	0.0
			16	374.5	6.2	0.1	0.0
	1		1	104857.0	1747.6	29.1	1.2
			8	43690.0	728.2	12.1	0.5
			16	26214.0	436.9	7.3	0.3
	30		1	3145710.0	52428.5	873.8	36.4
			8	1310700.0	21845.0	364.1	15.2
			16	786420.0	13107.0	218.5	9.1
	60		1	6291420.0	104857.0	1747.6	72.8
			8	2621400.0	43690.0	728.2	30.3
			16	1572840.0	26214.0	436.9	18.2
	900		1	94371300.0	1572855.0	26214.3	1092.3
			8	39321000.0	655350.0	10922.5	455.1
			16	23592600.0	393210.0	6553.5	273.1
	1800		1	188742600.0	3145710.0	52428.5	2184.5
			8	78642000.0	1310700.0	21845.0	910.2
			16	47185200.0	786420.0	13107.0	546.1
	3600		1	377485200.0	6291420.0	104857.0	4369.0
			8	157284000.0	2621400.0	43690.0	1820.4
			16	94370400.0	1572840.0	26214.0	1092.3

If data is not available for the entire duration of pre-trigger, the trigger position will be based on available pre-trigger.

The Data Logger setting configuration can be made at the **SETPOINTS\DEVICE DATA LOGGER** path, accessing directly through the IEDs front panel, or through the EnerVista Configuration software **Setting** tab.

The Data Logger files can be visualized using the EnerVista Configuration software by double clicking on the **DataLogger** file available at the **Browse Data** sub tab under the **Records** tab. The Data Logger file, in Comtrade format (\*.cfg, \*.dat, no header provided), can be exported and saved in a computer. A summary of the data contained in the file is also provided and can be accessed by double clicking on the **View Summary** icon.

Basic Data Logger information, such as: newest sample time and oldest sample time can be accessed through the IEDs front panel at **RECORDS\DATA LOGGER**. The recommended way of accessing to the Disturbance Recorder data is using the EnerVista Configuration software.

The Data Logger files can be deleted using the **Clear Data Logger** command accessible through the **Commands** window on the **Monitor** tab on EnerVista Configuration software. The files can also be deleted using the **Clear All Records** command (this command will clear all the records in the device, not just the Data Logger ones). The Clear Records commands are also available at the **SETPOINT\DEVICE\CLEAR RECORDS** path, directly through the IED's front panel, or through the EnerVista Configuration software **Setting** tab.

---

## 14.6 FAULT RECORDS

---

The **Fault Records** setting configuration can be made at the **SETPOINTS\DEVICE\FAULT RECORDS** path, accessing directly through the IEDs front panel, or through the EnerVista Configuration software **Setting** tab.

The Fault Report files can be visualized using the EnerVista Configuration software by double clicking on the **FaultReport-(n)** file available at the **Browse Data** sub tab under the **Records** tab, where (n) is the number of the fault report. The file fault report file is a text file with a (\*.flt) extension, that can be exported and saved in a computer. This file contains some data related to the IED and some of the Fault Records settings, the postfault phasor values, pre-fault and fault data from the programmed analogue channels.

Basic Fault Records information, such as: number of reports, last trip time, last clear time, type of fault and distance to fault and the date and time of the record, can be accessed through the IEDs front panel at **RECORDS\FAULT RECORDS**. Analogue pre-fault, fault and post-fault data for each fault record can be accessed via the EnerVista Configuration software.

The fault report files can be deleted using the **Clear Fault Reports** command accessible through the **Commands** window on the **Monitor** tab on the EnerVista Configuration software. The files can also be deleted using the **Clear All Records** command (this command will clear all the records in the device, not just the fault reports ones). The Clear Records commands are also available at the **SETPOINT\DEVICE\CLEAR RECORDS** path, directly through the IEDs front panel, or through the EnerVista Configuration software **Setting** tab.

---

## 14.7 EVENT DATA

---

The **Event Data** feature stores 64 FlexAnalog quantities each time an event occurs. The IED is able to capture a maximum of 2048 event records. The **Event Data** behaviour matches that of the Event Recorder. This is a Platform feature and a Basic option, so it has no dependencies.

There is no Enabling/Disabling of the feature. It is always ON.

The Event Data setting configuration can be made at the **SETPOINTS\DEVICE\EVENT DATA** path, accessing directly through the IEDs front panel, or through the EnerVista Configuration software **Setting** tab.

64 analogue parameters can be configured in the Event Data and its values will be recorded per event at the time of its occurrence.

Event Data values can be visualized if using the EnerVista Configuration software by clicking on each event contained in the **Evt** file available at the **Browse Data** sub tab under the **Records** tab. The Event Data information for each event will be shown (Parameter and Value) under **Event Info** in the right pane. The event file (\*.evt), containing the event data, can be exported and saved on a computer.

The Event Data recorder for each event can be also accessed through the IEDs front panel by pressing the ENTER key at **RECORDS\EVENTS**. Several screens will be accessible per event, containing the 64 analogue configurable parameters. The ones configured will show the name of the analogue signal and its value, the ones not configured will show OFF. To go to of the Event Data visualisation, press the Cancel key.

The Event Data will be cleared when the events are deleted.

---

## 14.8 FLEX STATES

---

The Flex State feature provides a mechanism where any of 256 selected states or any inputs can be used for efficient monitoring.

The Flex States setting configuration can be made at the **SETPOINTS\DEVICE\FLEX STATES** path, accessing directly through the IEDs front panel, or through the EnerVista Configuration software **Setting** tab.

256 digital parameters (FlexLogic operands) can be configured in the Flex States feature.

Flex States values can be visualized (Parameter (n) and Value (On, Off)) in the **Flex State** menu available at the **Device Status** sub tab under the **Monitoring** tab if using the EnerVista Configuration software.

The Flex States values can be also accessed through the IEDs front panel at **DEVICE STATUS\FLEX ELEMENTS** path.

## 14.9 FLEX ELEMENTS

There are 8 identical Flex Element that can be configured under the **SETPOINTS\FLEXLOGIC\FLEXELEMENTS** path. A Flex Element is a universal comparator, that can be used to monitor any analogue actual value measured or calculated by the IED, or a net difference of any two analogue actual values of the same type. Depending on how the Flex Element is programmed, the effective operating signal could be either a signed signal (“Signed” selected for Input Mode), or an absolute value (“Absolute” selected for Input Mode).


The element can be programmed to respond either to a signal level or to a rate-of-change (delta) over a pre-defined period of time. The output signal is asserted when the operating signal is higher than a threshold or lower than a threshold as per user’s choice.

When programming a Flex Element, one shall keep in mind the following limitations:

- The analogue inputs for any Flex Element shall be from the same “gender”:
  - current and current (in any combination, phase-symmetrical, phase-phase, kA-A, differential, restraint, etc.)
  - voltage and voltage (as above)
  - active power and active power (Watts and Watts)
  - reactive power and reactive power (Vars and Vars)
  - apparent power and apparent power (VA and VA)
  - angle and angle (any, no matter what signal, for example angle of voltage and angle of current are a valid pair)
  - % and % (any, for example THD and harmonic content is a valid pair)
  - V/Hz and V/Hz
  - Flex Element actual and Flex Element actual

For all the other combinations, the element will display 0.000 or N/A and will not assert any output signal. The IED displays an error message.

- The analogue value associated with one Flex Element can be used as an input to another Flex Element “Cascading”.



**Figure 103: Flex element logic diagram**

**Input 1 (+)** setting specifies the first input (non-inverted) to the Flex Element. Zero is assumed as the input if this setting is set to Off. For proper operation of the element at least one input must be selected. Otherwise, the element will not assert its output signal. **Input 2 (-)** setting specifies the second input (inverted) to the Flex Element. Zero is

assumed as the input if this setting is set to Off. For proper operation of the element at least one input must be selected, otherwise, the element will not assert its output signal. This input should be used to invert the signal if needed for convenience, or to make the element respond to a differential signal. A warning message is displayed, and the element does not operate if the two input signals are of different types, for example if one tries to use active power and phase angle to build the effective operating signal.

The element responds directly to the differential signal if this **Operating Mode** setting is set to Signed. The element responds to the absolute value of the differential signal if this **Operating Mode** setting is set to Absolute. Sample applications for the Absolute selection include monitoring the angular difference between two phasors with a symmetrical limit angle in both directions; monitoring power regardless of its direction or monitoring a trend regardless of whether the signal increases or decreases.

**Pickup** setting specifies the operating threshold for the effective operating signal of the element. If the Over direction is set in the **Oper Signal Dir.** setting, the element picks up when the operating signal exceeds the **PICKUP** value. If the Under direction is set, the element picks up when the operating signal falls below the value set in the **Pickup** setting. The **Hysteresis** setting controls the element drop out. Note that both the operating signal and the pickup threshold can be negative when facilitating applications such as reverse power alarms.

The Flex Element can be programmed to work with all analogue values measured or computed by the IED. The **Pickup** setting is entered in pu values using the following definitions of the base units:

#### Definitions of the Base Unit for the Flex Element

Measured or Calculated Analogue Value Related to:	Base Unit
Voltage	VBASE = maximum nominal primary RMS value of the Input 1 (+) and Input 2 (-) inputs
Current	IBASE = maximum nominal primary RMS value of the Input 1 (+) and Input 2 (-) inputs
Power	PBASE = maximum value of VBASE * IBASE for the Input 1 (+) and Input 2 (-) inputs
Power factor	PFBASE = 1.00
Phase angle	DegBASE = 360 deg
Harmonic content	HBASE = 100% of nominal
THD	THDBASE = 100%
Frequency	fBASE = nominal frequency as entered under the SYSTEM SETUP menu
Volt/Hz	BASE = 1.00
I <sup>2</sup> t (arcing amps)	BASE = 2000 kA <sup>2</sup> *cycle

**ROCOT Unit (dt)** setting specifies the time base dt when programming the FlexElement as a rate of change element.

**ROCOT Set** setting specifies the duration of the time interval for the rate of change mode of operation.

**Note:**

The **ROCOT Unit (dt)** and **ROCOT Set** settings are applicable only if the **I/P Comp Mode** is set to Delta.



## 14.10 DEVICE STATUS

### 14.10.1 MOTOR STATUS

The motor status related values can be visualized at **DEVICE STATUS\SUMMARY\MOTOR** path. The motor values are as follows:

- Motor Status (*Motor Status*)
- Motor Thermal Capacity Used (*Thermal Cap Used*)
- Estimated Trip Time on Overload (*Trip Time on OL*)
- Start Inhibit Lockout Times (*Thermal LO Time, St LO Time, C/H St LO Time, TBStarts LO Time, Rest Dly LO Time and Tot Mtr LO Time*)
- Motor Speed (*Motor Speed*)
- Motor Running Hours (*Mtr Running Hrs*)

#### 14.10.1.1 MOTOR STATUS IMPLEMENTATION AND LOGIC

The Motor Status states are five mutually exclusive FlexLogic operands that reflect the motor state, and are generated by a state machine in the IED to determine the motor status. These operands are *Motor Stopped*, *Motor Starting*, *Motor Running*, *Motor Overload* and *Motor Tripped*.

Motor Status		
Flexlogic Operands (*1)	Motor Status (*2)	Description
Motor Tripped	Tripped	The motor is tripped
Motor Stopped	Stopped	The motor is stopped
Motor Starting	Starting	The motor is starting
Motor Running	Running	The motor is running
Motor Overload	Overload	A motor overload condition has occurred

**Note:**

(\*) These messages describe the motor status at any given point in time. All motor status operands are mutually exclusive.

**Note:**

(\*1) Motor Status individual Flexlogic operands contain the prefix "Motor" before the corresponding motor status, this is, if the motor is running the corresponding Flexlogic operand would be *Motor Running*, this is valid for Events too. These Flexlogic operands are available for the user to be used in any setting configuration or part of a logic using the Flexlogic Equation Editor.

**Note:**


(\*2) The Motor Status actual value is only available at **DEVICE STATUS\SUMMARY\MOTOR\MOTOR STATUS**, for visualization purposes, and the status of the motor does not have the prefix "Motor" before the corresponding Motor Status. This, *Motor Running* Flexlogic operand and Event will be displayed as *Running* in the Motor Status multi status value at Device Status.

For the sake of brevity, the term 'switching device' is used for Breaker and Contactor devices.

*Motor Stopped* and *Tripped* conditions are detected based on the current level and switching device status (52a or 52b). When a switching device is not configured (\*3), then monitoring of the switching device status is no longer possible and the *Stopped*, *Tripped*, and *Starting* Motor Status are based only on current level monitoring.

**Note:**

(\*3) A switching device is 'not configured' when the **Aux 3p (52A)** and **Aux 3p (52b)** settings are both set to *Off* under **SETPOINTS\SYSTEM\CB SETUP** for Breaker or under **SETPOINTS\SYSTEM\CONTACTOR** for Contactor, depending on the switching device selected (*Breaker* or *Contactor*) at **Switch Dev Type** setting under **SETPOINTS\SYSTEM\MOTOR \SETUP**.



**Figure 104: Motor main supply application logic**

### MOTOR TRIPPED

The *Motor Tripped* condition is detected when the *Any Trip* operand is asserted, the motor current ( $I_{motor}^*$ ) is below 2% of CT, and the switching device is open. However, when the switching device is not configured the Motor Tripped condition is detected when the *Any Trip* operand is asserted, and the current is below 2% of CT. Resetting of the Motor Tripped can be done by resetting the trip condition.

**Note:**

(\*)  $I_{motor}$  is defined in the equation ( $I_{eq}$ ) in the Thermal Model section, under the **UB Bias K Factor** setting description in the Motor Protection Functions chapter as follows:

This equivalent current is calculated using the equation shown below:

$$I_{eq} = \sqrt{I_{avg}^2 \left( 1 + K \cdot \left( \frac{I_2}{I_1} \right)^2 \right)}$$

,

where:


- $I_{eq}$  = Thermal model biased motor load current
- $I_{avg}$  = Average of the three RMS currents
- $I_1$  = Positive sequence current
- $I_2$  = Negative sequence current
- $K$  = Constant

## MOTOR STOPPED

The state machine initially sets the *Motor Stopped* operand, as the switching device is open and the motor current is less than 2% of CT. To detect a *Motor Stopped* condition it is important to first reset any trip, or the *Any Trip* operand is deserted. When the switching device is not configured the *Motor Stopped* condition is detected, based on current only.

**Note:**

It is advisable that the IED is programmed to monitor the status of the switching device by means of contact input of the device.



**Figure 105: Motor stopped and trip state logic**

## MOTOR STARTING

The *Motor Starting* state is asserted if the previous motor status is *Motor Stopped*, and a load current greater than 2% of FLA is detected, then the *Motor Starting* operand becomes true. The motor cannot start if the previous condition is *Motor Tripped* unless the *Any Trip* condition is reset.

For normal motor starting, the *Motor Starting* condition remains asserted until currents fall below the overload pickup level (FLA x OL). As soon as the motor current falls below the overload pickup level (FLA x OL), the *Motor Running* operand is set.

**Note:**

OL (Overload Factor) is configurable at **Motor OL Factor** setting. FLA (Full Load Amps) is configurable at **Motor FL Amps** setting. Both settings are available under the **SETPOINTS\SYSTEM\MOTOR\SETUP** path.




Figure 106: Motor starting state logic

**MOTOR RUNNING**

In induction motor applications, the motor can only be in the *Motor Running* condition following a *Motor Starting* or *Motor Overload* condition when neither *Motor Starting* or *Motor Overload* are asserted, and the motor current falls below FLA x OL.





Figure 107: Motor running state logic

**MOTOR OVERLOAD**

In induction motor applications, if the motor current rises above FLA x OL while in the *Running State*, the *Motor Overload* operand is set. If the motor current then falls below FLA x OL, the *Motor Overload* operand is reset and the *Motor Running* operand is set.

*Note:*

OL (Overload Factor) is configurable at **Motor OL Factor** setting. FLA (Full Load Amps) is configurable at **Motor FL Amps** setting. Both settings are available under the **SETPOINTS\SYSTEM\MOTOR\SETUP** path.



**Figure 108: Motor overload state logic**

## CONSIDERATIONS ABOUT TWO SPEED MOTOR APPLICATIONS

In 2-Speed Motor applications, when the motor is switched from speed 1 to speed 2, the FLA (set at **Motor FL Amps** setting at **SETPOINTS\SYSTEM\MOTOR\SETUP** path) and CT Primary (set at **Phase CT Primary** setting at **SETPOINTS\SYSTEM\CT RATIO\CT RATIO** path), switch to Speed2 Motor FLA (set at **Spd2 Motor FLA** setting at **SETPOINTS\SYSTEM\MOTOR\SETUP** path), and Speed2 CT Primary (set at **Spd2 CT Prmry** setting also at **SETPOINTS\SYSTEM\MOTOR\SETUP** path).

In addition, during the **transition from speed 1 to speed 2** the current may drop below 2% and the *Motor Stopped* status may become true. To prevent this, if the previous status is *Running* (or *Starting* or *Overload*), the 2-Speed Motor Protection is enabled (**2-Spd Mtr Prot** setting set to *Enabled* at **SETPOINTS\SYSTEM\MOTOR\SETUP** path), and the Speed2 Motor Switch is true (operand assigned to **Spd2 Motor Sw** setting at **SETPOINTS\SYSTEM\MOTOR\SETUP** path is asserted), then the motor status (*Motor Running*, *Starting* or *Overload*) is maintained for 1 second. After 1 second, if the motor current detected is less than the FLA x OL settings, the *Motor Running* operand is maintained; otherwise, either the *Overload* or *Stopped* condition is declared.

If during a **transition from speed 2 to speed 1**, if the previous status is *Running* (or *Starting* or *Overload*), the 2-Speed Motor Protection is enabled (**2-Spd Mtr Prot** setting set to *Enabled*), and the Speed2 Motor Switch is true (operand assigned to **Spd2 Motor Sw** setting is asserted), then the motor status (*Motor Running*, *Starting* or *Overload*) is maintained for Speed2 Switch 2-1 Delay (**Spd2 Sw 2-1 Dly** setting configurable at **SETPOINTS\SYSTEM\MOTOR\SETUP** path) + 1 second.

### 14.10.1.2 THERMAL CAPACITY USED

The Thermal Capacity Used (Thermal Cap Used) value is continuously calculated and displayed when the *Thermal Model* element is *Enabled* at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\THERMAL MODEL** path.

The Thermal Capacity Used can be visualized at *Thermal Cap Used* at **DEVICE STATUS\SUMMARY\MOTOR**.

### 14.10.1.3 ESTIMATED TRIP TIME ON OVERLOAD

The Estimated Time to Trip on Overload (*Trip Time on OL*) is displayed when the motor is *Starting*, *Running* or in *Overload* condition. This value represents the estimated time to trip (in seconds) from the Thermal Model, assuming that the motor current remains at its current level. This value is obtained from the thermal model curve (\*) and takes into account that some percent of the thermal capacity has already been used.

**Note:**

(\*) The thermal model curve can be configured at the **Overload Curve** setting at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\THERMAL MODEL** path.

The Estimated Time to Trip on Overload can be visualized at *Trip Time on OL* at **DEVICE STATUS\SUMMARY\MOTOR**.

### 14.10.1.4 START INHIBIT LOCKOUT TIMES

**Note:**

The Start Inhibit lockout times: Thermal LO Time (from Thermal Inhibit), St LO Time (from Maximum Starting Rate), C/H St LO Time (from Maximum Cold/Hot Starting Rate), TBStarts LO Time (from Time Between starts) and Rest Dly LO Time (from Restart Delay) are constantly displayed regardless of the motor status. The times continuously decrease and when any value reaches zero, the respective lockout is removed.

The Start Inhibit Lockout Times available at **DEVICE STATUS\SUMMARYMOTOR** path are as follows:

Lockout Times	
LO Times	Description
Thermal LO Time	Thermal Inhibit Lockout Time
St LO Time	Maximum Starting Rate Lockout Time
C/H St LO Time	Maximum Cold/Hot Starting Rate Lockout Time
TBStarts LO Time	Time Between starts Lockout Time
Rest Dly LO Time	Restart Delay Lockout Time
Tot Mtr LO Time	Total Motor Lockout Time (*)

**Note:**

The Total Motor Lockout Time (Tot Mtr LO Time) displays the highest value of all calculated Start Inhibit lockout times.

### 14.10.1.5 MOTOR SPEED

The Motor Speed can be either *Low Speed* or *High Speed*.

The motor is running at *High Speed* when the 2-Speed protection is used (**2-Spd Mtr Prot** setting set to *Enabled* at **SETPOINTS\SYSTEMMOTOR\SETUP**) and the Speed2 Motor Switch (signal configured at **Spd2 Motor Sw** setting at **SETPOINTS\SYSTEMMOTOR\SETUP**) is asserted (speed2 motor switch closed). In that case the Motor Speed 2 Flexlogic operand is asserted. Otherwise, the motor speed will be determined as *Low Speed* and the *Motor Speed 2* Flexlogic operand will be de-asserted.

### 14.10.1.6 MOTOR RUNNING HOURS

Motor Running Hours (*Mtr Running Hrs*) shows the total (accumulated) motor running time.

---

## 14.11 MEASURED QUANTITIES

---

The device measures directly and calculates a number of system quantities, which are updated every second. You can view these values in the relevant *MEASUREMENT* window or with the Measurement Viewer in the settings software. Depending on the model, the device may measure and display some or more of the following quantities:

- Measured and calculated analogue current and voltage values
- Power and energy quantities
- Peak, fixed and rolling demand values
- Frequency measurements
- Thermal measurements

---

### 14.11.1 MEASURED AND CALCULATED CURRENTS

The device measures phase-to-phase and phase-to-neutral current values. The values are produced by sampling the analogue input quantities, converting them to digital quantities to present the magnitude and phase values. Sequence quantities are produced by processing the measured values. These are also displayed as magnitude and phase angle values.

These measurements are contained in the *MEASUREMENTS* window in the *CT1 BANK-B* tab.

---

### 14.11.2 MEASURED AND CALCULATED VOLTAGES

The device measures phase-to-phase and phase-to-neutral voltage values. The values are produced by sampling the analogue input quantities, converting them to digital quantities to present the magnitude and phase values. Sequence quantities are produced by processing the measured values. These are also displayed as magnitude and phase angle values.

These measurements are contained in the *MEASUREMENTS* window in the *PH VT1 BANK-A* or *4TH VT1 BANK-A* tabs.

---

### 14.11.3 POWER AND ENERGY QUANTITIES

Using the measured voltages and currents the device calculates the apparent, real and reactive power quantities. These are produced on a phase by phase basis together with three-phase values based on the sum of the three individual phase values. The device also calculates the per-phase and three-phase power factors.

---

### 14.11.4 DEMAND VALUES

The device produces fixed, rolling, and peak demand values. You reset these quantities using the **Reset demand** command.

The fixed demand value is the average value of a quantity over the specified interval. Values are produced for three phase currents and three phase real and reactive power. The fixed demand values displayed are those for the previous interval. The values are updated at the end of the fixed demand period according to the **Fix Dem Period** setting.

The rolling demand values are similar to the fixed demand values, but a sliding window is used. The rolling demand window consists of a number of smaller sub-periods. The resolution of the sliding window is the sub-period length, with the displayed values being updated at the end of each of the sub-periods according to the **Roll Sub Period** setting.

Peak demand values are produced for each phase current and the real and reactive power quantities. These display the maximum value of the measured quantity since the last reset of the demand values.

---

### **14.11.5 FREQUENCY MEASUREMENTS**

The device produces a range of frequency statistics and measurements relating to the Frequency Protection function. These include Check synchronisation, Slip frequency and Rate of Change of Frequency measurements.

The device produces the slip frequency measurement by measuring the rate of change of phase angle between the bus and line voltages, over a one-cycle period. The slip frequency measurement assumes the bus voltage to be the reference phasor.

---

### **14.11.6 OTHER MEASUREMENTS**

Depending on the model, the device produces a range of other measurements such as thermal measurements.



---

## 14.12 OPTO-INPUT TIME STAMPING

---

Each opto-input sample is time stamped within a tolerance of +/- 1 ms with respect to the Real Time Clock. These time stamps are used for the opto event logs and for the disturbance recording. The device needs to be synchronised accurately to an external clock source such as an IRIG-B signal or a master clock signal provided in the relevant data protocol.

For both the filtered and unfiltered opto-inputs, the time stamp of an opto-input change event is the sampling time at which the change of state occurred. If multiple opto-inputs change state at the same sampling interval, these state changes are reported as a single event.


## 14.13 POWER FACTOR

It is generally desirable for a system operator to maintain the Power Factor as close to unity as possible, to minimize both costs and voltage excursions. Since the Power Factor is variable on common non-dedicated circuits, it is advantageous to compensate for low (lagging) Power Factor values by connecting a capacitor bank to the circuit when required.

### 14.13.1 POWER FACTOR IMPLEMENTATION

Four independent elements are available for monitoring Power Factor. Each having a Switch-In and a Switch-Out level. The relay allows two stages of capacitance switching for Power Factor compensation. It calculates the average Power Factor in the three phases as follows:

$$t_{op} = TD \left( \frac{\beta}{M^{\alpha} - 1} + L \right) + C$$




**Figure 109: Capacitor bank switching**

The setting of this function produces Switch-In, Switch-Out and Operate flags. The Power Factor Switch-In flag is asserted when the absolute value of the calculated Power Factor is below the *Switch-In* value, and current and voltage supervision conditions are satisfied. The Power Factor Operate flag in the Switch-In level is asserted if the element stays switched in for the time defined by the **Time Delay**. After the element drops from Switch-In, the Power Factor Switch-Out flag is asserted when the Power Factor passes the *Switch-Out* value. The Power Factor Operate flag in the Switch-Out level is asserted if the element stays switched out for the time defined by the **Time Delay**.

The minimum operating voltage **Vmin** is set as a threshold below which the element is reset.

The following figure illustrates the conventions established for use in the relay, where the negative value means the lead power factor, and the positive value means the lag power factor.



**Figure 110: Conventions for power factor**

### 14.13.2 POWER FACTOR LOGIC

For each element, when the measured Power Factor becomes more lagging or leading (depending on the user setting) than the **Switch-In** level, the relay operates a user-selected output contact. This output can be used to control a switching device which connects capacitance to the circuit, or to signal an alarm to the system operator. After entering this state, when the Power Factor becomes less lagging or leading than the power factor **Switch-Out** level for a time greater than the set **Time Delay**, the relay will reset the output contact to the non-operated state.

For Delta-connected VTs, the Power Factor feature is inhibited from operating unless all three voltages are above a threshold  $V_{min}$  and one or more currents are above  $0.002 \times CT$ . Power Factor element delay timers will only be allowed to time when the voltage threshold is exceeded on all phases and the Power Factor remains outside of the region between the programmed **Switch-In** and **Switch-Out** levels. In the same way, when a Power Factor condition starts the delay timer programmed as **Time Delay**, if all three phase voltages fall below the threshold before the timer has timed-out, the element will reset without operating. A loss of voltage during any state will return Power Factor elements to the Reset state.

For wye-connected VTs, the power factor value is calculated from the valid phase(s) which voltage is above a user selected threshold and current is above  $0.002 \times CT$ . Power Factor element delay timers will only be allowed to time when the supervision conditions are met, and the Power Factor remains outside of the region between the programmed **Switch-In** and **Switch-Out** levels. In the same way, when a Power Factor condition starts the delay timer, if one or more valid phases no longer satisfy the supervision conditions, the power factor will be re-calculated based on the still valid phase(s). If the element is continuously asserted with the new power factor value, the timer would continue timing, otherwise, the element will reset without operating.







Figure 111: Power factor logic

### 14.13.3 POWER FACTOR LOGIC SETTING GUIDELINES

The settings **Switch-In** and **Switch-Out** can be set as negative value that denotes the lead power factor, and the positive value for the lag power factor. It should be noted that **Switch-In** and **Switch-Out** are mutually exclusive, as shown in the following application examples where there is no common zone in which both **Switch-In** and **Switch-Out** are asserted.

For example, the applications of **Switch-In** and **Switch-Out** levels are shown in the figures below:






Figure 112: Application examples of power factor element

---

## 14.14 BREAKER ARCING CURRENT

---

It is generally desirable for a system operator to maintain the Power Factor as close to unity as possible, to minimize both costs and voltage excursions. Since the Power Factor is variable on common non-dedicated circuits, it is advantageous to compensate for low (lagging) Power Factor values by connecting a capacitor bank to the circuit when required.

---

### 14.14.1 BREAKER ARCING CURRENT IMPLEMENTATION

Breaker Arcing current is implemented under the path **SETPOINTMONITROING\CIRCUIT BREAKER\CB 1 MONITOR**. The device provides one Breaker Arcing current element.

This Breaker Arcing current element calculates an estimate of the per-phase wear on the breaker contacts by measuring and integrating the current squared passing through the breaker contacts as an arc. These per-phase values are added to accumulated totals for each phase and are compared to a programmed threshold value as a setting in setpoint **Alarm Value**. When the threshold is exceeded in any phase, the relay can set an output operand, operate an output relay based on the setting and set an alarm. The accumulated value for each phase is; **Arc current Phase A, Arc current Phase B, Arc current Phase C &  $\Sigma$  Arcing Current** are displayed as an actual value in **Records**.

The values can be cleared by navigating to **Records/Clear Records** menu, and either executing an individual command to clear the accumulated "BKR (x) Arcing Current" values only, or executing the command to clear "All Records". The data will be cleared by changing a command setting to "YES" and pressing the ENTER key. After clearing the data, the command setting automatically reverts to "NO".

### 14.14.2 BREAKER ARCING CURRENT LOGIC




Figure 113: Breaker arcing current logic

### 14.14.3 BREAKER ARCING CURRENT APPLICATION NOTES

The same output operands that are selected to operate the Trip output relay, and are used to trip the breaker indicating a tripping sequence has begun, are used to initiate this feature. The inputs/operands are selected in setpoint **Initiation** and initiates the Breaker Arcing Current scheme.

The Setpoint **Delay** is the time delay introduced between initiation and starting of the integration, to prevent integration of current flow through the breaker before the contacts have parted. This interval includes the operating time of the output relay, and any other auxiliary relays and the breaker mechanism. For maximum measurement accuracy, the interval between the change-of-state of the operand (from 0 to 1) and contact separation should be measured for the specific installation.

Integration of the measured current continues for 100 ms, which is expected to include the total arcing period.

The setpoint **Alarm Value** specifies the threshold value (kA<sup>2</sup>-cycle) above which the output operand is set.






Figure 114: The breaker arcing current measurement

---

## 14.15 CB HEALTH MONITORING

---

The device records various statistics related to the circuit breaker trip operation, allowing an accurate assessment of the circuit breaker condition to be determined. The circuit breaker condition monitoring counters are incremented every time the device issues a trip command.

These statistics are available in the **RECORDS\CIRCUIT BREAKER** menu. The menu items are counter values only, and cannot be set directly. The counters may be reset, however, during maintenance. This is achieved with the **Clear All Records** command.

*Note:*

*When in Commissioning test mode the CB condition monitoring counters are not updated.*

### 14.15.1 CB HEALTH MONITORING LOGIC




Figure 115: CB health monitoring logic - page 1




Figure 116: CB health monitoring logic - page 2

## 14.15.2 APPLICATION NOTES

### 14.15.2.1 SETTING THE THRESHOLDS FOR THE ARC ENERGY

Where power lines use oil circuit breakers (OCBs), changing of the oil accounts for a significant proportion of the switchgear maintenance costs. Often, oil changes are performed after a fixed number of CB fault operations. However, this may result in premature maintenance where fault currents tend to be low, because oil degradation may be slower than would normally be expected. The Total Current Accumulator ( $I^A$  counter) cumulatively stores the total value of the current broken by the circuit breaker providing a more accurate assessment of the circuit breaker condition.

The dielectric withstand of the oil generally decreases as a function of  $I^2t$ , where 'I' is the broken fault current and 't' is the arcing time within the interrupter tank.

The ARC ENERGY is calculated by the breaker arcing current element. If the breaker arcing current element is disabled, the ARC ENERGY will not be calculated and the **Arc Energy Set** setting should not be used. The ARC ENERGY used here is the individual value for each trip rather than the accumulated value recorded in the Breaker Arcing Current element.

**Note:**

Any maintenance program must be fully compliant with the switchgear manufacturer's instructions.

### 14.15.2.2 SETTING THE THRESHOLDS FOR THE NUMBER OF OPERATIONS

Every circuit breaker operation results in some degree of wear for its components. Therefore routine maintenance, such as oiling of mechanisms, may be based on the number of operations. Suitable setting of the maintenance threshold will allow an alarm to be raised, indicating when preventative maintenance is due.

The lockout threshold **No. CB Ops Lock** may be set to disable autoreclosure when repeated further fault interruptions could not be guaranteed. This minimises the risk of oil fires or explosion.

### 14.15.2.3 SETTING THE THRESHOLDS FOR THE OPERATING TIME

Slow CB operation indicates the need for mechanism maintenance. Lockout thresholds (**Lockout Time**) is provided to enforce this. They can be set in the range of 0 to 600 ms. This time relates to the interrupting time of the circuit breaker.

### 14.15.2.4 SETTING THE THRESHOLDS FOR EXCESSIVE FAULT FREQUENCY

Intermittent faults such as clashing vegetation may repeat outside of any reclaim time, and the common cause might never be investigated. For this reason it is possible to set a frequent operations counter, which allows the number of operations **Fault Freq Count** over a set time period **Fault Freq Time** to be monitored. A separate alarm and lockout threshold can be set.

## 14.16 CB STATE MONITORING

CB State monitoring is used to verify the open or closed state of a circuit breaker. Most circuit breakers have auxiliary contacts through which they transmit their status (open or closed) to control equipment such as IEDs. These auxiliary contacts are known as:

- 52A for contacts that follow the state of the CB
- 52B for contacts that are in opposition to the state of the CB

This device can be set to monitor both of these types of circuit breaker state indication. If the state is unknown for some reason, an alarm can be raised.

Some CBs provide both sets of contacts. If this is the case, these contacts will normally be in opposite states. Should both sets of contacts be open, this would indicate one of the following conditions:

- Auxiliary contacts/wiring defective
- Circuit Breaker (CB) is defective
- CB is in isolated position

Should both sets of contacts be closed, only one of the following two conditions would apply:

- Auxiliary contacts/wiring defective
- Circuit Breaker (CB) is defective

If any of the above conditions exist, an alarm will be issued. An output contact can be assigned to this function via the Flexlogic Equation Editor. The time delay is set to avoid unwanted operation during normal switching duties.

In the **SETPOINTS\SYSTEM\CB SETUP\BREAKER** setpoint there is a setting called **CB Status Input** that can be set at one of the following four options:

- None
- 52A
- 52B
- Both 52A and 52B

Where *None* is selected no CB status is available. Where only 52A is used on its own then the device will assume a 52B signal opposite to the 52A signal. Circuit breaker status information will be available in this case but no discrepancy alarm will be available. The above is also true where only a 52B is used. If both 52A and 52B are used then status information will be available and in addition a discrepancy alarm will be possible, according to the following table:

Auxiliary Contact Position		CB State Detected	Action
52A	52B		
Open	Closed	Breaker open	Circuit breaker healthy
Closed	Open	Breaker closed	Circuit breaker healthy
Closed	Closed	State unknown	Alarm raised if the condition persists
Open	Open	State unknown	Alarm raised if the condition persists

### 14.16.1 CB STATE MONITORING LOGIC




Figure 117: CB state monitoring logic

---

## 14.17 SETPOINT GROUP

---

The IED provides six setting groups. All settings contained under the protection setpoints are reproduced in six groups, identified as Groups 1, 2, 3, 4, 5 and 6. These multiple settings provide the capability for both automatic and manual switching to protection settings for different operating situations. Automatic (adaptive) protection setting adjustment is available to change settings when the power system configuration is altered.

Automatic group selection can be initiated from any signal configured in the **Setting Group (n)** settings at **SETPOINTS\CONTROL\SETPOINT GROUP**, being (n) from 2 to 6.

Group 1 is the default for the Active Group and is used unless another group is requested to become active. The active group can be selected with the **Active Settings** setting at **SETPOINTS\CONTROL\SETPOINT GROUP**, or by the activation of the signals configured at **Setting Group (n)** settings. If there is a conflict in the selection of the active group, between the **Active Settings** setting and the activation of the signals configured in any of the **Setting Group (n)** settings, the higher numbered group is made active. For example, if the inputs for Group 2, 3, 4, 5 and 6 are all asserted, the IED uses Group 6. If the logic input for Group 6 then becomes de-asserted, the IED uses Group 5. Some application conditions require that the IED does not change from the present active group. The prevention of a setpoint group change can be applied by configuring the **Change Inhib.(n)** settings, being (n) from 1 to 6. These settings select the signals that inhibits the change of the active setpoint group. If needed, typically this change inhibit is done when any of the overcurrent (phase, earth (measured or derived), sensitive earth or negative sequence), overvoltage, bus or line undervoltage, or underfrequency elements are picked-up.

Setpoint Group Path: **SETPOINTS\CONTROL\SETPOINT GROUP**

*Note:*

*The Active Group status can be accessed at **DEVICE STATUS\DEVICE STATUS** path, directly in the HMI, or through the **Monitor** tab in EnerVista Configuration.*



---

## 14.18 MOTOR CONTROL FUNCTIONS

---

The P24D and P24N provide a series of motor control features. This section describes the operation of these functions including the principles, logic diagrams and applications.

The Motor Control features provided are as follows:

- Motor Starting Supervision, includes the following features:
  - Thermal Inhibit
  - Maximum Starting Rate
  - Maximum Cold/Hot Starting Rate
  - Time Between Starts
  - Restart Delay
- Motor Reduced Voltage Starting
- Contactor Control (\*)

**Note:**


*(\*) The Contactor Control feature is not described in this section. It is described in the Breaker/Contactor Control section where the Motor switching device control (both Breaker and Contactor) is described.*

---

### 14.18.1 MOTOR CONTROL FUNCTIONS MENU HIERARCHY

The following diagram is an example of the device control functions settings display navigation. This diagram shows all the control features within the device, not just the Motor specific ones. Motor specific features are described further in this section (Starting Supervision, Reduced Voltage Starting), but Contactor Control is described in the section for the control of the motor switching devices (Breaker/Contactor Control).

The device control features are not group related. There is a single control menu for the device where all control features are displayed. See the diagram below:



**Figure 118: Motor control functions menu hierarchy**

## 14.18.2 START SUPERVISION

Start Supervision consists of five elements that guard against excessive starting duty. All Start Supervision elements operate the FlexLogic operand *Start Inhibit*. The *Start Inhibit* FlexLogic operand is pre-configured by default to the Relay O/P 3 of the device.

In addition to Start Supervision elements, the *Start Inhibit* operand also operates when the Phase Reversal element or *Any Trip* operates, as shown in the figure below. The Phase Reversal issues the *Ph Rev Inhibit* operand element, upon operation of the element, to inhibit the starting of the motor.

If the condition that has caused the trip is still present, the *Start Inhibit* operand will not reset until the condition is no longer present or the lockout time has expired. The Relay Output, energized by the *Start Inhibit* operand, changes


state only when the motor is *Stopped* to accommodate control circuits that must be continuously energized, such as a contactor.

**Note:**

The Start Inhibit operand is programmed as factory default to energize the Relay O/P 3. It is recommended to use the Relay O/P 3 to inhibit the closing of the motor switching device.

The Start Supervision elements provide PKP (start) and OP (Trip) FlexLogic operands per each element. The *Start Inhibit* FlexLogic operand will be asserted in case any of the elements operate plus Any Trip and Phase Reversal operation, as per the following table (individual operands will be showed at each element description):

FlexLogic Operands	
Operand	Description
Start Inhibit	Any Start Inhibit has operated: Thermal Inhibit OR Maximum Starting Rate OR Maximum Cold/Hot Starting Rate OR Time Between Start OR Restart Delay OR Phase Rev Inhibit OR Any Trip.



**Figure 119: Start inhibit FlexLogic operand logic**

### 14.18.2.1 THERMAL INHIBIT

#### 14.18.2.1.1 THERMAL INHIBIT IMPLEMENTATION

This function is provided to inhibit the starting of a motor if there is insufficient thermal capacity available for a successful start. Starts are inhibited when the thermal capacity is greater than the adjusted thermal capacity  $TC_{ADJ}$  (adjusted thermal capacity) subtracted from 100%.

$TC_{ADJ}$  is the thermal capacity required for a successful start.

The IED can obtain the value for adjusted thermal capacity for a successful start ( $TC_{ADJ}$ ) in two ways:

- Automatically learning
- Manually configuring its value in the ***TC Rqrd to Start*** setting at ***SETPOINTS\CONTROL\MOTOR STARTING\STRT SUPERVISION\THERMAL INHIBIT*** path.

The Thermal Inhibit function uses the following formula, to automatically determine the thermal capacity required for a successful start ( $TC_{ADJ}$ ), from learned thermal capacity used at start ( $TC_L$ ) increased by the margin set up in the ***TC Used Margin*** setting.

$$TC_{ADJ} = TC_L \times \left(1 + \frac{TC_{Used\ Margin}}{100\%}\right)$$

For example, if the thermal capacity used for the last five starts is 24, 23, 27, 26 and 20% respectively, the learned starting capacity used at start is the maximum which is 27%.

If the set margin is 25%, the adjusted thermal capacity learned value ( $TC_{ADJ}$ ) is calculated as  $27\% \times (1+25\%/100\%) = 33.75\%$ .

A *Start Inhibit* is issued until the motor current TCU decays to  $100\% - 33.75\% = 66.25\%$ .

The learned thermal capacity used at start ( $TC_L$ ) is calculated even if the Thermal Start Inhibit element is disabled. The learned thermal capacity used at start ( $TC_L$ ) is stored in a non-volatile memory and it is available after the power is removed from the device. Once the  $TC_L$  is calculated, it will take N successful starts before the calculation is repeated. N (Number of Starts to Learn) is set at **Nb of Str to Lr** setting at **SETPOINTS\SYSTEM\MOTOR\SETUP** path.

A successful motor start is one in which the motor reaches the *Running* state.

**Note:**

The learned thermal capacity used ( $TC_L$ ) at start can be visualized at Lrnd Start TCU at **RECORDS\LEARNED DATA** path.

The Thermal Inhibit function normally uses the learned thermal capacity used at start ( $TC_L$ ) to determine the thermal capacity required for a successful start ( $TC_{ADJ}$ ), but there are some conditions where the function, instead of using  $TC_L$ , uses the TC Required to Start (**TC Rqrd to Start**) setting value directly.

These conditions are either one of the following:

- If "N" number of starts history is not available
- If the **Clear Motor Learned Data (Mtr Learn Data)** command (\*) is executed
- If the Bypass Learn Start TCU (**Bypas Lr Str TCU**) setting is set to *Yes*
- If the Thermal Inhibit function (\*1) is disabled and the Thermal Model function (\*2) trips the motor at 100% thermal capacity

Under any of these conditions, the thermal capacity required for a successful start ( $TC_{ADJ}$ ) is the manually configured thermal capacity required to start, **TC Rqrd to Start** setting value:  $TC_{ADJ} = \text{TC Rqrd to Start}$ .

**Note:**

(\*) The **Clear Motor Learned Data (Mtr Learn Data)** command can be executed either at the Commands menu in EnerVista, or at **SETPOINTS\DEVICE\CLEAR RECORDS** or **RECORDS\CLEAR RECORDS** paths, either in EnerVista or the device HMI.

**Note:**

(\*1) The Thermal Inhibit function **Function** setting set to *Disabled* at **SETPOINTS\CONTROL\MOTOR STARTING\STRT SUPERVISION\THERMAL INHIBIT** path.

(\*2) The Thermal Model function is configurable at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\THERMAL MODEL** path.

The Thermal Lockout Time (*Thermal LO Time*) calculation is based on the values of TCU (Thermal Capacity Used),  $TC_{ADJ}$  (Adjusted Thermal Capacity for a successful start) and the Cool Time Constant Stopped (CTCS). The latter cooling time constant (CTCS) is set at **Cool TC Stopped** setting at **SETPOINT\PROTECTION\GROUP [1-6]\MOTOR\THERMAL MODEL**.

If, for the example above, the **Cool TC Stopped** = 30 Minutes and the motor TCU = 90%, the lockout time is:

$$TC_{used} = TC_{used\ start} \times e^{\frac{-t}{\tau}} \Rightarrow 66\% = 90\% \times e^{\frac{-t}{30}}$$

$$\Rightarrow t = -30 \times \ln\left(\frac{66\%}{90\%}\right) = 9.3 \text{ minutes}$$

If the start history is not available or the **Bypas Lr Str TCU** setting is set to *Yes*, then the inhibit time is calculated using setpoint **TC Rqrd to Start** (assuming 85%) as:

$$t = -30 \times \ln\left(\frac{100\% - \text{TC Rqrd to Start}}{90\%}\right)$$

$$t = -30 \times \ln\left(\frac{100\% - 85\%}{90\%}\right) = 53.7 \text{ minutes}$$

The IED constantly displays the Thermal Lockout Time (*Thermal LO Time*) at the **DEVICE STATUS\SUMMARY MOTOR** menu, even if the motor is neither Stopped nor Tripped.

If the Emergency Restart input (\*) is asserted during a Thermal Start lockout, the TCU is set to zero and the *Therm Trip OP* operand is reset. This causes resetting of Thermal Lockout Time (Thermal LO Time) to zero and dropout of the *Start Inhibit* and *Therm Inhibit OP* operands and allows a new start.

In the event of a real emergency, the Emergency Restart input operand (\*), *Emrg Restart*, must remain asserted at logic 1 until the emergency is over. The *Therm Inhibit OP* and *Start Inhibit* operands will remain reset until the Emergency Restart input operand is de-asserted. However, calculation of the Thermal Lockout Time (*Thermal LO Time*) continues after resetting to zero, regardless of the duration of the Emergency Restart input.

**Note:**

(\*) The Emergency Restart input is configured at the **Emergency Restart** setting at **SETPOINTS\SYSTEMMOTOR\SETUP** path, and when the signal configured is asserted the *Emrg Restart* operand is set to 1. The FlexLogic operands related to the Emergency Restart (*Emrg Restart* and *Emrg Restart Alm*) are calculated in the Thermal Model feature (configurable at **SETPOINTPROTECTION\GROUP [1-6]\MOTOR\THERMAL MODEL** path).

## THERMAL MODEL SETTINGS AND FLEXLOGIC OPERANDS

Thermal Inhibit function provides the following Flexlogic operands:

FlexLogic Operands	
Operand	Description
Therm Inhibit PKP	Thermal Inhibit has picked up (start)
Therm Inhibit OP	Thermal Inhibit has operated (trip)

The Thermal Inhibit settings can be found at **SETPOINTS\CONTROL\MOTOR STARTING\STRT SUPERVISION \THERMAL INHIBIT** path.

The settings are as follows:

### Function

If the **Function** is set to *Enabled*, the element works as described at the beginning of this section.

If the **Function** is set to *Disabled*, the element is not functional unless the motor thermal capacity (TCU) has reached 100%, and the Thermal Model **Trip Function** is *Enabled*. In that case, the Thermal Start Inhibit operand (*Therm Inhibit OP*) operates and the lockout time (*Thermal LO Time*) is approximately 190% of the Cool Time Constant Stopped (**Cool TC Stopped**). After the lockout time expires, the TCU will decay by the level defined by the **TC Rqrd to Start** setting and a new start will be allowed.

### **TC Used Margin**

This setting specifies the margin (from 0% to 25%) to be included in the calculation of the adjusted Thermal Capacity Used at start value ( $TC_{ADJ}$ ). This setting is only applicable when learned start TCU ( $TC_L = Lrnd\ Start\ TCU$ ) is not bypassed (i.e. **Bypas Lr Str TCU** = *No*) and N number of starts history is available.

### **Bypas Lr Str TCU**

This setting provides flexibility to bypass the learned start TCU ( $TC_L = Lrnd\ Start\ TCU$ ) value to determine the thermal capacity required to successfully start the motor. When this setting is set to *No*, the Thermal Inhibit function determines the thermal capacity required to successfully start the motor using *Lrnd Start TCU* ( $TC_L$ ). When this setting is set to *Yes*, the thermal capacity required to successfully start the motor is determined by the value configured under the **TC Rqrd to Start** setting.

### **TC Rqrd to Start**

This value specifies the thermal capacity required to successfully start the motor. The Thermal Inhibit function uses this value instead of the learned thermal capacity used at start ( $TC_L$ ) when:

- N number of start history is not available
- Or **Bypas Lr Str TCU** setting is set to *Yes*
- Or Thermal Inhibit **Function** is *Disabled* and Thermal Model functions trips the motor at 100% thermal capacity

### 14.18.2.1.2 THERMAL INHIBIT LOGIC




Figure 120: Thermal start inhibit logic

## 14.18.2.2 MAXIMUM STARTING RATE

### 14.18.2.2.1 MAXIMUM STARTING RATE IMPLEMENTATION

**Note:**

Using the Maximum Cold/Hot Starting Rate element instead of the Maximum Starting Rate element when the allowable number of Cold and Hot starts is known, is recommended.

The Maximum Starting Rate element defines the number of start attempts, regardless of hot or cold, allowed in a programmable time interval. After every new start, the number of starts within the past time Interval is compared to the number of starts allowed. When the maximum number of actual starts within the past Interval is reached, the FlexLogic operand *Mx Strt Rate PKP* is asserted. Once the motor stops, the comparison is performed again and if the two numbers are the same, the Start Inhibit operand is activated to block the motor start. If a block occurs, the lockout time (*St LO Time*) is equal to the time elapsed since the 'oldest start' within the past Interval that occurred, subtracted from the time of the Interval. For more details, please refer to the figure: Maximum Starting Rate logic. Even unsuccessful start attempts are logged as starts for this feature.

**Note:**

The lockout time for the maximum number of starts (*St LO Time*) is available at **DEVICE STATUS\SUMMARY\MOTOR** path.

Example: If **Max NB of Starts** setting is set to 2 and the **Interval** setting is set to 60 minutes:

- One start occurs at T = 0 minutes
- A second start occurs at T = 17 minutes
- The motor is stopped at T = 33 minutes
- A block occurs
- The lockout time is 60 minutes - 33 minutes = 27 minutes

If the Emergency Restart input (configured at the **Emergency Restart** setting at **SETPOINTS\SYSTEMMOTOR\SETUP** and reflected in *Emrg Restart* operand) is asserted while the motor is *Stopped* or *Tripped* during a Maximum Starting Rate lockout, the information about the oldest start inside the selected time Interval is erased. This causes a dropout of the *Start Inhibit* operand and allows a new start. If the motor starts while the Emergency Restart input is asserted, the new start is still recorded. It is important that the Emergency Restart is removed either shortly before or shortly after the motor is started.

**Note:**

Consecutive assertion of multiple Emergency Restart inputs erases the equivalent number of the oldest motor starts. For example: when an Emergency Restart input is asserted twice consecutively, the two oldest starts will be erased and therefore allow two motor starts.

**Note:**

The information about motor starts and stops within the past Interval is stored in non-volatile memory and remains in the memory after the power is removed from the IED. When the power is restored, the Maximum Starting Rate (**Mx Starting Rate**) element continues working normally using the information collected before the power loss if the real time clock worked properly during the power loss. However, when the IED power is restored, if the clock is not working properly or is defaulted to the factory setting, "St LO Time" will remain unchanged and prevent the motor from starting until "St LO time" becomes zero or the Emergency Restart ("Emrg Restart" operand) is asserted.

## MAXIMUM STARTING RATE SETTINGS AND FLEXLOGIC OPERANDS

The Maximum Starting Rate function provides the following FlexLogic operands:

FlexLogic Operands	
Operand	Description
Mx Strt Rate PKP	Maximum Starting Rate has picked up (start)
Mx Strt Rate OP	Maximum Starting Rate has operated (trip)

Maximum Starting Rate settings can be found at **SETPOINTS\CONTROL\MOTOR STARTING\STRT SUPERVISIONMX STARTING RATE** path.

The settings are as follow:

### Function

This setting allows the user to set the Maximum Starting Rate element as *Enabled* or *Disabled*.

### Interval

This setting specifies the time interval for monitoring the maximum allowable rate of starting. Set it to 60 minutes for the classical starts-per-hour functionality.



### Max Nb of Starts

This setting specifies the maximum allowable number of starts that can occur within the specified time Interval set.

### Events

Setting introduced in 8A release to allow the user to enable or disable the events related to this feature. By default, this setting is set to *Enabled*.

### Targets

Setting introduced in 8A release to allow the user to disable or set to *Latched* or *Self-Reset* the targets related to this feature. By default, this setting is set to *Latched*.

#### 14.18.2.2.2 MAXIMUM STARTING RATE LOGIC




Figure 121: Maximum starting rate logic

#### 14.18.2.3 MAXIMUM COLD/HOT STARTING RATE

##### 14.18.2.3.1 MAXIMUM COLD/HOT STARTING RATE IMPLEMENTATION

**Note:**

Using the Maximum Starting Rate element instead of the Maximum Cold/Hot Starting Rate element when the allowable number of Cold and Hot starts is not known, is recommended.

This element defines the number of cold and hot start attempts allowed in a certain time interval. On each start, the TCU level defined by the **Cold/Hot TCU Lvl** setting is used by this element to determine the start type: Hot or Cold.

The new start is declared as:

- A Hot Start if the actual TCU% is greater than or equal to the **Cold/Hot TCU Lvl** setting.
- A Cold Start if the actual TCU% is less than the Cold/Hot TCU Lvl setting.

At each new start, the number of starts (hot or cold) within the past time interval is compared with the number of allowed starts (hot or cold).

When the maximum number of actual starts (hot or cold) within the past interval is reached, the FlexLogic operand **Mx Hot Strt PKP** or **Mx Cold Strt PKP** is asserted.

Once the motor stops, the comparison is performed again and if the two numbers are the same (number of actual starts compared with the number of allowed starts (hot or cold)), the *Start Inhibit* operand is activated to block the motor start. If a block occurs, the lockout time (*C/H St LO Time*) is equal to the time elapsed since the 'oldest start' within the past interval that occurred, subtracted from the time of the interval. For more details, please refer to the figure: Maximum Cold/Hot Starting Rate logic diagram.

*Note:*  
Unsuccessful start attempts are logged as starts for this feature.

*Note:*  
The lockout time for the maximum Cold/Hot number of starts (*C/H St LO Time*) is available at **DEVICE STATUS\SUMMARY\MOTOR** path.

A few examples of the application of this feature:

### Application Example 1

For this Application Example 1, the settings configured for Maximum Hot/Cold Starting Rate at **SETPOINTS\CONTROL\MOTOR STARTING\STRT SUPERVISION\MX C/H STARTING RATE**, are as follows:

- **Max Cold Starts** = 2
- **Max Hot Starts** = 2
- **Interval** = 60 min
- **Cold/Hot TCU Lvl** = 25%

The figure below illustrates example 1:




Figure 122: Application example 1

- When the motor starts at time  $T = 0$  minutes, and the TCU level (*Thermal Cap Used* at **DEVICE STATUS** **ISUMMARYMOTOR**) lies below the set **Cold/Hot TCU Lvl**, the element declares the first start as a Cold Start and increments the cold start counter to 1.
- The second start occurs at time  $T = 25$  minutes, and the TCU level lies below the set **Cold/Hot TCU Lvl**. Therefore, the element declares the second start as a cold start and increments cold start counter to 2.
- After the second start, the element compares the number of cold starts and hot starts within the past interval window with the set value of **Max Cold Starts** and **Max Hot Starts**, respectively. The element asserts the **Mx Cold Strt PKP** operand because the number of cold starts has reached the allowed number of cold starts attempts within the past interval.
- When the motor stops at  $T = 50$  minutes, the FlexLogic operands **Mx Cold Strt OP** and **Start Inhibit** are asserted. The motor remains inhibited from starting (**C/H St LO Time**) for 10mins (60 minutes - 50 minutes). Because the number of hot starts counter equals zero within the past time interval window, the FlexLogic operands **Mx Hot Strt PKP** and **Mx Hot Strt OP** remain at zero (de-asserted).

### Application Example 2

For this Application Example 2, the Maximum Hot/Cold Starting settings are the same as in the example above, but the starts and stops are not.

- **Max Cold Starts** = 2
- **Max Hot Starts** = 2
- **Interval** = 60 min
- **Cold/Hot TCU Lvl** = 25%

The figure below illustrates example 2:




Figure 123: Application example 2

- When the motor starts at time  $T = 0$  minutes, the TCU level lies below the set **Cold/Hot TCU Lvl**. Therefore, the element declares the first start as a cold start and increments the cold start counter to 1, while the hot start counter remains at zero.
- The second start occurs at time  $T = 25$  minutes, and the TCU level lies above the set **Cold/Hot TCU Lvl**. The element declares the second start as a hot start and increments the hot start counter to 1, while the cold start counter remains at 1.
- After the second start, the element compares the number of cold starts and hot starts within the past interval window with the corresponding set value of **Max Cold Starts** and **Max Hot Starts**, respectively. Within the past interval window, the number of cold starts ( $= 1$ ) remains below the allowed cold starts (**Max Cold Starts**  $= 2$ ), so the FlexLogic operand **Mx Cold Strt PKP** remains zero (un-asserted). Similarly, within the past interval window, the number of hot starts remains ( $= 1$ ) below the allowed hot starts (**Max Hot Starts**  $= 2$ ), so the FlexLogic operand **Mx Hot Strt PKP** remains zero (un-asserted).
- The third start occurs at  $T = 50$  minutes, and the TCU level lies above the set **Cold/Hot TCU Lvl**, so the element declares a third start a hot start and increments the hot start counter to 2.
- After the third start, the element compares the number of cold starts and hot starts within the past interval window with the corresponding set value of **Max Cold Starts** and **Max Hot Starts**, respectively. Within the past interval window, the number of cold starts remains below the allowed cold starts, so the FlexLogic operand **Mx Cold Strt PKP** remains zero. However, the number of hot starts has reached the allowed number of hot starts within the past interval window, therefore the FlexLogic operand **Mx Hot Strt PKP** is asserted.
- When the motor stops at  $T = 75$  minutes, **Mx Hot Strt OP** operand is asserted and blocks (\*) the motor from starting for the next 10 minutes (\*) (60 minutes - 50 minutes).

**Note:**

(\*) If a block occurs, the lockout time (C/H St LO Time) is equal to the time elapsed since the 'oldest start' (Start 3 = 50 min) within the past interval that occurred, subtracted from the time of the interval (60 min).

Since the number of cold start counter equals 1 within the past time interval window, the FlexLogic operands **Mx Cold Strt PKP** and **Mx Cold Strt OP** remain de-asserted.

If the Emergency Restart input (**Emrg Restart** operand) is asserted while the motor is **Stopped** or **Tripped** during a **C/H St LO Time**, the information about the oldest start inside the selected time interval is erased. This causes a

dropout of the *Start Inhibit* operand and allows a new start. If the motor starts while the Emergency Restart input (*Emrg Restart* operand) is asserted, the new start is still recorded. It is important that the Emergency Restart is removed either shortly before or shortly after the motor is started.

**Note:**

Consecutive assertion of multiple Emergency Restart inputs erases the equivalent number of the oldest motor starts. For example: when an Emergency Restart input is asserted twice consecutively, the two oldest starts will be erased and therefore allow two motor starts.

**Note:**

The information about motor hot and cold starts and stops within the past interval is stored in non-volatile memory and remains in the memory after the power is removed from the IED. When the power is restored, the Maximum Hot/Cold Starting Rate (**Mx C/H Strt Rate**) element continues working normally using the information collected before the power loss. However, when the IED power is restored if the clock is not working properly or it has defaulted to the factory setting, "C/H St LO Time" will remain unchanged and prevent the motor from starting until "C/H St LO Time" becomes zero or the Emergency Restart input ("Emrg Restart" operand) is asserted.

## MAXIMUM COLD/HOT STARTING RATE SETTINGS AND FLEXLOGIC OPERANDS

The Maximum Cold/Hot Starting Rate function provides the following FlexLogic operands:

FlexLogic Operands	
Operand	Description
Mx Cold Strt PKP	Maximum Cold Starting Rate has picked up (start)
Mx Cold Strt OP	Maximum Cold Starting Rate has operated (trip)
Mx Hot Strt PKP	Maximum Hot Starting Rate has picked up (start)
Mx Hot Strt OP	Maximum Hot Starting Rate has operated (trip)

The Maximum Cold/Hot Starting Rate settings can be found at **SETPOINTS\CONTROL\MOTOR STARTING\STRT SUPERVISIONMX C/H STARTING RATE** path.

The settings are as follows:

### Function

This setting allows the user to set the Maximum Cold/Hot Starting Rate element as *Enabled* or *Disabled*.

### Interval

This setting specifies the time interval for monitoring the maximum allowable rate of starting. Set it to 60 minutes for the classical starts-per-hour functionality.

### Max Cold Starts

This setting specifies the maximum allowable number of cold starts that can occur within the specified time Interval.

### Max Hot Starts

This setting specifies the maximum allowable number of hot starts that can occur within the specified time Interval.

### Cold/Hot TCU Lvl

The TCU level defined by this setting is used by the Maximum Cold/Hot Starting Rate function to determine the next start type; Hot or Cold. The new start is declared as:

- Hot Start if the actual TCU% is greater than this setting (*Thermal Cap Used* > **Cold/Hot TCU Lvl**).
- Cold Start if the actual TCU% is less than this setting (*Thermal Cap Used* < **Cold/Hot TCU Lvl**).

Once this start inhibit function declares the start type, it will take the corresponding configurable number of starts (**Max Cold Starts** or **Max Hot Starts**) in order to compare with the actual number of cold and hot starts within the past time interval.

### Events

Setting introduced in 8A release to allow the user to enable or disable the events related to this feature. By default, this setting is set to *Enabled*.

### Targets

Setting introduced in 8A release to allow the user to disable or set to Latched or Self-Reset the targets related to this feature. By default, this setting is set to *Latched*.

#### 14.18.2.3.2 MAXIMUM COLD/HOT STARTING RATE LOGIC




Figure 124: Maximum cold/hot starting rate logic

### 14.18.2.4 TIME BETWEEN STARTS

#### 14.18.2.4.1 TIME BETWEEN STARTS IMPLEMENTATION

The Time Between Starts function enforces a minimum time duration between two successive start attempts. A time delay is initiated with every start attempt, and a new start is not allowed until the specified interval has lapsed. This timer feature is useful in enforcing the duty limits of starting resistors or starting autotransformers.

At the detection of the motor start, the Time Between Starts timer is loaded with the value set at **Minimum Time** setting. Even unsuccessful start attempts are logged as starts for this feature. Once the motor is *Stopped*, if the time elapsed since the most recent start is less than the **Minimum Time** setting, the *Start Inhibit* operand is activated to block the motor start. If a block occurs, the lockout time (*TBStarts LO Time*) is equal to the time elapsed since the most recent start subtracted from the **Minimum Time** setting.

Example: If **Minimum Time** is set to *25 min*.

- A start occurs at T = 0 minutes
- The motor is stopped at T = 12 minutes
- A block occurs. The lockout time (*TBStarts LO Time*) is 25 minutes - 12 minutes = 13 minutes

If the Emergency Restart input (*Emrg Restart* operand) is asserted while the motor is *Stopped* or *Tripped* during a Time Between Starts lockout (*TBStarts LO Time*), the Time Between Starts timer is reset. This causes a dropout of the *Start Inhibit* operand and allows a new start. If the motor starts while the Emergency Restart input (*Emrg Restart* operand) is asserted, the lockout timer (*TBStarts LO Time*) does not remain reset and starts running from the rising edge of the *Motor Starting* state. However, *Start Inhibit* and *Time Btw Str OP* will remain reset until the Emergency Restart Input (*Emrg Restart* operand) is de-asserted.

**Note:**

The status of the Time Between Starts element (including the time) is stored in non-volatile memory and remains in the memory after the power is removed from the IED. When the power is restored, the Time Between Starts (**Time Bet Starts**) element continues working normally using the information collected before the power loss, if the real time clock worked properly during the power loss. However, when the IED power is restored, if the clock is not working properly or it has defaulted to the factory setting, the "TBStarts LO Time" will remain unchanged and prevent the motor from starting until "TBStarts LO Time" reaches zero, or the Emergency Restart ("Emrg Restart" operand) is asserted.

## TIME BETWEEN STARTS SETTINGS AND FLEXLOGIC OPERANDS

The Time Between Starts function provides the following FlexLogic operands:

FlexLogic Operands	
Operand	Description
Time Btw Str PKP	Time Between Starts has picked up (start)
Time Btw Str OP	Time Between Starts has operated (trip)

Time Between Starts settings can be found at **SETPOINTS\CONTROL\MOTOR STARTING\STRT SUPERVISION\TIME BET STARTS** path.

The settings are as follow:

### Function

This setting allows the user to set the Time Between Starts element as *Enabled* or *Disabled*.

### Minimum Time

This setting sets the amount of time following a start before a start control is permitted, to prevent restart attempts in quick succession (jogging).

### Events

Setting introduced in 8A release to allow the user to enable or disable the events related to this feature. By default, this setting is set to *Enabled*.

### Targets

Setting introduced in 8A release to allow the user to disable or set to *Latched* or *Self-Reset* the targets related to this feature. By default, this setting is set to *Latched*.

### 14.18.2.4.2 TIME BETWEEN STARTS LOGIC




Figure 125: Time between starts logic

### 14.18.2.5 RESTART DELAY

#### 14.18.2.5.1 RESTART DELAY IMPLEMENTATION

The Restart Delay feature is used to ensure that a certain amount of time passes between the time a motor is stopped and the restarting of that motor. This timer feature can be very useful for some process applications or motor considerations. If a motor is on a down-hole pump, after the motor stops, the liquid can fall back down the pipe and spin the rotor backwards. It is very undesirable to start the motor at this time and this feature can prevent that.

The Restart Delay inhibit lockout (*Rest Dly LO Time*) will remain active when the Emergency Restart input (*Emrg Restart* operand) is asserted.

The status of the Restart Delay element (including the time) is stored in non-volatile memory and remains in the memory after the power is removed. When the power is restored, the **Restart Delay** element continues working normally using the information collected before the power loss.

**Note:**

*The status of the Restart Delay element (including the time) is stored in non-volatile memory and remains in the memory after the power is removed from the IED. When the power is restored, the Restart Delay element continues working normally using the information collected before the power loss if the real time clock worked properly during the power loss.*

### RESTART DELAY SETTINGS AND FLEXLOGIC OPERANDS

Restart Delay function provides the following FlexLogic operands:

FlexLogic Operands	
Operand	Description
Restart Dly PKP	Restart Delay has picked up (start)
Restart Dly OP	Restart Delay has operated (trip)

Restart Delay settings can be found at **SETPOINTS\CONTROL\MOTOR STARTING\STRT SUPERVISION\RESTART DELAY** path.

The settings are as follows:

#### Function

This setting allows the user to set the Time Between Starts element as *Enabled* or *Disabled*.



### Minimum Time

This setting sets the amount of time following a stop before a start control is permitted.

### Events

Setting introduced in 8A release to allow the user to enable or disable the events related to this feature. By default, this setting is set to *Enabled*.

### Targets

Setting introduced in 8A release to allow the user to disable or set to *Latched* or *Self-Reset* the targets related to this feature. By default, this setting is set to *Latched*.

#### 14.18.2.5.2 RESTART DELAY LOGIC





Figure 126: Restart delay logic

#### 14.18.2.6 REDUCED VOLTAGE STARTING


##### 14.18.2.6.1 REDUCED VOLTAGE STARTING IMPLEMENTATION

The IED can control the transition of a reduced voltage starter from reduced to full voltage. That transition may be based on *Current Only*, *Current and Timer*, or *Current or Timer* (whichever comes first). When the IED detects a *Motor Starting* condition, the current will typically rise quickly to a value in excess of FLA (e.g.,  $5 \times \text{FLA}$ ). At this point, the **Start Timer** is initialized while the motor current is simultaneously monitored. When the transition from reduced to full voltage is initiated, the *Reduced V Ctrl* operand will be asserted for the time programmed in the **Start Rly Timer** setting. The intention is to link this operand to the auxiliary relay output that can control reduced voltage start contactors. This feature can also assert a trip signal if the current or timer transitions do not occur as expected. This element is functional only if the external motor Start/Stop command is used. An example of the control wiring related to this element is depicted in the diagram below.



**Figure 127: Reduced voltage start contactor control circuit**

The following figure provides a typical current - time diagram of a reduced voltage start sequence.



**Figure 128: Reduced voltage start current characteristic**

If this feature is used, the Starter Status Switch input must be either from a common control contact, or a parallel combination of Auxiliary 52a contacts, or a combination of Auxiliary 52b contacts from the reduced voltage contactor and the full voltage contactor, as shown in the following diagram.




Figure 129: Reduced voltage starting wiring example

### REDUCED VOLTAGE STARTING SETTINGS AND FLEXLOGIC OPERANDS

The Reduced Voltage Starting Rate function provides the following FlexLogic operands:

FlexLogic Operands	
Operand	Description
Reduced V Ctrl	Asserted upon a valid transition in any mode
Reduced V Fail	Asserted when an invalid transition occurs

Reduced Voltage Starting settings can be found at **SETPOINTS\CONTROL\MOTOR STARTING\REDUCED V STRTNG** path.

The settings are as follows:

#### Function

This setting enables the Reduced Voltage Starting functionality when set to any value other than *Disabled*. This feature can be set to *Trip*, *Latched Trip* or *Configurable*.

#### Control RlyOP[X]

Any assignable Relay Output can be selected to operate upon *Reduced V Ctrl* operand assertion.

#### Transition Mode

This setting establishes the type of transition mode we want to monitor (*Current Only*, *Current or Timer*, *Current and Timer*).

#### Current Only:

When the motor load falls below the **Start Curr Set** setting prior to the expiration of the **Start Timer** setting, a transition will be initiated by asserting the *Reduced V Ctrl* operand for the time programmed in the **Start Rly Timer** setting. Any relay output contact assigned to this operand will operate for this period of time. If the reduced voltage Start Timer expires prior to the motor load dropping below the **Start Curr Set** setting, the *Reduced V Ctrl* operand does not change state and the *Reduced V Fail* operand is asserted.

#### Current or Timer:

When the motor load falls below the **Start Curr Set** setting, or if the reduced voltage **Start Timer** expires, a transition will be initiated by asserting the *Reduced V Ctrl* operand for the time programmed in the **Start Rly Timer** setting. Any relay output contact assigned to this control signal will operate for this period of time.

**Current and Timer:**

A transition will be initiated by asserting the *Reduced V Ctrl* operand for the time programmed in the **Start Rly Timer** setting, when the reduced voltage **Start Timer** expires, and the motor load has dropped below the **Start Curr Set** setting prior to the expiration of the reduced voltage **Start Timer**. If the reduced voltage **Start Timer** expires prior to the motor load dropping below the **Start Curr Set** setting, the *Reduced V Ctrl* operand does not change state and the *Reduced V Fail* operand is asserted. Start Rly Timer

This setting establishes the time that the *Reduced V Ctrl* operand will be kept asserted after initiating a transition.

**Start Curr Set**

The motor current has to drop below the value selected in this setting to initialize the transition. This applies if *Current Only* or *Current or Timer* are selected as **Transition Mode**.

**Start Timer**

This setting establishes the reduce voltage timer which expiration will determine the initialization of a transition.

**Inhibit**

This setting defines the FlexLogic operand to inhibit (block), when asserted, the Reduce Voltage Starting feature.

**Trip RlyOP[X]**

Any assignable Relay Output can be selected to operate upon *Reduced V Fail* operand assertion.

**Events**

Setting introduced in 8A release to allow the user to enable or disable the events related to this feature. By default, this setting is set to *Enabled*.

**Targets**

Setting introduced in 8A release to allow the user to disable or set to *Latched* or *Self-Reset* the targets related to this feature. By default, this setting is set to *Latched*.

14.18.2.6.2 REDUCED VOLTAGE STARTING LOGIC




Figure 130: Reduced voltage starting logic

## 14.19 SELECT BEFORE OPERATE

### 14.19.1 SELECT BEFORE OPERATE IMPLEMENTATION

In 30TE models with a configurable single line diagram, Multilin Agile provides local control of the breaker and switches using the front panel pushbuttons through the Select Before Operate (SBO) function. The SBO feature is only available in local mode, when the relay is ordered with 30TE. SBO can be enabled using the setpoint **Local with SBO** located under menu Path: **Setpoint\Control\Local Control w/SBO**.

- When the setting **Local with SBO** is enabled, it will enable the local control of all the CB and Switches using the front panel. In this case, the breaker setting **Control By** and all the switches setting **Control By** become default to local mode. The settings **Control By** for Breaker and Switches are located under menu Path: **Setpoint\Control\CB Control for Breaker**, and Path: **Setpoint\Control\Switch Control**, for Switches respectively.
- When **Local with SBO** remains disabled, then the breaker can be individually set to local/remote/opto modes using the Setpoint **Control By** in menu Path: **Setpoint\Control\CB Control**. Similarly, a switch can be individually set to local or remote mode using the Setpoint **Control By** in menu Path: **Setpoint\Control\Switch Control**.

### 14.19.2 SELECT BEFORE OPERATE LOGIC

#### 14.19.2.1 SWITCHING DEVICE SELECTION USING NAVIGATION KEYS

The Multilin Agile front panel provides navigation pushbuttons that highlight the component (breaker or disconnect \overhead switch) from the single line diagram. As shown in the following figure, the navigation pushbuttons (Up/Down/Left/Right), are used to browse through the SLD components. These pushbuttons are used for SLD navigation only. The navigation starts with highlighting the first breaker, and then goes through all the other components in sequence, until the last one (breaker or switch). Only the breakers (contactor) and switches included in the SLD from the display will be browsed (navigated).

*Note:*

*The selection of Breaker and Switches is available only to those configured and included in the SLD. If the breaker or a switch **Function** setting is programmed to Disabled, it will be skipped from the sequence during navigation.*

#### 14.19.2.2 SWITCHING DEVICE CONTROL USING FRONT PANEL

Once the breaker or the switch is highlighted in the SLD, using the navigation pushbuttons, the component must be selected before an open or close action is performed. The selection of the component is performed by pressing the "ENTER" key from the front panel. A flash message "CB Selected", or "Sw # Selected" appears on the screen to denote the selection.

If breaker is selected, it can be controlled using:

- The hardcoded 'Open' (O) and 'Close' (I) pushbuttons or
- If, in addition to local mode, Opto control is configured under setting **Control By**, once the breaker is selected, the control signal programmed under settings **Init Close** and **Init Open** can be used to Close and Open the breaker, respectively. With SBO, the addition of Opto-inputs for closing and opening the breaker in local mode provides the flexibility to use a pair of pushbuttons mounted on the cubicle in close proximity to the relay.

If switch is selected, it can be Opened and Closed using the hardcoded 'Open' (O) and 'Close' (I) pushbuttons, respectively. The relay doesn't allow closing and opening of a switch using Opto-inputs, regardless of the SBO being enabled or disabled.

When **Local with SBO** is disabled, the breaker can be controlled directly by the hardcoded 'Open' and 'Close' pushbuttons without additional confirmation or manually using the **Trip/Close** command directly or from the Front

Port. The **Trip/Close** command is located at **SETPOINTS\CONTROL\CB CONTROL** menu. Opto-inputs can also be used to open and close, if **Control By** is programmed to Opto, Local+Opto or Local+Opto+Remote.

When **Local with SBO** is disabled, the local control for the disconnect\overhead switches is suspended from the front panel. Open and Close control of switches using the Open and Close pushbuttons on the front panel is only available when **Local with SBO** is enabled. When **Local with SBO** is disabled, switches cannot be controlled using the front panel pushbuttons in local mode. In that case, switches can be controlled manually using the **Trip/Close** command directly or from the Front Port. The **Trip/Close** command is located at **SETPOINTS\CONTROL\SWITCH CONTROL** menu.

The navigation, the breaker or switch selection and the front panel control are operational when in **Local mode with SBO** is enabled. When both **Local with SBO** and remote options are configured, the default breaker and switch control remain in Remote mode until the relay enters into local mode by pressing the L/R pushbutton on the front panel for 3 seconds. When the relay enters into front panel local mode control, LM letters are displayed on the relay display banner and **Local Mode On** operand becomes true. Alternatively, an LED can be programmed to turn ON using the **Local Mode On** operand to indicate activation of local control from the front panel of the relay.

**Note:**

Regardless of whether remote mode is selected with local mode, the L/R pushbutton must be pressed for 3 seconds to enter into the front panel local control mode.

With IEC 61850 OrCAT control, the relay can also enter in local mode control when setting '**IED Local Status**' operand becomes true. Once in local mode, when 'L/R PB' is short pressed the relay exits local mode. Moreover, the relay can also exit the local mode when setting '**IED Local Status**' operand becomes false only if the relay was entered into Local Mode using the '**IED Local Status**'. If the relay was entered using the 'L/R PB 3sec pulse' then '**IED Local Status**' cannot be used to exit the local mode.

The selected component from SLD can be deselected by one of the following three ways:

- If the time programmed in **SETPOINTS\CONTROL\LOCAL CONTROL W/SBO\CB/SW SELECT TIMEOUT** expires
- The RESET PB is short pressed. It only deselects the selected component while the relay remains in Local Mode and the LM icon is displayed.
- Short pressing of the L/R PB can also be used to deselect the selected component. Moreover, by pressing the L/R PB while in local mode, the relay exits local mode and the LM icon turns off

**Note:**

The "HOME" button will not deselect the selected object. To navigate to the home page, the component must first be deselected on the SLD page using the PB 'L/R'.

**Note:**

When setting **Local with SBO** is enabled and the relay enters into the front panel local control mode by pressing L/R button for 3 seconds, the 'Reset' button is exclusively used by the relay to deselect the switching component on the SLD, and therefore, any other resetting functionality of the Reset button is ignored.

**Note:**

The selection of the breaker or a switch allows the user to apply only one control command, either open or close. After the status of the component is confirmed to match the applied control action, the component gets deselected. The component needs to be selected again to apply another command.

The local mode breaker or switch selection and operation is only active if the user has the proper level of security access.




Figure 131: Navigation and SLD component selection




Figure 132: Multilin Agile 20TE local and remote mode selection logic






Figure 133: Multilin Agile 30TE local mode on logic




Figure 134: Multilin Agile 30TE local and remote mode selection logic

## 14.20 CIRCUIT BREAKER/CONTACTOR CONTROL

**Note:**

Multilin Agile Motor IEDs have the option of Breaker or Contactor as a Switching Device selected at **Switch Dev Type** setting at **SETPOINT\SYSTEM\MOTOR\SETUP** path. Depending on the **Switch Dev Type** setting selection, the related settings for Breaker or Contactor may or may not be available for the user to configure.

E.g. if the **Switch Dev Type** is set as Breaker: **CB SETUP** menu settings at **SETPOINTS\SYSTEM** path and **CB CONTROL** menu settings at **SETPOINT\CONTROL** path will be available. If the **Switch Dev Type** is set as Contactor: **CONTACTOR** menu settings at **SETPOINTS\SYSTEM** path and **CONTACTOR CTRL** menu settings at **SETPOINT\CONTROL** path will be available.

This section describes both Breaker Control and Contactor Control functionality.

Although some circuit breakers or contactors do not provide auxiliary contacts, most provide auxiliary contacts to reflect the state of the circuit breaker or contactor. These are:

- CBs/Contactors with 52A contacts (where the auxiliary contact follows the state of the CB or contactor)
- CBs/Contactors with 52B contacts (where the auxiliary contact is in the opposite state from the state of the CB or contactor)
- CBs/Contactors with both 52A and 52B contacts

Circuit Breaker or Contactor control is only possible if the circuit breaker or contactor in question provides auxiliary contacts. The **Status Input** setting in the **SETPOINTS\SYSTEM\CB SETUP\CONTACTOR MENU** element must be set to the type of circuit breaker or contactor. If no CB or contactor auxiliary contacts are available then this setting should be set to *None*, and no CB or contactor control will be possible.

For local control, the **Control by** setting should be set at **SETPOINTS\CONTROL\CB CONTROL/CONTACTOR CTRL** menu.

The output contact can be set to operate following a time delay defined by the setting **Man Close Delay**. One reason for this delay is to give personnel time to safely move away from the circuit breaker or contactor following a CB or contactor close command.

The control close cycle can be cancelled at any time before the output contact operates by any appropriate trip signal, or by activating the **Reset Close Dly** signal.

The length of the trip and close control pulses can be set via the **Trip Pulse Time** and **Close Pulse Time** settings respectively. These should be set long enough to ensure the breaker has completed its open or close cycle before the pulse has elapsed.

If an attempt to close the breaker or contactor is being made, and a protection trip signal is generated, the protection trip command overrides the close command.

If the CB or contactor fails to respond to the control command (indicated by no change in the state of CB or contactor Status inputs) an alarm is generated after the relevant trip or close pulses have expired. These alarms can be viewed on the LCD display, remotely, or can be assigned to output contacts using the Flexlogic Equation Editor.

**Note:**

The **Healthy Time** under the menu section is applicable to manual circuit breaker or contactor operations only.

The device includes the following options for control of a single circuit breaker or contactor:

- The IED menu (local control)
- The Hotkeys (local control 20TE)/Front Panel Pushbuttons (local control 30TE)
- The opto-inputs (local control)
- SCADA communication (remote control)

### 14.20.1 MOTOR CONTROL USING THE IED MENU

Manual trips and closes can be manually launched using the **Trip/Close** command at **SETPOINTS\CONTROL\CB CONTROL/CONTACTOR CTRL** menu. This can be set to *No Operation*, *Trip*, or *Close* accordingly.

For this to work you have to set the **control by** setting to *Local*, *Local+Remote*, *Opto+Local*, or *Opto+Rem+Local* in the **CB CONTROL OR CONTACTOR CONTROL** menu.

### 14.20.2 MOTOR CONTROL USING THE HOTKEYS IN 20TE FRONT PANEL

The hotkeys allow the user to manually stop and start the motor without the need to enter the **CB OR CONTACTOR CONTROL** menus. For this to work the **Control by** setting must be set to *Local*, *Local+Remote*, *Opto+Local*, or *Opto+Rem+Local* in the **CB OR CONTACTOR CONTROL** element.

Motor control using the hotkey is achieved by pressing the right-hand Up button directly below LCD screen text MTR CTR at the Default Display that shows the Model Number, Database Date and Shortcuts. This button is only enabled if:

- The **Control by** setting is at **SETPOINTS\CONTROL\CB CONTROL/CONTACTOR CTRL** set to one of the options where local control is possible
- The **Status Input** setting at **SETPOINTS\SYSTEM\CB SETUP/CONTACTOR** is set to '52A', '52B', or 'Both 52A and 52B'

Once in MTR CTR hotkey operating mode by pressing the right-hand Up button, the CB or Contactor Status (Closed, Open or Unknown) will be displayed. Depending on the CB or Contactor status, different command options will be available: If the CB is currently closed, the command text on the bottom left of the LCD screen reads *Stop*. If the switching device (CB or Contactor) is currently open, and the motor is currently stopped, the command text on the bottom right of the LCD screen will read *Start*. If the switching device status is unknown, there is no command text given, just the *Exit* hotkey.

If a *Stop* is executed, a screen with the motor status will be displayed once the command has been completed. If a *Start* is executed, a screen with a countdown will appear while the command is being executed. The time delay is determined by the **Man Close Delay** setting in the **CB OR CONTACTOR CTRL** menu. When the command has been executed, a screen confirming the present status of the motor is displayed. The user is then prompted to select the next appropriate command or exit.

The hotkey functionality is summarised graphically below:




Figure 135: Hotkey menu navigation

**Note:**

There may be a very rare situation, when the switching device is closed while the supply to motor is disconnected from the upstream switching device. In this case, the motor status remains Stopped because the motor currents are zero, but the switching device status becomes/remains Closed. In this situation, Hotkeys control provides the capability to execute the switching device open command

### 14.20.3 MOTOR CONTROL USING THE STOP AND START PUSHBUTTONS IN 30TE FRONT PANEL

Certain applications may require the use of pushbuttons or other external signals to control the various CB control operations. It is possible to connect such pushbuttons and signals to opto-inputs and map these to the relevant IEDs signals.

For this to work, the **CB control by** setting must be set to *opto*, *Opto+Local*, *Opto+Remote*, or *Opto+Rem+Local* in the **CB CONTROL** menu.

### 14.20.4 MOTOR CB OR CONTACTOR CONTROL USING THE OPTO-INPUTS

Certain applications may require the use of pushbuttons or other external signals to control the various motor CB or Contactor control operations. It is possible to connect such pushbuttons and signals to opto-inputs and map these to the relevant IEDs signals.

In 20TE models, for this to work, the **Control by** setting must be set to *opto*, *Opto+Local*, *Opto+Remote*, or *Opto+Rem+Local* in the **CB CONTROL** or **CONTACTOR CTRL** menu.

In 30TE models:

- If the **Select Before Operate** feature is not enabled, this is, the **Local with SBO** setting at **SETPOINTS\CONTROL\LOCAL CONTROL W/SBO** path is *Disabled*, the Opto-inputs can be directly used if the **Control by** setting at **CB CONTROL** or **CONTACTOR CTRL** menus at **SETPOINTS\CONTROL** path is set to *Opto*, *Opto+Local*, *Opto+Remote*, or *Opto+Rem+Local*.
- If the **Select Before Operate** feature is enabled, this is, **Local with SBO** setting at **SETPOINTS\CONTROL\LOCAL CONTROL W/SBO** path is *Enabled*, and the **Control by** setting is set to *Opto+Local* or *Opto+Remote*, then, once the breaker or contactor is selected on the single line diagram, the control signals programmed under **Init Close** and **Init Trip** settings at **CB CONTROL** or **CONTACTOR CTRL** menus at **SETPOINTS\CONTROL** path, can be used to Close and Open the breaker or contactor, respectively. With SBO, the addition of Opto-inputs for closing and opening the breaker or contactor in local mode provides flexibility to use a pair of pushbuttons mounted on the cubicle in the same proximity with the device.

### 14.20.5 REMOTE CB CONTROL

Remote CB control can be achieved by setting the **Trip/Close** to trip or close in the **CB CONTROL** or **CONTACTOR CTRL** menus at **SETPOINTS/CONTROL** path by using a command over a communication link.

For this to work, the **Control by** setting must be set to *Remote*, *Local+Remote*, *Opto+remote*, *Opto+Local+Rem+Local* in the **CB CONTROL** or **CONTRACTOR CTRL** menus.

We recommend that separate relay output contacts are allocated for remote CB or Contactor control and protection tripping. This allows you to select the control outputs using a simple local/remote selector switch as shown below. Where this feature is not required the same output contact(s) can be used for both protection and remote tripping.




Figure 136: Remote control of circuit breaker

### 14.20.6 CB/CONTACTOR HEALTHY CHECK

A CB or Contactor Healthy check is available if required. The **Healthy** setting at **SETPOINTS\CONTROL\CB CONTROL/CONTACTOR** path accepts any logic signal or opto input to indicate that the breaker or contactor is capable of closing (e.g. that it is fully charged). A time delay can be set with the setting **Healthy Time**. If the CB or contactor does not indicate a healthy condition within the time period following a Close command, the device will raise a *Man CB Unhealthy* for Breaker or *Man Cnct Unhealthy* for Contactor logic signals that can be used for signalisation.

### 14.20.7 CB CONTROL LOGIC




Figure 137: CB control logic




Figure 138: 20TE HMI close and HMI trip logics






Figure 139: 30TE HMI close logic




Figure 140: 30TE HMI trip logic

Figure 141:




Figure 142: IEC 61850 control authority settings logic

### 14.20.8 CONTROL AUTHORITY (IEC61850)

This section describes the IEC 61850 control authority feature implementation in Multilin Agile.

Within the substation, control commands to the primary equipment, such as breaker or contactor or disconnect switch, can be originated from one of the three levels: Bay level, Station level or Remote level. The local/remote control feature (described in IEC 61850 7-4: Annex B) allows users to enable or disable control authority from one or more of the three levels.

The below table shows the control authority implemented in Multilin Agile IEDs.

#### Control Authority

	Switch	Bay Control			Manual Control at Switch Process)	Non 61850 Bay Control (Front Panel PB, HMI)	Command From		
		Mode of Switching Authority for Local Control	Local Control Behaviour	Control Authority at Station Level			Bay	Station	NCC
							OrCat		
LLN0.LocKey	XCBR.Loc XSWI.Loc	LLN0.MitLev	CSWI.Loc	CSWI.LocSta OR LLN0.LocSta			Local Ctl (Bay)	Station	Remote
IED Local Status = 1	Local Mode Selected = 1	Multilevel Control (ENABLED)	Bay Level 61850 Authority (ON)	Station Level 61850 Authority (ON)					
T	T	F	n.a.	n.a.	AA	AA	NA	NA	NA
F	F	F	T	n.a.	AA	AA	AA	NA	NA
F	F	F	F	T	AA	AA	NA	AA	NA
F	F	F	F	F	AA	AA	NA	NA	AA
T	T	T	n.a.	n.a.	AA	AA	NA	NA	NA

	Switch	Bay Control			Manual Control at Switch Process)	Non 61850 Bay Control (Front Panel PB, HMI)	Command From		
		Mode of Switching Authority for Local Control	Local Control Behaviour	Control Authority at Station Level			Bay	Station	NCC
							OrCat		
LLN0.LocKey	XCBR.Loc XSWI.Loc	LLN0.MitLev	CSWI.Loc	CSWI.LocSta OR LLN0.LocSta			Local Ctl (Bay)	Station	Remote
F	F	T	T	n.a.	AA	AA	AA	NA	NA
F	F	T	F	T	AA	AA	AA	AA	NA
F	F	T	F	F	AA	AA	AA	AA	AA

#### Loc status (behaviour of the LN reg. switching authority)

T = TRUE                      command only allowed at this level  
 F = FALSE                    command not allowed at this level  
 n.a. = not applicable      the position of this Loc is of no importance

#### Command

AA = ALWAYS ALLOWED                      Command always allowed  
 NA = NOT ALLOWED                          Command not allowed

#### MitLev (mode of switching authority for local control)

F = only one level (Originator) at a time has the switching authority (default, if this data object is not present)  
 T = more than one level (Originator) at any time has the switching authority (e.g. station and bay level)

**Non-61850 Bay Control** - Any manual control from the relay, such as control from Front panel or relay push buttons or command initiated from Flexoperands.

With **IED Local Status** setting, the operand **Local Mode On** is generated when the value of the **IED Local Status** setting at **SETPOINTS\DEVICE\COMMUNICATION\GENERAL** path is True and, either the **Local with SBO** setting at **SETPOINTS\CONTROL\LOCAL CONTROL W/SBO** is *Enabled* or the **Control By** setting at **SETPOINTS\CONTROL\CB CONTROL** is configured to either *Local*, *Local+Remote*, *Opto+Local*, *Opto+Rem+Local*. LLN0.Loc is mapped to **Local Mode On**.

**Manual control at switch (process)** - means the control outside IED, may be breaker is controlled directly from control panel without IED intervention.

There are several settings in Multilin Agile to configure IEC 61850 control authority, these settings are placed at **SETPOINTS\DEVICE\COMMUNICATIONS\GENERAL** for generic settings and at **SETPOINTS\CONTROL\CB CONTROL** and **SETPOINTS\CONTROL\SWITCH CONTROL** for breaker and switches respectively.

#### GENERIC SETTINGS

These settings can be set at **SETPOINTS\DEVICE\COMMUNICATIONS\GENERAL** path.

##### **Multi Lvl Ctrl**

When this setting is set to *Enabled*, control authority from multiple levels (Bay, Station and Remote) are allowed simultaneously based on Local/Remote status and status authority status. Otherwise only one level has the authority to control, based on Local/Remote status and status authority status.

##### **IED Local Status**

This setting allows the selection of an operand, that indicates IED in local mode. When the operand value is set, the IED is considered in local mode and when the operand is reset, the IED is considered in remote mode.

The **IED Local Status** setting is related to the **Local Mode On** Flexlogic operand.

With **IED Local Status** setting, the operand **Local Mode On** is generated when the value of the **IED Local Status** setting at **SETPOINTS\DEVICE\COMMUNICATION\GENERAL** path is True and, either the **Local with SBO** setting at **SETPOINTS\CONTROL\LOCAL CONTROL W/SBO** is *Enabled* or the **Control By** setting at **SETPOINTS\CONTROL\CB CONTROL** is configured to either *Local*, *Local+Remote*, *Opto+Local*, *Opto+Rem+Local*. LLN0.Loc is mapped to **Local Mode On**.

#### **StnLv 61850 Auth**

This setting allows the selection of an operand that indicates the Station level authority status.

The operand status is modelled in the IEC 61850 server, using respective breakers CSWI LocSta data object. The operand status is applied to the control authority table to determine the control authority for different levels. It is an Edge driven function.

#### **BAY SETTINGS (BREAKER AND SWITCHES)**

These settings are available at **SETPOINT\CONTROL\CB CONTROL** for breaker and at **SETPOINT\CONTROL\SWITCH CONTROL** for switches (1 to 8).

#### **BayLv 61850 Auth**

This setting allows the selection of an operand that indicates the Bay level authority status.

The operand status is modelled in the IEC 61850 server using respective breakers CSWI Loc data object. The operand status is applied to the control authority table to determine the control authority for different levels. It is an Edge driven function.

---

### **14.20.9 CONTROL AUTHORITY (IEC61850)**

The settings for the CB Control function are placed at **SETPOINTS\CONTROL\CB CONTROL** path.

The settings are as follows:

#### **Control by**

This setting selects the type of circuit breaker control to be used.

In 30TE models with configurable single line diagram, when the **Local with SBO** setting at **SETPOINTS\CONTROL\LOCAL CONTROL W/SBO** path is **Enabled**, the default of this setting becomes *Local*.

An example of the default settings and ranges for 20TE or 30TE with **Local with SBO** set as *Disabled*, and 30TE with **Local with SBO** set as *Enabled*.

20TE or 30TE with **Local with SBO** set as *Disabled*.

Default: *Disabled*

Range: *Disabled*, *Local*, *Remote*, *Local+Remote*, *Opto*, *Opto+local*, *Opto+Remote*, *Opto+Rem+local*

30TE with **Local with SBO** set as *Enabled*.

Default: *Local*

Range: *Disabled*, *Local*, *Local + Remote*, *Opto + Local*, *Opto+Rem+Local*

#### **HMI Close**

This setting is available when the remote mode is enabled with local mode. This is either *Local+Remote* or *Opto+Rem+local* set at **Control by** setting.

When **HMI Close** setting is configured as *Operate*, the breaker closing through the HMI is possible. When **HMI Close** setting is set as *No Operate*, the breaker closing through the HMI is not possible.

#### **Close Pulse Time**

This setting defines the duration of the close pulse, which the CB should close when a close command is issued.

*Note:*  
*This timer is a Pulse timer.*

### **Trip Pulse Time**

This setting defines the duration of the trip pulse, which the CB should trip when a manual or protection trip command is issued.

*Note:*  
*This timer is a Pulse timer.*

### **Man Close Delay**

This setting defines the delay time before the close pulse is executed.

### **Healthy Time**

This setting defines the time period in which a CB needs to indicate a healthy condition before it closes.

If the CB does not indicate a healthy condition in this time period following a close command, the IED will raise an alarm.

### **Sys Check Time**

This setting sets a time delay for manual closure with System Check Synchronizing.

If the System Check Synchronizing criteria are not satisfied in this time period following a close command, the IED will produce an alarm.

### **Init Trip**

This setting allows the configuring of a Flexlogic operand that when asserted will initiate the circuit breaker to open.

This setting is applicable only when **Control by** setting is set to either *Opto*, *Opto+local*, *Opto+Remote*, *Opto+Rem+local*.

### **Trip Command In**

This setting allows the configuring of a Flexlogic operand that when asserted triggers the fixed Trip LED. It is mapped to the Trip Command. The default value of this setting is set to *Any Trip*.

### **Ext. Trip 3ph**

The Flexlogic operand configured in this setting receives an external three-phase trip signal.

### **Init Close**

This setting allows the configuring of a Flexlogic operand that when asserted will initiate the circuit breaker to close.

This setting is applicable only when **Control by** setting is set to either *Opto*, *Opto+local*, *Opto+Remote*, *Opto+Rem+local*.

### **Reset Close Dly**

This setting allows the configuring of a Flexlogic operand that when asserted will reset the Manual CB Close Time Delay.

### **Healthy**

This setting allows the configuring of a Flexlogic operand that indicates that the CB is healthy. A healthy condition is needed in order to close the breaker.

### **Man Check Synch**

This signal can be mapped to an opto-input to allow the IED to receive a signal from built in system check functionality.

### **Trip/Close**

This is a command (setting) to directly *Trip* or *Close* the breaker.

This setting is available for Local operation when **Control by** setting is set to either *Local*, *Local+Remote*, *Opto+Local*, *Opto+Rem+local* (HMI and front port).

This setting is available in all Protocols for Remote Operation when **Control by** setting is set either to *Remote*, *Local+Remote*, *Opto+Remote*, *Opto+Rem+local* (Rear port).

### **Interlock Open**

A setting to be set in the setup software or via SCL File. It selects an operand that indicates the Breaker Interlock status for "Open/Off" command from an IEC 61850 client. When the operand value is set (**CBCILO1.EnaOpn.stVal: is set to false**), the "Open/Off" command from the IEC 61850 Client is rejected if the client set the interlock-check, but in the "Check" parameter of the control command.

### **Interlock Close**

A setting to be set in the setup software or via SCL File. It selects an operand that indicates the Breaker Interlock status for "Close/On" command from an IEC 61850 client. When the operand value is set (**CBCILO1.EnaCls.stVal: is set to false**), the "Close/On" command from the IEC 61850 Client is rejected if the client set the interlock-check, but in the "Check" parameter of the control command.

### **Block Open**

The assertion of the operand assigned to this setpoint prevents the breaker from opening/tripping.

### **Block Close**

The assertion of the operand assigned to this setpoint prevents the breaker from closing.

### **BayLv 61850 Auth**


This setting allows the selecting of an operand that indicates the Bay level authority status. The operand status is modelled in the IEC 61850 server using respective breakers CSWI Loc data object. The operand status is applied to control authority table to determine the control authority for different levels. It is an Edge driven function.

## 14.21 SWITCH STATUS AND CONTROL

All Multilin Agile products support Switch Status and Control for up to 8 switchgear elements in an IEC 61850 substation. The device is able to monitor the status of and control up to eight switches. The type of switches that can be controlled are:

- Load Break switch
- Disconnecter
- Earthing Switch
- High Speed Earthing Switch

Consider the following feeder bay:



**Figure 143: Representation of typical feeder bay**

This bay shows four switches of the type LN XSWI and one circuit breaker of type LN XCBR. In this example, the switches XSW1 – XSWI3 are disconnectors and XSWI4 is an earthing switch.

For the device to be able to control the switches, the switches must provide auxiliary contacts to indicate the switch status. For convenience, the device settings refer to the auxiliary contacts as 52A and 52B, even though they are not circuit breakers.

There are eight sets of **SW(n) CONTROL** settings in the **SWITCH CONTROL** menu at **SETPOINTS\CONTROL\**, which allows the user to set up the Switch control, one set for each switch where (n) is the number of the switch. These settings are as follows:

### Type

This setting defines the type of switch. It can be a load breaking switch, a disconnector, an earthing switch or a high speed earthing switch.

### Status Input

This setting defines the type of auxiliary contacts that will be used for the control logic. For convenience, the device settings refer to the auxiliary contacts as 52A and 52B, even though they are not circuit breakers. "A" contacts match the status of the primary contacts, whilst "B" contacts are of the opposite polarity.

### Control by

This setting determines how the switch is to be controlled. This can be Local (using the device directly), Remote (using a remote communications link), or both (Local+Remote).

### Trip/Close



This is a command to directly trip or close the switch.

Remote Switch control can be achieved by setting the **CB Trip/Close** to trip or close by using a command over a communication link.

For this to work, the **Control by** setting should be set to *Remote* or *Local+Remote* in the **SW(n) CONTROL** menu for each switch.

Local Switch control can be achieved by setting the **CB Trip/Close** to trip or close by using a command over the IEDs front panel or USB communications.

For this to work, the **Control by** setting should be set to *Local* or *Local+Remote* in the **SW(n) CONTROL** menu for each switch.

The *SWI(n) Control Trp* and *SWI(n) Control Cls* logic operands are the outcome of the Trip and Close commands. This logic operand can be assigned to relay output contacts to physically operate the switches.

### **SWI1 Aux (52A) and SWI1 Aux (52B)**

This setting defines the signals that provides the status of the associated auxiliary contacts for each switch.

#### **Trip Pulse Time and Close Pulse Time**

These settings allow the user to control the width of the open and close pulses.

#### **Status Alrm Time**

This setting allows the user to define the duration of wait timer before the IED raises a status alarm.

#### **Trip Alrm Time and Close Alrm Time**

These settings control the delay of the open and close alarms when the final switch status is not in line with expected status.

### **SWI1 Blk Rmt Ops**

This setting blocks Switch Remote operation.

### **Reset Data**

This setting resets the switch monitoring data.

**Note:**

*In order to detect SWI1 Cls Fail, Close Alrm Time must be less than Close Pulse Time.*

**Note:**

*In order to detect SWI1 Trip Fail, Trip Alarm Time must be less than Trip Pulse Time.*

The actual values SWI1 Status and SWI1 Operations provided by the Switch Control can be accessed at the **DEVICE STATUS\SWITCH CONTROL** path directly in the IEDs front panel, or through the **Monitor** tab in the EnerVista Configuration Software.

*SWI1 Status* represents the status of the switch.

*SWI1 Operations* increments its status based on the number of switch trips. This a value saved in Non-volatile memory that can be reseted only using the **Reset Data** setting per each Switch.

**Note:**

*Settings for switch 1 are shown, but settings for all other switch elements are the same.*

### 14.21.1 SWITCH STATUS LOGIC




Figure 144: Switch status logic

### 14.21.2 SWITCH CONTROL LOGIC




Figure 145: Switch control logic

## 14.22 HARMONIC DETECTION

The Harmonic Detection function monitors the 2nd harmonic, which is present in the phase currents. The IED provides four identical Harmonic Detection elements.

During transformer energization or motor starts, the inrush current present in phase currents can impact some sensitive elements, such as negative sequence overcurrent. Therefore, the ratio of the second harmonic to the fundamental magnitude per phase is monitored, while exceeding the settable pickup level, an operand is asserted, which can be used to block such sensitive elements. The harmonics are updated every protection pass.

This function defines the phases required for operation like *Any One*, *Any Two*, *Any Three* or *Average*. This phase definition can be done at the **Operate Mode** setting at **SETPOINTS\MONITORING\HARMONIC DETEC**. If set to *Average*, the IED calculates the average level of the 2nd harmonic and compares this level against the pickup setting. Averaging of the 2nd harmonic follows an adaptive algorithm depending on the fundamental current magnitude per-phase. If the fundamental magnitude on any of the three phases goes below the current cut-off level, the 2nd harmonic current from that phase is dropped (zeroed) from the equation for averaging, and the divider is decreased from 3 to 2. The same happens if the magnitude of the fundamental magnitude on one of remaining two phases drops below the cut-off level. In this case the 2nd harmonic on this phase is dropped from summation, and the divider is decreased to 1.

**Imin** setting at **SETPOINTS\MONITORING\HARMONIC DETEC** sets the minimum value of current required to allow the Harmonic Detection element to operate. If **Operate Mode** is set to *Average*, the average of three-phase currents is used for supervision. A similar adaptive average algorithm is applied to calculate the average of operation current magnitude.




Figure 146: Harmonic detection logic

**Note:**

Harmonic Detection functionality is only available in P24D & P24N products.

**Note:**

Take into account that Harmonic Detection signals can be used to block sensitive elements. In order to get proper functionality, the **Threshold** setting in the Harmonic Detection element should be programmed with values higher enough to allow measurement oscillation over the accuracy level. **Time Delay** setting should be higher enough to avoid transients in metering, and lower than the time delay of the IOC or TOC element being supervised by it.

## 14.23 DEMAND

### 14.23.1 CURRENT DEMAND

Current Demand is measured on each phase, and on three phases for real and reactive power. Setpoints allow the user to emulate some common electrical utility demand measuring techniques for statistical or control purposes.

The IED can be set to calculate Demand using the following two methods:

1. **Fixed Demand:** This calculates a linear average of the quantity (RMS current, real power, reactive power) over the programmed Demand time interval, starting daily at 00:00:00 (i.e. 12 am). The 1440 minutes per day is divided into the number of blocks as set by the programmed time interval. Each new value of demand becomes available at the end of each time interval.
2. **Rolling Demand:** This calculates a linear average of the quantity (RMS current, real power, reactive power) over the programmed Demand time interval, in the same way as Fixed Interval. The value is updated every minute and indicates the Demand over the time interval just proceeding the time of update.




Figure 147: Current demand logic

### 14.23.2 ACTIVE POWER DEMAND

**Active Demand** is monitored by comparing it to a Pickup value. If the **Active Demand Pickup** is ever equaled or exceeded, the IED can be configured to cause an alarm or signal an output relay.




Figure 148: Active demand logic

### 14.23.3 REACTIVE POWER DEMAND

The **Reactive Power Demand** is monitored by comparing to a Pickup value. If the **Reactive Power Demand Pickup** is ever equaled or exceeded, the relay can be configured to cause an alarm or signal an output relay.




Figure 149: Reactive power demand logic

---

## 14.24 DIGITAL COUNTERS

---

The IED provides sixteen identical Digital Counters. A Digital Counter counts the number of state transitions from logic 0 to logic 1. The Digital Counters are numbered from 1 to 16. The counters are used to count operations such as the Pickups of an element, the changes of state of an external contact (e.g. breaker auxiliary switch), or the pulses from a watt-hour meter.

**Pre-set** sets the count to a required pre-set value before counting begins. This may be necessary where a substitute relay is to be installed in place of an in-service relay, or while the counter is running.

**Compare** sets the value to which the accumulated count value is compared. Three output operands are provided to indicate if the present value is more than (*HI*), equal to (*EQL*), or less than (*LO*), the set value.

**Up** selects the operand for incrementing the Counter. If an enabled **Up** input is received when the accumulated value is at the limit of +2147483647, the counter rolls over to -2147483648 and shows the alarm *Digital Counter 1 at Limit*.

**Down** selects the operand for decrementing the Counter. If an enabled **Down** input is received when the accumulated value is at the limit of +2147483647, the counter rolls over to -2147483648 and shows the alarm *Digital Counter 1 at Limit*.

**Set To Pre-Set** selects the operand used to set the counter to the pre-set value. The counter is set at pre-set value in the following situations:

- When the Counter is enabled and **Digital Counter 1 Set to Pre-Set** operand has value *1* (when the Counter is enabled and **Digital Counter 1 Set to Pre-Set** operand has value *0*, the Counter will be set to 0).
- When the Counter is running and **Digital Counter 1 Set to Pre-Set** operand changes the state from *0* to *1* (**Digital Counter 1 Set to Pre-Set** changing from *1* to *0* while the Counter is running has no effect on the count).
- When a **Reset** or **Reset/Freeze** command is sent to the Counter and **Digital Counter 1 Set to Pre-Set** operand has the value *1* (when a reset or reset/freeze command is sent to the Counter and **Digital Counter 1 Set to Pre-Set** operand has the value *0*, the Counter will be set to 0).

**Reset** selects the operand for setting the count, either 0 or the pre-set value depending on the state of the Counter **1 Set to Pre-set** operand.

**Freeze/Reset** selects the operand for freezing (capturing) the accumulating count value into a separate register with the associated date and time of the operation while resetting the count to either 0 or the pre-set value depending on the state of the **Counter 1 Set to Pre-set** operand.

**Freeze/Count** selects the operand for freezing (capturing) the accumulating count value into a separate register with the associated date and time of the operation while continuing to count. The present accumulated value and frozen (captured) value with the associated date/time stamp are available as *Status* values. If control power is interrupted, during the power-down operation, the accumulated and frozen (captured) values are saved into non-volatile memory.



---

## 14.25 LOSS OF COMMUNICATIONS

---

The device monitors activity on an interface via the configured protocol for this interface. The communications status is set for each protocol. If communications are lost, the enabled interface will issue a *Loss of Comms* event and operate a combination of output relays/states. With the **Interface** setting, only the protocols associated with the selected interface are shown on this screen as options. For example, if **Ethernet** is selected, the Ethernet protocols are available to monitor. The Ethernet protocols selection is defined as EthernetProtocolBitmask.

---

## 14.26 TRIP BUS

---

Mutlin Agile IEDs provide six identical Trip Bus elements. The Trip Bus element allows aggregating outputs of protection, monitoring, control elements, inputs, etc., without the need to use the FlexLogic Equation Editor to assign them. In a simple and effective manner, you can directly map each each signal to any of the 16 input entry signals available to each Trip Bus element. Each Trip Bus can be assigned to trip, alarm, or the other logic actions. Simple trip conditioning such as latch, delay, and seal-in delay are available.

---

### 14.26.1 TRIP BUS IMPLEMENTATION

The settings for the **Trip Bus** control function are placed at **SETPOINTS\CONTROL\TRIP BUS** path. There are six **Trip Bus** elements available with sixteen signal inputs available for each **Trip Bus** element.

These settings are as follows:

#### **Input 1 to 16**

These settings (**Input 1 to Input 16**) select a FlexLogic operand to be assigned as an input to the **Trip Bus**.

#### **Latching**

This setting *enables* or *disables* the latching of the **Trip Bus** output. This is typically used when lockout is required, or user acknowledgement of the relay response is required.

#### **Reset**

The **Trip Bus** output is reset when the operand assigned to this setting is asserted.

#### **Pickup Delay**

This setting provides a definite time Pickup Delay (Time Delay) for the **Trip Bus** operation. Instantaneous operation is selected by a Pickup time delay setting of 0.000 s.

#### **Dropout Delay**

This setting provides a definite time Dropout Delay (tRESET). Instantaneous reset is provided by a Dropout time delay setting of 0.000 s.

#### **Inhibit**

The **Trip Bus** element will be blocked when the selected operand is asserted.

**Note:**

*The **Any Trip** operand must not be programmed as an input for the **Trip Bus** function.*

### 14.26.2 TRIP BUS LOGIC




Figure 150: Trip bus logic

## 14.27 DIGITAL ELEMENTS

Multilin Agile IEDs have 64 identical digital elements available. A digital element can monitor any FlexLogic operand, present a target message and enable events recording depending on the output operand state. The digital element settings include a name to be referenced in any target message, an inhibit input from any selected FlexLogic operand, and a timer for pickup (time delay) and dropout (tRESET) delays for the output operand.

**Note:**

*Digital elements run once per power system cycle. They can easily fail to react to an input signal or a block signal with a duration less than one power system cycle. This also means that the digital element output can react up to one power system cycle later than the pickup and reset delay settings indicate.*

**Warning:**

**Do not use digital elements with transient signals, such as communications commands.**

**Warning:**

**Do not use digital elements where random delays of up to one cycle cannot be tolerated, such as in high-speed protection.**

### 14.27.1 DIGITAL ELEMENTS IMPLEMENTATION

The settings for the **Digital Elements** control function are placed at **SETPOINTS\CONTROL\DIGITAL ELEMENTS** path. There are 64 **Trip Bus** elements available with sixteen signal inputs available for each **Trip Bus** element.

These settings are as follows:

**Name**

The user can assign a user-defined name to each **Digital Element**. Default pre-defined names are *Dig ElemX*, X being the number of each element. This **Name** is used In FlexLogic operands, Target messages and Events, etc.

**Input**

Selects a FlexLogic operand to be monitored by the **Digital Element**.

**Pickup Delay**

Sets the required time delay from the element pickup (start) to the element operation (trip). Instantaneous operation is selected by a Pickup time delay setting of 0.000 s.

**Note:**

*To avoid nuisance alarms, set the delay greater than the operating time of the breaker.*

**Dropout Delay**

This setting sets the dropout time delay (tRESET) to reset. Instantaneous reset is provided by a Dropout time delay setting of 0.000 s.

**Inhibit**

The Digital Element will be blocked when the selected operand is asserted.

### 14.27.2 DIGITAL ELEMENTS LOGIC




Figure 151: Digital elements logic

### 14.27.3 APPLICATION EXAMPLE

#### Trip Circuit Integrity Monitoring

In many applications it is desired to monitor the breaker trip circuit integrity so that problems can be detected before a trip operation is required. The circuit is considered to be healthy when the voltage monitor connected across the trip output contact detects a low level of current (Relay output voltage is not zero), well below the operating current of the breaker trip coil. If the circuit presents a high resistance, the trickle current falls below the monitor threshold, and an alarm is declared.

In most breaker control circuits, the trip coil is connected in series with a breaker auxiliary contact, which is open when the breaker is open. To prevent unwanted alarms in this situation the trip circuit monitoring logic must include the breaker position.

Relay Output 1 -Trip is a trip contact. Using the output settings, this output is given an ID name; for example, *Relay 1-Trip*. Assume a 52a breaker auxiliary contact is connected to Opto Input 1 to monitor breaker status (Inhibit when Opto input 1 is Off).

Using the Opto Input settings, this input is given a name, for example, **Opto I/P 1**, and is set to *On* when the breaker is closed, and the function is blocked when the breaker is open, e.g. **Opto I/P 1 Off**. The settings to use digital element 1 to monitor the breaker trip circuit are as indicated.

Setting	Parameter
Function	Enabled
Name	Bkr Trip Cct Out
Input	Opto I/P 1 On
Pickup Delay	0.200 s
Dropout Delay	0.100 s
Relays	Relay: Disabled
Inhibit	Opto I/P 1 Off
Events	Enabled
Target	Self-Reset

## CHAPTER 15

# SUPERVISION

---

## 15.1 CHAPTER OVERVIEW

---

This chapter describes the supervision functions.

This chapter contains the following sections:

Chapter Overview	345
DC Supply Monitor	346
Voltage Transformer Supervision	348
Current Transformer Supervision	351
Trip Circuit Supervision	353

## 15.2 DC SUPPLY MONITOR


This product can be powered using either a DC or AC supply. As a DC supply is normally used, a DC Supply Monitoring feature is included to indicate the DC supply status. The nominal DC Station supply is 48 V DC, which is provided by a bank of batteries. It is sometimes possible for this nominal supply to fall below or rise above acceptable operational limits. If the voltage is too high, it may indicate overcharging. If the voltage is too low, it may indicate a failing battery.

In such cases it is very useful to have DC supply monitoring functionality. Multilin Agile products provide such functionality by measuring the auxiliary DC supply fed into the device and processing this information using settings to define certain limits. In addition, the DC Auxiliary Supply value can be displayed on the front panel LCD to a resolution of 0.1 V DC. The measuring range is from 19 V DC to 300 V DC.

### 15.2.1 DC SUPPLY MONITOR IMPLEMENTATION

The P40Agile products provide three DC supply monitoring zones; zone 1, zone 2, and zone 3. This allows multiple monitoring criteria. Each zone must be configured to correspond to either an overvoltage condition or an undervoltage condition. A single zone cannot be configured to provide an alarm for both undervoltage and overvoltage conditions. Typically, you would configure zones 1 and 2 for undervoltage conditions, whereby the lowest limit is set very low, and zone 3 for an overvoltage condition whereby the upper limit is very high.

This is best illustrated diagrammatically:



**Figure 152: DC supply monitor zones**


It is possible to have overlapping zones whereby zone 2 upper limit is lower than zone 1 lower limit in the above example.

The DC Supply Monitoring function is implemented using settings in the **SETPOINTS\MONITORING\DC SUP. MONITOR** path. There are three sets of settings; one for each of the zones. The settings allow you to:

- Enable or disable the function for each zone
- Set a lower voltage limit for each zone
- Set an upper voltage limit for each zone
- Set a time delay for each zone
- Set an inhibition signal for each zone



## 15.2.2 DC SUPPLY MONITOR LOGIC



**Figure 153: DC supply monitor logic**

The diagram above shows the DC supply monitoring logic for stage 1 only. Stages 2 and 3 are identical in principle.

The logic function will work when the **VdcX Function** setting value is set to *Enabled* and the DC Supply Monitoring inhibit signal (**VdcX Inhibit**) is low. Being X from 1 to 3.

If the auxiliary supply voltage (Vdc) exceeds the lower limit AND falls below the upper limit, the voltage is in the unhealthy zone and a **VdcXStart** signal is generated.

The **VdcX Trip** signals from all stages are OR'd together to produce an alarm signal **DC Supply Fail**.

The DC Supply magnitude can be checked under **MEASUREMENTS\DC SUPPLY SUPV.\C SUPPLY MAG** path.

The **VdcX Start** and **VdcX Trip** signals for all stages and the **DC Supply Fail** signal can be checked under **TARGETS** path when the signals are active and at any time (active or not active) under **RECORDS\EVENTS** path.

The signals **VdcX Start** and **VdcX Trip** signals for all stages and the **DC Supply Fail** signal are for monitoring purposes and can be checked under **TARGETS** path when active and under **RECORDS\EVENTS** path when an event have been raised for those signals.

**VdcX Start**, **VdcX Trip** and **DC Supply Fail** signals can be used to configure an LED or an output to raise an alarm (if needed) using the Multilin Agile Flexlogic Equation Editor.

## 15.3 VOLTAGE TRANSFORMER SUPERVISION

The Voltage Transformer Supervision (VTS) function is used to detect failure of the AC voltage inputs to the protection. This may be caused by voltage transformer faults, overloading, or faults on the wiring, which usually results in one or more of the voltage transformer fuses blowing.

If there is a failure of the AC voltage input, the IED could misinterpret this as a failure of the actual phase voltages on the power system, which could result in unnecessary tripping of a circuit breaker.

The VTS logic is designed to prevent such a situation by detecting voltage input failures, which are NOT caused by power system phase voltage failure, and automatically blocking associated voltage dependant protection elements.

The following scenarios are possible with respect to the failure of the VT inputs.

- Loss of one or two-phase voltages
- Loss of all three-phase voltages

*Note:*

*VT supervision functionality is only available for products with CT & VT inputs (P24D only)*

### 15.3.1 LOSS OF ONE OR TWO PHASE VOLTAGES

If the power system voltages are healthy, no Negative Phase Sequence (NPS) voltage will be present. If however, one or two of the AC voltage inputs are missing, there will be Negative Phase Sequence voltage present, even if the actual power system phase voltages are healthy. VTS works by detecting Negative Phase Sequence (NPS) voltage without the presence of Negative Phase Sequence current. So if there is NPS voltage present, but no NPS current, it is certain that there is a problem with the voltage transformers and a VTS block should be applied to voltage dependant protection functions to prevent maloperation. The use of negative sequence quantities ensures correct operation even where three-limb or V-connected VTs are used.

### 15.3.2 LOSS OF ALL THREE PHASE VOLTAGES

If all three voltage inputs are lost, there will be no Negative Phase Sequence quantities present, but the device will see that there is no voltage input. If this is caused by a power system failure, there will be a step change in the currents. However, if this is not caused by a power system failure, there will be no change in any of the currents. So if there is no measured voltage on any of the three phases and there is no change in any of the currents, this indicates that there is a problem with the voltage transformers and a VTS block should be applied to voltage dependant protection functions to prevent maloperation.

### 15.3.3 VTS IMPLEMENTATION

VTS is implemented under the **SETPOINTS/CONTROL/VT SUPERVISION** path.

The following settings are relevant for VT Supervision:

- **Function:** The selection of *Alarm*, *Latched Alarm* or *Configurable* setting enables the VTS function. When the *Alarm* function is selected, and the VTS operates, the Alarm LED will flash, and will self-reset, when the operating conditions are cleared. When the *Latched Alarm* function is selected, and the VTS operates, the Alarm LED will flash during the VTS operating condition, and will be steady lit after the conditions are cleared. The Alarm LED can be cleared by issuing a reset command. When the *Configurable* function is selected, the dedicated Alarm LED will not turn on automatically. Any configurable LED can be set as an alarm using Flexlogic operands related to VTS operation under the **SETPOINT/DEVICE/FRONT PANEL/PROG.** LED.

For all Function setting options (*Alarm, Latched Alarm, Configurable*), the relay output selected (if any) will operate following the VTS operation behaviour.

- **Time Delay:** This setting can be used to avoid fuse failure detection in case of sudden loss of voltage when the current is zero (breaker remains in open condition) and the transient negative sequence voltage appears.
- **Operate Delay:** This setting determines the operate time-delay upon detection of a VTS condition.
- **Relay O/P X:** All available relay outputs (except the watchdog relay output) from 2 to X (where X is the number outputs, which is Cortec dependant), can be selected to operate upon VTS operation. The operation of these relay outputs is programmed by the user.
- **VT Ntrl Wire Det:** This setting enables and disables the VT neutral wire open detection function. When the VT is connected in Delta, do not enable this function because there is no neutral wire for Delta connected VT.
- **VT Ntrl Wire PKP:** This setting specifies the pickup level of the 3rd harmonic of 3V0 signal, for the VT neutral wire open detection logic to pick up. % is calculated based on the Phase VT Secondary.

VTS is only enabled during a live line condition to prevent operation under dead system conditions.

### 15.3.4 VTS LOGIC




Figure 154: VTS logic

As can be seen from the diagram, the VTS function is inhibited if the phase current changes over the period of 2 cycles.

---

## 15.4 CURRENT TRANSFORMER SUPERVISION

---

The Current Transformer Supervision function (CTS) is used to detect failure of the AC current inputs to the protection. This may be caused by internal current transformer faults, overloading, or faults on the wiring. If there is a failure of the AC current input, the protection could misinterpret this as a failure of the actual phase currents on the power system, which could result in maloperation. Also, an open circuit in the AC current circuits can cause dangerous CT secondary voltages to be generated.

*Note:*

*CT supervision functionality is only available in P24D & P24N products.*

---

### 15.4.1 CTS IMPLEMENTATION

The Multilin Agile IED provides a CT Supervision element that uses three distinct checks that can be enabled or disabled individually once the overall function is enabled. These three checks are the sequence check, differential check, and symmetry check.

The sequence check is the first check and should ideally be used for CT supervision. The sequence check uses zero sequence current, zero sequence voltage, and earth current. This check may not be an option if the earth current is not available, voltages are not available, or not connected in wye configuration to be able to calculate zero sequence voltage. If voltages are not available or they are available but in delta configuration, the differential check can be used.

The differential check uses calculated zero sequence current and earth current to calculate differential current. If earth current is not available, the symmetry check can be used.

The symmetry check operates by calculating a quotient or a ratio of minimum current over maximum current and comparing against a threshold. This function should be set appropriately considering possible minimum and maximum load currents occurred in various scenarios.

To further enhance the security of these functions and not block overcurrent in case of fault events, an additional maximum load current supervision is added where the maximum of the phase current magnitudes  $I_{\max}$  must be less than the maximum load current.

## 15.4.2 CTS LOGIC




Figure 155: CTS logic

## 15.4.3 APPLICATION NOTES

### 15.4.3.1 SETTING GUIDELINES

**Sequence Check:** The earth current input for the sequence check must come from a core balance CT or a transformer neutral point earthing CT. The residual earth input method should not be used for sequence check.

**Differential Check:** The CT Supervision element earth current input must come from a core balance CT. Transformer neutral point earthing or the residual earth input method should not be used for the differential check.

If CT Supervision is used for blocking instantaneous current protection elements, the pickup delay should be coordinated to allow blocking of the fastest current element.

## 15.5 TRIP CIRCUIT SUPERVISION

In most protection schemes, the trip circuit extends beyond the IED enclosure and passes through components such as links, relay contacts, auxiliary switches and other terminal boards. Such complex arrangements may require dedicated schemes for their supervision.

There are two distinctly separate parts to the trip circuit; the trip path, and the trip coil. The trip path is the path between the IED enclosure and the CB cubicle. This path contains ancillary components such as cables, fuses and connectors. A break in this path is possible, so it is desirable to supervise this trip path and to raise an alarm if a break should appear in this path.

The trip coil itself is also part of the overall trip circuit, and it is also possible for the trip coil to develop an open-circuit fault.

This product supports a number of trip circuit supervision (TCS) schemes.

**Note:**


Multilin Agile IED's have two dedicated opto inputs for TCS purposes: Opto-input 4 and Opto-input 5. Refer to Inputs/Outputs Connections in the Technical Specifications chapter for more details.

### 15.5.1 TRIP CIRCUIT SUPERVISION SCHEME 1

This scheme provides supervision of the trip coil with the CB open or closed, however, it does not provide supervision of the trip path whilst the breaker is open. The CB status can be monitored when a self-reset trip contact is used. However, this scheme is incompatible with latched trip contacts, as a latched contact will short out the TCS opto-input for a time exceeding the recommended Delayed Dropout (DDO) timer setting of 400 ms, and therefore does not support CB status monitoring. If you require CB status monitoring, further opto-inputs must be used.

**Note:**

A 52a CB auxiliary contact follows the CB position. A 52b auxiliary contact is the opposite.



**Figure 156: TCS scheme 1**

When the CB is closed, supervision current passes through the TCS opto-input, blocking diode and trip coil. When the CB is open, supervision current flows through the TCS opto-input and into the trip coil via the 52b auxiliary contact. This means that *Trip Coil* supervision is provided when the CB is either closed or open, however *Trip Path* supervision is only provided when the CB is closed. No supervision of the trip path is provided whilst the CB is open (pre-closing supervision). Any fault in the trip path will only be detected on CB closing, after a 400 ms delay.

#### 15.5.1.1 RESISTOR VALUES

The supervision current is a lot less than the current required by the trip coil to trip a CB. The TCS opto-input limits this supervision current to less than 10 mA. If the TCS opto-input were to be short-circuited however, it could be possible for the supervision current to reach a level that could trip the CB. For this reason, a resistor R1 is often

used to limit the current in the event of a short-circuited TCS opto-input. This limits the current to less than 60 mA. The table below shows the appropriate resistor value and voltage setting for this scheme.

Trip Circuit Voltage	Resistor R1
24/27	620 Ohms at 2 Watts
30/34	820 Ohms at 2 Watts
48/54	1.2 kOhms at 5 Watts
110/125	2.7 kOhms at 10 Watts
220/250	5.2 kOhms at 15 Watts

### 15.5.1.2 FLEXLOGIC EQUATION EDITOR FOR TCS SCHEME 1

The TCS opto-input can be used, after being passed through a 400 ms delayed dropout timer and inverted, to drive a normally open output relay, which in turn can be used to drive alarm equipment. The signal can also be configured to drive a latching programmable LED.

The timer operates as soon as the TCS opto-input is energised, but will take 400 ms to dropout/reset in the event of a trip circuit failure. The 400 ms delay prevents a false alarm due to voltage dips caused by faults in other circuits or during normal tripping operation when the TCS opto-input is shorted by a self-reset trip contact.

The 50 ms delay on pickup timer prevents false LED and user alarm indications during the power up time, following a voltage supply interruption.

## 15.5.2 TRIP CIRCUIT SUPERVISION SCHEME 2

This scheme provides supervision of the trip coil with the breaker open or closed but does not provide pre-closing supervision of the trip path. However, using two TCS opto-inputs (opto-input 4 and opto-input 5) allows the IED to correctly monitor the circuit breaker status since they are connected in series with the CB auxiliary contacts. This is achieved by assigning one opto-input to the 52a contact and another TCS opto-input to the 52b contact. Provided the **CB Status Input** setting under *THE SETPOINT/SYSTEM/CB SETUP* path is set to *Both 52A and 52B*, and the **CB Aux 3ph (52A)** and **CB Aux 3ph (52B)** settings are set to the corresponding TCS opto-inputs, the IED will correctly monitor the status of the breaker. This scheme is also fully compatible with latched contacts as the supervision current will be maintained through the 52b contact when the trip contact is closed.




Figure 157: TCS scheme 2

When the breaker is closed, supervision current passes through TCS opto-input 4 and the trip coil. When the breaker is open current flows through TCS opto-input 5 and the trip coil. No supervision of the trip path is provided whilst the breaker is open. Any fault in the trip path will only be detected on CB closing, after a 400 ms delay.

### 15.5.2.1 RESISTOR VALUES

As with scheme 1, optional resistors R1 and R2 can be added to prevent tripping of the CB if either TCS opto-input is shorted. The table below shows the appropriate resistor value and voltage setting for this scheme.



Trip Circuit Voltage	Resistor R1 and R2
24/27	620 Ohms at 2 Watts
30/34	820 Ohms at 2 Watts
48/54	1.2 kOhms at 5 Watts
110/125	2.7 kOhms at 10 Watts
220/250	5.2 kOhms at 15 Watts

### 15.5.2.2 FLEXLOGIC EQUATION EDITOR FOR TCS SCHEME 2

In this TCS scheme, both TCS opto-inputs must be low before a trip circuit fail alarm is given.

The TCS opto-inputs can be used, after being passed through a 400 ms delayed dropoff timer and inverted, to drive a normally open output relay, which in turn can be used to drive the alarm equipment. The signal can also be configured to drive a latching programmable LED.

The timer operates as soon as both TCS opto-inputs are energised, but will take 400 ms to drop off/reset in the event of a trip circuit failure. The 400 ms delay prevents a false alarm due to voltage dips caused by faults in other circuits or during normal tripping operation when the TCS opto-inputs are shorted by a self-reset trip contact.

The 50 ms delay on pickup timer prevents false LED and user alarm indications during the power up time, following a voltage supply interruption.

### 15.5.3 TRIP CIRCUIT SUPERVISION SCHEME 3

TCS Scheme 3 is designed to provide supervision of the trip coil with the breaker open or closed. It provides pre-closing supervision of the trip path. Since only one TCS opto-input is used, this scheme is not compatible with latched trip contacts. If you require CB status monitoring, further opto-inputs must be used.




Figure 158: TCS scheme 3

When the CB is closed, supervision current passes through the TCS opto-input 4, resistor R2 and the trip coil. When the CB is open, current flows through the TCS opto-input 4, resistors R1 and R2 (in parallel), resistor R3 and the trip coil. The supervision current is maintained through the trip path with the breaker in either state, therefore providing pre-closing supervision.

#### 15.5.3.1 RESISTOR VALUES

As with TCS schemes 1 and 2, resistors R1 and R2 are used to prevent false tripping, if the TCS opto-input is accidentally shorted. However, unlike the other two schemes, this scheme is dependant on the position and value of these resistors. Removing them would result in incomplete trip circuit monitoring. The table below shows the resistor values and voltage settings required for satisfactory operation.

Trip Circuit Voltage	Resistor R1 and R2	Resistor R3
24/27	620 Ohms at 2 Watts	330 Ohms at 5 Watts
30/34	820 Ohms at 2 Watts	430 Ohms at 5 Watts
48/54	1.2 kOhms at 5 Watts	620 Ohms at 10 Watts

Trip Circuit Voltage	Resistor R1 and R2	Resistor R3
110/125	2.7 kOhms at 10 Watts	1.5 k Ohms at 15 Watts
220/250	5.2 kOhms at 15 Watts	2.7 k Ohms at 25 Watts

### 15.5.3.2 FLEXLOGIC EQUATION EDITOR FOR TCS SCHEME 3

The TCS opto-input can be used, after being passed through a 400 ms delayed dropoff timer and inverted, to drive a normally open output relay, which in turn can be used to drive the alarm equipment. The signal can also be configured to drive a latching programmable LED.

The timer operates as soon as the TCS opto-input is energised, but will take 400 ms to drop off/reset in the event of a trip circuit failure. The 400 ms delay prevents a false alarm due to voltage dips caused by faults in other circuits or during normal tripping operation when the TCS opto-input is shorted by a self-reset trip contact.

The 50 ms delay on the pickup timer prevents false LED and user alarm indications during the power up time, following a voltage supply interruption.

### 15.5.4 TRIP CIRCUIT SUPERVISION SCHEME 4




Figure 159: TCS scheme 4

Under normal non-fault conditions, a current of 2 mA flows through one of the following paths:

- Post Close Supervision: When the CB is in a closed state, the current flows through R1, TCS opto-input 4, Contact 52A and the trip coil.
- Pre-close Supervision: When the CB is in an open state, the current flows through R1, TCS opto-input 4, R2, TCS opto-input 5, Contact 52B and the trip coil.
- Momentary Tripping with Self-reset Contact: When a self-reset trip contact is in a closed state, the current flows through the trip contact, contact 52A and the trip coil.
- Tripping with Latched Contact: When a latched trip contact is used and when it is in a closed state, the current flows through the trip contact, Contact 52A, the trip coil, then changing to the path trip contact, R2, Contact 52B, TCS opto-input 5, and the trip coil.

A current of 2 mA through the Trip Coil is insufficient to cause operation of the Trip Contact, but large enough to energise the TCS opto-inputs. Under this condition both of the opto-inputs will output logic 1, which inverts to 0, so the output relay (TCS health) will be open and the LED will be off. If a break occurs in the trip circuit, the current ceases to flow, resulting in both TCS opto-inputs outputting logic 0, which inverts to 1. This will close the output relay and set the LED On.

#### 15.5.4.1 RESISTOR VALUES

The TCS opto-inputs sink a constant current of 2 mA. The values of external resistors R1 and R2 are chosen to limit the current to a maximum of 60 mA in the event that a TCS opto-input becomes shorted. The values of these resistors depend on the trip circuit voltage.

Trip Circuit Voltage	Resistor R1 and R2 (ohms)
24/27	620 Ohms at 2 Watts
30/34	820 Ohms at 2 Watts
48/54	1.2 kOhms at 5 Watts
110/125	2.7 kOhms at 10 Watts
220/250	5.2 kOhms at 15 Watts

For the momentary tripping condition, none of the opto-inputs are energised. To tide over this normal CB operation, a dropout time delay of about 400 ms is added in the Flexlogic Equation Editor.

#### 15.5.4.2 FLEXLOGIC EQUATION EDITOR FOR TCS SCHEME 4

In this TCS scheme, both TCS opto-inputs must be low before a trip circuit fail alarm is given.

The TCS opto-inputs can be used, after being passed through a 400 ms delayed dropoff timer and inverted, to drive a normally open output relay, which in turn can be used to drive the alarm equipment. The signal can also be configured to drive a latching programmable LED.

The timer operates as soon as both TCS opto-inputs are energised, but will take 400 ms to drop off/reset in the event of a trip circuit failure. The 400 ms delay prevents a false alarm due to voltage dips caused by faults in other circuits or during normal tripping operation when the TCS opto-inputs are shorted by a self-reset trip contact.

The 50 ms delay on pickup timer prevents false LED and user alarm indications during the power up time, following a voltage supply interruption.

## CHAPTER 16

# DIGITAL I/O AND FLEXLOGIC EQUATION EDITOR

---

## 16.1 CHAPTER OVERVIEW

---

This chapter introduces the Enervista Flexlogic Equation Editor (Flexlogic Equation Editor & Logic Designer), and describes the configuration of the digital inputs and outputs. It provides an outline of Flexlogic concepts and the Flexlogic Equation Editor.

This chapter contains the following sections:

Chapter Overview	359
Configuring Digital Inputs and Outputs	360
Flexlogic Equation Editor	361
Configuring the Opto-Inputs	362
Fixed Function LEDs	363
Programmable LEDs	364
Virtual Inputs	365
GOOSE Subscribe (Remote Inputs, RI DPS, GOOSE Analog) and Remote Output	367
Relay Outputs	368
Virtual Outputs	369

---

## 16.2 CONFIGURING DIGITAL INPUTS AND OUTPUTS

---

Configuration of the digital inputs and outputs in this product is very flexible. You can use a combination of settings and programmable logic to customise them to your application. You can access some of the settings using the keypad on the front panel, but you will need a computer running the EnerVista Configuration software to configure the device (if needed).

The Enervista Configuration Software includes an Enervista Flexlogic Equation Editor (Flexlogic Equation Editor & Logic Designer) to be used for Flexlogic configuration (if needed). The Flexlogic Equation Editor of the device lets you allocate inputs and outputs according to your specific application. It also allows you to apply attributes to some of the signals such as a dropoff delay for an output contact.

In this product, digital inputs and outputs that are configurable are:

- Optically isolated digital inputs (opto-inputs). These can be used to monitor the status of associated plant
- Relay output contacts. These can be used for purposes such as initiating the tripping of circuit breakers, providing alarm signals, etc
- Programmable LEDs and Pushbuttons (Cortec dependant)
- IEC 61850 GOOSE Subscribe (Remote Inputs, RI DPS, GOOSE Analog) and Remote Outputs (Cortec dependant). These are only provided on products that have been specified for connection to an IEC 61850 system. The details of the GOOSE are presented in the documentation on IEC 61850

## 16.3 FLEXLOGIC EQUATION EDITOR

The product is supplied with EnerVista Flexlogic Equation Editor (Flexlogic Equation Editor & Logic Designer).


Flexlogic Equation Editor is built around a concept called the FlexLogic Operand. These FlexLogic operands encompasses all of the digital signals which are used in the Flexlogic Equation Editor. The input to the Flexlogic Equation Editor is any combination of the status of the digital input signals from the opto-inputs, virtual inputs, virtual outputs, relay outputs, GOOSE subscribe (remote inputs, remote inputs DPS, GOOSE analog) and remote outputs, any outputs of the protection, control and monitoring elements, non-volatile latches, Flex Elements and any internal signal available as a FlexLogic Operand.

The Flexlogic Equation Editor provides the ability to develop custom schemes to suit customer applications, if the factory-programmed default Flexlogic Equation Editor CID files, including the default settings and schemes do not meet the required needs. Default CID files including default settings and default Flex Equation Editor schemes are programmed before the product leaves the factory. These default CID files including default Flexlogic Equation Editor schemes, have been designed to suit typical applications, and if these schemes suit customer requirements you do not need to take any action. However, if there is a need to change the existing default Flexlogic Equation Editor, or to implement new custom scheme logic, it can be done using the Flexlogic Equation Editor contained in the EnerVista Configuration software.

The Flexlogic Equation Editor consists of components such as logic gates and timers, which combine and condition digital signals.

The logic gates can be programmed to perform a range of different logic functions. The number of inputs to a logic gate are not limited. The timers can be used either to create a programmable delay or to condition the logic outputs. Relay output contacts and programmable LEDs have dedicated conditioners.

The following diagram shows how the Flexlogic Equation Editor interacts with the rest of the IED.



**Figure 160: Flexlogic equation editor scheme logic interfaces**

## 16.4 CONFIGURING THE OPTO-INPUTS

The number of optically isolated status inputs (opto-inputs) depends on the specific model supplied (Cortec dependant). The use of the opto-inputs will depend on the application. The opto-input assignments for each particular application is achieved through IED settings, via HMI or EnerVista Configuration software. The opto-inputs can also be used for certain applications as inputs in the Flexlogic Equation Editor via EnerVista Configuration software.

Depending on the type of Cortec Binary Input/Output options selection the settings applicable to the opto-inputs are different. For details of input and output boards and settings configuration, refer to the "IO Population - Type of Boards (usage and configuration) Appendix.

- For some Cortec options there is just one Opto-Config selection available. Global Nominal V and Characteristic settings can be configurable at **SETPOINTS\INPUTS\OPTO INPUTS\OPTO CONFIG**. Global Nominal Voltage and Characteristic settings are applicable for Normal Binary opto-inputs only and not for TCS opto-inputs. TCS opto-inputs have a fixed DC voltage level of 5V, with no hysteresis.
- For other Cortec options there are two Opto-Config selections available. Global Nominal V 1 and Characteristic 1 settings can be configurable at **SETPOINTS\INPUTS\OPTO INPUTS\OPTO CONFIG 1**. Global Nominal V 2 and Characteristic 2 settings can be configurable at **SETPOINTS\INPUTS\OPTO INPUTS\OPTO CONFIG 2**. The selection of the Opto Config X that applies to each group of opto-inputs can be done at **SETPOINTS\INPUTS\OPTO INPUTS\CONFIG SELECTION**.
- Independently of the Cortec selection:

**Global Nominal** setting allows the set up of the appropriate energising voltage range value.

The **Characteristic** setting is used to set the pickup/dropout ratios of the input signals. By default, the pickup threshold is 80% of the minimum DC input value. This value can be changed to other available thresholds if required. The available thresholds for the Characteristic setting are, Standard 80%, 75% and 70%. Dropout is fixed at 20% of Nominal Voltage.

Each opto-input has a programmable **Name** and **Debounce Time** setting at **SETPOINTS\INPUTS\OPTO INPUTS\OPTO I/P X** path, to prevent false operation from induced voltage. The name allows the user to assign a configurable alphanumeric name to an input for diagnostic, setting and event recording purposes. The **Debounce Time** is adjustable by the user per manufacturer specifications.



---

## 16.5 FIXED FUNCTION LEDS

---

Four fixed-function LEDs on the left-hand side of the front panel indicate the following conditions

- Trip (Red) switches ON when the IED issues a trip signal. The Trip LED is a latched LED that can be reset after the fault condition is cleared
- Alarm (Orange) flashes when the IED registers an alarm. This may be triggered by a fault, event or maintenance record. For non-latched Alarms the LED flashes until the alarm conditions disappear, then it switches OFF. For Latched Alarms the LED flashes until the alarm conditions disappear, then changes to constantly ON. When the alarms are cleared, the LED switches OFF
- Out of service (Red) is ON when the IEDs functions are unavailable
- Healthy (Green) is ON when the IED is in correct working order, and should be ON at all times. It goes OFF if the unit's self-tests show there is an error in the hardware or software. The state of the healthy LED is reflected by the watchdog contacts at the back of the unit

**Note:**

Any latched Fixed Function LED indicator (Trip LED and Alarm LED when Alarm is latched ) can be reset using a **RESET** command, once the condition has been cleared. The **RESET** command can be initiated in a number of ways: by pressing the **Clear/Reset** key for a few seconds, by selecting the **Up** hotkey (configured for **RESET**) at the default product display in the HMI (for 20TE), by a configurable operand that can be configured in the menu **SETPOINTS\DEVICE\RESETTING** or by a remote device via a communication channel.

---

## 16.6 PROGRAMMABLE LEDs

---

The device has programmable LEDs (Cortec dependant).

All the programmable LEDs on the unit are tri-colour. These can be illuminated red, green, or amber.

The Trigger (Red) and Trigger (Green) selection (any FlexLogic Operand) and the LED type (Self-reset or Latched) can be set, either through the IED corresponding settings at **SETPOINTS\DEVICE\FRONT PANEL\PROG. LED \LED (n)** menu.

*Note:*

*Any programmable LED indicator, when set to Latched, can be reset with a **RESET** command, once the condition has been cleared.*

*Note:*

*The **RESET** command can be initiated in a number of ways, by pressing the **Clear/Reset** key for a few seconds, by selecting the **Up** hotkey (configured for **RESET**) at the default product display in the HMI (for 20TE), by a configurable operand that can be configured in the **SETPOINTS\DEVICE\RESETTING** menu or by a remote device via a communication channel.*

## 16.7 VIRTUAL INPUTS

The Multilin Agile IED is equipped with 128 Virtual Inputs that can be individually programmed to respond to input signals from the keypad or from communications protocols. This has the following advantages over opto-inputs only:

- The number of logic inputs can be increased without introducing additional hardware.
- Logic functions can be invoked from a remote location over a single communication channel.
- The same logic function can be invoked both locally via opto-input or front panel keypad, and/or remotely via communications.
- Panel switches can be replaced entirely by virtual switches to save cost and wiring.

All Virtual Input operands are defaulted to *OFF* (logic 0) unless the appropriate input signal is received.

The following setting options at **SETPOINTS\INPUTS\VIRTUAL INPUTS\VIRTUAL I/P (N)** are available:

### FUNCTION

Range: *Disabled, Enabled*

Default: *Disabled*

If this setting is set to *Disabled*, the virtual input will be forced to *OFF* (logic 0) regardless of any attempt to alter the input. If set to *Enabled*, the input operates as shown on the logic diagram below, and generates output FlexLogic operands in response to received input signals and the applied settings.




Figure 161: Virtual inputs scheme logic

### NAME

Range: Up to 13 alphanumeric characters

Default: *VI (n)*

An alphanumeric name may be assigned to a Virtual Input for diagnostic, setting, and event recording purposes.

### TYPE

Range: *Latched, Self-reset*

Default: *Latched*

There are two types of operation: self-reset and latched. If the Virtual Input **Type** setting is set to *Self-Reset* when the input signal transits from *OFF* to *ON* the output operand will be set to *ON* for only one evaluation of the FlexLogic equations, then return to *OFF*. If set to *Latched*, the virtual input sets the state of the output operand to the same state as the most recent received virtual input.

**Note:**

*The self-reset operating mode generates the output operand for a single evaluation of the FlexLogic equations (i.e., a pulse of one protection pass). If the operand is to be used anywhere other than internally in a FlexLogic equation, it will likely have to be lengthened in time. A FlexLogic timer with a delayed reset time can perform this function.*

## 16.8 GOOSE SUBSCRIBE (REMOTE INPUTS, RI DPS, GOOSE ANALOG) AND REMOTE OUTPUT

IEC 61850 is a Cortec dependant feature for all models.

The Multilin Agile IED supports 8 GOOSE transmissions, with up to 64 digital/analogue items per GOOSE. Any digital/analogue value existing in the 61850 logical nodes can be assigned to a transmission item.

The Multilin Agile IED supports 32 GOOSE receptions, with up to 128 digital items that can be mapped into any of the 128 remote inputs, up to 16 double digital items that can be mapped into any of the 16 remote Inputs DPS and up to 32 analogue items that can be mapped into any of the 32 Analogue inputs (24 float and 8 integer).

The FlexLogic operand named Remote GOOSE RX Offline indicates if configured GOOSE receptions are all working. The FlexLogic operand "Remote GOOSE RX Offline" works as follows:

'1' when any of configured GOOSE receptions are not being received

'0' if all configured GOOSE reception dataset is being received properly

The IEC 61850 GOOSE transmission and reception for Multilin Agile IEDs should be configured using the IEC61850 Configuration tool available in EnerVista Configuration software.

Remote inputs provide a means of exchanging digital state information between Ethernet networked devices supporting IEC 61850. Remote inputs that create FlexLogic operands at the receiving relay are extracted from GOOSE messages originating in remote devices. Remote input (n) must be programmed to replicate the logic state of a specific signal from a specific remote device for local use.

The 128 remote inputs, 16 remote input DPS (double point remote inputs) and the 32 Remote GOOSE RX Offline FlexLogic operands are available to be selected as inputs for any configurable digital signal in the IED settings and in the Flexlogic Equation Editor.

The **Name** and **Default State** of each remote input can be configured in the **Remote I/P (n)** menu at the **SETPOINTS\DEVICE\COMMUNICATIONS\GOOSE SUBSCRIBE\REMOTE INPUTS** path.

The **Name** and **Default State** of each double point remote input can be configured at the **RI DPS (n)** menu at the **SETPOINTS\DEVICE\COMMUNICATIONS\GOOSE SUBSCRIBE\RI DPS** path.

The **Float Name**, **Float ID**, **Default Mode**, **Default Value**, **Units** and **PU Base** of each goose analogue input can be configured at the **GOOSE Analog (n)** menu at the **SETPOINTS\DEVICE\COMMUNICATIONS\GOOSE SUBSCRIBE\GOOSE ANALOG** path.

The **Name** and **Indication** (FlexLogic Operand trigger) for each remote output can be configured at **Remote O/P (n)** menu at the **SETPOINTS\OUTPUTS\REMOTE OUTPUTS** path.

The actual values of all GOOSE Subscribe related inputs (remote inputs, double point remote inputs analogue inputs) and remote outputs are available under **DEVICE STATUS\COMMUNICATIONS\** under each specific header (**\REMOTE INPUTS**, or **\RI DPS**, or **\GOOSE ANALOG**, or **\REMOTE OUTPUTS**) depending on the value required.

---

## 16.9 RELAY OUTPUTS

---

The Multilin Agile IED is equipped with a number of relays outputs specified at the time of ordering.

On the first slot (D for 20TE or F for 30TE) of any Cortec option, the first three relay outputs (RL1, RL2 and RL3) are normally open (NO) general-purpose contacts designated for tripping, opening and closing. The rest of the relay outputs are general-purpose relay outputs for signalling. The (Critical Fail) is a normally closed (NC) contact used as watchdog for any ordering option.

For more details, refer to the Input/Output Connections section in the Technical Specifications chapter. For details of input and output boards and settings configuration, refer to the "IO Population - Type of Boards (usage and configuration) Appendix.

The first output relay (RELAY 1-TRIP) in the IED is a NO relay that can be used for Trip Coil monitoring and is designated for tripping the breaker. The relay is energised upon operation of any element with setpoint **Function** set to Trip. The relay can be customised by changing the **Mode** and adding triggers to the Operate setting or blocking signals to the **Inhibit** setting under the **SETPOINTS\OUTPUTS\RELAY OUTPUTS\RELAY 1-TRIP** menu. This relay output is programmed internally for tripping the breaker, and it cannot be changed, disabled, or replaced by any other relay.

Additional relay outputs can be selected to operate as well from each protection, control, or monitoring element, selecting the relay output to operate through the settings menu for each element.

All relay outputs settings can be modified at the **SETPOINT\OUTPUTS\RELAY OUTPUTS** path, at **RELAY 1-TRIP** menu for the first output relay and **RELAY O/P (n)** menus for the rest of the relay outputs. The watchdog is not configurable, and it will not appear in the relay output settings.

The behaviour of the relay output contacts can be modified by choosing different operating Mode including *Pickup*, *Dropoff*, *Dwell*, *Pulse*, *Pickup/Dropoff*, *Straight-Through*, *Latching* options.

---

### 16.9.1 ASSIGNING RELAY OUTPUTS

The relay contact action can be controlled either through the device settings at the **SETPOINT\OUTPUTS\RELAY OUTPUTS** path, at **RELAY 1-TRIP** menu for the first output relay and **RELAY O/P (n)** menus for the rest of the relay outputs.

The configuration of the blocking signal to inhibit the action of the relay output contact is only possible to be done through the Inhibit setting under the **SETPOINTS\OUTPUTS\RELAY OUTPUTS\RELAY 1-TRIP** path for the first output relay and the **SETPOINTS\OUTPUTS\RELAY OUTPUTS\RELAY O/P (n)** path for the rest of the relay outputs.

The **Mode** assignment and setting of *Pickup* and *Dropoff* values is possible to be done both through the IED settings.

The signal that drives the output relays operation can be assigned through the IED **Operate** setting per each relay contact in the IED settings.

---

## 16.10 VIRTUAL OUTPUTS

---

The Multilin Agile IED has 128 virtual outputs that may be assigned via the Flexlogic Equation Editor. If not assigned, the virtual output is forced to OFF (Logic 0). Virtual outputs are resolved in each pass through the evaluation of the logic equations.

An ID may be assigned to each virtual output using the **Name** setting in the **VIRTUAL O/P (N)** menu at the **SETPOINTS\OUTPUTS\VIRTUAL OUTPUTS** path.

Any change of state of a virtual output can be logged as an event in the event recorder if programmed to do so selecting the **Events** setting to *Enabled* in the **VIRTUAL O/P (N)** menu at the **SETPOINTS\OUTPUTS\VIRTUAL OUTPUTS** path.

## CHAPTER 17

# COMMUNICATIONS



---

## 17.1 CHAPTER OVERVIEW

---

This product supports Substation Automation System (SAS), and Supervisory Control and Data Acquisition (SCADA) communication. The support embraces the evolution of communications technologies that have taken place since microprocessor technologies were introduced into protection, control, and monitoring devices which are now ubiquitously known as Intelligent Electronic Devices for the substation (IEDs).

As standard, all products support rugged serial communications for SCADA and SAS applications. By option, any product can support Ethernet communications for more advanced SCADA and SAS applications.

This chapter contains the following sections:

Chapter Overview	371
Communication Interfaces	372
Serial Communication	374
Standard Ethernet Communication	376
Redundant Ethernet Communication	377
Data Protocols	381
Time Synchronisation	409

## 17.2 COMMUNICATION INTERFACES

Multilin Agile products have a number of standard and optional communication interfaces. The standard and optional hardware and protocols are summarised below:

Port	Availability	Physical Layer	Use	Data Protocols
Front	Standard	USB	Local settings Firmware update SNTP (*) TFTP (*) SFTP (*) SSH (*)	Modbus TCP, DNP3oE, IEC 61850 Ed.2 (*)
Rear serial port 1 (COM1)	Standard	RS485	SCADA Remote settings IRIG-B	Modbus RTU, DNP3 Serial, IEC 60870-5-103
Rear serial port 2 (COM2) (*)	Optional (*)	RS485	SCADA Remote settings	Modbus RTU, DNP3 Serial, IEC 60870-5-103
Rear Ethernet port 1 (ETH1) (*)	Optional (*)	Ethernet/copper (*) Ethernet/fibre (*)	SCADA (*) Remote settings Firmware update PTP SNTP (*) TFTP (*) SFTP (*) SSH (*)	Modbus TCP, DNP3oE, IEC 61850 Ed.2 (*)
Rear Ethernet ports 2 and 3 (ETH2, ETH3) (*)	Optional (*)	Ethernet/copper Ethernet/fibre (*)	SCADA (*) Remote settings Firmware update PTP SNTP (*) TFTP (*) SFTP (*) SSH (*) Configurable PRP/HSR/LLA (*)	Modbus TCP, DNP3oE, IEC 61850 Ed.2 (*)

**Note:**

*The options marked with (\*) are features which are Cortec dependant.*

*The rest of the options not marked with (\*) are available for all ordering options.*

*See ordering options appendix for more details.*

From now on the following nomenclature will be used to refer to the hardware-independent protocols implemented in this IED.

Modbus Protocol:

- Modbus for generic Modbus protocol references
- Modbus RTU for serial Modbus
- Modbus TCP for Modbus over Ethernet (TCP)

**DNP 3.0 Protocol:**

- DNP 3.0 for generic DNP 3.0 protocol references
- DNP3 Serial for serial DNP3 3.0
- DNP3oE for DNP 3.0 over Ethernet (TCP/UDP)

For hardware dependant protocols and standards, such as IEC 60870-5-103 (serial based protocol) and IEC 61850 (Ethernet based standard) the protocols will be named as per its IEC description.

## 17.3 SERIAL COMMUNICATION

The physical layer standards that are used for serial communications for SCADA purposes.

RS485 is similar to RS232 but for longer distances and it allows daisy-chaining and multi-dropping of IEDs.

It is important to note that these are not data protocols. They only describe the physical characteristics required for two devices to communicate with each other.

A full description of the RS485 is available in the published standard.

**Note:**


*It is recommended that any unused RS485 ports are disabled.*

### 17.3.1 EIA(RS)485 BIASING REQUIREMENTS

Biasing requires that the signal lines be weakly pulled to a defined voltage level of about 1 V. There should only be one bias point on the bus, which is best situated at the master connection point. The DC source used for the bias must be clean to prevent noise being injected.

**Note:**

*Some devices may be able to provide the bus bias, in which case external components would not be required.*



**Figure 162: RS485 biasing circuit**



**Warning:**

**It is extremely important that the 120 Ω termination resistors are fitted. Otherwise the bias voltage may be excessive and may damage the devices connected to the bus.**

### 17.3.2 EIA(RS)485 BUS

The RS485 two-wire connection provides a half-duplex, fully isolated serial connection to the IED. The connection is polarised but there is no agreed definition of which terminal is which. If the master is unable to communicate with the product, and the communication parameters match, then it is possible that the two-wire connection is reversed.

The RS485 bus must be terminated at each end with 120 Ω 0.5 W terminating resistors between the signal wires.

The RS485 standard requires that each device be directly connected to the actual bus. Stubs and tees are forbidden. Loop bus and Star topologies are not part of the RS485 standard and are also forbidden.

Two-core screened twisted pair cable should be used. The final cable specification is dependant on the application, although a multi-strand 0.5 mm<sup>2</sup> per core is normally adequate. The total cable length must not exceed 1000 m. It is important to avoid circulating currents, which can cause noise and interference, especially when the cable runs between buildings. For this reason, the screen should be continuous and connected to ground at one end only, normally at the master connection point.

It may be necessary to bias the signal wires to prevent jabber. Jabber occurs when the signal level has an indeterminate state because the bus is not being actively driven. This can occur when all the slaves are in receive mode and the master is slow to turn from receive mode to transmit mode. This may be because the master is waiting in receive mode, in a high impedance state, until it has something to transmit. Jabber causes the receiving device(s) to miss the first bits of the first character in the packet, which results in the slave rejecting the message and consequently not responding. Symptoms of this are; poor response times (due to retries), increasing message error counts, erratic communications, and in the worst case, complete failure to communicate.

Multilin Agile IEDs are equipped with one or two rear serial communication ports, depending on Cortec selection. The RS485 port has settings for baud rate and parity. It is important that these parameters agree with the settings used on the computer or other equipment connected to this port. A maximum of 32 relays can be daisy-chained and connected to a DCS, PLC or a PC using the RS485 port.

Path: **SETPOINTS\DEVICE\COMMUNICATIONS\RS485**

## 17.4 STANDARD ETHERNET COMMUNICATION

The Ethernet interface is required for either IEC 61850 and/or DNP3oE (IEC 61850 protocol availability must be selected at the time of order, see ordering options for more details). With either of these protocols, the Ethernet interface also offers communication with Modbus TCP for remote configuration and record extraction.

ETH1 port selection between fibre and copper (RJ45) hardware options is done in the Cortec when ordering the device.

Fibre optic connection is recommended for use in permanent connections in a substation environment, as it offers advantages in terms of noise rejection. The fibre optic port provides 100 Mbps communication and uses type LC connectors.

The device can also be connected to either a 10Base-T or a 100Base-TX Ethernet hub or switch using the RJ45 port. The port automatically senses which type of hub is connected. Due to noise and interference reasons, this connection type is only recommended for short-term connections over a short distance.

The pins on the RJ45 connector are as follows:

Pin	Signal Name	Signal Definition
1	TXP	Transmit (positive)
2	TXN	Transmit (negative)
3	RXP	Receive (positive)
4	-	Not used
5	-	Not used
6	RXN	Receive (negative)
7	-	Not used
8	-	Not used

**Note:**

The update of the Network Port settings at path: **SETPOINT/DEVICE/COMMUNICATIONS/ETHERNET/** should not be done off line in the CID and sent to the IED. The Ethernet settings update should be done on line directly in the IED, either entering the settings manually through the HMI, or by communications through the front USB port. 172.17.X.X/16 and 172.18.X.X/16 are reserved IP's.

### 17.4.1 USB

The USB port is used for connecting computers locally for the purposes of transferring settings, measurements and records to and from the computer to the IED and to download firmware updates from a local computer to the IED.

The USB parameters are as follows:

IP Address: 172.16.0.3

IP Mask: 255.255.255.0

IP Gateway: 172.16.0.1

---

## 17.5 REDUNDANT ETHERNET COMMUNICATION

---

Redundancy is required where a single point of failure cannot be tolerated. It is required in critical applications such as substation automation. Redundancy acts as an insurance policy, providing an alternative route if one route fails.

The redundancy interface in the device provides two Ethernet ports (ETH2, ETH3), both of which are for the same physical medium (two copper, or two fibre).

Industry standard PRP (Parallel Redundancy Protocol) and HSR (High-availability Seamless Redundancy) protocols, LLA (Link Loss Alert) functionality as well as physical medium selection (copper or fibre) are all available in the ordering options.

PRP addresses the need for seamless switchover and zero recovery time in case of single network failure in substation automation networks. PRP achieve redundancy by using a combination of LAN duplication and frame duplication technique. Identical frames are sent on two completely independent networks that connect source and destination. Under normal circumstances both frames will reach destination and one of them will be sent up the OSI stack to the destination application, while the second one will be discarded.

HSR functionality, like PRP, addresses the need for seamless switchover and zero recovery time in case of single network failure in substation automation networks. A source node in HSR ring receives a frame from its upper layer and sends it over its two ports in different directions. Under normal circumstances (fault-free state) both identical frames will reach destination node within a certain interval and the first frame will be sent up the OSI stack to the destination application, while the second one will be discarded.

LLA (Link Loss Alert) detects a failure in the fibre link. When the link failure is detected, communication is switched to the standby port. When the primary port link detected is good, the communication is switched back to primary and the backup port goes back into standby mode.

*Note:*

*172.17.X.X/16 and 172.18.X.X/16 are reserved IP's.*

---

### 17.5.1 SUPPORTED PROTOCOLS AND FUNCTIONALITY

One of the key requirements of substation redundant communications is "bumpless" redundancy. This means the ability to transfer from one communication path to another without noticeable consequences. Standard protocols of the time could not meet the demanding requirements of network availability for substation automation solutions.

Switch-over times were unacceptably long. For this reason, companies developed proprietary protocols. More recently, however, standard protocols, which support bumpless redundancy (namely PRP and HSR) have been developed and ratified.

Multilin Agile version 02 onwards supports redundant Ethernet. Variants for each of the following protocols are available:

- PRP (Parallel Redundancy Protocol)
- HSR (High-availability Seamless Redundancy)
- LLA (Link Loss Alert functionality)

PRP and HSR are open standards, so their implementation is compatible with any standard PRP or HSR device respectively. PRP provides bumpless redundancy.

*Note:*

*The protocol you require must be selected at the time of ordering.*

## 17.5.2 PARALLEL REDUNDANCY PROTOCOL (PRP)

PRP (Parallel Redundancy Protocol) is defined in IEC 62439-3. PRP provides bumpless redundancy and meets the most demanding needs of substation automation. The PRP implementation of the REB is compatible with any standard PRP device.


PRP uses two independent Ethernet networks operating in parallel. PRP systems are designed so that there should be no common point of failure between the two networks, so the networks have independent power sources and are not connected together directly.

Devices designed for PRP applications have two ports attached to two separate networks and are called Doubly Attached Nodes (DAN). A DAN has two ports, one MAC address and one IP address.

The sending node replicates each frame and transmits them over both networks. The receiving node processes the frame that arrives first and discards the duplicate. Therefore there is no distinction between the working and backup path. The receiving node checks that all frames arrive in sequence and that frames are correctly received on both ports.

Devices such as printers that have a single Ethernet port can be connected to either of the networks but will not directly benefit from the PRP principles. Such devices are called Singly Attached Nodes (SAN). For devices with a single Ethernet port that need to connect to both LANs, this can be achieved by employing Ethernet Redundancy Boxes (sometimes abbreviated to RedBox). Devices with a single Ethernet port that connect to both LANs by means of a RedBox are known as Virtual DAN (VDAN).

The figure below summarises DAN, SAN, VDAN, LAN, and RedBox connectivity.



**Figure 163: IED attached to separate LANs**

In a DAN, both ports share the same MAC address so it does not affect the way devices talk to each other in an Ethernet network (Address Resolution Protocol at layer 2). Every data frame is seen by both ports.

When a DAN sends a frame of data, the frame is duplicated on both ports and therefore on both LAN segments. This provides a redundant path for the data frame if one of the segments fails. Under normal conditions, both LAN segments are working and each port receives identical frames.

The selection of PRP in the device can be done by selecting *PRP* at the **ETH2 Operation** setting at path: **SETPOINTS\DEVICE\COMMUNICATIONS\ETHERNET\ETHERNET 2**

When set to PRP (Parallel Redundancy Protocol), ETH2 (PortA) and ETH3 (PortB) are the paired ports and use the same MAC address of ETH2 and combine information at the link layer. In this mode of operation both ports are connected two different switches on LANA and LANB. The relay processes the first received frame by forwarding the packet to upper layers and discards the duplicate frame, using the Link Redundancy Entity (LRE) service at layer 2. When received a frame from the network, LRE forwards the first received frame of a pair to the upper layers



after removing the RCT and discards the duplicate. When receiving a frame from the upper layers of the node, LRE appends the RCT and sends the frame through both ports. PRP main mode of operation is Duplicate Discard Mode and Duplicate Accept Mode is not supported.

### 17.5.3 HIGH-AVAILABILITY SEAMLESS REDUNDANCY (HSR)

HSR is standardized in IEC 62439-3 (clause 5) for use in ring topology networks. Similar to PRP, HSR provides bumpless redundancy and meets the most demanding needs of substation automation. HSR has become the reference standard for ring-topology networks in the substation environment. The HSR implementation of the redundancy Ethernet board (REB) is compatible with any standard HSR device.

HSR works on the premise that each device connected in the ring is a doubly attached node running HSR (referred to as DANH). Similar to PRP, singly attached nodes such as printers are connected via Ethernet Redundancy Boxes (RedBox).

The selection of HSR in the device can be done by selecting HSR at the **ETH2 Operation** setting at path **SETPOINTS \DEVICE\COMMUNICATIONS\ETHERNET\ETHERNET 2**

When set to HSR (High-availability Seamless Redundancy Protocol), ETH2 (PortA) and ETH3 (PortB) are the paired ports and use the same MAC address of ETH2. In this mode, all the participating devices are connected in ring topology and in normal condition (fault-free state) both identical frames will reach destination device within a certain interval and the first frame will be sent up the OSI stack to the destination application, while the second one will be discarded. When received a frame that is destined to the relay from network, the relay processes the first received packet by removing the HSR tag and discards the duplicate.

#### 17.5.3.1 HSR MULTICAST TOPOLOGY

When a DANH is sending a multicast frame, the frame (C frame) is duplicated (A frame and B frame), and each duplicate frame A/B is tagged with the destination MAC address and the sequence number. The frames A and B differ only in their sequence number, which is used to identify one frame from the other. Each frame is sent to the network via a separate port. The destination DANH receives two identical frames, removes the HSR tag of the first frame received and passes this (frame D) on for processing. The other duplicate frame is discarded. The nodes forward frames from one port to the other unless it was the node that injected it into the ring.




Figure 164: HSR multicast topology

Only about half of the network bandwidth is available in HSR for multicast or broadcast frames because both duplicate frames A & B circulate the full ring.

### 17.5.3.2 HSR UNICAST TOPOLOGY

With unicast frames, there is just one destination and the frames are sent to that destination alone. All non-recipient devices simply pass the frames on. They do not process them in any way. In other words, D frames are produced only for the receiving DANH. This is illustrated below.




Figure 165: HSR unicast topology

For unicast frames, the whole bandwidth is available as both frames A & B stop at the destination node.

### 17.5.4 LINK LOSS ALERT FUNCTIONALITY (LLA)

LLA (Link Loss Alert) detects a failure in the fiber link. When the link failure is detected, communication is switched to the standby port. When the primary port link detected is good, the communication is switched back to primary and the backup port goes back into standby mode.

The selection of LLA in the device can be done by selecting *LLA* at the **ETH2 Operation** setting at **SETPOINTS \DEVICE\COMMUNICATIONS\ETHERNET\ETHERNET 2**

When set to "LLA", ETH2 and ETH3 will use ETH2's MAC and IP address settings. In this mode ETH3 is in standby mode and is not actively communicate on the Ethernet network but will monitor its link. If ETH2's LLA detects a problem with the link, communication is switched to ETH3. ETH3 is, in effect, acting as a redundant or backup link to the network for ETH2. Once ETH2 detects that the link is good, communications automatically switches back to ETH2 and ETH3 switches back into standby mode.

## 17.6 DATA PROTOCOLS

The product supports a wide range of protocols to make them applicable to many industries and applications. The exact data protocols supported by a particular product depend on its chosen application, but the following table gives a list of the data protocols that are typically available.

### SCADA data protocols

Data Protocol	Layer 1 Protocol	Description
Modbus	RS485, Ethernet	Standard for SCADA communications developed by Modicon.
IEC 60870-5-103	RS485	IEC standard for SCADA communications
DNP 3.0	RS485, Ethernet	Standard for SCADA communications developed by Harris. Used mainly in North America.
IEC 61850	Ethernet	IEC standard for substation automation. Facilitates interoperability.

The relationship of these protocols to the lower level physical layer protocols are as follows:

<b>Data Protocols</b>	Modbus RTU DNP3 Serial IEC 60870-5-103	Modbus TCP DNP3oE IEC 61850		
<b>Data Link Layer</b>	EIA(RS)485	Ethernet	USB	
<b>Physical Layer</b>	Copper			

### 17.6.1 IEC 60870-5-103

The specification IEC 60870-5-103 (Telecontrol Equipment and Systems Part 5 Section 103: Transmission Protocols), defines the use of standards IEC 60870-5-1 to IEC 60870-5-5, which were designed for communication with protection equipment

This section describes how the IEC 60870-5-103 standard is applied to Multilin Agile IEDs. It is not a description of the standard itself. The level at which this section is written assumes that the reader is already familiar with the IEC 60870-5-103 standard.

This section should provide sufficient detail to enable understanding of the standard at a level required by most users.

The IEC 60870-5-103 interface is a master/slave interface with the device as the slave device. The point map for the IEC 60870-5-103 is different from the one used by DNP 3.0 protocol.

#### Cause of Transmission

Cause of transmission is an unsigned integer and it shall take one of the values specified in the following tables:

In monitor direction

<1>	Spontaneous
<2>	Cyclic
<3>	Reset frame count bit (FCB)
<4>	Reset communication unit (CU)
<5>	Start/restart
<6>	Power on
<8>	Time synchronization
<9>	General interrogation
<10>	Termination of general interrogation

<20>	Positive ack of command
<21>	Nack of command

In control direction

<8>	Time synchronization
<9>	Initiation of general interrogation
<20>	General command

### 17.6.1.1 PHYSICAL CONNECTION AND LINK LAYER

There is just one option for IEC 60870-5-103:

- Rear serial ports 1 and 2 (\*) for permanent SCADA connection via RS485

*Note:*

*DNP3 Serial, IEC 60870-5-103 and Modbus RTU may not be enabled simultaneously on the RS485 serial port. But you may enable DNP3oE and be able to work with Modbus TCP on Ethernet and enable IEC 60870-5-103 on serial RS485.*

The IED address and baud rate can be selected using the front panel menu or by a suitable application such as EnerVista Configuration.

*Note:*

*The options marked with (\*) are features which are Cortec dependant.*

*Those not marked with (\*) are available for all ordering options.*

*See ordering options appendix for more details.*

### 17.6.1.2 INITIALISATION

Whenever the device has been powered up, or if the communication parameters have been changed a reset command is required to initialise the communications. The device will respond to either of the two reset commands; Reset CU or Reset FCB (Communication Unit or Frame Count Bit). The difference between the two commands is that the Reset CU command will clear any unsent messages in the transmit buffer, whereas the Reset FCB command does not delete any messages.

The device will respond to the reset command with an identification message ASDU 5. The Cause of Transmission (COT) of this response will be either Reset CU or Reset FCB depending on the nature of the reset command. The content of ASDU 5 is described in the IEC 60870-5-103 section of the Menu Database, available from GE Vernova separately if required.

### 17.6.1.3 TIME SYNCHRONISATION

The time and date can be set using the time synchronization feature of the IEC 60870-5-103 protocol. The device will correct for the transmission delay as specified in IEC 60870-5-103. If the time synchronization message is sent as a send/confirm message then the device will respond with a confirm message. A time synchronization Class 1 event will be generated/produced whether the time-synchronization message is sent as a send confirm or a broadcast (send/no reply) message.

### 17.6.1.4 IEC103 INTEROPERABILITY

The Multilin Agile IEC 60870-5-103 interface is a master/slave interface with the device as the slave device. This section describes the protocol IEC 60870-5-103 slave implementation in the IED.

## Physical layer

### Electrical interface

X	EIA RS-485
32	Number of loads for one protection equipment

### Optical Interface

	Glass fibre
	Plastic fibre
	F-SMA type connector
	BFOC/2,5 type connector

### Transmission Speed

X	9600 bits/s
X	19200 bits/s
X	38400 bits/s
X	57600 bits/s
X	115200 bits/s

## Link Layer

There are no choices for the link layer.

## Application Layer

### Transmission mode for application data

Mode 1 (least significant octet first), as defined in 4.10 of IEC 60870-5-4, is used exclusively in this companion standard.

### Common address of ASDU

X	One COMMON ADDRESS OF ASDU (identical with station address)
	More than one COMMON ADDRESS OF ASDU

### Selection of standard information numbers in monitor direction

#### System functions in monitor direction

	INF	Semantics
X	<0>	End of general interrogation
X	<0>	Time synchronization
X	<2>	Reset FCB

X	<3>	Reset CU
X	<4>	Start/restart
X	<5>	Power on

### Status indications in monitor direction

The status indications in monitor direction are not selected in the table but they can be configured under, **SETPOINTS\DEVICE\COMMUNICATIONS\IEC103 PT LISTS\BINARY INPUTS** settings.

	INF	Semantics
	<17>	Teleprotection active
	<18>	Protection active
	<19>	LED reset
	<20>	Monitor direction blocked
	<21>	Test mode
	<22>	Local parameter setting
	<23>	Characteristic 1
	<24>	Characteristic 2
	<25>	Characteristic 3
	<26>	Characteristic 4
	<27>	Auxiliary input 1
	<28>	Auxiliary input 2
	<30>	Auxiliary input 4
	<29>	Auxiliary input 3

### Supervision indications in monitor direction

The supervision indications in monitor direction are not selected in the table but they can be configured under, **SETPOINTS\DEVICE\COMMUNICATIONS\IEC103 PT LISTS\BINARY INPUTS** settings.

	INF	Semantics
	<32>	Measurand supervision I
	<33>	Measurand supervision V
	<35>	Phase sequence supervision
	<36>	Trip circuit supervision
	<37>	I>> back-up operation

	<38>	VT fuse failure
	<39>	Teleprotection disturbed
	<46>	Group warning
	<47>	Group alarm

#### Earth fault indications in monitor direction

	INF	Semantics
	<48>	Earth fault L1
	<49>	Earth fault L2
	<50>	Earth fault L3
	<51>	Earth fault forward, i.e. line
	<52>	Earth fault reverse, i.e. busbar

#### Fault indications in monitor direction

The fault indications in monitor direction are not selected in the table but they can be configured under **SETPOINTS** `\DEVICE\COMMUNICATIONS\IEC103 PT LISTS\BINARY INPUTS` settings.

	INF	Semantics
	<64>	Start/pick-up L1
	<65>	Start/pick-up L2
	<66>	Start/pick-up L3
	<67>	Start/pick-up N
	<68>	General trip
	<69>	Trip L1
	<70>	Trip L2
	<71>	Trip L3
	<72>	Trip I>> (back-up operation)
	<74>	Fault forward/line
	<75>	Fault reverse/busbar
	<76>	Teleprotection signal transmitted
	<77>	Teleprotection signal received
	<78>	Zone 1

<79>	Zone 2
<80>	Zone 3
<81>	Zone 4
<82>	Zone 5
<83>	Zone 6
<84>	General start/pick-up
<85>	Breaker failure
<86>	Trip measuring system L1
<87>	Trip measuring system L2
<88>	Trip measuring system L3
<89>	Trip measuring system E
<90>	Trip I>
<91>	Trip I>>
<92>	Trip IN>
<93>	Trip IN>>

#### Auto-reclosure indications in monitor direction

The auto-reclosure indications in monitor direction are not selected in the table but they can be configured under **SETPOINTS\DEVICE\COMMUNICATIONS\IEC103 PT LISTS\BINARY INPUTS** settings.

	INF	Semantics
	<128>	CB 'on' by AR
	<129>	CB 'on' by long-time AR
	<130>	AR blocked

#### Measurands in monitor direction

The measurands in monitor direction are not selected in the table but they can be configured under **SETPOINTS\DEVICE\COMMUNICATIONS\IEC103 PT LISTS\MEASURANDS** settings.

	INF	Semantics
	<144>	Measurand I
	<145>	Measurands I, V
	<146>	Measurands I, V, P, Q
	<147>	Measurands In, Ven



	<148>	Measurands IL123, VL123, P, Q, f
--	-------	----------------------------------

### Generic functions in monitor direction

	INF	Semantics
	<240>	Read headings of all defined groups
	<241>	Read values or attributes of all entries of one group
	<243>	Read directory of a single entry
	<244>	Read value or attribute of a single entry
	<245>	End of general interrogation of generic data
	<249>	Write entry with confirmation
	<250>	Write entry with execution
	<251>	Write entry aborted

### Selection of standard information numbers in control direction

#### System functions in control direction

	INF	Semantics
X	<0>	Initiation of general interrogation
X	<0>	Time synchronization

#### General commands in control direction

The General commands in control direction are not selected in the table but they can be configured under **SETPOINTS\DEVICE\COMMUNICATIONS\IEC103 PT LISTS\COMMANDS** settings.

	INF	Semantics
	<17>	Teleprotection on/off
	<18>	Protection on/off
	<19>	LED reset
	<23>	Activate characteristic 1
	<24>	Activate characteristic 2
	<25>	Activate characteristic 3
	<26>	Activate characteristic 4

#### Generic functions in control direction

	INF	Semantics
--	-----	-----------

	<240>	Read headings of all defined groups
	<241>	Read values or attributes of all entries of one group
	<243>	Read directory of a single entry
	<244>	Read value or attribute of a single entry
	<245>	General interrogation of generic data
	<248>	Write entry
	<249>	Write entry with confirmation
	<250>	Write entry with execution
	<251>	Write entry abort

### Basic application functions

	Test mode
	Blocking of monitor direction
X	Disturbance data
	Generic services
	Private data

### Miscellaneous

Measurand	Max. MVAL = times rated value	
	1.2	2.4
Current L1		X
Current L2		X
Current L3		X
Voltage L1-E		X
Voltage L2-E		X
Voltage L3-E		X
Active power P		X
Reactive power Q		X
Frequency f		X
Voltage L1-L2		X

### 17.6.1.5 IEC 60870-5-103 APPLICATION LEVEL

#### Application Functions

The unbalanced transmission mode of the protocol is used to avoid the possibility that more than one protection equipment attempts to transmit on the channel at the same time, over the RS485 backside port.

Data is transferred to the primary or control station (master) using the "data acquisition by polling" principle. Cyclically, the master requests class 2 data to the secondary station (slave). When slave has class 1 data (high priority) pending, the ACD control bit is set to 1 demanding the master to request for that data. Periodically, the master can send a General Interrogation in order to update the complete database.

The measurands are sent to the primary station as a response to a class 2 request. There is a setting (0-60 min) in order to configure the desired interval, where 0 means transmission as fast as possible.

The following functions are supported:

- Initialization
- General Interrogation
- Synchronization
- Commands transmission

#### Type Identification

The implemented Type Identification values (TYPE IDENTIFICATION UI8 [1...8] <1...255>) are listed below:

<1...31>	Definitions of this companion standard (compatible range)
<32...255>	For special use (private range)

#### Information in monitor direction

<1>	Time-tagged message
<3>	Measurands I
<5>	Identification
<6>	Time synchronization
<8>	General interrogation termination
<9>	Measurands II

#### Information in control direction

<6>	Time synchronization
<7>	General interrogation
<20>	General command

#### Function Type

The implemented Function Type values (FUNCTION TYPE UI8 [1...8] <0...255>) are listed below:

0...127>	Private range
----------	---------------

<128...129>	Compatible range
<130...143>	Private range
<144...145>	Compatible range
<146...159>	Private range
<160...161>	Compatible range
<162...175>	Private range
<176...177>	Compatible range
<178...191>	Private range
<192...193>	Compatible range
<194...207>	Private range
<208...209>	Compatible range
<210...223>	Private range
<224...225>	Compatible range
<240...241>	Compatible range
<242...253>	Private range
<254...255>	Compatible range

The Multilin Agile IED is identified at the protocol level as "overcurrent protection", so the Function Type <160> is used for all the digital and analogue points proposed by the standard and mapped in this profile. For the other data supported by the device, the number can be set from the private range.

### Information Number

The implemented Information Number values (INFORMATION NUMBER UI8 [1...8] <0...255>) are listed below:

#### Information in monitor direction

<0...15>	System functions
<16...31>	Status
<32...47>	Supervision
<48...63>	Earth fault
<64...127>	Short circuit
<128...143>	Auto-reclosure
<144...159>	Measurands
<160...239>	Not used

<240...255>	Generic functions
-------------	-------------------

### Information in control direction

<0...15>	System functions
<16...31>	General commands
<240...255>	Generic functions

**Note:**

Changes to the IEC 60870-5-103 settings under **SETPOINT/DEVICE/COMMUNICATIONS/IEC 60870-5-103, IEC103 PT LISTS, IED103DISTRECORD** take effect only after rebooting the IED.

## 17.6.2 DNP 3.0

This section describes how the DNP 3.0 protocol is applied in the product. It is not a description of the protocol itself. The level at which this section is written assumes that the reader is already familiar with the DNP 3.0 protocol.

For more detail information for the DNP 3.0 protocol, please refer to the documentation available from the user group. The device profile document specifies the full details of the DNP 3.0 implementation. This is the standard format DNP 3.0 document that specifies which objects; variations and qualifiers are supported. The device profile document also specifies what data is available from the device using DNP 3.0. The IED operates as a DNP 3.0 slave.

The DNP 3.0 protocol is defined and administered by the DNP Users Group. For further information on DNP 3.0 and the protocol specifications, please see the DNP website ([www.dnp.org](http://www.dnp.org)).

### 17.6.2.1 PHYSICAL CONNECTION AND LINK LAYER

DNP 3.0 can be used with two physical layer protocols: EIA(RS)485, or Ethernet.

Several connection options are available for DNP 3.0

- DNP3 Serial: Rear serial port 1 - for permanent SCADA connection via RS485
- DNP3oE: The rear Ethernet RJ45 port - for permanent SCADA Ethernet connection

With DNP3 Over Ethernet, a maximum of 2 Clients can be configured.

The IED address and baud rate can be selected using the front panel menu or by a suitable application.

When using a serial interface, the data format is: 1 start bit, 8 data bits, 1 stop bit and optional configurable parity bit.

#### Binary input data

Binary input data is used to monitor two-state device operations such as the position of a breaker. The user can configure up to 96 Binary inputs. All binary inputs are configured from Flexlogic Equation Editor signals.

#### Binary output data

Binary output data is used to control two-state devices such as the opening and closing of a breaker. The IED can be configured to support up to 32 Binary outputs. The client's Binary outputs are mapped to a list of Virtual Inputs and Coils. Please note that the number of Binary/ Control outputs is configurable. Of the total number of outputs configured the user can configure a subset that supports dual point control.

### There is just one option for IEC 60870-5-103:analogue input data

Analogue input data is used to monitor analogue signals such as voltages, currents, and power. The device has 32 analogue points.

### Analogue output data

Not supported in the device.

### Time stamps

### Count input data

Count input data could represent a cumulative quantity such as kilowatt hours of energy. The Multilin Agile has 16 Count input data.

Supported Object Numbers		
Object	DNP Data Type	Multilin Agile
1	Binary Input status	User assigned FlexLogic Operands
2	Binary Input change since last read	
10	Binary output status for monitoring	User assigned Virtual Inputs and/or Commands (client looks at status only)
12	Control Relay Output Block	User assigned Virtual Inputs and/or Commands (client can write to the user specified number of control relay outputs)
20	Counter value	Digital counters 1 through 16,
21	Frozen counter value	
22	Counter value change since last read	
23	Frozen counter value change since last read by client	
30	User configured Analogue input value	
32	User configured Analogue input value changed since last time read by client.	

### 17.6.2.2 OBJECT 1 BINARY INPUTS

The DNP binary input data points are configured under the path: **SETPOINTS\DEVICE\COMMUNICATIONS\DNP POINT LISTS\BINARY INPUTS** When a freeze function is performed on a binary counter point, the frozen value is available in the corresponding frozen counter point.

#### Binary Input Points

Static (Steady-State) Object Number: 1

Change Event Object Number: 2

Request Function Codes supported: 1 (read), 22 (assign class)

Static Variation reported when variation 0 requested: 2 (Binary Input with status), Configurable

Change Event Variation reported when variation 0 requested: 2 (Binary Input Change with Time), Configurable

Change Event Scan Rate: 8 times per power system cycle

Change Event Buffer Size: 1024

Default Class for All Points: 1

### 17.6.2.3 OBJECT 10 BINARY OUTPUTS

Object 10, binary outputs, contains commands that can be operated using DNP 3.0. Therefore the points accept commands of type pulse on (null, trip, close) and latch on/off as detailed in the device profile in the relevant Menu Database document, and execute the command once for either command. The other fields are ignored (queue, clear, trip/close, in time and off time).

Object Number: 10

Request Function Codes supported: 1 (read)

Default Variation reported when Variation 0 requested: 2 (Binary Output Status)

### 17.6.2.4 OBJECT 20 BINARY COUNTERS

The following details lists both Binary Counters (Object 20) and Frozen Counters (Object 21). When a freeze function is performed on a Binary Counter point, the frozen value is available in the corresponding Frozen Counter point. IED Digital Counter values are represented as 16 or 32-bit integers. The DNP 3.0 protocol defines counters to be unsigned integers. Care should be taken when interpreting negative counter values.

#### Binary Counters

Static (Steady-State) Object Number: 20

Change Event Object Number: 22

Request Function Codes supported: 1 (read), 7 (freeze), 8 (freeze noack), 9 (freeze and clear), 10 (freeze and clear, noack), 22 (assign class)

Static Variation reported when variation 0 requested: 1 (32-Bit Binary Counter with Flag)

Change Event Variation reported when variation 0 requested: 1 (32-Bit Counter

Change Event without time)

Change Event Buffer Size: 10

Default Class for all points: 3

#### Frozen Counters

Static (Steady-State) Object Number: 21

Change Event Object Number: 23

Request Function Codes supported: 1 (read)

Static Variation reported when variation 0 requested: 1 (32-Bit Frozen Counter with Flag)

Change Event Variation reported when variation 0 requested: 1 (32-Bit Counter Change Event without time)

Change Event Buffer Size: 10

Default Class for all points: 3

#### Binary and Frozen Counters Point Index Name/Description

0 Digital Counter 1

1 Digital Counter 2

2 Digital Counter 3

3 Digital Counter 4

4 Digital Counter 5

5 Digital Counter 6

- 6 Digital Counter 7
- 7 Digital Counter 8
- 8 Digital Counter 9
- 9 Digital Counter 10
- 10 Digital Counter 11
- 11 Digital Counter 12
- 12 Digital Counter 13
- 13 Digital Counter 14
- 14 Digital Counter 15
- 15 Digital Counter 16

### 17.6.2.5 OBJECT 30 ANALOGUEUE INPUT

It is important to note that 16-bit and 32-bit variations of analogue inputs are transmitted through DNP as signed numbers. Even for analogue input points that are not valid as negative values, the maximum positive representation is 32767 for 16-bit values and 2147483647 for 32-bit values. This is a DNP requirement. The deadbands for all Analogue Input points are in the same units as the Analogue Input quantity. For example, an Analogue Input quantity measured in volts has a corresponding deadband in units of volts. IED settings are available to set default deadband values according to data type. Deadbands for individual Analogue Input Points can be set using DNP Object 34.

*Note:*

1. A default variation refers to the variation response when variation 0 is requested and/or in class 0, 1, 2, or 3 scans. The default variations for object types 1, 2, 20, 21, 22, 23, 30, and 32 are selected via relay settings. This optimizes the class 0 poll data size.
2. For static (non-change-event) objects, qualifiers 17 or 28 are only responded when a request is sent with qualifiers 17 or 28, respectively. Otherwise, static object requests sent with qualifiers 00, 01, 06, 07, or 08, are responded with qualifiers 00 or 01. For change event objects, qualifiers 17 or 28 are always responded.
3. Cold restarts are implemented the same as warm restarts - the Multilin Agile is not restarted, but the DNP process is restarted.
4. Only value changes of Binary or Analogue Points are considered as events. Flag changes i.e. say a point becomes offline to online with same value or Time stamp changes i.e. the time stamp of say frozen counter events changes without value change are not considered as events and not reported to master as events.

### 17.6.2.6 DNP 3.0 DEVICE PROFILE

This section describes the specific implementation of DNP version 3.0 within GE Vernova Multilin Agile IED's.

#### 17.6.2.6.1 DNP 3.0 DEVICE PROFILE TABLE

The following table provides the device profile in a similar format to that defined in the DNP 3.0 Subset Definitions Document. While it is referred to in the DNP 3.0 Subset Definitions as a "Document", it is just one component of a total interoperability guide. This table, in combination with the subsequent Implementation and Points List tables should provide a complete interoperability/configuration guide for the device.

The following table provides the device profile in a similar format to that defined in the DNP 3.0 Subset Definitions Document. While it is referred to in the DNP 3.0 Subset Definitions as a "Document", it is just one component of a total interoperability guide. This table, in combination with the subsequent Implementation and Points List tables should provide a complete interoperability/configuration guide for the device.

(Also see the IMPLEMENTATION TABLE in the following section)

Vendor Name: GE Vernova



Device Name: Multilin Agile			
Highest DNP Level Supported:			
For Requests:	Level 2		
For Responses:	Level 2		
Device Function:			
<input type="checkbox"/> Master			
<input checked="" type="checkbox"/> Slave			
Notable objects, functions, and/or qualifiers supported in addition to the Highest DNP Levels Supported (the complete list is described in the attached table):			
Binary Inputs	(Object 1)		
Binary Input Changes	(Object 2)		
Binary Outputs	(Object 10)		
Control Relay Output Block	(Object 12)		
Binary Counters	(Object 20)		
Frozen Counters	(Object 21)		
Counter Change Event	(Object 22)		
Frozen Counter Event	(Object 23)		
Analogue Inputs	(Object 30)		
Analogue Input Changes	(Object 32)		
Analogue Deadbands	(Object 34)		
Time and Date	(Object 50)		
Time Delay Fine	(Object 52)		
Class Data	(Object 60)		
Internal Indications	(Object 80)		
Maximum Data Link Frame Size (octets):		Maximum Application Fragment Size (octets):	
Transmitted:	292	Transmitted:	Configurable up to 2048
Received:	292	Received:	2048
Maximum Data Link Re-tries:		Maximum Application Layer Re-tries:	
x	None Fixed at 3 Configurable	x	None Configurable
Requires Data Link Layer Confirmation:			
x	Never Always Sometimes Configurable		
Requires Application Layer Confirmation:			
x	Never Always When reporting event data		
x	When sending multi-fragment responses Sometimes Configurable		
Timeouts While Waiting for: Configurable			
Data link confirm:	None Fixed at ____ Variable Configurable		
Complete appl. fragment:	None Fixed at ____ Variable Configurable		
Application confirm:	None Fixed at 10 s Variable Configurable		
Complete appl. response:	None Fixed at ____ Variable Configurable		

Others:	
Transmission delay:	No intentional delay
Need time interval:	Configurable (default = 24 hrs.)
Select/operate arm timeout:	10 s
Binary input change scanning period:	8 times per power system cycle
Analogue input change scanning period:	500 ms
Counter change scanning period:	500 ms
Frozen counter event scanning period:	500 ms
Sends/Executes Control Operations:	
WRITE Binary Outputs	<u>Never</u> Always Sometimes Configurable
SELECT/OPERATE	Never <u>Always</u> Sometimes Configurable
DIRECT OPERATE	Never <u>Always</u> Sometimes Configurable
DIRECT OPERATE – NO ACK	Never <u>Always</u> Sometimes Configurable
Count > 1	<u>Never</u> Always Sometimes Configurable
Pulse On	Never Always <u>Sometimes</u> Configurable
Pulse Off	Never Always <u>Sometimes</u> Configurable
Latch On	Never Always <u>Sometimes</u> Configurable
Latch Off	Never Always <u>Sometimes</u> Configurable
Queue	<u>Never</u> Always Sometimes Configurable
Clear Queue	<u>Never</u> Always Sometimes Configurable
<p>Explanation of 'Sometimes': Object 12 points are mapped to Virtual Inputs and Commands(Force Coils). Both "Pulse On" and "Latch On" operations perform the same function in the series8; that is, the appropriate Virtual Input or Coil is put into the "On" state. The On/Off times and Count value are ignored. "Pulse Off" and "Latch Off" operations put the appropriate Virtual Input or Coil into the "Off" state. "Trip" and "Close" operations both put the appropriate Virtual Input or coil into the "On" state if a paired mapping is set, otherwise "Trip" will put into "Off" and "Close" will put into "On".</p>	

<p>Reports Binary Input Change Events when no specific variation requested:</p> <ul style="list-style-type: none"> <li>Never</li> <li>x Only time-tagged</li> <li>.. Only non-time-tagged</li> <li>.. Configurable</li> </ul>	<p>Reports time-tagged Binary Input Change Events when no specific variation requested:</p> <ul style="list-style-type: none"> <li>.. Never</li> <li>x Binary Input Change With Time</li> <li>Binary Input Change With Relative Time</li> <li>Configurable (attach explanation)</li> </ul>
<p>Sends Unsolicited Responses:</p> <ul style="list-style-type: none"> <li>Never</li> <li>Configurable</li> <li>Only certain objects</li> <li>x Sometimes</li> <li>x ENABLE/DISABLE unsolicited Function codes supported</li> </ul>	<p>Sends Static Data in Unsolicited Responses:</p> <ul style="list-style-type: none"> <li>x Never</li> <li>When Device Restarts</li> <li>When Status Flags Change</li> <li>No other options are permitted.</li> </ul>
<p>Explanation of 'Sometimes': It will be disabled for RS-485 applications, since there is no collision avoidance mechanism. For Ethernet communication it will be available and it can be disabled or enabled with xhe proper function code.</p>	
<p>Default Counter Object/Variation:</p> <ul style="list-style-type: none"> <li>No Counters Reported</li> <li>Configurable (attach explanation)</li> <li>x Default Object: 20</li> </ul>	<p>Counters Roll Over at:</p> <ul style="list-style-type: none"> <li>No Counters Reported</li> <li>Configurable (attach explanation)</li> <li>x 16 Bits</li> </ul>

Default Variation: 1	32 Bits
x Point-by-point list attached	Other Value: _____
	x Point-by-point list attached
Sends Multi-Fragment Responses:	
x Yes	
No	

### 17.6.2.6.2 DNP 3.0 IMPLEMENTATION TABLE

The implementation table provides a list of objects, variations and control codes supported by the device:

Object No.	Variation No.	Description	Function Codes (DEC)	Qualifier Codes (HEX)	Function Codes (DEC)	Qualifier Codes (HEX)
1	0	Binary Input (Variation 0 is used to request default variation)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)		
	1	Binary Input	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	2	Binary Input with Status	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
2	0	Binary Input Change (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all) 07, 08 (limited quantity)		
	1	Binary Input Change without Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	2	Binary Input Change with Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	3	Binary Input Change with Relative Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)		
10	0	Binary Output Status (Variation 0 is used to request default variation)	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)		
	2	Binary Output Status	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
12	1	Control Relay Output Block	3 (select) 4 (operate) 5 (direct op) 6 (dir. op, noack)	00, 01 (start-stop) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	echo of request

Object No.	Variation No.	Description	Function Codes (DEC)	Qualifier Codes (HEX)	Function Codes (DEC)	Qualifier Codes (HEX)
20	0	Binary Counter (Variation 0 is used to request default variation)	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28(index)		
	1	32-Bit Binary Counter	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	2	16-Bit Binary Counter	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	5	32-Bit Binary Counter without Flag	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	6	16-Bit Binary Counter without Flag	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
21	0	Frozen Counter (Variation 0 is used to request default variation)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)		
	1	32-Bit Frozen Counter	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	2	16-Bit Frozen Counter	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	9	32-Bit Frozen Counter without Flag	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	10	16-Bit Frozen Counter without Flag	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)

Object No.	Variation No.	Description	Function Codes (DEC)	Qualifier Codes (HEX)	Function Codes (DEC)	Qualifier Codes (HEX)
22	0	Counter Change Event (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all) 07, 08 (limited quantity)		
	1	32-Bit Counter Change Event	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	2	16-Bit Counter Change Event	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	5	32-Bit Counter Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	6	16-Bit Counter Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
23	0	Frozen Counter Event (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all) 07, 08 (limited quantity)		
	1	32-Bit Frozen Counter Event	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	2	16-Bit Frozen Counter Event	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	5	32-Bit Frozen Counter Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	6	16-Bit Frozen Counter Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
30	0	Analogue Input (Variation 0 is used to request default variation)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)		
	1	32-Bit Analogue Input	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	2	16-Bit Analogue Input	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	3	32-Bit Analogue Input without Flag	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	4	16-Bit Analogue Input without Flag	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	5	Short floating point	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)

Object No.	Variation No.	Description	Function Codes (DEC)	Qualifier Codes (HEX)	Function Codes (DEC)	Qualifier Codes (HEX)
32	0	Analogue Change Event (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all) 07, 08 (limited quantity)		
	1	32-Bit Analogue Change Event without Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	2	16-Bit Analogue Change Event without Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	3	32-Bit Analogue Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	4	16-Bit Analogue Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	5	Short floating point Analogue Change Event without Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	7	Short floating point Analogue Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited quantity)	129 (response) 130 (unsol. resp.)	17, 28 (index)
34	0	Analogue Input Reporting Deadband (Variation 0 is used to request default variation)	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)		
	1	16-bit Analogue Input Reporting Deadband (default - see Note 1)	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
			2 (write)	00, 01 (start-stop) 07, 08 (limited quantity) 17, 28 (index)		
	2	32-bit Analogue Input Reporting Deadband	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited quantity) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
			2 (write)	00, 01 (start-stop) 07, 08 (limited quantity) 17, 28 (index)		
	50	1	Time and Date (default - see Note 1)	1 (read) 2 (write)	00, 01 (start-stop) 06 (no range, or all) 07 (limited qty=1) 08 (limited quantity) 17, 28 (index)	129 (response)
52	2	Time Delay Fine (quantity = 1)	129 (response)	07 (limited quantity)		
60	0	Class 0, 1, 2, and 3 Data - used for changing the class of objects and enabling/disabling unsolicited responses.	1 (read) 20 (enable unsol) 21 (disable unsol) 22 (assign class)	06 (no range, or all)		
	1	Class 0 Data	1 (read) 22 (assign class)	06 (no range, or all)		
	2	Class 1 Data	1 (read) 20 (enable unsol)	06 (no range, or all)		
	3	Class 2 Data	21 (disable unsol)	07, 08 (limited quantity)		
	4	Class 3 Data	22 (assign class)			

Object No.	Variation No.	Description	Function Codes (DEC)	Qualifier Codes (HEX)	Function Codes (DEC)	Qualifier Codes (HEX)
80	1	Internal indications clearing	1 (read)	00, 01 (start-stop) (index =7)	129 (response)	00, 01 (start-stop)
			2 (write) (see Note 3)	00 (start-stop) (index =7)		
		No Object (function code only) see Note 3	13 (cold restart)			
		No Object (function code only)	14 (warm restart)			
		No Object (function code only)	23 (delay meas.)			

**Note:**

1: A default variation refers to the variation responded when variation 0 is requested and/or in class 0, 1, 2, or 3 scans. The default variations for object types 1, 2, 20, 21, 22, 23, 30, and 32 are selected via rIED settings. This optimizes the class 0 poll data size.

2: For static (non-change-event) objects, qualifiers 17 or 28 are only responded when a request is sent with qualifiers 17 or 28, respectively. Otherwise, static object requests sent with qualifiers 00, 01, 06, 07, or 08, will be responded with qualifiers 00 or 01 (for change event objects, qualifiers 17 or 28 are always responded.)

3: Cold restarts are implemented the same as warm restarts, the Multilin Agile IED is not restarted, but the DNP process is restarted.

### 17.6.3 MODBUS

This section describes how the Modbus protocol is applied to the Multilin Agile IEDs. It is not a description of the standard itself. The level at which this section is written assumes that the reader is already familiar with the Modbus protocol.

The Modbus protocol is a master/slave protocol, defined and administered by the Modbus Organization. For further information on Modbus and the protocol specifications, please see the Modbus web site ([www.modbus.org](http://www.modbus.org)).

The Multilin Agile IED implements a subset of the Modicon Modbus RTU serial communication standard. The Modbus protocol is hardware independent. That is, the physical layer can be any of a variety of standard hardware configurations. This includes USB, RS485, RJ45 etc. Modbus is a single master/multiple slave type of protocol suitable for a multi-drop configuration.

All Ethernet ports and serial communication ports support the Modbus protocol. The only exception is if the serial port has been configured for DNP or IEC 60870-5-103 operation (as the serial port allows just one serial protocol (selectable by setting) at a time). This allows the EnerVista Configuration software (which is a Modbus master application) to communicate to the IED.

The Multilin Agile IED is always a Modbus slave with a valid slave address range 1 to 254.

#### 17.6.3.1 PHYSICAL CONNECTION AND LINK LAYER

##### Data Frame Format

One data frame of an asynchronous transmission to or from a Multilin Agile IED typically consists of 1 start bit, 8 data bits, and 1 stop bit. This produces a 10-bit data frame. This is important for transmission through modems at high bit rates.

##### Data Rate

The Modbus protocol can be implemented at any standard communication speed. The Multilin Agile supports operation at 9600, 19200, 38400, 57600, and 115200 baud. The USB and Ethernet interfaces support Modbus TCP.

### 17.6.3.2 RESPONSE CODES

MCode	MODBUS Description	MiCOM Interpretation
01	Illegal Function	The function code transmitted is not supported by the slave.
02	Illegal Data Address	The data address in the request is not an allowable value.
03	Illegal Data Value	A value referenced in the data field transmitted by the master is not within range.

### 17.6.3.3 SUPPORTED FUNCTION CODES

The following functions are supported by the Multilin Agile IED:

- FUNCTION CODE 03H - Read Setpoints
- FUNCTION CODE 04H - Read Actual Values
- FUNCTION CODE 05H - Execute Operation
- FUNCTION CODE 06H - Store Single Setpoint
- FUNCTION CODE 07H - Read Device Status
- FUNCTION CODE 08H - Loopback Test
- FUNCTION CODE 10H - Store Multiple Setpoints

When a Modbus master communicates to the IED over Ethernet, the IED slave address, TCP port number and the IED IP address for the associated port must be configured and are also configured within the Master for this device. The default Modbus TCP port number is 502.

Configurable Modbus parameters are found at the following Path: **SETPOINT/DEVICE/COMMUNICATIONS/MODBUS/**

For Modbus Memory Map addresses for the IED, please refer to the Setting and Signals appendix.

*Note:*

*Changes to the Modbus TCP Port Number setting under **SETPOINT/DEVICE/COMMUNICATIONS/MODBUS/TCP PORT NUMBER** takes effect only after rebooting the IED.*

### 17.6.3.4 ADMINISTRATOR LOGIN AND COMMANDS VIA MODBUS

#### Logging in as Administrator

Logging in as Administrator is demonstrated in the example below. The process requires writing 44 bytes which consist of the Role ID and Password. Password characters are 22 bytes and role characters are also 22 bytes. The logging in must be done using a single Modbus command, using Function 10H (Store Multiple Setpoints).

The following table shows data to be written to the relay to login as Administrator. The relay password in this example is 0.

#### Data Written to Relay to Login as Administrator

Description	Memory Map Address		Values to be Written	
	DEC	HEX	DEC	HEX
Role Characters 1 and 2	62242	F322	16740	4164
Role Characters 3 and 4	62243	F323	28009	6D69
Role Characters 5 and 6	62244	F324	28265	6E69
Role Characters 7 and 8	62245	F325	29556	7374
Role Characters 9 and 10	62246	F326	29281	7261
Role Characters 11 and 12	62247	F327	29807	746F



Description	Memory Map Address		Values to be Written	
	DEC	HEX	DEC	HEX
Role Characters 13 and 14	62248	F328	29184	7200
Role Characters 15 and 16	62249	F329	0	0000
Role Characters 17 and 18	62250	F32A	0	0000
Role Characters 19 and 20	62251	F32B	0	0000
Role Characters 21 and 22	62252	F32C	0	0000
Password Characters 1 and 2	62253	F32D	12288	3000
Password Characters 3 and 4	62254	F32E	0	0000
Password Characters 5 and 6	62255	F32F	0	0000
Password Characters 7 and 8	62256	F330	0	0000
Password Characters 9 and 10	62257	F331	0	0000
Password Characters 11 and 12	62258	F332	0	0000
Password Characters 13 and 14	62259	F333	0	0000
Password Characters 15 and 16	62260	F334	0	0000
Password Characters 17 and 18	62261	F335	0	0000
Password Characters 19 and 20	62262	F336	0	0000
Password Characters 21 and 22	62263	F337	0	0000

### Login as Administrator Function Format

Slave#	Function	Data Starting Address	Number of Setpoints	Byte Count	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7	Data 8	Data 9
FE	10	F322	0016	2C	4164	6D69	6E69	7374	7261	746F	7200	0	0

### Login as Administrator Function Format continued

Data 10	Data 11	Data 12	Data 13	Data 14	Data 15	Data 16	Data 17	Data 18	Data 19	Data 20	Data 21	Data 22
0	0	3000	0	0	0	0	0	0	0	0	0	0

### Commands Using Modbus Function 10H (Store Multiple Setpoints)

Sending commands requires writing 4 bytes to the Command address register using the Modbus Function 10H (Store Multiple Setpoints). The 4 bytes are the function and the command values. The function value is always 05.

### Modbus Commands Registers

Description	Memory Map Address	
	DEC	HEX
Command Register	40129	0x0080
Command Function Register	40130	0x0081

### Examples of Command Values

Command Value	Value Description
1	Reset
96	Clear All Records
98	Clear Event Records

Command Value	Value Description
105	Clear Energy Use Data
4096	Force Vir I/P 1

#### Function Format for "Clear All" Command

Slave#	Function	Data Starting Address	Number of Setpoints	Byte Count	Data 1	Data 2
FE	10	0080	0002	04	0005	0060

#### Function Format for "Clear Energy Use Data" Command

Slave#	Function	Data Starting Address	Number of Setpoints	Byte Count	Data 1	Data 2
FE	10	0080	0002	04	0005	0069

#### Function Format for "Force Vir I/P 1" Command

Slave#	Function	Data Starting Address	Number of Setpoints	Byte Count	Data 1	Data 2
FE	10	0080	0002	04	0005	1000

#### Commands Using Modbus Function 05H (Execute Operation)

Specific command operations, such as described above, can also be performed using function code 05H.

#### Format for Function Code 05H

Master Transmission	Byte#	Example	Description
Slave Address	1	FE	Message for slave # 254
Function Code	1	05	Execute operation
Operation Code	2	00 01	Operation code
Code Value	2	FF 00	Perform function
CRC	2	DF 6A	CRC error code

#### Examples of Command Values

Command Value	Value Description
1	Reset
96	Clear All Records
98	Clear Event Records
105	Clear Energy Use Data
4096	Force Vir I/P 1

#### Function Format for Reset Command

Slave #	Function	Operation Code	Code Value
FE	05	0001	FF00

## 17.6.4 IEC 61850

This section describes how the IEC 61850 standard is applied to GE Vernova's products. It is not a description of the standard itself. The level at which this section is written assumes that the reader is already familiar with the IEC 61850 standard.

IEC 61850 is the international standard for Ethernet-based communication in substations. It enables integration of all protection, control, measurement and monitoring functions within a substation, and additionally provides the means for interlocking and inter-tripping. It combines the convenience of Ethernet with the security that is so essential in substations today.

Multilin Agile IEDs support both the IEC 61850 GOOSE and IEC 61850 MMS Server service as per IEC 61850 standard Ed. 2. The GOOSE messaging service provides the Multilin Agile IED the ability to Publish/Subscribe Digital Input and other element statuses and its Quality and Timestamp to/from other IEDs with supporting GOOSE messaging service. Server support allows remote control center, RTU/Gateway, local HMI or other client role devices access to the IED for monitoring and control. The configuration of IEC 61850 services is accomplished using the EnerVista Configuration Setup software.

### 17.6.4.1 BENEFITS OF IEC 61850

The standard provides:

- Standardised models for IEDs and other equipment within the substation
- Standardised communication services (the methods used to access and exchange data)
- Standardised formats for configuration files
- Peer-to-peer communication

The standard adheres to the requirements laid out by the ISO OSI model and therefore provides complete vendor interoperability and flexibility on the transmission types and protocols used. This includes mapping of data onto Ethernet, which is becoming more and more widely used in substations, in favour of RS485. Using Ethernet in the substation offers many advantages, most significantly including:

- Ethernet allows high-speed data rates (currently 100 Mbps, rather than tens of kbps or less used by most serial protocols)
- Ethernet provides the possibility to have multiple clients
- Ethernet is an open standard in every-day use
- There is a wide range of Ethernet-compatible products that may be used to supplement the LAN installation (hubs, bridges, switches)


### 17.6.4.2 IEC 61850 INTEROPERABILITY

A major benefit of IEC 61850 is interoperability. IEC 61850 standardizes the data model of substation IEDs, which allows interoperability between products from multiple vendors.

An IEC 61850-compliant device may be interoperable, but this does not mean it is interchangeable. You cannot simply replace a product from one vendor with that of another without reconfiguration. However, the terminology is pre-defined and anyone with prior knowledge of IEC 61850 should be able to integrate a new device very quickly without having to map all of the new data. IEC 61850 brings improved substation communications and interoperability to the end user, at a lower cost.

### 17.6.4.3 THE IEC 61850 DATA MODEL

The data model of any IEC 61850 IED can be viewed as a hierarchy of information, whose nomenclature and categorization is defined and standardized in the IEC 61850 specification.



**Figure 166: Data model layers in IEC 61850**

The levels of this hierarchy can be described as follows:

#### Data Frame format

Layer	Description
Physical Device	Identifies the actual IED within a system. Typically the device's name or IP address can be used (for example Feeder_1 or 10.0.0.2).
Logical Device	Identifies groups of related Logical Nodes within the Physical Device. For the MiCOM IEDs, 5 Logical Devices exist: Control, Measurements, Protection, Records, System.
Wrapper/Logical Node Instance	The IEC 61850 Logical Device top-level data model consists of instances of Logical Nodes. The data model name for a Logical Node instance is constructed from an optional prefix (known as the wrapper), the Logical Node name, and an instance ID (or suffix). For example, XCBR1 (CB Control), MMXU1 (measurements), PTOF2 (overfrequency protection, stage 2).
Data Object	This next layer is used to identify the type of data you will be presented with. For example, Pos (position) of Logical Node type XCBR.
Data Attribute	This is the actual data (measurement value, status, description, etc.). For example, stVal (status value) indicating actual position of circuit breaker for Data Object type Pos of Logical Node type XCBR.

#### 17.6.4.4 IEC 61850 IN IEDS

To communicate with an IEC 61850 IED on Ethernet, it is necessary only to know its IP address. This can then be configured into either:

- An IEC 61850 client (or master), for example a bay computer
- An HMI
- An MMS browser, with which the full data model can be retrieved from the IED, without any prior knowledge of the IED

The IEC 61850 compatible interface standard provides capability for the following:

- Read access to measurements
- Refresh of all measurements at a standard rate.

- Generation of non-buffered and buffered reports on change of status or measurement
- SNTP time synchronization over an Ethernet link. (This is used to synchronize the IEDs internal real time clock.
- GOOSE peer-to-peer communication
- Disturbance record extraction by IEC 61850 MMS file transfer. The record is extracted as an ASCII format COMTRADE file
- Controls (Direct and Select Before Operate)

#### 17.6.4.5 IEC 61850 DATA MODEL IMPLEMENTATION

The data model is described in the Model Implementation Conformance Statement (MICS) document, which is available as a separate document.

#### 17.6.4.6 IEC 61850 COMMUNICATION SERVICES IMPLEMENTATION

The IEC 61850 communication services which are implemented in the IEDs are described in the Protocol Implementation Conformance Statement (PICS) document, which is available as a separate document.

#### 17.6.4.7 IEC 61850 PEER-TO-PEER (GOOSE) COMMUNICATIONS

The implementation of IEC 61850 Generic Object Oriented Substation Event (GOOSE) enables faster communication between IEDs offering the possibility for a fast and reliable system-wide distribution of input and output data values. The GOOSE model uses multicast services to deliver event information. Multicast messaging means that messages are sent to selected devices on the network. The receiving devices can specifically accept frames from certain devices and discard frames from the other devices. It is also known as a publisher-subscriber system. When a device detects a change in one of its monitored status points it publishes a new message. Any device that is interested in the information subscribes to the data it contains.

#### 17.6.4.8 MAPPING GOOSE MESSAGES TO REMOTE INPUTS

Each GOOSE signal contained in a subscribed GOOSE message can be mapped to any of the remote inputs within the IEC61850 configuration. The remote inputs allow the mapping to internal logic functions for protection control, directly to output contacts or LEDs for monitoring.

An IED can subscribe to all GOOSE messages but only the following data types can be decoded and mapped to a remote input:

- BOOLEAN
- INT16
- INT32
- INT8
- UINT16
- UINT32
- UINT8

##### 17.6.4.8.1 IEC 61850 GOOSE CONFIGURATION

All GOOSE configuration is performed using the software application.

#### 17.6.4.9 ETHERNET DISCONNECTION

IEC 61850 **Associations** are unique and made between the client and server. If Ethernet connectivity is lost for any reason, the associations are lost, and will need to be re-established by the client. The IED has a **TCP\_KEEPALIVE** function to monitor each association, and terminate any which are no longer active.

#### 17.6.4.10 LOSS OF POWER

The IED allows the re-establishment of associations without disruption of its operation, even after its power has been removed. As the IED acts as a server in this process, the client must request the association. Uncommitted settings are cancelled when power is lost, and reports requested by connected clients are reset. The client must re-enable these when it next creates the new association to the IED.

#### 17.6.4.11 IEC 61850 CONFIGURATION

The EnerVista Configuration settings application software provides an IEC 61850 Configurator tool, which allows the pre-configured IEC 61850 configuration file to be imported and transferred to the IED. As well as this, you can manually create configuration files for all products, based on their original IED capability description (ICD file).

Other features include:

- The extraction of configuration data for viewing and editing.
- A sophisticated error checking sequence to validate the configuration data before sending to the IED.

##### 17.6.4.11.1 IEC 61850 NETWORK CONNECTIVITY

Configuration of the IP parameters is performed by the EnerVista Configuration IEC 61850 Configurator tool. If these parameters are not available using an SCL (Substation Configuration Language) file, they must be configured manually.

Every IP address on the Local Area Network must be unique. Duplicate IP addresses result in conflict and must be avoided.

The IED can be configured to accept data from other networks using the **Gateway** setting. If multiple networks are used, the IP addresses must be unique across networks.

*Note:*

*Measurements Deadband changes in IEC 61850 settings take effect only after rebooting the IED.*

## 17.7 TIME SYNCHRONISATION

In modern protection schemes it is necessary to synchronise the IEDs real time clock so that events from different devices can be time stamped and placed in chronological order. This is achieved in various ways depending on the chosen options and communication protocols.

- Using PTP (Precision Time Protocol) specified in IEEE Std 1588TM 2008 (PTP v2)
- Using the IRIG-B input
- Using the SNTP time protocol
- By using the time synchronisation functionality inherent in the data protocols

The Multilin Agile IED is capable of receiving a time reference from several time sources in addition to its own internal clock for the purpose of time-stamping events, disturbance records and other occurrences within the device. The accuracy of the time stamp is based on the time reference that is used. The Multilin Agile IED supports an internal clock, SNTP, IRIG- B, and PTP IEEE 1588 (version 2) as potential time references.

If two or more time sources are available, the time source with the higher priority shown in Time Sources table is used where 1 is considered to be the highest priority. Please note that the time source priority of PTP and IRIG-B can be swapped. If both PTP and IRIG-B are available to the Multilin Agile IED, by default the Multilin Agile IED clock syncs to PTP over IRIG-B. If PTP is not available, the IED syncs the internal clock to IRIG-B.

Time Source	Priority
PTP (IEEE1588)	1*
IRIG-B	2*
SNTP	3
Internal Clock	4

\* The priority of IRIG-B and PTP can be swapped in **SETTINGS\DEVICE\DATE AND TIME\CLOCK\SYNC SRC PRIO.** path by choosing between values *PTP*, *IRIG B* and *OTHER*.

**Note:**

*Synchronisation via communication protocols, IEC 60870-5-103, DNP3 Serial and DNP3oE, Modbus RTU and Modbus TCP, etc. will not be accepted if the sync source is from IRIG-B, SNTP or PTP.*

### 17.7.1 IEEE 1588 PRECISION TIME PROTOCOL (PTP VERSION 2)

The PTP settings are placed under the path: **SETPOINT\DEVICE\DATE AND TIME\PTP**.

The PTP status can be viewed at **DEVICE STATUS\PTP**.

The System Clock (device date and time) and RTC Sync Source (Type of synchronization in place) are available at **DEVICE STATUS\CLOCK** path.

#### 17.7.1.1 FEATURE SUMMARY

The IED implements PTP functionality on each of its Ethernet ports independently, and automatically selects the port with the best time using the Best Master Clock Algorithm. Depending on the Cortec selection, the device will have one Ethernet port (ETH1) or three (ETH1, ETH2, and ETH3) for redundancy.

The IED may use PTP, IRIG-B, or SNTP time sources based on the user configuration or it may free-run if none of the time sources are available.

When both PTP and IRIG-B are enabled and time sources are available, the priority between the PTP and IRIG-B is user configurable.

PTP version 2 is supported and only the transport over IEEE 802.3/Ethernet PTP option is supported. PTP Version 1 is not supported.

Only the slave-only operation option is supported, master operation is not implemented.

Multilin Agile IED supports both 1-step and 2-step synchronisation on ingress. As the IED operates only in slave mode, it doesn't egress any synchronisation messages except peer delay request.

The peer delay mechanism is implemented, but in the requestor mode responder mode is not supported. The end-to-end delay mechanism is not implemented as it is forbidden by both Power and Power Utility Profiles.

The IED supports synchronising to the grandmasters with either Power Profile (IEEE C37.238: 2017) or Power Utility Profile (IEC61850 9-3).

Multilin Agile IED synchronises (meets the time accuracy requirements) within 15 seconds, given an error-free PP input and stable temperature.

The ALTERNATE\_TIME\_OFFSET\_INDICATOR TLV in PP is not used to calculate local time zone.

### 17.7.1.2 SYSTEM OPERATION

The IED supports the Precision Time Protocol (PTP) specified in IEEE Std 1588TM 2008 (PTP v2). This enables the IED to synchronize to the international time standard over an Ethernet network that implements both the Power Profile (PP) specified in IEEE Std C37.238TM 2017 and Power Utility profile (PU) specified in IEC61850 9-3.

Power profile specifies PTP message extensions that includes two TLVs (type, length, and values) as given below:

- IEEE\_C37\_238 TLV - providing additional information to monitor clock performance in real time
- ALTERNATE\_TIME\_OFFSET\_INDICATOR TLV - providing local time zone information

\*See IEEE C37.238-2017: clause 6 for more information on TLVs.

However, the usage of TLVs is made optional in IEEE Std C37.238 2017. The IED doesn't use the information provided in optional TLVs and tolerates the missing TLVs. When a master clock with power profile and power utility profile are available in network, the IED can synchronize to best master based on best master clock algorithm.

When the ETH1/2/3 PTP Function is enabled, Slave-only operation is supported, where a grandmaster is available on the port communication path, the Best Master Clock Algorithm selects the best master clock out of all the enabled ports, and the respective port state is set to SLAVE. The IED implements the state machine for slave-only implementation specified in PTP clause 9.2 independently on each Ethernet port.

When the Process Bus Module NW redundancy function is set to PRP or HSR, the general operating mode of duplicate detection and discard does not apply to PTP frames and PTP frames are processed as if the NW redundancy is disabled. The RCT of the ingress PTP messages is ignored and no RCT is appended to the egress PTP messages.

The paired ports (ETH2 & ETH3 in case of PRP) are considered independent and the specified state machines and Best Master Clock Algorithm are executed independently on both the paired ports.


---

## 17.7.2 IRIG-B

IRIG stands for Inter Range Instrumentation Group, which is a standards body responsible for standardising different time code formats. There are several different formats starting with IRIG-A, followed by IRIG-B and so on. The letter after the "IRIG" specifies the resolution of the time signal in pulses per second (PPS). IRIG-B, the one which we use has a resolution of 100 PPS. IRIG-B is used when accurate time-stamping is required.

The following diagram shows a typical GPS time-synchronised substation application. The satellite RF signal is picked up by a satellite dish and passed on to receiver. The receiver receives the signal and converts it into time signal suitable for the substation network. IEDs in the substation use this signal to govern their internal clocks and event recorders.





**Figure 167: GPS satellite timing signal**

The IRIG-B time code signal is a sequence of one second time frames. Each frame is split up into ten 100 mS slots as follows:

- Time-slot 1: Seconds
- Time-slot 2: Minutes
- Time-slot 3: Hours
- Time-slot 4: Days
- Time-slot 5 and 6: Control functions
- Time-slots 7 to 10: Straight binary time of day

The first four time-slots define the time in BCD (Binary Coded Decimal). Time-slots 5 and 6 are used for control functions, which control deletion commands and allow different data groupings within the synchronisation strings. Time-slots 7-10 define the time in SBS (Straight Binary Second of day).

### 17.7.2.1 DEMODULATED IRIG-B IMPLEMENTATION

All models have the option of accepting a demodulated IRIG-B input.

To set the device to use IRIG-B, Set the IRIG-B setting under path, **SETPOINT\ DEVICE\ DATE AND TIME** to Enabled.

The IRIG-B status can be viewed in the at **DEVICE STATUS\ CLOCK\ RTC SYNC SOURCE**.

---

## 17.7.3 SNTP

SNTP is used to synchronise the clocks of computer systems over packet-switched, variable-latency data networks, such as IP.

The device is synchronised by the main SNTP server. This is achieved by entering the IP address of the SNTP server into the IED using the EnerVista Configuration Setup Software.

This function issues an alarm when there is a loss of time synchronisation on the SNTP server. This could be because there is no response or no valid clock signal.

Multilin Agile IEDs SNTP synchronisation may take up to 1-2 minutes, as it needs to get many time values and average them.

---

#### **17.7.4 TIME SYNCHRONISATION USING THE COMMUNICATION PROTOCOLS**

All communication protocols have in-built time synchronisation mechanisms. If an external time synchronisation mechanism such as IRIG-B, SNTP or PTP is not used to synchronise the devices, the time synchronisation mechanism within the relevant protocol is used. The real time is usually defined in the master station and communicated to the relevant IEDs via the rear port using the chosen protocol. It is also possible to define the time locally.

The time synchronisation for each protocol is described in the relevant protocol description section.

## CHAPTER 18

# CYBER-SECURITY

---

## 18.1 OVERVIEW

---

In the past, substation networks were traditionally isolated and the protocols and data formats used to transfer information between devices were often proprietary.

For these reasons, the substation environment was very secure against cyber-attacks. The terms used for this inherent type of security are:

- Security by isolation (if the substation network is not connected to the outside world, it cannot be accessed from the outside world).
- Security by obscurity (if the formats and protocols are proprietary, it is very difficult to interpret them).

The increasing sophistication of protection schemes, coupled with the advancement of technology and the desire for vendor interoperability, has resulted in standardisation of networks and data interchange within substations. Today, devices within substations use standardised protocols for communication. Furthermore, substations can be interconnected with open networks, such as the internet or corporate-wide networks, which use standardised protocols for communication. This introduces a major security risk making the grid vulnerable to cyber-attacks, which could in turn lead to major electrical outages.

Clearly, there is now a need to secure communication and equipment within substation environments. This chapter describes the security measures that have been put in place for our range of Intelligent Electronic Devices (IEDs).

*Note:*

*Cyber-security compatible devices do not enforce NERC compliance, they merely facilitate it. It is the responsibility of the user to ensure that compliance is adhered to as and when necessary.*

This chapter contains the following sections:

Overview	414
The Need for Cyber-Security	415
Standards	416
Cyber-Security Implementation	424
RBAC User Management Cyber-Security Configuration Tool	438

---

## 18.2 THE NEED FOR CYBER-SECURITY

---

Cyber-security provides protection against unauthorised disclosure, transfer, modification, or destruction of information or information systems, whether accidental or intentional. To achieve this, there are several security requirements:

- Confidentiality (preventing unauthorised access to information)
- Integrity (preventing unauthorised modification)
- Availability/Authentication (preventing the denial of service and assuring authorised access to information)
- Non-repudiation (preventing the denial of an action that took place)
- Traceability/Detection (monitoring and logging of activity to detect intrusion and analyse incidents)

The threats to cyber-security may be unintentional (e.g. natural disasters, human error), or intentional (e.g. cyber-attacks by hackers).

Good cyber-security can be achieved with a range of measures, such as closing down vulnerability loopholes, implementing adequate security processes and procedures and providing technology to help achieve this.

Examples of vulnerabilities are:

- Indiscretions by personnel (users keep passwords on their computer)
- Bad practice (users do not change default passwords, or everyone uses the same password to access all substation equipment)
- Bypassing of controls (users turn off security measures)
- Inadequate technology (substation is not firewalled)

Examples of availability issues are:

- Equipment overload, resulting in reduced or no performance
- Expiry of a certificate preventing access to equipment

To help tackle these issues, standards organisations have produced various standards. Compliance with these standards significantly reduces the threats associated with lack of cyber-security.

## 18.3 STANDARDS

There are several standards, which apply to substation cyber-security. The standards currently applicable to GE Vernova's IED's are NERC and IEEE1686.

Standard	Country	Description
NERC CIP (North American Electric Reliability Corporation)	USA	Framework for the protection of the grid critical Cyber Assets
BDEW (German Association of Energy and Water Industries)	Germany	Requirements for Secure Control and Telecommunication Systems
ANSI ISA 99	USA	ICS oriented then Relevant for EPU completing existing standard and identifying new topics such as patch management
IEEE 1686	International	International Standard for substation IED cyber-security capabilities
IEC 62351	International	Power system data and Comm. protocol
ISO/IEC 27002	International	Framework for the protection of the grid critical Cyber Assets
NIST SP800-53 (National Institute of Standards and Technology)	USA	Complete framework for SCADA SP800-82and ICS cyber-security
CPNI Guidelines (Centre for the Protection of National Infrastructure)	UK	Clear and valuable good practices for Process Control and SCADA security

### 18.3.1 NERC COMPLIANCE

The North American Electric Reliability Corporation (NERC) created a set of standards for the protection of critical infrastructure. These are known as the CIP standards (Critical Infrastructure Protection). These were introduced to ensure the protection of 'Critical Cyber Assets', which control or have an influence on the reliability of North America's electricity generation and distribution systems.

These standards have been compulsory in the USA for several years now. Compliance auditing started in June 2007, and utilities face extremely heavy fines for non-compliance.

#### NERC CIP standards

CIP Standard	Description
CIP-002-1 Critical Cyber Assets	Define and document the Critical Assets and the Critical Cyber Assets
CIP-003-1 Security Management Controls	Define and document the Security Management Controls required to protect the Critical Cyber Assets
CIP-004-1 Personnel and Training	Define and Document Personnel handling and training required protecting Critical Cyber Assets
CIP-005-1 Electronic Security	Define and document logical security perimeters where Critical Cyber Assets reside. Define and document measures to control access points and monitor electronic access
CIP-006-1 Physical Security	Define and document Physical Security Perimeters within which Critical Cyber Assets reside
CIP-007-1 Systems Security Management	Define and document system test procedures, account and password management, security patch management, system vulnerability, system logging, change control and configuration required for all Critical Cyber Assets
CIP-008-1 Incident Reporting and Response Planning	Define and document procedures necessary when Cyber-security Incidents relating to Critical Cyber Assets are identified

CIP Standard	Description
CIP-009-1 Recovery Plans	Define and document Recovery plans for Critical Cyber Assets

### 18.3.1.1 CIP 002

CIP 002 concerns itself with the identification of:

- Critical assets, such as overhead lines and transformers
- Critical cyber assets, such as IEDs that use routable protocols to communicate outside or inside the Electronic Security Perimeter; or are accessible by dial-up

Power Utility Responsibilities	GE Vernova's Contribution
Create the list of the assets	We can help the power utilities to create this asset register automatically. We can provide audits to list the Cyber assets

### 18.3.1.2 CIP 003

CIP 003 requires the implementation of a cyber-security policy, with associated documentation, which demonstrates the management's commitment and ability to secure its Critical Cyber Assets.

The standard also requires change control practices whereby all entity or vendor-related changes to hardware and software components are documented and maintained.

Power Utility Responsibilities	GE Vernova's Contribution
To create a cyber-security policy	We can help the power utilities to have access control to its critical assets by providing centralized Access control. We can help the customer with its change control by providing a section in the documentation where it describes changes affecting the hardware and software.

### 18.3.1.3 CIP 004

CIP 004 requires that personnel with authorized cyber access or authorized physical access to Critical Cyber Assets, (including contractors and service vendors), have an appropriate level of training.

Power Utility Responsibilities	GE Vernova's Contribution
To provide appropriate training of its personnel	We can provide cyber-security training

### 18.3.1.4 CIP 005

CIP 005 requires the establishment of an Electronic Security Perimeter (ESP), which provides:

- The disabling of ports and services that are not required
- Permanent monitoring and access to logs (24x7x365)
- Vulnerability Assessments (yearly at a minimum)
- Documentation of Network Changes

Power Utility Responsibilities	GE Vernova's Contribution
To monitor access to the ESP To perform the vulnerability assessments To document network changes	To disable all ports not used in the IED To monitor and record all access to the IED

### 18.3.1.5 CIP 006

CIP 006 states that Physical Security controls, providing perimeter monitoring and logging along with robust access controls, must be implemented and documented. All cyber assets used for Physical Security are considered critical and should be treated as such:

Power Utility Responsibilities	GE Vernova's Contribution
Provide physical security controls and perimeter monitoring Ensure that people who have access to critical cyber assets don't have criminal records	GE Vernova cannot provide additional help with this aspect

### 18.3.1.6 CIP 007

CIP 007 covers the following points:

- Test procedures
- Ports and services
- Security patch management
- Antivirus
- Account management
- Monitoring
- An annual vulnerability assessment should be performed

Power Utility Responsibilities	GE Vernova's Contribution
To provide an incident response team and have appropriate processes in place	Test procedures, we can provide advice and help on testing Ports and services, our devices can disable unused ports and services Security patch management, we can provide assistance Antivirus, we can provide advise and assistance Account management, we can provide advice and assistance Monitoring, our equipment monitors and logs access

### 18.3.1.7 CIP 008

CIP 008 requires that an incident response plan be developed, including the definition of an incident response team, their responsibilities and associated procedures.

Power Utility Responsibilities	GE Vernova's Contribution
To provide an incident response team and have appropriate processes in place.	GE Vernova cannot provide additional help with this aspect.

### 18.3.1.8 CIP 009

CIP 009 states that a disaster recovery plan should be created and tested with annual drills.

Power Utility Responsibilities	GE Vernova's Contribution
To implement a recovery plan	To provide guidelines on recovery plans and backup/restore documentation

## 18.3.2 IEEE 1686-2013

IEEE 1686-2013 is an IEEE Standard for substation IEDs' cyber-security capabilities. It proposes practical and achievable mechanisms to achieve secure operations.



The following features described in this standard apply:

- Passwords are 8 characters long and can contain upper-case, lower-case, numeric and special characters.
- Passwords are never displayed or transmitted to a user.
- IED functions and features are assigned to different password levels. The assignment is fixed.
- The audit trail is recorded, listing events in the order in which they occur, held in a circular buffer.
- Records contain all defined fields from the standard and record all defined function event types where the function is supported.
- No password defeat mechanism exists. Instead a secure recovery password scheme is implemented.
- Unused ports (physical and logical) may be disabled.

### 18.3.3 IEC 62351

IEC 62351 is a standard developed for handling the security of IEC TC 57 series of protocols including IEC 60870-5 series, IEC 60870-6 series, IEC 61850 series, IEC 61970 series & IEC 61968 series. The different security objectives include authentication of data transfer through digital signatures, ensuring only authenticated access, prevention of eavesdropping, prevention of playback and spoofing, and intrusion detection.

The Roles described in chapter 62351-8 apply. The table below shows predefined roles, IDs and permissions assignment according to it:

VALUE	ROLE NAME (REVISION =1)	PERMISSION									
		LISTOBJECTS	READVALUES (READ)	DATASET	REPORTING	FILEREAD	FILEMNGT	CONTROL	CONFIG	SETTINGGROUP	SECURITY
<0>	VIEWER	x	C	x	C <sub>1</sub>						
<1>	OPERATOR	x	x	x	C <sub>1</sub>			x		x	
<2>	ENGINEER	x	x	x	X <sub>1</sub>	X <sub>1</sub>	X <sub>1</sub>		x	x	
<3>	INSTALLER	x	x	x	X <sub>2</sub>	X <sub>2</sub>			x	x	
<4>	SECADM	x	x		X <sub>4</sub>	X <sub>4</sub>	X <sub>4</sub>		x		x
<5>	SECAUD	x	x	x	X <sub>1</sub>						
<6>	RBACMNT	x	x				X <sub>4</sub>		x		
<7> (*1)	ADMINISTRATOR	x	x	x	x	x	x	x	x	x	x
<7, ..., 32767>	RESERVED	For future use of IEC defined roles.									
<-32768, ..., -1>	PRIVATE	Defined by external agreement. Not guaranteed to be interoperable.									

VALUE	ROLE NAME (REVISION =1)	PERMISSION									
		LISTOBJECTS	READVALUES (READ)	DATASET	REPORTING	FILEREAD	FILEMNGT	CONTROL	CONFIG	SETTINGGROUP	SECURITY

C = Conditional read access, clarification of specific data objects might be necessary (e.g., VIEWER may not access security settings, but process values)

C<sub>1</sub> = Conditional read access to files or filetype data

X<sub>1</sub> = Access to files of type data and config

X<sub>2</sub> = Access to files of type config and firmware (updates)

X<sub>3</sub> = Access to files of type audit log

X<sub>4</sub> = Access to files of type security (config)

(\*1) ADMINISTRATOR is a LEGACY predefined role containing full permissions assignment. The ADMINISTRATOR is a pre-configured role using the <7> first available IEC RESERVED role. The role ID value is configurable in EnerVista for all roles (but the first 6 currently fixed by the standard), so the user can change the ID to another value if needed (from 7 till 32767 and from -1 till -32768).

### Permissions Definition

As there is not enough granularity in the permissions to accomplish all the filters and assignments to the different roles, some new permissions have been added to the ones predefined by the standard, e.g. to differentiate the FILEMNGM, the FW Upgrade, etc.

Below is the list of permissions implemented:

Permission ID	Name	Comment
1	LISTOBJECTS	View settings names/traverse settings (except security settings)
2	READVALUES	View non security settings values, view PSL, view 61850
3	DATASET	Configure and edit 61850
4	REPORTING	View status, metering
5	FILEREAD	Read configuration file, read events reports, read waveforms reports, read fault reports, read disturbance records
6	FILEWRITE	Write configuration file, create/edit configuration project, import SCL
7	FILEMNGT	Clear records, restore defaults, export SCL, delete configuration project
8	CONTROL	Command Breaker, Reset
9	CONFIG	View non security settings, edit/configure all non-security settings, configure and Edit 61850, save settings
10	SETTINGGROUP	View non security settings, modify group control settings
11	SECURITY	View and modify security settings view, configure security, modify users and rbac
12 (*)	FILEREAD_SEC	Read sec audit log
13 (*)	FILEMNGT_SEC	Access to files of type security (config)
14 (*)	FWUPGRADE	Firmware upgrade

**Note:**

(\* ID's 1 to 11 are the set of permissions predefined by the standard, available for all device firmware releases. ID's 12 to 14 are new customized permissions added, available from 08A release on.

With this permissions definition the roles are defined as follow:

**Legacy Roles (Basic Security)**

ID	Role	Permissions
0	VIEWER	1, 2, 4, 5
1	ADMINISTRATOR	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14
2	ENGINEER	1, 2, 3, 4, 5, 6, 7, 8, 9, 10
3	OPERATOR	1, 2, 4, 5, 8, 10

**Standard Roles (Advanced Security):**

ID	Role	Permissions
0 (*1)	VIEWER	1, 2, 4, 5
1 (*1)	OPERATOR	1, 2, 4, 5, 8, 10
2 (*1)	ENGINEER	1, 2, 3, 4, 5, 6, 7, 9, 10
3 (*1)	INSTALLER	1, 2, 4, 5, 6, 9, 10, 14
4 (*1)	SECADM	1, 2, 3, 5, 6, 9, 11, 13
5 (*1)	SECAUD	1, 2, 4, 12
6 (*1)	RBACMNT	1, 2, 9, 13
7 (*2)	ADMINISTRATOR	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14

**Note:**

(\*1) Role defined by the standard.

**Note:**

(\*2) ADMINISTRATOR is a predefined role containing full permissions assignment. The ADMINISTRATOR role is pre-configured for MAgile release 08A onwards using the <7> first available IEC RESERVED role.

MAgile has two Cyber-Security options available in the Cortec.

Basic Security where there are 4 fixed roles/users: Administrator, Engineer, Operator and Viewer.

**Administrator:** Has all the permissions to perform a firmware upgrade, change of parameters, change of security settings, CID read/write, read data files, issue commands, and read all the values from the device.

**Engineer:** Change of parameters, CID read/write, read data files, issue commands, and read values from the device.

**Operator:** Issue commands and read values of the device.

**Viewer:** This user can only read values from the device.

In Advanced Security the device has up to 20 configurable users. Each user will have a configurable username and password, and it could select one role from the standard and new user defined roles. As stated in the standard, there is the possibility to redefine new roles, adjusting the name, ID and permissions for each new defined role. There is no possibility of role combination.

For more detailed information of users and rights/permission definition see the list below:

#### **User/Role Definition:**

**VIEWER (\*1):** Can view what objects are present within a Logical-Device by presenting the type ID of those objects.

**OPERATOR (\*1):** An operator can view what objects and values are present within a Logical Device by presenting the type ID of those objects as well as perform control actions.

**ENGINEER (\*1):** An engineer can view what objects and values are present within a Logical Device by presenting the type ID of those objects. Moreover, an engineer has full access to DataSets and Files and can configure the server locally or remotely.

**INSTALLER (\*2):** An installer can view what objects and values are present within a Logical Device by presenting the type ID of those objects. Moreover, an installer can write files and can configure the server locally or remotely.

**SECADM (\*2):** Security administrator can change subject-to-role assignments (outside the device) and role-to-right assignment (inside the device) and validity periods; change security setting such as certificates for subject authentication and access token verification.

**SECAUD (\*2):** Security auditor can view audit logs.

**RBACMNT (\*2):** RBAC management can change role-to-right assignment.

**ADMINISTRATOR (\*1):** Has All read/write access.

**RESERVED (\*2):** This user/role can be defined by the user adjusting name, ID and permissions for each new defining role.

*Note:*

(\*1) Roles applying to both Basic and Advanced Cyber-Security.

*Note:*

(\*2) Roles only applying to Advanced Cyber-Security.

#### **Rights/Permissions Definition:**

- **VIEW/LISTOBJECTS (\*1):** Allows the subject/role to discover what objects are present within a Logical Device by presenting the type ID of those objects.
- **READ/READVALUES (\*1):** Allows the subject/role to obtain all or some of the values in addition to the type and ID of objects that are present within a Logical-Device.
- **DATASET (\*1):** Allows the subject/role to have full management rights for both permanent and non-permanent DataSets.
- **REPORTING (\*1):** Allows a subject/role to use buffered reporting as well as un-buffered reporting.
- **FILEREAD (\*1):** Allows the subject/role to have read rights for file objects.
- **FILEWRITE (\*1):** Allows the subject/role to have write rights for file objects. This right includes the FILEREAD right.
- **FILEMNGT (\*1):** Allows the role to transfer files to the Logical-Device, as well as delete existing files on the Logical- Device.
- **CONTROL (\*1):** Allows a subject to perform control operations.
- **CONFIG (\*1):** Allows a subject to locally or remotely configure certain aspects of the server.
- **SETTINGGROUP (\*1):** Allows a subject to remotely configure Settings Groups.

- **SECURITY (\*1)**: Allows a subject/role to perform security functions at both a Server/Service Access Point and Logical-Device basis.
- **FILEREAD\_SEC (\*2)**: Allows a subject/role to read sec audit log.
- **FILEMNGT\_SEC (\*2)**: Allows a subject/role to access to files of type security (config).
- **FWUPGRADE (\*2)**: Allows a subject/role to perform firmware upgrade.

*Note:*

*(\*1) Standard defined permissions. Available for all device firmware releases.*


*Note:*

*(\*2) New customized permissions added. Available from 08A release on.*

## 18.4 CYBER-SECURITY IMPLEMENTATION

GE Vernova's IED's have always been and will continue to be equipped with state-of-the-art security measures. Due to the ever-evolving communication technology and new threats to security, this requirement is not static. Hardware and software security measures are continuously being developed and implemented to mitigate the associated threats and risks.

This section describes the current implementation of cyber-security. The bulk of the implementation consists of RBAC (Role Based Access Control) Cyber-security mode, Centralised Authentication, Remote Logging and System Hardening. The features are compliant with NERC-CIPv6 and IEEE 1686. This is valid for the release of platform software to which this manual pertains.



**Figure 168: Cyber security implementation**

Two levels of Cyber-security are available as ordering options for the Multilin Agile IEDs:

- Basic Cyber-security
- Advanced Cyber-security

Basic Cyber-security includes the following security features:

- Device/Local Authentication
- Four-level access: Fixed local users and roles (Administrator, Engineer, Operator, Viewer)
- ByPass Access
- Password complexity
- Disabling of unused physical and logical ports
- Flag for Failed authentication
- User lockout for configurable period
- Inactivity time out

Advanced security includes additional security features as follows:

- Remote/Server Authentication (supports RADIUS and Legacy LDAP)
- Local authentication with up to 20 configurable users, with configurable roles, username and passwords
- Secure encrypted communication (Modbus/SSH, SFTP)
- Syslog
- Increased product hardening

### 18.4.1 RBAC FUNCTIONALITY

Role based access control, RBAC, is the core of session management. Every login attempt will connect to the RBAC service and it will allow or deny the login of the user.

In Basic Security, default connection is done as Viewer, without password requirement.

In case of Advanced Security, a username and password will be required. If the login is successful, the access level will correspond to the role defined to this user.

The user cannot change its own role. So, in case of more rights needed, another different user with the corresponding role should be logged in.

The maximum number of concurrent sessions is only one for all roles, except of Viewer role, which has the limit of 5 sessions.

There is a session timeout adjustable by settings. This timeout means that open sessions are automatically closed if they remain inactive till the timer elapses. This inactivity timer defines the period that IED waits in idleness before a logged in user will be automatically logged out. This timeout is different for HMI interface and other interfaces (Serial, Ethernet, etc).

There is a lockout period adjustable by settings. For each account, when a maximum number of failed login attempts is reached, it is locked during the specified period. It doesn't matter the interface the login comes from. The account will be unlocked at the first successful login passed the lockout period.

If the Authentication Method setting is changed, the logged in user will be forced to logout.

---

## 18.4.2 BASIC SECURITY IMPLEMENTATION

### 18.4.2.1 DEVICE/LOCAL AUTHENTICATION

In Device Authentication mode, IED provide local RBAC Server security. The IED supports unique device usernames, and stores device passwords securely. For password encryption, PBKDF2 with SHA256 and a unique 64bits salt per user is used.

Only Administrator can change other user's passwords. All device users can change their own passwords. For password reset/recovery procedure the Administrator role will be required.

Viewer access level has no password associated and is the default connection to the device. Default password for Administrator, Engineer and Operator access levels is 0.

### 18.4.2.2 FOUR-LEVEL ACCESS

Basic IED Security supports 4 fixed roles: Administrator, Engineer, Operator and Viewer. The fixed local usernames match with these roles.

All the roles are password protected except the Viewer. A Viewer connection is directly logged in without entering a password using front panel or any communication port.

The different features of each role or access level are shown in the table below, for Basic Security (Legacy):

Feature		Administrator	Engineer	Operator	Viewer
<b>Settings</b>	Security settings	RW	R	R	R
	Change own PW	Yes	Yes	Yes	X
	Change own PW (Advanced security)	Yes	Yes	Yes	Yes
	Create New/Modify users, assign roles (advanced security OC)	RW	X	X	X
	Non-Security settings	RW	RW	R	R
	FlexLogic	RW	RW	R	R
	IEC 61850 settings	RW	RW	R	R
	Factory Settings	X	X	X	X
<b>Commands</b>	Date change	RW	RW	X	X
	BKR related	RW	RW	RW	X
	Clear records	RW	X	X	X
	Restore Defaults	RW	X	X	X
	RESET	W	W	W	X
<b>File</b>	Config File read	R	R	R	R
	Config File write	W	W	X	X
<b>Firmware Upgrade</b>		W	X	X	X
<b>Upload FW</b>		W	X	X	X
<b>Actual Values</b>	Status	R	R	R	R
	Metering	R	R	R	R
<b>Reports</b>	Events	R	R	R	R
	Waveforms	R	R	R	R
	Security Audit log	R	R	X	X

### 18.4.2.3 BYPASS ACCESS

The 'Bypass Access' feature allows to bypass security authentication. Once this setting is other than 'Disabled', then user gets Administrator access rights on configured interface. For example, if user configures it as 'Local' then no user authentication is needed for accessing over USB or HMI. Other possible option is to bypass authentication for 'HMI only' where user can view and modify all the settings, view actual values or execute commands. The bypass security feature provides an easier access, with no authentication and encryption. Therefore, the use of this feature should be restricted only in commissioning phase or when it is considered safe. Only the Administrator, can enable this feature.



#### 18.4.2.4 ENHANCED PASSWORD SECURITY

When Password complexity setpoint is set to 'Enabled', it allows user to configure password strings which adhere to complexity rules defined below. When the setting is configured as 'Disabled' then user can change the password to any string with max length of 20 characters.

Password complexity has the following features:

- Passwords cannot contain the user's account name or parts of the user's full name that exceed two consecutive characters.
- Must be at least 8 characters in length. Max length can be 20 ASCII char
- Passwords must contain characters from all four categories:
  - English uppercase characters (A through Z).
  - English lowercase characters (a through z).
  - Numeric: Base 10 digits (0 through 9).
  - Special non-alphanumeric (such as @,!,#,{, but not limited to only those, etc.)

The IED supports encryption for passwords. The encryption algorithm used is PBKDF2 with SHA256 and a unique 64bits salt per user, where this salt is generated randomly.

#### 18.4.2.5 DISABLING PHYSICAL AND LOGICAL PORTS

To secure your system it is advised to harden the product (product hardening) by disabling the unused protocols and physical ports. This is the simplest method to ensure lesser security risk. The IED offers possibility to enable or disable protocols / ports based on the usage.

The IED supports the ability to turn off any of the following specific physical ports:

- front USB serial port
- rear port RS485
- Ethernet port

The IED supports the ability to turn off any of the following specific communication protocols:

- IEC 61850 (MMS and GOOSE)
- Modbus RTU
- Modbus TCP
- DNP3oE
- DNP3 Serial
- IEC 60870-5-103
- TFTP

Time synchronization protocols can be selectively enabled/disabled based on the configuration.

- IRIG-B
- SNTP

Services	Port Type	Port Numbers
Modbus TCP	TCP	502
DNP3oE	TCP	20000
	UDP	20000
IEC 61850 (MMS)	TCP	102
TFTP	UDP	69

Services	Port Type	Port Numbers
SFTP (SSH)	TCP	22

**Note:**

For data protocols, service availability and detailed information, refer to the Communication Interfaces section in the Communications chapter.

### 18.4.2.6 NON-ENCRYPTED/CLEAR TEXT MODBUS

Due to customers' requests to use 'plain' or 'non-encrypted' Modbus communication with SCADA applications for certain scenarios, the Modbus TCP setting under the **DEVICE\COMMUNICATIONS\MODBUS** path supports the following options:

Disabled: when the **Modbus TCP** setting is set to Disabled, the port 502 will be closed.

Enabled: when the **Modbus TCP** setting is set to Enabled, the legitimate user can read or write over plain Modbus using port 502 on successful authentication.

Read-Only (\*): when the **Modbus TCP** setting is set to Read-Only, the legitimate user can only read over plain Modbus using port 502.

By default, the **Modbus TCP** Setting is set to Enabled.

User with 'Administrator' role can configure this setting. Once the setting is configured to other than Disabled, the IED will allow communication with a 3rd party SCADA application in plain text Modbus over port 502. Also, for configuration change, the Multilin Agile IED will register a security event to identify the user.

**Note:**

EnerVista Configuration software will always communicate with the IED over SSH using port 22.

**Note:**

(\*) Read-Only option only available for Basic Cybersecurity Cortec options. Advanced Cybersecurity will have just Disabled and Enabled options.

### 18.4.2.7 SECURITY EVENTS

Security Events can be displayed in EnerVista Configuration software at RECORDS\SECURITY EVENTS path.

'securelog.csv' file stores security events information. A total of minimum 1024 events are stored in a circular buffer in non-volatile memory. Once the file reaches its max limit, oldest event Will get over-written by newest security event.

The security events information supported & stored in events file for each event contains: Priority, Version, Timestamp, Host, Process Name, Message Id, IEC@41912 ID, Text and UsrID.

The timestamp is the UTC time.

This file will be stored on the IED and will be accessible from EnerVista Configuration software for user with "Administrator" role. For Basic security, this is the only file to give security audit information to user. And this file will be useful for advanced security user if in case syslog is not configured or non-functional due to some issue.

**Note:**

For 8A firmware release, the security events can be visualized at RECORDS\SECURITY EVENTS path. Security Events files (securelog) are available for download, in "csv" and "txt" format, from the Service Report zip file that can be downloaded from the Online Window of the EnerVista Configuration software, clicking on the last icon from the right, called "Service Report".

### 18.4.3 ADVANCED CYBER-SECURITY IMPLEMENTATION

In advanced cybersecurity device authentication, all users: Viewer, Administrator, Engineer and Operator, need to enter username as well as password to get access privileges. Default advanced cybersecurity password is ChangeMe1#.

**For firmware releases prior to 08A:** The Advance Cyber-security was built on top of Basic Cyber-security, providing Basic Cyber-security options plus extra properties for Advance Cyber-Security that were not available in Basic Cyber-Security.

**For firmware releases 08A onwards:** Basic Cyber-Security is a legacy implementation matching Basic Cyber-Security implementation of releases 06A and prior. Advance Cyber-security is a separate cyber-security implementation fully configurable following the IEC 62351-8 standard.

#### 18.4.3.1 PERMISSIONS VS ACCESS MATRIX/PERMISSION ASSIGNMENT

In Basic (legacy) security the access is managed with a matrix table based on roles (see Four-level Access in Basic Security Implementation section).

In Advanced Security the access is managed through permission set. The following table shows the different features managed by EnerVista Configuration software, and the permissions that the user shall have in order to write or read values in the different screens:

Feature		Write Permissions ID	Read Permission ID
<b>Settings</b>	Security settings	11+13	11+13
	Change own PW	Current User	N.A.
	Change all PW	13	13
	Create new/modify users, assign roles (advanced security)	13	13
	Non-security settings	9	2
	Flexlogic	9	2
	IEC 61850 settings	3	2
	Settings group	10	2
<b>Commands</b>	Data change	9	N.A.
	BKR related	8	N.A.
	Clear records	7	N.A.
	Restore defaults	7	N.A.
	RESET	8	N.A.
<b>File Operations</b>	Config file	6	5
<b>Firmware Upgrade</b>	Firmware upgrade	14	N.A.
<b>Actual Values</b>	Status	N.A.	2
	Metering	N.A.	2
<b>Reports</b>	Events	N.A.	5
	Waveforms	N.A.	5
	Security audit logs	N.A.	12

Note:

For permissions definition see Permission Definition table in IEC 62351 section.

### 18.4.3.2 SERVER/REMOTE AUTHENTICATION

The Server/Remote Authentication implementation in MAgile varies between releases prior to 08A, and releases from 08A onwards.

**For firmware releases prior to 08A:** The Server Authentication Mode **uses only RADIUS**.

Where the following RADIUS servers can be set as customer's central authentication server:

- FreeRADIUS server
- Microsoft NPS server
- RSA Authentication Manager

And where the RADIUS implementation supports the following authentication protocols:

- PEAPv0 with inner authentication method MS-CHAPv2 (To support Microsoft NPS server)
- EAP-TTLS with inner authentication method PAP (To support RSA AM)
- EAP with inner authentication method GTC (To support RSA AM)
- PAP (unsecured, to support any RADIUS server)

**For firmware releases 08A and later:** The Server Authentication Mode can use either **RADIUS** or **LDAP** where:

#### **RADIUS:**

Servers used as a central authentication server can be:

- FreeRADIUS server
- RSA Authentication Manager

Implementation supports the authentication protocols:

- PEAPv0 with inner authentication method MS-CHAPv2
- EAP-TTLS with inner authentication method PAP (To support RSA AM)
- PAP (unsecured, to support any RADIUS server)

#### **LDAP:**

Servers used as a central authentication server can be:

- Microsoft Active Directory server
- OpenLDAP

Implementation supports the authentication protocols:

- TCP
- STARTTLS

### 18.4.3.3 SERVER/REMOTE AUTHENTICATION (RADIUS)


In Server Authentication mode, the IED authenticates the user using RADIUS server. RADIUS client resides in the product and connects to the RADIUS server.

Customer can use any of the following RADIUS servers as their central authentication server

- FreeRADIUS server
- RSA Authentication Manager

RADIUS users and passwords are created in the server (in the Active Directory). Each RADIUS user should have a password (that meets the password policy of the Active Directory) and specific role assigned to in the Active Directory.

Multilin Agile supports 2 servers in the configuration for redundancy. The IED will try each in sequence until one respond. When the first RADIUS server is unavailable, the next server in the list is tried for RADIUS Authentication.



**Figure 169: RADIUS server/client communication**

The IED will first try the server 1 up to the configured number of retries leaving request timeout between each request. After this point, if it still does not have a valid answer from server 1, it switches to server 2 and repeats for up to the number of configured retries again. If it maxes out on retries on the second server, it gives up entirely on Server Authentication and fallback to device authentication (Only if Authentication Method Server and Device is selected). A "RADIUS Server unavailable" security event is also logged under this condition.

IED will authenticate and authorize RADIUS users using the following authentication stack:

- Primary Radius if enabled (stop on invalid credential failure, continue all other failures)
- Secondary Radius if enabled (stop on invalid credential failure, continue all other failures) The RADIUS implementation supports the following authentication protocols:
  - PEAPv0 with inner authentication method MS-CHAPv2 (To support Microsoft NPS server)
  - EAP-TTLS with inner authentication method PAP (To support RSA AM)
  - PAP (unsecured, to support any RADIUS server)

The RADIUS implementation will query the Role ID vendor attribute and establish the logged in user security context with that role.

In case of Server Authentication mode but if the RADIUS server is not operational, IED will try Device Authentication.

**Note:**

For release 8A and later, the default security settings are different to releases 6A and prior, (e.g., RADIUS Port Prim and Sec settings in 8A release are 2083, whereas in 6A they are 1812). Check the 8A default values set in your device and update them to the value needed for your security configuration.

- 

#### 18.4.3.4 SERVER/REMOTE AUTHENTICATION (LEGACY LDAP PULL MODEL)

Multilin Agile supports Legacy LDAP Pull Model. The PULL model with LDAP is explained in the IEC 62351-8 section.

In legacy projects with an LDAP repository (e.g., Windows Active Directory), RBAC information is limited to roles, and they are returned in a simple LDAP response after successful authentication of the user. Multilin Agile implements this legacy usage of LDAP.

### RBAC and Legacy LDAP

In the RBAC model, users are assigned to roles through which they acquire permissions. A mapping between these generic permissions and device-specific actions is used to determine if a user has the right to perform a given action on a resource (object).

The RBAC data that changes more frequently is stored outside the device in an identity provider repository which is the LDAP server in this case. This data includes user credentials, roles and associations between users and roles.

The table below explains the RBAC data versus LDAP data representation:

RBAC Data	LDAP Data
subject (user)	user
password	password
role	group
role-user association	membership (of a user in a group)

### Communication Protocols

Multilin Agile implementation of LDAP supports two protocols: TCP and TCP over TLS, and For TCP over TLS supports STARTTLS.

TLSv 1.2 and above are supported. TLS versions below 1.2 are not supported.


### LDAP Query and Access Token

For an already authenticated user, LDAP returns a token containing IEC 62351-8 groups that the user is a member of upon request (LDAP search request).

For better performance (faster queries) and to forge the correct LDAP query, the following input is required:

- **users OU:** The organizational unit where users reside. It is assumed that even in an existing LDAP server like Active Directory with a large number of users, users all reside in the same organizational unit.
- **roles OU:** The organizational unit where groups reside. Again, it is assumed that roles reside in one OU dedicated to this purpose.
- **base DN:** Ideally the nearest node to the above OUs that is also a direct or indirect parent of both. In fact, this value is used to limit the search area for user-group memberships. Consequently, both users and roles OU must be part of this domain.

The following figure shows an example LDAP tree:



**Figure 170: LDAP tree example**

For the data structure shown above, the following shall be provided:

- **user OU:** ou=DSusers,ou=DSAgile,dc=example, dc=com
- **roles OU:** ou=DSroles,ou=DSAgile,dc=example, dc=om
- **based DN:** ou=DSAgile,dc=example,dc=com

*Note:*

For the base DN, we can also provide dc=example, dc=com but it will result in lower performance as the search area will be expanded unnecessarily.

*Note:*

In EnerVista configuration software user DN, roles DN and Based DN are to be provided for LDAP configuration. DN provided the full path, where OU provides the local path.

## Configuration

The LDAP client in the device is configured using the "RBAC UserManagement" configuration tool embedded in the EnerVista configuration tool. For more information See LDAP configuration in the EnerVista configuration tool chapter.

## Main and Backup Servers

Up to two LDAP servers can be defined. They will be called main and backup servers respectively. The main server is mandatory, and the backup server is optional.

At initialization, the main server is set as the working server.

If the main server becomes unavailable:

- The backup server is set as the working server.
- When the main server is up again, it will become the working server always taking precedence over the backup server.
- If the backup server also becomes inaccessible, the device will switch to local fallback mode.
- When the backup server is up again, it will become the working server and it will switch back to the remote mode, e.g. Legacy LDAP.

#### Summary:

- The main server always takes precedence over the backup server.
- Local fallback happens only when both servers are down.

#### An LDAP server can be considered down for a variety of reasons such as:

- It cannot be reached due to network issues or hardware issues.
- A secure TLS tunnel cannot be established due to a certificate issue, e.g., missing, invalid or revoked certificate, when communication protocol is set to StartTLS.

---

### 18.4.4 UNIQUE CONFIGURABLE USERNAMES

In 'Advanced Security', the user can configure up to 20 configurable user accounts. As part of this, user can configure a Username (length can be up to 20 ASCII char), Password for the username (in compliance with the Password complexity) and assign a supported user role (range: Administrator, Engineer, Operator, Viewer, any other role configured by the user).

The 'Administrator' is eligible to configure various accounts and modify passwords for all available accounts. Non-Admin users can only modify their own account password.

It is recommended to have more than one 'Administrator' account.

---

### 18.4.5 SECURE ENCRYPTED COMMUNICATION

#### 18.4.5.1 MODBUS/SSH

Secure Shell (SSH) protocol provides a secure channel over an unsecured network by using a client-server architecture. The SSH server reside in the IED. It securely encrypts the Modbus commands and data between the Toolsuite and itself using port forwarding.

SSH architecture is described in RFC4251 and is composed of three components:

- The transport Layer protocol (SSH-TRANS) – RFC 4253
- The User Authentication Protocol (SSH-USERAUTH) – RFC 4252
- The Connection Protocol (SSH-CONNECT) – RFC 4254

The port forwarding feature is available only on TCP/IP frames. UDP is not supported. The SSH server on the product runs on port 22.

It supports the Encryption Ciphers: RSA 2048, AES-128-CBC or AES-128-GCM, HMAC-SHA-256.

The SSH server has a timeout for authentication and disconnect if the authentication has not been accepted within the timeout period.

#### 18.4.5.2 SFTP

SFTP (SSH File Transfer Protocol) is the file transfer protocol used with SSHv2. Provides secure file access, file transfer, and file management.



The SFTP commands will be limited for a given period of time to avoid DOS attacks and also implement role-based access to the file.

### 18.4.6 SYSLOG

The IED supports security event reporting through the Syslog protocol for supporting Security Information Event Management (SIEM) systems for centralized cyber security Monitoring over UDP and TCP protocols.




Figure 171: Syslog implementation

2 Syslog servers are supported in the configuration for redundancy. The IED will try each in sequence until one respond.

The IED logs to a remote syslog server:

- User log events, whether successful or unsuccessful
- Error log events
- Kernel error log events

### Syslog Events

Mnemonic	LogType	IEC version	Severity	Cyber Security Event Numerical Event Identifier (ID)	Text (Single Space Between Each Consecutive Words)	Reference and Comments
LOGIN_OK	IEC 62351-14	1	notice	IEC 62351-14:1	Log-in successful	[IEEE 1686] specifies event logging for user successful login. In general, [IEC 62443-4-2] requires audit logs for access control.
LOGIN_OK_PW_EXPIRED	IEC 62351-14	1	notice	IEC 62351-14:2	Password expired, Log-in successful	[NERC-CIP-007-5] requires security policy. In case the entity local security policy allows a user to still login, the course of its password expiry such as for handling a critical emergency situation, then this event would be useful. In general, [IEC 62443-4-2] requires audit logs for access control.
LOGIN_FAIL_WRONG_CR	IEC 62351-14	1	notice	IEC 62351-14:3	Log-in failed - wrong credentials	[NERC-CIP-007-5] requires cyber security respective logging for both successful and failed user logins. In general, [IEC 62443-4-2] requires audit logs for access control.
LOGIN_FAIL_3_TIMES	IEC 62351-14	1	alarm	IEC 62351-14:5	Log-in failed 3 times	[IEEE 1686] Although [IEEE 1686] mentions to log an event after 3 unsuccessful access attempts, the earlier this anomaly is logged the better cyber secured an entity can be.

Mnemonic	LogType	IEC version	Severity	Cyber Security Event Numerical Event Identifier (ID)	Text (Single Space Between Each Consecutive Words)	Reference and Comments
LOGIN_FAIL_SESSIONS_LIMIT	IEC 62351-14	1	alarm	IEC 62351-14:6	Log-in failed too many user sessions	[IEEE 1686] [NERC-CIP-007-5] requires cyber security respective logging for both successful and failed user logins. In general, [IEC 62443-4-2] requires audit logs for access control.
LOCK_USER_WRONG_CR	IEC 62351-14	1	alarm	IEC 62351-14:7	User locked - wrong credentials	[NERC-CIP-007-6] recommends limiting the number of unsuccessful access attempts and suggests measures for account lockout. In case the entity local security policy restricts its access to a user for a certain duration of time due to repeated certain failed number of logins attempts from that user, then it is necessary to generate a corresponding event. This type of event improves the security of an entity by reducing the brute force attack surface from an attacker.
LOGOUT_USER	IEC 62351-14	1	notice	IEC 62351-14:8	Log-out (user logged out)	[IEEE 1686] specifies event logging for user initiated log out.
LOGOUT_TIMEOUT	IEC 62351-14	1	notice	IEC 62351-14:9	Log-out by user inactivity (timeout)	[IEEE 1686] specifies event logging for user when the user is inactive after logging in for a certain duration of time.
SW_UPDATE_OK	IEC 62351-14	1	notice	IEC 62351-14:14	Software update was successful	[IEEE 1686] requires audit logging for firmware related aspects. A software is generic that also includes firmware.
SW_UPDATE_FAIL	IEC 62351-14	1	alarm	IEC 62351-14:15	Software update failed	
SYSLOG_EVENT_SETTING_CHANGE	IEC 62351-14	1	alarm	IEC 62351-14:1	Setting change	'Setting change'. An event to indicate setting change(s). Origin: Username and IP address.
SYSLOG_EVENT_CLEAR_EVENT_RECORDS	IEC 62351-14	1	notice	IEC62351-14:1	Clear events	'Clear events command'. Clear event records command was issued. Origin: Username and IP address.
SYSLOG_EVENT_CLEAR_TRANSIENT_RECORDS	IEC 62351-14	1	notice	IEC62351-14:1	Clear transient records	'Clear transient records command'. Clear transient records command was issued. Origin: Username and IP address.
SYSLOG_EVENT_MODBUSTCP_ENABLED	IEC 62351-14	1	alarm	IEC62351-14:1	Modbus TCP enabled	ModbusTCP Enabled'. Port 502 has been opened for Read/ Write.
SYSLOG_EVENT_MODBUSTCP_DISABLED	IEC 62351-14	1	alarm	IEC62351-14:1	Modbus TCP disabled	ModbusTCP Disabled'. Port 502 closed
SYSLOG_EVENT_MODBUSTCP_READONLY	IEC 62351-14	1	alarm	IEC62351-14:1	Modbus TCP read only	'ModbusTCP ReadOnly'. Port 502 has been opened for Read Only operations.
SYSLOG_EVENT_BYPASS_ACCESS_ENABLED	IEC 62351-14	1	alarm	IEC62351-14:1	ByPass access enabled	'Bypass Access activated'. Bypass access has been activated.
SYSLOG_EVENT_BYPASS_ACCESS_DISABLED	IEC 62351-14	1	alarm	IEC62351-14:1	ByPass access disabled	'Bypass Access deactivated'. Bypass access has been deactivated.
	IEC 62351-14	1	notice	IEC62351-14:1 [IEC@41912 ID="2910:6"]	Configuration update has failed	Couldn't update configuration from given file. INVALID_CONFIGURATION_XML" UsrID="Application
	IEC62351-14	1	notice	IEC62351-14:1 [IEC@41912 ID="2910:8"]	Application configuration is valid	

**Note:**

For release 8A and later, forward, clear events, clear transient records syslog events are available for the user. FlexLogic operands are not available.

For all firmware releases, bypass access disabled, and bypass access enabled syslog events are available for the user. FlexLogic operands are not available.

---

## 18.4.7 INCREASED PRODUCT HARDENING

In Advanced security, the IED supports the ability to turn off the added features in encrypted communication. SSH and SFTP protocols on port 22 can be disabled.

### 18.4.7.1 ADDITIONAL FEATURES

The Advanced security option provides the properties listed below.

---

## 18.4.8 LOST PASSWORD

Multilin Agile IEDs allow modification of all user account passwords by user with “Administrator” privileges. Also, non-Admin users can update their own passwords.

For 'Advanced Security', it is recommended to have more than one user with 'Administrator' role. This will help in case 'Administrator' password is lost. Other local 'Administrator' account or Remote authentication user 'Administrator' can modify the password for the 'Administrator' whose password is lost.

If Remote authentication server is not configured or is unreachable, and if there is a single 'Administrator' configured on IED for Local authentication, then the only way to reset 'Administrator' password is to execute 'Service command' **SETPOINTS\DEVICE\INSTALLATION** path on HMI. This action will default passwords for all accounts.

To default passwords for all accounts, access IED from HMI as another role. Go to Settings -> Product setup -> Install: Screen will have option to enter 'Service command'. User can enter the command to reset passwords for all accounts.

Please, contact GE Vernova customer support to get the code to perform this action.

---

## 18.4.9 LOADING FACTORY CONFIGURATION

User needs to login as 'Administrator'. Go to Security screen and then 'Restore Defaults' can be set to 'Yes'.

---

## 18.4.10 ADDITIONAL FEATURES

In addition to all the Basic security features, the Advanced security option provides the properties listed below.

### 18.4.10.1 LOST PASSWORD

Multilin Agile IEDs allow modification of all user account passwords by user with “Administrator” privileges. Also, non-Admin users can update their own passwords.

For 'Advanced Security', it is recommended to have more than one user with 'Administrator' role. This will help in case 'Administrator' password is lost. Other local 'Administrator' account or Remote authentication user 'Administrator' can modify the password for the 'Administrator' whose password is lost.

If Remote authentication server is not configured or is unreachable, and if there is a single 'Administrator' configured on IED for Local authentication, then the only way to reset 'Administrator' password is to execute command from HMI. This action will default passwords for all accounts.

Access IED from HMI as another role. Go to Settings -> Product setup -> Install: Screen will have option to enter 'Service command'. User can enter the command to reset passwords for all accounts.

Please, contact GE customer support to get the code and perform this action.

### 18.4.10.2 LOADING FACTORY CONFIGURATION

User needs to login as 'Administrator'. Go to Security screen and then 'Restore Defaults' can be set to 'Yes'.

## 18.5 RBAC USER MANAGEMENT CYBER-SECURITY CONFIGURATION TOOL

This section describes the "RBAC UserManagement" configuration tool used to configure cyber-security for Multilin Agile 8A release and later.

**For firmware releases prior to 08A:** The Cyber-security configuration was done fully on Modbus settings placed at **SETPOINTS\DEVICE\SECURITY** path. See the figures below for more detail.

**For firmware releases 08A and later:** The Cyber-security configuration is done partially using Modbus settings placed at **SETPOINTS\DEVICE\SECURITY** path, plus the use of the RBAC UserManagement cyber-security configuration tool through EnerVista software.

The "RBAC UserManagement" cyber-security configuration tool can be found at EnerVista configuration tool under Setpoints, this is at **SETPOINTS\RBAC USERMANAGEMENT** path. RBAC UserManagement is only accessible online when communicating with the device. The Modbus settings available at **SETPOINTS\DEVICE\SECURITY \SECURITY CONFIG** path, such as Bypass Access, Acc Timeout HMI, Pswd Complexity, Factory Service, Require PW for Reset Key, Require PW for D/T Change, Require PW for Control, are both available in the offline and online mode of EnerVista and can also be changed through the HMI menus.

*Note:*

*For release 8A and later, the default security settings are different to releases 6A and earlier.*

*Note:*

*Energivista Software configuration tool file conversion will not convert cyber-security settings from 6A to 8A. The Cyber-security settings for 8A should be entered directly on the device.*

### 18.5.1 CYBER-SECURITY MODBUS SETTINGS CONFIGURATION

For 8A the Modbus Cyber-security settings are placed at **SETPOINTS\DEVICE\SECURITY\SECURITY CONFIG** path. All Modbus settings are the same for Basic and Advanced Cyber-security, but the **Bypass PW for RC** setting is only available for Basic.

See the list of Modbus Cyber-security settings below:

Setting Name	Default Value	Basic/Advanced
Factory Service	Disabled	Disabled
Restore Defaults	No	No
Acc Timeout HMI	5 min	5 min
Pswd Complexity	Enabled	Enabled
Bypass Access	Disabled	Disabled
Require PW for Reset Key	Enabled	Enabled
Require PW for D/T Change	Enabled	Enabled
Require PW for Control	Enabled	Enabled
Bypass PW For RC	Off	Off

#### 18.5.1.1 CYBER-SECURITY NON-MODBUS SETTINGS CONFIGURATION

For 8A the non-Modbus Cyber-security settings can be configured when connecting online to the device through the EnerVista configuration software, using the **Rback UserManagement** configuration tool at **SETPOINTS\RBAC USERMANAGEMENT** path.

Below is an example of **RBAC UserManagement** screens for cyber-security configuration, for Users and Roles, Security Settings and Syslog Configuration.

### 18.5.1.2 USER MANAGEMENT CONFIGURATION

The **USER MANAGEMENT** screen initial screen is similar for Basic and Advanced security. The difference is that for Basic security the 4 fixed available users/roles can be used (Viewer, Administrator, Engineer and Operator) and for Advanced Cyber-security up to 20 users can be created and managed.

#### Basic Security




Figure 172: Basic security user management configuration (not configurable)

#### Advanced Security




Figure 173: Advanced security user management configuration

In **Advanced Security** the device has up to 20 configurable users. Each user will have a configurable username and password, and can select one role from the standard and new user defined roles. As stated in the standard, there is the possibility to redefine new roles by adjusting the name, ID and permissions for each new defined role. It is not possible to combine roles.

The screens to configure new users in Advanced Security are as follows:

Click on the right side icon on the users screen:






Figure 174: List of pre-configured users for advanced security

A **New User** window will open with a list of the already existing roles. In case a new role is needed it can be configured under the Roles window. See the list of pre-configured roles for Advanced Security.



**Figure 175: Example of new user creation for advanced security**

For the configuration to be saved on the device, the **Save** button needs to be clicked, otherwise the configuration will not be saved. A warning message will appear if leaving the RBAC USERMANAGEMENT configurator without saving.




**Figure 176: Save changes warning message before closing the RBAC USERMANAGEMENT configurator**

### 18.5.1.3 ROLES CONFIGURATION

The **ROLES** initial screen is similar for Basic and Advanced security. The difference is that for Basic security the 4 fixed available roles can be used (VIEWER, ADMINISTRATOR, ENGINEER and OPERATOR) and they are not editable. For Advanced Cyber-security 7 roles are pre-configured, the first 6 defined by the standard (VIEWER, OPERATOR, ENGINEER, INSTALLER, SECADM, SECAUD, RBACMNT), and the 7th one (ADMINISTRATOR), predefined with Role ID 7 that can be changed to any of the available private values allowed by the standard (See the IEC 62351 table in the IEC 62351 section).

#### Basic Security



**Figure 177: Basic security roles configuration (not configurable)**

#### Advanced Security

The first 6 roles are defined by the standard and all their parameters are fixed. The 7th role, ADMINISTRATOR, is a pre-configured role to provide all of the set permissions together in a single role. The Role Name and Role Definition are not configurable, but the Role ID can be configured. The Role ID provided is set to 7, but it can be configured to -1 or any value from the Private Role ID's available.

To add a new role, click on the right side icon on the **Roles** window:




Figure 178: Advanced security roles configuration

A **New Role** window will open with a list of permissions that can be added to any role.




Figure 179: Advanced security new roles configuration

In order to select more than one of the available options, the CTRL+Click combination of keys must be selected. Only the Role Name and Role ID can be changed when a new role is created. The Role Definition is fixed to "IEC 62351-8" for all roles.

Follow the rules for Role Name and Role ID creation and press "Apply Changes". The new user will appear on the Roles' window:




Figure 180: Example of new role creation for advance security

For the configuration to be saved on the device, the **Save** button needs to be clicked, otherwise the configuration will not be saved. A warning message will appear if leaving the RBAC USERMANAGEMENT configurator without saving.

### 18.5.1.4 SECURITY SETTINGS CONFIGURATION

#### Basic Security

For Basic Security **Access Lockout**, **Acc Lockout Time**, and **Acc Timeout**, other settings are available.



**Figure 181: Basic Security Settings**

### Advanced Security

For Advance Cyber-security, besides the **Access Lockout**, **Acc Lockout Time** and **Acc Timeout Othr**, an **Authentication Method** setting is provided. Depending on the **Authentication Method** setting selection (*LOCAL*, *RADIUS\_LEGACY*, *LDAP\_LEGACY*) different setting windows will be displayed.

### Advanced Security Settings with Local Authentication Method

If the **Authen. Method** is set to *LOCAL*, **Access Lockout**, **Acc Lockout Time** and **Acc Timeout Othr** settings are displayed.



**Figure 182: Advanced security settings, authent. method set to local**

### Advance Security Settings with Radius Legacy Authentication Method

If the **Authen. Method** is set to *RADIUS\_LEGACY*, the corresponding RADIUS setting will be displayed, number of retries, primary and secondary ports and IP addresses, path to certificate.

The Authentication Methods supported on *RADIUS\_LEGACY* for the 8A release are as follows:

- PEAPv0 with inner authentication method MS-CHAPv2
- EAP-TTLS with inner authentication method PAP (To support RSA AM)
- PAP (unsecured, to support any RADIUS server)





Figure 183: Advance security settings with radius legacy as authentication method

To select the certificate needed to communicate through RADIUS\_LEGACY, click on the **Browse** button and select the path to a valid certificate. The certificate for RADIUS should have a \*.der extension.




Figure 184: Advance security settings: radius legacy certificate

### Advanced Security Settings with LDAP\_LEGACY Authentication Method

If the **Authen. Method** is set to *LDAP\_LEGACY*, the corresponding LDAP setting will be displayed, number of retries, primary and secondary ports and IP addresses, path to certificate, as well as the base DN, users DN, roles DN parameters. See the LDAP section for more details. The Certificate for LDAP should have a \*.pem extension.

The LDAP Authentication Methods available are "TCP" and "STARTTLS".




Figure 185: Advanced security settings, authen. method set to LDAP LEGACY




Figure 186: Advance security settings, LDAP LEGACY certificate

### 18.5.1.5 SYSLOG CONFIGURATION

The IED supports security event reporting through the Syslog protocol, supporting Security Information Event Management (SIEM) systems for centralized cyber security Monitoring over UDP and TCP protocols.

*Note:*

For Basic security for releases 6A and earlier, Syslog is not available. For releases 8A and later, Syslog is available for both Basic and Advanced Security.

Syslog configuration has the following settings:

- **Network Protocol:** Available protocols for syslog configuration, to be selected between UDP and TCP
- **Syslog IP Primary, Syslog IP Secondary:** IP Primary and secondary
- **Syslog Primary Port, Syslog Secondary Port:** Primary and secondary port for syslog

*Note:*

0.0.0.0 or 127.0.0.1 values are considered to be empty or unconfigured Ips. A valid IP value should be entered in each of the Syslog IP Primary and Syslog IP Secondary settings.



Figure 187: Syslog configuration settings for both basic and advanced security

For any part of the Cyber-security configuration to be saved on the device, the **Save** button needs to be clicked before leaving the **RBAC USERMANAGEMENT** configuration tool, otherwise the changes on the configuration will not be saved. A warning message will appear if the **RBAC USERMANAGEMENT** configurator is left without saving.

## CHAPTER 19

# INSTALLATION

---

## 19.1 CHAPTER OVERVIEW

---

This section describes the mechanical installation of the system, including dimensions for mounting and information on module withdrawal and insertion.

This chapter contains the following sections:

Chapter Overview	446
Product Identification	447
Handling the Goods	448
Mounting the Device	449
Cables and Connectors	457
Case Dimensions and Panel Cutout	464

---

## 19.2 PRODUCT IDENTIFICATION

---

The product identification label is located on the side panel of the IED. This label indicates the product model, serial number, and date of manufacture. However, when the IED is installed the label may not be visible. In this case, the product may be identified using the model number printed on the front panel and the Cortec provided in the Ordering Options Appendix.

---

## 19.3 HANDLING THE GOODS

---

Our products are of robust construction but require careful treatment before installation on site. This section discusses the requirements for receiving and unpacking the goods, as well as associated considerations regarding product care and personal safety.



**Caution:**  
**Before lifting or moving the equipment you should be familiar with the Safety Information chapter of this manual.**

---

### 19.3.1 RECEIPT OF THE GOODS

On receipt, ensure the correct product has been delivered. Unpack the product immediately to ensure there has been no external damage in transit. If the product has been damaged, make a claim to the transport contractor and notify us promptly.

For products not intended for immediate installation, repack them in their original delivery packaging.

---

### 19.3.2 UNPACKING THE GOODS

When unpacking and installing the product, take care not to damage any of the parts and make sure that additional components are not accidentally left in the packing or lost. Do not discard any CDROMs or technical documentation (where included). These should accompany the unit to its destination substation and put in a dedicated place.

The site should be well lit to aid inspection, clean, dry and reasonably free from dust and excessive vibration. This particularly applies where installation is being carried out at the same time as construction work.

---

### 19.3.3 STORING THE GOODS

If the unit is not installed immediately, store it in a place free from dust and moisture in its original packaging. Keep any de-humidifier bags included in the packing. The de-humidifier crystals lose their efficiency if the bag is exposed to ambient conditions. Restore the crystals before replacing it in the carton. Ideally regeneration should be carried out in a ventilating, circulating oven at about 115°C. Bags should be placed on flat racks and spaced to allow circulation around them. The time taken for regeneration will depend on the size of the bag. If a ventilating, circulating oven is not available, when using an ordinary oven, open the door on a regular basis to let out the steam given off by the regenerating silica gel.

On subsequent unpacking, make sure that any dust on the carton does not fall inside. Avoid storing in locations of high humidity. In locations of high humidity the packaging may become impregnated with moisture and the de-humidifier crystals will lose their efficiency.

The device can be stored between  $-40^{\circ}$  to  $+85^{\circ}\text{C}$  for unlimited periods (see technical specifications).

To avoid deterioration of electrolytic capacitors, power up units that are stored in a deenergised state once per year, for one hour continuously.

---

### 19.3.4 DISMANTLING THE GOODS

If you need to dismantle the device, always observe standard ESD (Electrostatic Discharge) precautions. The minimum precautions to be followed are as follows:

- Use an antistatic wrist band earthed to a suitable earthing point.
- Avoid touching the electronic components and PCBs.

## 19.4 MOUNTING THE DEVICE

The products are available in the following forms

- For flush panel and rack mounting
- Software only (for upgrades)

### 19.4.1 FLUSH PANEL MOUNTING



**Caution:**  
To avoid the potential for personal injury due to fire hazards, ensure the unit is mounted in a safe location and/or within an appropriate enclosure.

Panel-mounted devices are flush mounted into panels using M4 SEMS Taptite self-tapping screws with captive 3 mm thick washers (also known as a SEMS unit).



**Caution:**  
Do not use conventional self-tapping screws, because they have larger heads and could damage the faceplate.

Alternatively, you can use tapped holes if the panel has a minimum thickness of 2.5 mm.

For applications where the product needs to be semi-projection or projection mounted, a range of collars are available.

If several products are mounted in a single cut-out in the panel, mechanically group them horizontally or vertically into rigid assemblies before mounting in the panel.



**Caution:**  
Do not fasten products with pop rivets because this makes them difficult to remove if repair becomes necessary.

#### 19.4.1.1 RACK MOUNTING


Panel-mounted variants can also be rack mounted using single-tier rack frames (our part number FX0021 001), as shown in the figure below. These frames are designed with dimensions in accordance with IEC 60297 and are supplied pre-assembled ready to use. On a standard 483 mm (19 inch) rack this enables combinations of case widths up to a total equivalent of size 80TE to be mounted side by side.

The two horizontal rails of the rack frame have holes drilled at approximately 26 mm intervals. Attach the products by their mounting flanges using M4 Taptite self-tapping screws with captive 3 mm thick washers (also known as a SEMS unit).



**Caution:**  
Risk of damage to the front cover molding. Do not use conventional self-tapping screws, including those supplied for mounting products because they have slightly larger heads.

Once the tier is complete, the frames are fastened into the racks using mounting angles at each end of the tier.



**Figure 188: Rack mounting of products**

Products can be mechanically grouped into single tier (4U) or multi-tier arrangements using the rack frame. This enables schemes using products from different product ranges to be pre-wired together before mounting.

Use blanking plates to fill any empty spaces. The spaces may be used for installing future products or because the total size is less than 80TE on any tier. Blanking plates can also be used to mount ancillary components. The part numbers are as follows:

Case Size Summation	Blanking Plate Part Number
5TE	GJ2028 001
10TE	GJ2028 002
15TE	GJ2028 003
20TE	GJ2028 004
25TE	GJ2028 005
30TE	GJ2028 006
35TE	GJ2028 007
40TE	GJ2028 008

#### 19.4.1.2 DRAW-OUT UNIT WITHDRAWAL AND INSERTION

Unit withdrawal and insertion may only be performed when control power has been removed from the unit.

**Warning:**  
Turn off control power before drawing out or re-inserting the IED to prevent maloperation.



### 19.4.1.2.1 20TE (AND 30TE WITHOUT CAM) DRAW-OUT UNIT WITHDRAWAL AND INSERTION

Required tools:

- T10 Torx or PZ1 Posidrive screwdriver, depending on the relay model

*Note:*

*30TE without cam IED images are provided to illustrate the extraction/insertion of the unit. All steps listed below, for 30TE without cam, also apply to 20TE.*


Follow the steps outlined below to **withdraw** the draw-out unit:

1. Remove (with the appropriate screwdriver), the 4 front panel screws that fix the front panel to the chassis, and keep the screws safe.



**Figure 189: 30TE (without cam) screws placement**

2. Grab the module by both hands, in the top and the bottom. End the module extraction process by pulling manually.




**Figure 190: 30TE module extraction**

Follow the steps outlined below, to insert the draw-out unit.

3. Place the module centered in the device's chassis, and guide it by pushing manually on the top and bottom frames of the front panel (\*). Push firmly until the module is totally inserted.

**Warning:**  
Pushing from the display or keypad zones could cause the device to be damaged.



**Figure 191: 30TE insertion**

4. Assemble and screw (with the appropriate screwdriver), the 4 screws that fix the front panel to the chassis, applying no more than 0.8Nm torque.

**Warning:**  
Applying more than maximum 0.8Nm torque when re-assembling the unit could cause the device to be damaged.

#### 19.4.1.2.2 30TE (WITH CAM) DRAW-OUT UNIT WITHDRAWAL AND INSERTION

Required tools:

- T10 Torx or PZ1 Posidrive screwdriver, depending on the relay model
- Two 4.5mm max diameter rods (about 10cm long) or screwdrivers to be used as levers for the cam rotation

**Warning:**  
IED 30TE withdrawal and insertion can be done using just one lever, and pulling manually with the other hand, but using 2 levers is strongly recommended.


Follow the steps outlined below to **withdraw** the draw-out unit:

1. Remove (with the appropriate screwdriver), the 4 front panel screws that fix the front panel to the chassis, and keep the screws safe.




**Figure 192: 30TE (with cam) screws and cams placement**

2. Insert the levers into each of the 2 cam holes (one in the top part of the frame, and the other in the bottom). The total cam holes' depth is around 10mm.




**Figure 193: 30TE levers insertion**

3. Rotate the cams horizontally but slowly, while firmly pulling from the levers. The total cam rotation shall be about 90 degrees and the module will be pulled out approximately 6mm.



**Figure 194: 30TE 2 levers rotation direction**

4. Remove the levers.
5. Grab the module with both hands, in the top and the bottom. End the module extraction process by pulling manually.




**Figure 195: 30TE module extraction**

**Warning:**

**IED 30TE withdrawal and insertion can be done using just one lever, and pulling manually with the other hand, but using 2 levers is strongly recommended.**

If only one lever is to be used, insert it into the top cam, and pull manually from the bottom, with the other hand's fingers, while rotating the top cam through the lever.




**Figure 196: 30TE 1 lever rotation, direction and extraction**

Follow the steps outlined below to **insert** the draw-out unit:

1. Before inserting the module, the cams must be manually placed in the folded position. For this, using your fingers, push the cams from the rear until they are folded.
2. Place the module centered in the device's chassis, and guide it by pushing manually on the top and bottom frames of the front panel (\*). Push firmly until the module is totally inserted.

**Warning:**

(\* ) Pushing from the display or keypad zones could cause the device to be damaged.



**Figure 197: 30TE insertion**

3. Assemble and screw (with the appropriate screwdriver), the 4 screws that fix the front panel to the chassis, applying no more than 0.8Nm torque.

**Warning:**

Applying more than maximum 0.8Nm torque when re-assembling the unit could cause the device to be damaged.

## 19.4.2 SOFTWARE ONLY

It is possible to upgrade an existing device with advanced software functions by purchasing software only (providing the device is already fitted with the requisite hardware).

There are two options for software-only products:

- Your device is sent back to the GE Vernova factory for upgrade.
- The software is downloaded or sent to you for upgrade. Please contact your local representative if you wish to procure the services of a commissioning engineer to help you with your device upgrade.

**Note:**

*Software-only products are licensed for use with devices with specific serial numbers.*

**Caution:**

Do not attempt to upgrade an existing device if the software has not been licensed for that specific device.

## 19.5 CABLES AND CONNECTORS

This section describes the type of wiring and connections that should be used when installing the device. For pin-out details please refer to the Hardware Design chapter or the wiring diagrams.

A broad range of applications are available for the IEDs. As such, it is not possible to present typical connections for all possible schemes. The information in this section covers the important aspects of interconnections, in the general areas of instrument transformer inputs, other inputs, outputs, communications and grounding.



**Caution:**  
Before carrying out any work on the equipment you should be familiar with the Safety Section and the ratings on the equipment's rating label.

Copper wiring is suggested with a minimum temperature rating of 75°C.


### 19.5.1 LUG ORIENTATION

When installing two lugs on one terminal, both lugs should be installed as per lug manufacturer instructions and engineering best practise.

### 19.5.2 TERMINAL BLOCKS

The device uses terminal blocks as shown below.

The device uses terminal blocks, each consisting of up to 16 x M3.5 screw terminals. The wires can be terminated with rings using ring terminals, with no more than two rings per terminal. If two rings are used, remove the teeth of the IP20 cover, as shown.



**Figure 198: IP20 cover with teeth removed, alone and installed**

The terminal block is supplied with a 3-pole jumper to create a star configuration with the current transformers when one is needed (instead of wiring one externally), as shown.



**Figure 199: Terminal block with 3-pole jumper for 20TE**



**Figure 200: Terminal block with 3-pole jumper for 30TE (PIN terminals)**






Figure 201: Terminal block with 3-pole jumper for 30TE (Hybrid PIN + RING terminals)

### 19.5.3 POWER SUPPLY CONNECTIONS

These should be wired with 1.5 mm PVC insulated multi-stranded copper wire terminated with M3.5 8 mm maximum diameter ring terminals. Recommended ring terminals: TE B-106-1403 or Molex 193240012

The wire should have a minimum voltage rating of 300 V RMS.



**Caution:**

Control power supplied to the IED must match the installed power supply range. If the applied voltage does not match, damage to the unit may occur. All earths **MUST** be connected for normal operation regardless of control power supply type.



**Caution:**

Protect the auxiliary power supply wiring with a maximum 10 A high rupture capacity (HRC) type NIT or TIA fuse.

### 19.5.4 EARTH CONNECTION

Every device must be connected to the earth connection using the earth terminal.

Use the shortest practical path. A tinned copper, braided, shielding and bonding cable should be used. As a minimum, 96 strands of number 34 AWG should be used.

The wire should have a minimum voltage rating of 300 V RMS.

*Note:*

*To prevent any possibility of electrolytic action between brass or copper ground conductors and the rear panel of the product, precautions should be taken to isolate them from one another. This could be achieved in several ways, including placing a nickel-plated or insulating washer between the conductor and the product case, or using tinned ring terminals.*

### 19.5.5 PHASE SEQUENCE AND TRANSFORMER POLARITY

For correct operation of the IEDs features, follow the instrument transformer polarities, shown in the Typical Wiring Diagram. Note the solid square markings that are shown with all instrument transformer connections. When the connections adhere to the drawing, the arrow shows the direction of power flow for positive watts and the positive direction of vars. The phase sequence is user programmable for either ABC or ACB rotation.

The Multilin Agile IED has four (4) current inputs. Three of them are used for connecting to the phase CT phases A, B, and C. The fourth input is an earth input that can be connected to either a earth CT placed on the neutral from a Wye connected transformer winding, or to a “donut” type CT measuring the zero sequence current from a earthed system. The IED CTs are placed in a packet mounted to the chassis of the IED. There are no internal earth connections on the current inputs.



**Caution:**  
Verify that the IEDs CT Ratio Settings under *SETPOINTS\SYSTEM\CT RATIO* are correctly set matching the Primary and Secondary rating of the connected CTs. Unmatched CTs may result in equipment damage or inadequate protection.

### 19.5.6 CURRENT TRANSFORMERS

Current transformers would generally be wired with 2.5 mm<sup>2</sup> PVC insulated multi-stranded copper wire terminated with M3.5 8 mm maximum diameter ring terminals. Recommended ring terminals: TE B-106-1403 or Molex 193240012.

Due to physical limitations, the maximum wire size you can use is 4.0 mm<sup>2</sup> using ring terminals. If you need a greater cross-sectional area, use two wires in parallel, each terminated in a separate ring terminal.

The wire should have a minimum voltage rating of 300 V RMS.



**Caution:**  
Current transformer circuits must never be fused.

*Note:*

*If there are CTs present, ensure that the terminals into which the CTs connect are shorted before the CT module is removed.*

*Note:*

*For 5A CT secondaries, we recommend using 2 x 2.5 mm<sup>2</sup> PVC insulated multi-stranded copper wire.*

*Note:*

*The terminal block is supplied with a 3-pole jumper to create a star configuration with the current transformers when one is needed (instead of wiring one externally).*

### 19.5.7 VOLTAGE TRANSFORMER CONNECTIONS

Voltage transformers would generally be wired with 2.5 mm<sup>2</sup> PVC insulated multi-stranded copper wire terminated with M3.5 8 mm maximum diameter ring terminals. Recommended ring terminals: TE B-106-1403 or Molex 193240012.

The wire should have a minimum voltage rating of 300 V RMS.

---

## 19.5.8 WATCHDOG (CRITICAL FAIL) CONNECTIONS

These should be wired with at least 1mm PVC multi stranded copper wire with/without pin terminals up to 2.5mm.

The wire should have a minimum voltage rating of 300 V RMS.

The watchdog for Multilin Agile IED's is a reserved Critical Fail normally closed non-programmable contact for relay healthy/relay fail indication. Its status can be checked under **DEVICE STATUS\RELAY OUTPUTS\RELAY OUTPUTS** path. Watchdog terminals are showed as 'Critical Fail' in the corresponding IEDs wiring diagram.

---

## 19.5.9 EIA(RS)485 CONNECTIONS

For connecting the EIA(RS485) ports, use 2-core screened cable with a maximum total length of 1000 m or 200 nF total cable capacitance.

A typical cable specification would be:

- Each core: 16/0.2 mm<sup>2</sup> copper conductors, PVC insulated
- Nominal conductor area: 0.5 mm<sup>2</sup> per core
- Screen: Overall braid, PVC sheathed

Up to 32 P14 Series IEDs can be daisy-chained together on a communication channel without exceeding the driver capability. For larger systems, additional serial channels must be added. Commercially available repeaters can also be used to add more than 32 relays on a single channel.

**Caution:**

To ensure that all devices in a daisy-chain are at the same potential, it is imperative that the common terminals of each RS485 port are tied together and grounded only once, at the master or at the IED. Failure to do so may result in intermittent or failed communications.

The last device at each end of the daisy-chain should be terminated with a 120 ohm ¼ watt resistor in series with a 1 nF capacitor across the positive and negative terminals. Some systems allow the shield (drain wire) to be used as a common wire and to connect directly to the COM terminal; others function correctly only if the common wire is connected to the COM terminal, but insulated from the shield.


Observing these guidelines ensure a reliable communication system immune to system transients.

To guarantee the performance specifications, you must ensure continuity of the screen, when daisy chaining the connections. There is no electrical connection of the cable screen to the device. The link is provided purely to link together the two cable screens.

---

## 19.5.10 IRIG-B CONNECTION

IRIG-B is a standard time code format that allows time stamping of events to be synchronized among connected devices within 1 millisecond. The IRIG-B time code formats are serial, width-modulated codes DC level shift form. Third party equipment is available for generating the IRIG-B signal; this equipment may use a GPS satellite system to obtain the time reference so that devices at different geographic locations can also be synchronized.



The optional IRIG-B input uses the same terminals as the EIA(RS)485 port COM1. It is therefore apparent that RS485 communications and IRIG-B input are mutually exclusive.

A typical cable specification would be:

- Each core: 16/0.2 mm<sup>2</sup> copper conductors, PVC insulated
- Nominal conductor area: 0.5 mm<sup>2</sup> per core
- Screen: Overall braid, PVC sheathed

IRIG-B connection (two wires) to Multilin Agile IED COM1 terminals:

- IRIG-B positive wire should be connected to COM1 B(+) terminal
- IRIG-B neutral wire should be connected to COM1 GND terminal
- COM1 A(-) terminal should remain not connected.

The uncovered communications cable shield connected to the common terminal should not exceed 1" (2.5 cm) for proper EMC shielding of the communications cable.

**Note:**

To use the IRIG-B connection, the IRIG-B setting under **SETPOINT\DATE AND TIME\CLOCK\IRIG-B** should be set to *Enabled*.

**Note:**

The IRIG-B connection is a two cable connection so the COM1 A(-) terminal should not be connected

## 19.5.11 OPTO-INPUT CONNECTIONS

Depending on the order code, the Multilin Agile IED has a different number of contact inputs which can be used to operate a variety of logic functions for circuit switching device control, external trips, blocking of protection elements,

etc. The IED has 'contact inputs' and 'virtual inputs' that are combined in a form of programmable logic to facilitate the implementation of various schemes.

These should be wired with at least 1mm PVC multi stranded copper wire with/without pin terminals up to 2.5mm.

Each opto-input has a **Debounce Time** setting. This makes the input immune to noise induced on the wiring. This can, however slow down the response.



**Caution:**  
Protect the opto-inputs and their wiring with a maximum 2A high rupture capacity (HRC) type NIT or TIA fuse.

### 19.5.12 OUTPUT RELAY CONNECTIONS

These should be wired with at least 1mm PVC multi stranded copper wire with/without pin terminals up to 2.5mm.

### 19.5.13 ETHERNET COPPER CONNECTIONS

If the device has a copper Ethernet connection, it can be connected to either a 10Base-T or a 100Base-TX Ethernet hub. Due to noise sensitivity, we recommend this type of connection only for short distance connections, ideally where the products and hubs are in the same cubicle.

The connector for the Ethernet port is a shielded RJ-45. The pin-out is as follows:

Pin	Signal Name	Signal Definition
1	TXP	Transmit (positive)
2	TXN	Transmit (negative)
3	RXP	Receive (positive)
4	-	Not used
5	-	Not used
6	RXN	Receive (negative)
7	-	Not used
8	-	Not used

**Note:**

For increased noise immunity, it is recommended to use CAT 6 (category 6) STP (shielded twisted pair) cable and connectors.

### 19.5.14 ETHERNET FIBRE CONNECTIONS

We recommend the use of fibre-optic connections for permanent connections in a substation environment. The 100 Mbps fibre optic port is based on the 100BaseFX standard and uses type LC connectors. They are compatible with 50/125  $\mu\text{m}$  or 62.5/125  $\mu\text{m}$  multimode fibres at 1300 nm wavelength.

### 19.5.15 USB CONNECTION

The IED has a type B USB socket on the front panel. A standard USB printer cable (type A one end, type B the other end) can be used to connect a local PC to the IED. This cable is the same as that used for connecting a printer to a PC.

## 19.6 CASE DIMENSIONS AND PANEL CUTOUT




Figure 202: 20TE case dimensions and panel cutout




Figure 203: 30TE case dimensions and panel cutout

## CHAPTER 20

# COMMISSIONING INSTRUCTIONS



---

## 20.1 CHAPTER OVERVIEW

---

This chapter contains the following sections:

Chapter Overview	467
General Guidelines	468
Commissioning Test Menu	469
Commissioning Equipment	472
Product Checks	474
Setting Checks	480
Protection Timing Checks	482
Onload Checks	483
Final Checks	485

## 20.2 GENERAL GUIDELINES

GE Vernova's IED's are self-checking devices and will raise an alarm in the unlikely event of a failure. This is why the commissioning tests are less extensive than those for non-numeric electronic devices or electro-mechanical relays.

To commission the devices, you (the commissioning engineer) do not need to test every function. You need only verify that the hardware is functioning correctly and that the application-specific software settings have been applied. You can check the settings by extracting them using the EnerVista Configuration settings software, or by means of the front panel interface (HMI panel).

The menu language is user-selectable, so you can change it for commissioning purposes if required.

*Note:*

*Remember to restore the language setting to the customer's preferred language on completion.*



**Caution:**

**Before carrying out any work on the equipment you should be familiar with the contents of the Safety Section or Safety Guide SFTY/4LM as well as the ratings on the equipment's rating label.**



**Warning:**

**Do not disassemble the device during commissioning.**

## 20.3 COMMISSIONING TEST MENU

The Multilin Agile IED provides several testing features under *THE SETPOINTS\TESTING* menu heading in the *HMI and MONITORING\TESTING* tab in the EnerVista Configuration software. These testing features facilitate IED testing during commissioning. The testing features supported are as follows:

- Simulation
- Test LEDs
- Opto Inputs
- Relay Outputs
- GOOSE

The **Simulation State** setting under the *SETPOINTS\TESTING\SIMULATION\SETUP* path may be set to *Prefault State*, *Fault State*, *Postfault State* or *Disabled*. The specific **Pre-Fault**, **Fault** and **Post-Fault** setting values for each mode can be programmed in its corresponding setting menu under the *SETPOINTS\TESTING\SIMULATION* path.

The **PreFit-Fit Trig** setting under the *SETPOINTS\TESTING\SIMULATION\SETUP* path sets the signal that triggers the change of state from *Prefault State* to *Fault State*.

The **Force Relays** setting under the *SETPOINTS\TESTING\SIMULATION\SETUP* path enables or disables the relay outputs testing mode. The specific forcing value for each relay output contact is set under the *SETPOINTS\TESTING\RELAY OUTPUTS* path.

The **Force LEDs** setting under the *SETPOINTS\TESTING\SIMULATION\SETUP* path enables or disables the LEDs testing mode. The specific forcing value for each LED is set under the *SETPOINTS\TESTING\TEST LEDs* path.

The Opto inputs states can be simulated by forcing the specific value for each Opto input under the *SETPOINTS\TESTING\OPTO INPUTS* path. The Opto inputs testing mode is enabled when the **Simulation State** setting is set to any value except *Disabled*.

### 20.3.1 SIMULATION

The Simulation feature under the *SETPOINTS\TESTING\SIMULATION* path is provided for testing the functionality of the Multilin Agile IEDs in response to programmed conditions, without the need of external AC voltage and current inputs. First time users will find this to be a valuable training tool. System parameters such as currents, voltages and phase angles are entered as settings. When placed in test mode, the IED suspends reading actual AC inputs, generates samples to represent the programmed phasors, and loads these samples into the memory to be processed by the IED. Normal (pre- fault), fault, and post-fault conditions can simulate a wide variety of system disturbances and utilise many of the Multilin Agile IEDs features.

Program the **Simulation State** setting under the *SETPOINTS\TESTING\SIMULATION* path to *Disabled* if actual system inputs are to be monitored and test mode to be disabled.

If the **Simulation State** setting is set to any other value (*Pre-Fault state*, *Fault state* or *Post-Fault state*), the IED is in test mode and actual system parameters are not monitored, including current, voltage, and opto-inputs. The system parameters simulated by the IED are those corresponding to the programmed value of the **Simulation State** setting. For example, if programmed to *Fault State*, then the system parameters are set to those defined by the **Fault** setting values under the *SETPOINTS\TESTING\SIMULATION* path.

While in test mode, opto-input states are automatically forced to the values set in *SETPOINTS\TESTING\OPTO INPUTS*.

When the *Fault State* is set as the **Simulation State** and a Trip occurs, the Simulation State automatically transitions to the *Postfault State*.

The *Pre-Fault*, *Fault* and *Post-Fault* setting values (magnitudes and angles) are programmed in its corresponding setting menu under the *SETPOINTS/TESTING/SIMULATION* path.

When in test mode, and Force Relays under the **SETPOINTS\TESTING\SIMULATION\SETUP** path is *Enabled*, relay output states can be forced from the **SETPOINTS\TESTING\RELAY OUTPUTS** menu, this overrides the normal operation of the relay output contacts. When in test mode, and Force Relays is Disabled, the relay output states maintain their normal operation. Forcing of relay outputs states is not performed when the **Simulation State** is *Disabled*.

When in test mode, and **Force LEDs** is *Enabled*, LED states and colours can be forced from the **SETPOINTS\TESTING\TEST LEDS** menu, this will override the normal operation of the LEDs. When in test mode, and **Force LEDs** is *Disabled*, the LED states and colours will maintain their normal operation. Forcing of LEDs is not performed when the **Simulation State** is *Disabled*.

### 20.3.1.1 PRE-FAULT

The *PreFault State* is intended to simulate the normal operating condition of a system by replacing the normal input parameters with programmed pre-fault values. For proper simulation, values entered in the **SETPOINTS\TESTING\SIMULATION\PRE-FAULT** menu must be below the minimum trip setting of any protection feature.

When the *PreFault State* is set as the **Simulation State** and the conditions of the **PreFit-Fit Trig** setting under the **SETPOINT\TESTING\SIMULATION\TESTING** path are met, the **Simulation State** automatically transitions from *PreFault State* to *Fault State*.

### 20.3.1.2 FAULT

The *Fault State* is intended to simulate the faulted operating condition of a system by replacing the normal input parameters with programmed fault values.

When *Fault State* is set as the **Simulation State** and a trip occurs, the **Simulation State** automatically transitions to the *Postfault State*.

### 20.3.1.3 POST-FAULT

The *PostFault State* is intended to simulate a system that has tripped by replacing the normal input parameters with programmed postfault values.

**Note:**

For **Pre-Fault, Fault and Post-Fault** settings under the **SETPOINT\TESTING\SIMULATION** path:

**Note:**

Voltage magnitudes are entered in secondary VT units. Primary and secondary settings for VT inputs can be found on VT Ratio menu under the **SETPOINT\SYSTEM\VT RATIO** path.

**Note:**

Current magnitudes are entered as a multiple of the corresponding **CT Primary** setting. Primary and secondary settings for CT inputs can be found on **CT Ratio** menu under the **SETPOINT\SYSTEM\CT RATIO** path.

**Note:**

All Simulation settings revert to default values at power up.

## 20.3.2 TEST LEDS

The **Test LEDs** settings under the **SETPOINTS\TESTING** path allows programming of the state and colour of each LED when the device is in test mode and the **Force LEDs** setting under **SETPOINTS\TESTING\SIMULATION\SETUP** is set to *Enabled*.

All LEDs from 2 till 8 can be tested by changing its colour and state from Off, Green, Orange and Red and the LED will be set to off or to the selected colour in the corresponding LED X setting.

LED 1 can be tested by changing its colour from Off to Red. Green and Orange options are available in the setting selection, but the LED 1 will always turn red with any colour selection.

*Note:*  
All **Test LEDs** settings revert to default values at power up.

### 20.3.3 OPTO-INPUTS

The Opto Inputs settings under **SETPOINTS\TESTING** path allows the programming of the state (*Off*, *On*) of each opto-input when the device is in test mode.

*Note:*  
All **Opto Inputs** settings revert to default values at power up.

*Note:*  
The number of opto-inputs available for the IED is Cortec dependant.

### 20.3.4 RELAY OUTPUTS

The Relay Outputs settings under the **SETPOINTS\TESTING** path allows the programming of the state of each relay output when the device is in test mode and the Force Relays setting under **SETPOINTS\TESTING\SIMULATION\SETUP** is set to *Enabled*.

*Note:*  
All **Relay Outputs** settings revert to default values at power up.

*Note:*  
The number of relay outputs available for the IED is Cortec dependant.

### 20.3.5 GOOSE

When the IED provides GOOSE (IEC 61850B Cortec dependant function), a menu under **SETPOINTS\TESTING\GOOSE** is available for testing GOOSE messaging.

- **TxGOOSE Sim Mode:** When set to disabled, the sim bit in all transmitted GOOSE messages are set to FALSE. When set to enabled, the sim bit in all transmitted GOOSE messages are set to TRUE.
- **Accept Sim GOOSE:** When set to disabled, the relay "Sim" attribute (LPHD1.Sim.StVal) is set to False and the GOOSE/SV messages received with simulation flag/bet set are ignored. When set to Enabled, the relay "Sim" attribute (LPHD1.Sim.StVal) is set to True, so that if GOOSE/SV messages are received with the "simulation" flag/bit set, these will be used in place of the normal messages.

---

## 20.4 COMMISSIONING EQUIPMENT

---

Specialist test equipment is required to commission this product. We recognise three classes of equipment for commissioning :

- Recommended
- Essential
- Advisory

Recommended equipment constitutes equipment that is both necessary, and sufficient, to verify correct performance of the principal protection functions.

Essential equipment represents the minimum necessary to check that the product includes the basic expected protection functions and that they operate within limits.

Advisory equipment represents equipment that is needed to verify satisfactory operation of features that may be unused, or supplementary, or which may, for example, be integral to a distributed control/automation scheme. Operation of such features may, perhaps, be more appropriately verified as part of a customer defined commissioning requirement, or as part of a system-level commissioning regime.

---

### 20.4.1 RECOMMENDED COMMISSIONING EQUIPMENT

The minimum recommended equipment is a multifunctional three-phase AC current and voltage injection test set featuring :

- Controlled three-phase AC current and voltage sources,
- Transient (dynamic) switching between pre-fault and post-fault conditions (to generate delta conditions),
- Dynamic impedance state sequencer (capable of sequencing through 4 impedance states),
- Integrated or separate variable DC supply (0 - 250 V)
- Integrated or separate AC and DC measurement capabilities (0-440V AC, 0-250V DC)
- Integrated and/or separate timer,
- Integrated and/or separate test switches.

In addition, you will need :

- A portable computer, installed with appropriate software to liaise with the equipment under test (EUT). Typically this software will be proprietary to the product's manufacturer.
- Suitable electrical test leads.
- Electronic or brushless insulation tester with a DC output not exceeding 500 V
- Continuity tester
- Verified application-specific settings files

---

### 20.4.2 ESSENTIAL COMMISSIONING EQUIPMENT

As an absolute minimum, the following equipment is required:

- AC current source coupled with AC voltage source
- Variable DC supply (0 - 250V)
- Multimeter capable of measuring AC and DC current and voltage (0-440V AC, 0-250V DC)
- Timer
- Test switches
- Suitable electrical test leads
- Continuity tester

---

### 20.4.3 ADVISORY TEST EQUIPMENT

Advisory test equipment may be required for extended commissioning procedures:

- Current clamp meter
- Multi-finger test plug:
- Electronic or brushless insulation tester with a DC output not exceeding 500 V
- EIA(RS)485 to EIA(RS)232/USB converter for testing EIA(RS)485 MODBUS/IEC60870-5-103/DNP3 port
- A portable printer (for printing a setting record from the portable PC) and or writeable, detachable memory device.
- Phase angle meter
- Phase rotation meter

## 20.5 PRODUCT CHECKS

These product checks are designed to ensure that the device has not been physically damaged prior to commissioning, is functioning correctly and that all input quantity measurements are within the stated tolerances.

If the application-specific settings have been applied to the IED prior to commissioning, you should make a copy of the settings. This will allow you to restore them at a later date if necessary. This can be done by:

- Obtaining a setting file from the customer.
- Extracting the settings from the IED itself, using a portable PC with appropriate setting software.

If the customer has changed the password that prevents unauthorised changes to some of the settings, either the revised password should be provided, or the original password restored before testing.

*Note:*

*If the password has been lost, a recovery password can be obtained from GE Vernova.*

*Note:*

*CT and VT and protection, control and monitoring features availability for testing and product checks will be Cortec dependant for each model.*

### 20.5.1 PRODUCT CHECKS WITH THE IED DE-ENERGISED



**Warning:**

**The following group of tests should be carried out without the auxiliary supply being applied to the IED and, if applicable, with the trip circuit isolated.**

The current and voltage transformer connections must be isolated from the IED for these checks. If a test block is provided, the required isolation can be achieved by inserting a test plug. This open circuits all wiring routed through the test block.

Before inserting the test plug, you should check the scheme diagram to ensure that this will not cause damage or a safety hazard (the test block may, for example, be associated with protection current transformer circuits). The sockets in the test plug, which correspond to the current transformer secondary windings, must be linked before the test plug is inserted into the test block.



**Warning:**

**Never open-circuit the secondary circuit of a current transformer since the high voltage produced may be lethal and could damage insulation.**

If a test block is not provided, the voltage transformer supply to the IED should be isolated by means of the panel links or connecting blocks. The line current transformers should be short-circuited and disconnected from the IED terminals. Where means of isolating the auxiliary supply and trip circuit (for example isolation links, fuses and MCB) are provided, these should be used. If this is not possible, the wiring to these circuits must be disconnected and the exposed ends suitably terminated to prevent them from being a safety hazard.



### 20.5.1.1 VISUAL INSPECTION



**Caution:**  
Check the rating information provided with the device. Check that the IED being tested is correct for the line or circuit.

Carefully examine the IED to see that no physical damage has occurred since installation.

Ensure that the case earthing connections (bottom left-hand corner at the rear of the IED case) are used to connect the IED to a local earth bar using an adequate conductor.

### 20.5.1.2 INSULATION

Insulation resistance tests are only necessary during commissioning if explicitly requested.

Isolate all wiring from the earth and test the insulation with an electronic or brushless insulation tester at a DC voltage not exceeding 500 V. Terminals of the same circuits should be temporarily connected together.

The insulation resistance should be greater than 100 MΩ at 500 V.

On completion of the insulation resistance tests, ensure all external wiring is correctly reconnected to the IED.

### 20.5.1.3 EXTERNAL WIRING



**Caution:**  
Check that the external wiring is correct according to the relevant IED and scheme diagrams. Ensure that phasing/phase rotation appears to be as expected.

The auxiliary DC voltage supply uses terminals A1 (supply positive) and A2 (supply negative).

### 20.5.1.4 WATCHDOG (CRITICAL FAIL) CONTACT

Using a continuity tester, check that the watchdog (Critical Fail) contact is in the following state:

Terminals	De-energised Contact
D23 - D24	Closed

### 20.5.1.5 POWER SUPPLY

The IED can accept a nominal DC voltage from 24 V DC to 250 V DC, or a nominal AC voltage from 110 V AC to 240 V AC at 50 Hz or 60 Hz. Ensure that the power supply is within this operating range. The power supply must be rated at 10 Watts or more.



**Warning:**  
Do not energise the IED or interface unit using the battery charger with the battery disconnected as this can irreparably damage the power supply circuitry.



**Caution:**  
Energise the IED only if the auxiliary supply is within the specified operating ranges. If a test block is provided, it may be necessary to link across the front of the test plug to connect the auxiliary supply to the IED.

## 20.5.2 PXXX\_CI\_PRODUCTCHECKSENERGISED



### Warning:

The current and voltage transformer connections must remain isolated from the IED for these checks. The trip circuit should also remain isolated to prevent accidental operation of the associated circuit breaker.

The following group of tests verifies that the IED hardware and software is functioning correctly and should be carried out with the supply applied to the IED.

### 20.5.2.1 WATCHDOG (CRITICAL FAIL) CONTACT

Using a continuity tester, check that the watchdog (Critical Fail) contact is in the following state:

Terminals	Energised Contact
D23 - D24	Open

### 20.5.2.2 DATE AND TIME

The date and time is stored in non-volatile memory. If the values are not already correct, set them to the correct values. The method of setting will depend on whether accuracy is being maintained by the IRIG-B port or by the IEDs internal clock.

When using IRIG-B to maintain the clock, the IED must first be connected to the satellite clock equipment, which should be energised and functioning.

1. Set the **IRIG-B** setting under the path **SETPOINT\DEVICE\DATE AND TIME** to *Enabled*.
2. Ensure the IED is receiving the IRIG-B signal by checking that **Clock** Status at **DEVICE STATUS\CLOCK\RTC SYNC SOURCE** reads **IRIG-B**.
3. Once the IRIG-B signal is active, adjust the time offset of the universal coordinated time (satellite clock time) on the satellite clock equipment so that local time is displayed.
4. Check that the time, date and month are correct in the **SETPOINT\DEVICE\DATE AND TIME\CLOCK** element. The IRIG-B signal does not contain the current year so it will need to be set manually.
5. Reconnect the IRIG-B signal.

If the time and date is not being maintained by an IRIG-B signal, ensure that the **IRIG-B** setting in the **DATE AND TIME** element is set to *Disabled*. Set the date and time to the correct local time and date using the **SETPOINT\DEVICE\DATE AND TIME\CLOCK** element, the **SETPOINTS\DEVICE\DATE AND TIME\PTP**, the **SETPOINTS\DEVICE\DATE AND TIME\SNTP** or the communication protocols.

### 20.5.2.3 TEST LEDES

If any of the LEDs are ON then they should be reset before proceeding with further testing. If the LEDs successfully reset (the LED goes off), no testing is needed for that LED because it is obviously operational.

For more detail on LEDs testing refer to the **Commissioning Test** Menu in this chapter.

Return the IED to service by setting the **Simulation State** to *Disabled* in the **SETPOINTS\TESTING\SIMULATION\SETUP** menu.

### 20.5.2.4 TEST OPTO-INPUTS

This test checks that all the opto-inputs on the IED are functioning correctly.

The opto-inputs should be energised one at a time. For terminal numbers, refer to the Wiring Diagrams Appendix. Ensuring correct polarity, connect the supply voltage to the appropriate terminals for the input being tested.

The status of each opto-input can be viewed using the **DEVICE STATUS\OPTO INPUTS** element.

*On* indicates an energised opto-input and *Off* indicates a de-energised opto-input.

Opto-inputs can be simulated when the device is in test mode (set the Simulation State setting under the **SETPOINTS\TESTING\SIMULATION\SETUP** path to any value but Disabled). The existing status of each opto-input can be changed from *Off* to *On* and vice versa. Take into account that this simulates the opto input, so any logic associated with it should be checked.

If the opto-inputs have been tested using the IED test mode, ensure to return the IED to service by setting the Simulation State to Disabled in the **SETPOINTS\TESTING\SIMULATION\SETUP** menu.

The rest of the test mode settings should also be set to their default values.

### 20.5.2.5 TEST RELAY OUTPUTS

This test checks that all the output relays are functioning correctly.

1. Ensure that the IED is in test mode by checking that the Simulation State setting under **SETPOINTS\TESTING\SIMULATION\SETUP** is set to any value except *Disabled* and that the **Force Relays** setting under **SETPOINTS\TESTING\SIMULATION\SETUP** is set to *Enabled*.
2. The relay output contacts should be energised one at a time. To select any relay output relay for testing, set the corresponding relay output setting at **SETPOINT\TESTING\RELAY OUTPUT AS APPROPRIATE**.
3. Connect a continuity tester across the terminals corresponding to the relay output contact being tested as shown in the external wiring diagram.
4. To operate the relay output contact change the relay output status at **SETPOINT\TESTING\RELAY OUTPUTS**.
5. Check the operation with the continuity tester.
6. Measure the resistance of the contacts in the closed state.
7. Reset the relay output contact by changing the relay output status.
8. Repeat the test for all the relay output contacts.
9. Return the IED to service by setting the **Simulation State** to *Disabled* in the **SETPOINTS\TESTING\SIMULATION\SETUP** menu. The rest of the test mode settings should also be set to their default values.

**Note:**

Take into account that all relay output contacts are normally open, but the watchdog (Relay Output 8 or 6 depending on the Binary Input/Output Options ordered) that is normally closed.

### 20.5.2.6 TEST SERIAL COMMUNICATION PORT COM1

You need only perform this test if the IED is to be accessed from a remote location with a permanent serial connection to the communications port. The scope of this test does not extend to verifying operation with connected equipment beyond any supplied protocol converter. It verifies operation of the rear communication port (and if applicable the protocol converter) and varies according to the protocol fitted.

#### 20.5.2.6.1 CHECK PHYSICAL CONNECTIVITY

The rear communication port COM1 is on the rear of the IED. Screened twisted pair cable is used to make a connection to the port.

EIA(RS)485 is polarity sensitive, so you must ensure the wires are connected the correct way round.

If RS485 is being used, an RS485-RS232/USB converter will have been installed. In the case where a protocol converter is being used, a laptop PC running appropriate software can be connected to the incoming side of the protocol converter. Most modern laptops have USB ports, so it is likely you will also require a RS232 to USB converter too.

### 20.5.2.6.2 CHECK LOGICAL CONNECTIVITY

The logical connectivity depends on the chosen data protocol, but the principles of testing remain the same for all protocol variants:

1. Ensure that the communications baud rate and parity settings in the application software are set the same as those on the protocol converter.
2. Check that communications can be established with this IED using the portable PC/Master Station.

### 20.5.2.7 TEST SERIAL COMMUNICATION PORT COM2

For products that employ Ethernet communications, we recommend that testing be limited to a visual check that the correct ports are working and that there is no sign of physical damage.

### 20.5.2.8 TEST ETHERNET COMMUNICATION

COM2 is a Cortec dependant option. If applicable, this test is the same as for COM1, just taking into account that the terminal connections are different. Refer to Appendix C Wiring Diagrams for terminal connections details and to Appendix A Ordering Options for Cortec detailed description.

### 20.5.2.9 TEST CURRENT INPUTS

This test verifies that the current measurement inputs are configured correctly.

All devices leave the factory set for operation at a system frequency of 50 Hz. If operation at 60 Hz is required then this must be set in the **Nom. Frequency** setting at **SETPOINTS\SYSTEMPOWER SYSTEM**.

1. Apply current equal to the line current transformer secondary winding rating to each current transformer input in turn. Ensure that the CT RATIO settings (primary and secondary for all current inputs) under **SETPOINTS\SYSTEM** are properly set.
2. Check its magnitude using a multimeter or test set readout. The corresponding reading can then be checked in the **MEASUREMENTS\CT1 BANK-B** menu.

An additional allowance must be made for the accuracy of the test equipment being used.

<b>Measurement\CT1 Bank-B Menu</b>	<b>Corresponding CT Ratio (in CT and VT Ratios Menu)</b>
CT1 IA CT1 IB CT1 IC	Phase CT Primary/Phase CT Sec'y
CT1 IN2 (derived current)	E/F CT Primary/E/F CT Sec'y
CT1 IN1 (EF measured current)	E/F CT Primary/E/F CT Sec'y
CT1 SEF (SEF measured current)	SEF CT Primary/SEF CT Sec'y

**Note:**

*E/F or SEF current values are displayed for each device depending of the Cortec selected.*

### 20.5.2.10 TEST VOLTAGE INPUTS

This test verifies that the voltage measurement inputs are configured correctly.

1. Apply rated voltage to each voltage transformer input in turn.. Ensure that the VT RATIO settings (primary and secondary for all current inputs) under **SETPOINTS\SYSTEM** are properly set.
2. Check its magnitude using a multimeter or test set readout. The corresponding reading can then be checked in the **MEASUREMENTS\PH VT1BANK-A** and **MEASUREMENT\4th VT1 BANK-A** menus.

<b>Measurements\PH VT1 Bank-A and Measurement\ 4th VT1 Bank-A Menus</b>	<b>Corresponding VT Ratio (in <i>CT</i> and <i>VT Ratios</i>)</b>
VT1 VAN VT1 VBN VT1 VCN	Main VT Primary/Main VT Sec'y
4th VT1 Mag	4th VT Primary/4th VT Sec'y

## 20.6 SETTING CHECKS

The setting checks ensure that all of the application-specific settings (both the IEDs function and Flexlogic Equation Editor settings) have been correctly applied.

**Note:**

*If applicable, the trip circuit should remain isolated during these checks to prevent accidental operation of the associated circuit breaker.*

### 20.6.1 APPLY APPLICATION-SPECIFIC SETTINGS

There are two different methods of applying the settings to the IED

- Transferring settings to the IED from a pre-prepared setting file using EnerVista Configuration software
- Enter the settings manually using the IEDs front panel HMI

#### 20.6.1.1 TRANSFERRING SETTINGS FROM A SETTINGS FILE

This is the preferred method for transferring function settings. It is much faster and there is a lower margin for error.

1. Connect a PC running the EnerVista Configuration software Settings Application Software to the IEDs USB front port, or the rear Ethernet port.
2. Power on the IED
3. Create or open an existing project including the CID file for the IED and click in the appropriate device name in the project and select **Send CID** from the top toolbox.
4. Enter the IP address of the device related to the interface selected, USB or Ethernet
5. In the **User Authentication** dialog select the Username and Password and click **Continue** and then **Finish**

**Note:**

*The device CID file may not already exist in the **project**. In this case, select **Quick Download** from the top toolbox entering the appropriate IP address for the interface selected (USB or Ethernet) and, then manually add the settings file to the device name in the project. Refer to the EnerVista Configuration chapter for details.*

#### 20.6.1.2 ENTERING SETTINGS USING THE HMI

1. Starting at the default display, press the Down cursor key to navigate through the HMI menus.
2. Use the vertical cursor keys to select the required Setpoint setting under SETPOINTS menu.
3. Press **OK** to access to the next menu and to view the setting data in the selected menu.
4. To return to the previous header menu press the **Cancel** key once.
5. To return to the default display, press the Cancel key repeatedly from any of the menu headings until the default display is reached.
6. To change the value of a setting, go to the relevant setting in the menu, then press the **Enter** key to change the setting value. A steady cursor on the LCD shows that the value can be changed. You may be prompted for a password first.
7. To change the setting value, press the vertical cursor keys.
8. Press the **Enter** key to confirm the new setting value.
9. The changes must be confirmed before they are used. When all required changes have been entered, press the Clear key. Before returning to the default display, the following prompt appears.

CONFIRM CHANGES?  
NO YES

10. Press the **YES** right Up key key to accept the new settings or press the **NO** left Up key key to discard the new settings.

*Note:*

*It is not possible to change the Flexlogic Equation Editor or IEC 61850 configuration using the IEDs front panel HMI.*



**Caution:**

**Where the installation needs the application-specific Flexlogic Equation Editor, the relevant logic must be transferred to the IED, taking into account that the logic should apply for each and every setting group that will be used.**

---

## 20.7 PROTECTION TIMING CHECKS

---

There is no need to check every protection function. Only one protection function needs to be checked as the purpose is to verify the timing on the processor is functioning correctly.

---

### 20.7.1 OVERCURRENT CHECK

If the overcurrent protection function is being used, test the overcurrent protection for stage 1.

1. Check for any possible dependency conditions and simulate as appropriate.
2. In the *SETPOINTS* menu, disable all protection elements other than the one being tested.
3. Make a note of which elements need to be re-enabled after testing.
4. Connect the test circuit.
5. Perform the test.
6. Check the operating time.

---

### 20.7.2 CONNECTING THE TEST CIRCUIT

1. Use the Flexlogic Equation Editor and device setpoints to determine which output relay will operate when an overcurrent trip occurs.
2. Relay output 1 is pre-configured to trip.
3. Use the Flexlogic Equation Editor and device setpoints to map the protection stage under test directly to a relay output other than **RELAY 1-TRIP**, in case a different output (other than 1) would be needed for testing purposes.
4. Connect the output relay so that its operation will trip the test set and stop the timer.
5. Connect the current output of the test set to the A-phase current transformer input.
6. Ensure that the timer starts when the current is applied.

---

### 20.7.3 PERFORMING THE TEST

1. Ensure that the timer is reset.
2. Apply a current of twice the setting shown in the **I>1 Current Set** setting in the **CORRESPONDING CURRENT PROT.** setpoint.
3. Note the time displayed when the timer stops.
4. Check that the red trip LED has illuminated.

---

### 20.7.4 CHECK THE OPERATING TIME

Check that the operating time recorded by the timer is within the range shown in the technical specification for each function.

For all characteristics, allowance must be made for the accuracy of the test equipment being used.



**Caution:**  
On completion of the tests, you must restore all settings to customer specifications.



## 20.8 ONLOAD CHECKS



**Warning:**  
Onload checks are potentially very dangerous and may only be carried out by qualified and authorised personnel.

Onload checks can only be carried out if there are no restrictions preventing the energisation of the plant, and the other devices in the group have already been commissioned.

Remove all test leads and temporary shorting links, then replace any external wiring that has been removed to allow testing.



**Warning:**  
If any external wiring has been disconnected for the commissioning process, replace it in accordance with the relevant external connection or scheme diagram.



**Warning:**  
Ensure that the IED is in service and that the test mode is disabled.

### 20.8.1 CONFIRM CURRENT CONNECTIONS

1. Measure the current transformer secondary values for each input using a multimeter connected in series with the corresponding current input, or using an amperometric clamp.
2. Check that the current transformer polarities are correct by measuring the phase angle between the current and voltage, either against a phase meter already installed on site and known to be correct or by determining the direction of power flow by contacting the system control centre.
3. Ensure the current flowing in the neutral circuit of the current transformers is negligible.
4. Compare the values of the secondary phase currents and phase angle with the measured values, IED current measurements can be found in the **MEASUREMENTS\CT1 BANK-B** menu.

### 20.8.2 CONFIRM VOLTAGE CONNECTIONS

1. Using a multimeter, measure the voltage transformer secondary voltages to ensure they are correctly rated.
2. Check that the system phase rotation is correct using a phase rotation meter.
3. Compare the values of the secondary phase voltages with the measured values, IED voltage measurements can be found in the **MEASUREMENTS\PH VT1 BANK-A** and **MEASUREMENTS\4th VT1 BANK-A** menus.

Measurements\PH VT1 Bank-A and Measurement\4th VT1 Bank-A Menus	Corresponding VT Ratio in CT and VT Ratios Column
VT1 VAN VT1 VBN VT1 VCN VT1 VAB VT1 VBC VT1 VCA	Main VT Primary/Main VT Sec'y
4th VT1 Mag	4th VT Primary/4th VT Sec'y

---

### 20.8.3 ON-LOAD DIRECTIONAL TEST

This test ensures that directional overcurrent functions have the correct forward/reverse response to fault and load conditions. The availability of the directional overcurrent functions will be correct and model dependant. For this test you must first know the actual direction of power flow on the system. If you do not already know this you must determine it using adjacent instrumentation or protection already in-service.

- For load current flowing in the Forward direction (power export to the remote line end), the **A Phase Watts** value in the **MEASUREMENTS\POWER 1** menu should show positive power signing.
- For load current flowing in the Reverse direction (power import from the remote line end), the **A Phase Watts** value in the **MEASUREMENTS\POWER 1** menu should show negative power signing.

In the event of any uncertainty, check the phase angle of the phase currents with respect to their phase voltage.

---

## 20.9 FINAL CHECKS

---

1. Remove all test leads and temporary shorting leads.
2. If you have had to disconnect any of the external wiring in order to perform the wiring verification tests, replace all wiring, fuses and links in accordance with the relevant external connection or scheme diagram.
3. The settings applied should be carefully checked against the required application-specific settings to ensure that they are correct, and have not been mistakenly altered during testing.
4. Ensure that all protection elements required have been set to *Enabled* in the **SETPOINTS** menus.
5. Ensure that the IED has been restored to service by checking that the **Simulation State** setting in the **SETPOINTS\TESTING\SIMULATION\SETUP** menu is set to *Disabled*.
6. If the IED is in a new installation or the circuit breaker has just been maintained, the circuit breaker maintenance and current counters should be zero. These counters can be reset using the **All Records** command under **SETPOINTS\DEVICE\CLEAR RECORDS** menu. If the required access level is not active, the device will prompt for a password to be entered so that the setting change can be made.
7. If the menu language has been changed to allow accurate testing it should be restored to the customer's preferred language.
8. If a test block is installed, remove the test plug and replace all wiring so that the protection is put into service.
9. Ensure that all event records, fault records, disturbance records, alarms and LEDs and communications statistics have been reset.

**Note:**

Remember to restore the language setting to the customer's preferred language on completion.

## CHAPTER 21

# MAINTENANCE AND TROUBLESHOOTING

## 21.1 CHAPTER OVERVIEW

The Maintenance and Troubleshooting chapter provides details of how to maintain and troubleshoot Multilin Agile products. Always follow the warning signs in this chapter. Failure to do so may result injury or defective equipment.



**Caution:**

**Before carrying out any work on the equipment you should be familiar with the contents of the Safety Section or the Safety Guide SFTY/4LM and the ratings on the equipment's rating label.**

The troubleshooting part of the chapter allows an error condition on the IED to be identified so that appropriate corrective action can be taken.

If the device develops a fault, it is usually possible to identify which module needs replacing. It is not possible to perform an on-site repair to a faulty module.

If you return a faulty unit or module to the manufacturer or one of their approved service centres, you should include a completed copy of the Repair or Modification Return Authorization (RMA) form.

This chapter contains the following sections:


Chapter Overview	487
Maintenance	488
Maintenance Checks	495
Replacing the Unit	497
Cleaning	498
Troubleshooting	499

## 21.2 MAINTENANCE

### 21.2.1 MOTOR HEALTH REPORT

This section describes the behaviour of the Motor Health Report for Multilin Agile. This feature is only available in EnerVista D&I Setup software in path: *Maintenance* → *Motor Operational Report*.

Selecting this menu item will open a dialog that allows the user to customize the Report before it is generated.



**PDF File Name:** By default the 'PDF File Name' is stored in the folder *\Documents and Settings\All Users\Documents\GE Power Management\8SeriesPC* or *\Users\Public\Documents\GE Power Management\8SeriesPC*, depending on the operating system. The filename will use the device name (taken from the environment) with *\_Health\_Report* appended and with the extension **PDF**. The customer can modify the path and the filename.

**Report Created by:** The 'Report Created by' field is editable and defaulted to the windows login name. The user can modify the field.

**Motor Name:** The 'Motor Name' field is defaulted to the setting of Device Name of the motor. The user cannot modify the field.

#### Report Periods:

##### Last 24 hrs

- 24hrs ending with: 59min of the current hour

##### Yesterday

- 00:00:00 of the previous day to 23:59:59 of the previous day

##### Last 7 Days

- 00:00:00 (6 days ago) to 23:59:59 today

##### Last Week

- 00:00:00 Monday to 23:59:59 Sunday (Sunday that has just been passed)

##### Last 30 Days

- 00:00:00 am (29 days ago) to 23:59:59 of the current day

##### Last Month

- 00:00:00 of 1st day to 23:59:59 of the last day of the previous month

**Last Year**

- 00:00:00 of Jan 1st to 23:59:59 of Dec 31st of the last year

**Custom**


- The minutes field in the Custom Date Range selection does not allowed editing
- The oldest date is 2008/01/01

**21.2.1.1 MOTOR HEALTH REPORT LAYOUT**

The Health Report contains information that is divided into seven categories.

**Overview:**

OVERVIEW	
Requested Period	Jun 18, 2024 12:00 AM - Jun 19, 2024 10:59 AM
Report Created By	Admin
Motor Name	Relay 1
Protection Device	P24DB1DJ3C0080E
Firmware Version	05A
Motor FLA	100 A
Rated Voltage	600 V
Phase Rotation	ABC
System Frequency	50 Hz
Motor Running Time	1 days 7 hours
Generated At	Jun 19, 2024 10:00 AM




**Status Overview:**

Available Time Range		Jul 26, 2024 - Jul 26, 2024		
Status	Parameter	% Change	Oldest Record ( Jul 26, 2024 )	Latest Record ( Jul 26, 2024 )
<span style="background-color: red; color: white;">■</span>	Acceleration Time	Increased	0.0 s	18.0 s
<span style="background-color: green; color: white;">■</span>	Starting Current	Increased	0.0 xFLA	4.0 xFLA
<span style="background-color: red; color: white;">■</span>	Starting Capacity	Increased	0 %	77 %
<span style="background-color: green; color: white;">■</span>	Average Motor Load	Decreased 2.0 %	0.51 xFLA	0.50 xFLA
<span style="background-color: red; color: white;">■</span>	Run Time After Start		0 days 0 min	0 days 0 min
<span style="background-color: red; color: white;">■</span>	Average kW	Decreased 43.5 %	17.00 KW	9.60 KW
<span style="background-color: red; color: white;">■</span>	Average kvar	Decreased 100.0 %	-0.10 Kvar	0.00 Kvar
<span style="background-color: red; color: white;">■</span>	Average PF		-0.99	-0.99

**Trip Summary:**

Trip Summary		
Available Time Range		Jul 26, 2024 12:00 AM - Jul 27, 2024 02:59 PM
Overload / Thermal	1	
Current	14	
Voltage / Frequency / Power	22	
Miscellaneous	12	



**Motor Operating History:**



**Motor Starting Learned Information:**


**LDR verification:**

The 'Available Data Range' should show the time span of the Learned Data Records used for the report. This time range may be less than the requested time range for the entire report.






**Motor Stopping/Tripping:**



**Motor Start Records:**

Channel
lavg
lub
lgnd
Van or Vab
P
Q
PF
TC Used
Frequency
Status - Starting
Status - Running
Status - Overload
Status - Stopped
Status - Tripped



In summary, lists the actual values to be used in each category. Details can be referred to the individual section.

Category	Name	Comment
Device Overview	Motor Running time	Total motor running time.
Status Overview	Acceleration Time	Oldest and latest values; PC program calculates trends and trend color.
	Starting Current	
	Starting Capacity	
	Average Motor Load	
	Average kW	
	Average kvar	
	Average PF	
	Run Time After Start	
Trip Summary	Overload/Thermal	Statistical values extracted from operands in the available time range.
	Current	
	Voltage/Frequency/Power	
	Miscellaneous	

Category	Name	Comment
Motor Operating History	Motor Starting/Running	Statistical values extracted from operands in the available time range.
	Manual Stop Commands	
	Trip Commands	
	Lockouts	
	Alarm Conditions	
	Emergency Restarts	
Motor Starting Learned Information	Acceleration Time	All values in the available time range, illustrated in Chart and Table.
	Starting Current	
	Starting Capacity	
	Average Motor Load	
	Average kW	
	Average kvar	
	Average PF	
	Run Time After Start	
Motor Start Records	lavg	6 records: first record since record cleared, and 5 latest records. lavg is extracted from Start Records, Vavg is calculated by PC.
	Unbalance Current	
	Ground Current	
	$V_{avg}=(V_a+V_b+V_c)/3$	
	P	
	Q	
	PF	
	TCU	
	Frequency	
	Motor Status	

Category	Name	Comment
Motor Stopping/Tripping	Overload Trip	Statistical values extracted from operands in the available time range.
	Mechanical Jam	
	Short Circuit	
	Under Power	
	Current Unbalance	
	Ground Fault	
	Under/Over Voltage	
	Under/Over Frequency	
	Manual/Remote Stop	
	Acceleration Time	
	Over Current	
	Under Current	
	Phase Reversal	
	Directional Power	

---

## 21.3 MAINTENANCE CHECKS

---

In view of the critical nature of the application, GE Vernova products should be checked at regular intervals to confirm they are operating correctly. GE Vernova products are designed for a life in excess of 20 years when the environment and electrical conditions are within stated specifications.

The devices are self-supervising and so require less maintenance than earlier designs of protection devices. Most problems will result in an alarm, indicating that remedial action should be taken. However, some periodic tests should be carried out to ensure that they are functioning correctly and that the external wiring is intact. It is the responsibility of the customer to define the interval between maintenance periods. If your organisation has a Preventative Maintenance Policy, the recommended product checks should be included in the regular program. Maintenance periods depend on many factors, such as:

- The operating environment
- The accessibility of the site
- The amount of available manpower
- The importance of the installation in the power system
- The consequences of failure

Although some functionality checks can be performed from a remote location, these are predominantly restricted to checking that the unit is measuring the applied currents and voltages accurately, and checking the circuit breaker maintenance counters. For this reason, maintenance checks should also be performed locally at the substation.



**Caution:**  
Before carrying out any work on the equipment you should be familiar with the contents of the Safety Section or the Safety Guide SFTY/4LM and the ratings on the equipment's rating label.

---

### 21.3.1 TARGETS AND ALARMS

Target messages are automatically displayed for any active condition on the IED such as pickups, trips, or alarms or minor or major errors. The IED displays the most recent event first, active target messages will be displayed until the conditions clear.

Target and Alarm messages can be reviewed by accessing the Targets menu using the Up and Down keys in the display, or using the Read key in case the Alarm LED is ON.

For Non-latched Alarms the Alarm LED flashes until the alarm conditions disappears, then it switches OFF.

For Latched Alarms the Alarm LED flashes until the alarm condition disappears, then changes to constantly ON.

When the alarms are cleared, the Alarm LED switches OFF.

---

### 21.3.2 OPTO-INPUTS

Check the opto-inputs by repeating the commissioning test detailed in the Commissioning chapter.

---

### 21.3.3 RELAY OUTPUT CONTACTS

Check the relay output contacts by repeating the commissioning test detailed in the Commissioning chapter.

---

### 21.3.4 MEASUREMENT ACCURACY

If the power system is energised, the measured values can be compared with known system values to check that they are in the expected range. If they are within a set range, this indicates that the A/D conversion and the calculations are being performed correctly. Suitable test methods can be found in Commissioning chapter.

Alternatively, the measured values can be checked against known values injected into the device using the test block, (if fitted) or injected directly into the device's terminals. Suitable test methods can be found in the Commissioning chapter. These tests will prove the calibration accuracy is being maintained.

---

### 21.3.5 EXTERNAL DAMAGE

Complete a visual inspection for any damage, corrosion, dust, or loose wires.

---

### 21.3.6 RECORDS

Check Event Recorder file downloads, with further events analysis.

---

### 21.3.7 OUT-OF-SERVICE MAINTENANCE

1. Check wiring connections for firmness.
2. Analogue values (currents/voltages) injection test and metering accuracy verification. Calibrated test equipment is required.
3. Protection elements setting verification (analogue values injection or visual verification of setting file entries against IED settings schedule).
4. Opto-inputs and relay output contacts verification. This test can be conducted by direct change of state forcing or as part of the system functional testing.
5. Visual inspection for any damage, corrosion, or dust.
6. Event recorder file download with further events analysis.

*Note:*

*To avoid deterioration of electrolytic capacitors, power up units that are stored in a deenergized state once per year, for one hour continuously.*

---

### 21.3.8 UNSCHEDULED MAINTENANCE (SYSTEM INTERRUPTION)

View the event recorder and oscillography for correct operation of opto-inputs, relay output contacts and elements.

## 21.4 REPLACING THE UNIT

If your product should develop a fault while in service, depending on the nature of the fault, the watchdog contacts will change state and an alarm condition will be flagged. In the case of a fault, you should normally replace the cradle which slides easily out of the case. This can be done without disturbing the scheme wiring.

In the unlikely event that the problem lies with the wiring and/or terminals, then you must replace the complete device, rewire and re-commission the device.



**Caution:**  
If the repair is not performed by an approved service centre, the warranty will be invalidated.



**Caution:**  
Before carrying out any work on the equipment, you should be familiar with the contents of the Safety Information section of this guide or the Safety Guide SFTY/4LM, as well as the ratings on the equipment's rating label. This should ensure that no damage is caused by incorrect handling of the electronic components.



**Warning:**  
Before working at the rear of the unit, isolate all voltage and current supplying it.

To replace the cradle without disturbing the case and wiring:

1. Remove the faceplate.
2. Carefully withdraw the cradle from the front.

To reinstall the unit, follow the above instructions in reverse, ensuring that each connector is relocated in the correct position and all connections are replaced. The terminal blocks are labelled alphabetically with 'A' on the right hand side when viewed from the rear.

Once the unit has been reinstalled, it should be re-commissioned as set out in the Commissioning chapter.

---

## 21.5 CLEANING

---

**Warning:**

**Before cleaning the device, ensure that all AC and DC supplies and transformer connections are isolated, to prevent any chance of an electric shock while cleaning.**

Only clean the equipment with a lint-free cloth dampened with clean water. Do not use detergents, solvents or abrasive cleaners as they may damage the product's surfaces and leave a conductive residue.



## 21.6 TROUBLESHOOTING

### 21.6.1 SELF-DIAGNOSTIC SOFTWARE

The device includes several self-monitoring functions to check the operation of its hardware and software while in service. If there is a problem with the hardware or software, it should be able to detect and report the problem.

The self-monitoring is implemented in two stages: firstly a thorough diagnostic check which is performed on boot-up, and secondly a continuous self-checking operation, which checks the operation of the critical functions whilst it is in service.

### 21.6.2 POWER-UP ERRORS

If the IED does not appear to power up, use the following checks to determine whether the fault is in the external wiring, auxiliary fuse, IED power supply module or IED front panel.

Test	Check	Action
1	Measure the voltage on terminals A2 and A1. Verify the voltage level and polarity against the rating label	If the auxiliary voltage is correct, go to test 2. Otherwise check the wiring and fuses in the auxiliary supply.
2	Check the LEDs and LCD backlight switch on at power-up. Also check the N/C (normally closed) watchdog contact to see if it opens.	If the LEDs and LCD backlight do not switch on and the N/C Watchdog contact does not open, the fault is probably in the IED PSU.

### 21.6.3 SELF-TEST ERRORS

The IED performs self diagnostics at initialisation (after power up), and continuously as a background task to ensure that the hardware and software are functioning correctly.

There are two types of self-test warnings indicating either a minor or major problem. Minor problems indicate a problem with the IED that does not compromise protection of the power system. Major errors indicate a problem with the IED which takes it out of service.



**Caution:**  
Self-Test Warnings may indicate a serious problem with the relay hardware.

Upon detection of a minor problem, the IED will:

- Display the detailed description of the error on the IED display as a target message
- Record the minor self-test error in the Event Recorder.
- Flash the ALARM LED.

When Trip is selected as a function, upon detection of a major problem, the relay will:


- Energize the relay assigned under setting **Output Relay**
- De-energize all the other output relays
- Turn the "IN SERVICE" LED orange
- Flash the "Alarm" LED
- Assert 'Any Major Error' FlexLogic operand
- Display the major self-test error as a target message
- Record the major self-test error in the Event Recorder
- Prevent the execution of protection functions including the Trip Element, by taking the relay out of service

When Alarm is selected as a function, upon detection of a major problem, the relay will:

- Flash the "ALARM" LED
- Assert 'Any Major Error' FlexLogic operand
- Display the **major self-test** error as a target message
- Record the **major self-test** error in the Event Recorder
- Continue to run protection elements as normal, keeping the relay in service

**Note:**

The normally closed Critical Failure Relay (Relay Output 8 or 6 depending on the Binary Input/Output Options ordered) is energised (open) when the IED is in-service, and no major error is present.



**Figure 204: Minor error events and message generation**




Figure 205: Major error events and message generation

Minor self-test errors

Self-Test Error Message	Description of the Problem	How Often the Test is Performed	What to Do
Order Code Error	Hardware doesn't match order code	Every 2.5 seconds	If alert doesn't self-reset, then contact factory.  Otherwise monitor re-occurrences as a momentary error was detected but recovered.
CPU S/N Invalid	CPU card doesn't have valid data to match the order code.	Every 2.5 seconds	
Slot 'n' IO S/N Invalid (see note below)	IO card located in slot 'n' doesn't have valid data to match the order code.	Every 2.5 seconds	
PSU S/N Invalid	Power Supply Unit doesn't have valid data to match the order code.	Every 2.5 seconds	
RTC Error	The CPU cannot read the time from the real time clock	Every 2.5 seconds	
Product Serial Invalid	The product serial number doesn't match the product type	Every 2.5 seconds	
Serial Comm.1 Error	Errors when initializing or accessing serial port 1.	Every 2.5 seconds	
Serial Comm.2 Error	Errors when initializing or accessing serial port 2.	Every 2.5 seconds	
FLASH Error	The permanent storage memory has been corrupted	Every 2.5 seconds	
SPI Error	Communication error between CPU and LEDs, Keypad or peripheral memory devices	Every 2.5 seconds	
Invalid MAC Address	MAC address is not in the product range	Every 2.5 seconds	

Self-Test Error Message	Description of the Problem	How Often the Test is Performed	What to Do
Link Error Primary	ETH1 port is not connected	Every 2.5 seconds	Ensure Ethernet cable is connected, check cable functionality (i.e. physical damage or perform continuity test) and ensure master or peer device is functioning. If none of these apply, contact the factory.
Link Error Secondary	ETH2 port is not connected	Every 2.5 seconds	
Link Error Third	ETH3 port is not connected	Every 2.5 seconds	
Traffic Error Primary	Abnormally high amount of Broadcast and Uni-cast traffic on Eth1 port	Every 2.5 seconds	Contact site IT department to check network for malfunctioning devices
Ambient Temperature >80C	The ambient temperature surrounding the product has exceeded 80°C (176°F)	Every 2.5 seconds	Inspect mounting enclosure for unexpected heat sources (i.e loose primary cables) and remove accordingly
IRIG-B Failure	A bad IRIG-B input signal has been detected	Every 2.5 seconds	Ensure IRIG-B cable is connected, check cable functionality (i.e. physical damage or perform continuity test), ensure IRIG-B receiver is functioning, and check input signal level (it may be less than specification). If none of these apply, contact the factory.
STNP Failure	Synchronization from a SNTP server failed.	Every 2.5 seconds	Ensure Ethernet connection, check cable functionality (i.e. physical damage) and ensure SNTP server configuration is correct. If none of these apply, contact the factory.
PTP Failure	Synchronization from a PTP master failed.	Every 2.5 seconds	Ensure Ethernet connection, check cable functionality (i.e. physical damage) and ensure PTP settings are correct. If none of these apply, contact the factory.
Version Mismatch	CPU firmware revision must match with Order Code and CID.	Boot-up and Every 2.5 seconds	Ensure CPU was uploaded during the upgrade process. Ensure Order Code and CID are correct.
SelfTestFWUpdate	The updating of the firmware failed	Every 2.5 seconds	Re-try uploading firmware. If the upload doesn't work a second time contact factory

### Major self-test errors

Self-Test Error Message	Description of the Problem	How Often the Test is Performed	What to Do
Out-Of-Service	The <b>Device InService</b> setting at <b>SETPOINTS\DEVICE\INSTALLATION</b> menu is not in a programmed state (Not Ready).	On power up and whenever <b>Device InService</b> setting at <b>SETPOINTS\DEVICE\INSTALLATION</b> menu	Program all required settings and then set the <b>Device InService</b> setting at <b>SETPOINTS\DEVICE\INSTALLATION</b> menu to Ready.
Major Self-Test (error code)	Unit hardware failure detected	Every 2.5 seconds	Contact the factory and supply the failure code as noted on the display.

where 'n' is the slot ID (i.e. F, G, H etc.)

Slot F =IO Board

Slot G = IO Extension Board

Slot J = CT/VT Board

Under both conditions (minor and/or major errors), the targets cannot be cleared if the error is still active.

### Major self-test errors failure codes (Format Code FC240)

Code	Type	Definition	Description
FC240	unsigned 32 bits	Self Test Error	
	0x00000001	Order Code Error	Hardware doesn't match the order code
	0x00000002	System Health Error	System health is compromised due to a task failure flagged by software watchdogs
	0x00000004	CPU Serial# Invalid	CPU card doesn't have valid data to match the order code
	0x00000008	Slot F I/O SN Invalid	IO card located in slot F doesn't have valid data to match the order code
	0x00000010	Slot G I/O SN Invalid	IO card located in slot G doesn't have valid data to match the order code
	0x00000100	Slot J I/O SN Invalid	IO card located in slot J doesn't have valid data to match the order code
	0x00002000	CalibrationError	Calibration procedure failed due to EEPROM access error, bad calibration checksum or bad calibration data
	0x00004000	RTC Error	The CPU cannot read the time from the real time clock
	0x00010000	FLASH Error	The permanent storage memory has been corrupted or damaged, or it is near the end of its lifetime
	0x00020000	EEPROM Error	EEPROM access from host failed due to a read error, write error or CRC error
	0x00020000	Ambient Temperature <80°C	The ambient temperature surrounding the product has exceeded 80°C
	0x00800000	CriticalPath Error	A failure along the metering path was detected, because no measurement events arrived within the corresponding timeout

## 21.6.4 ERROR CODE DURING OPERATION

The IED performs continuous self-checking. If the IED detects an error it displays an error message, logs a maintenance record in the event recorder. A permanent problem (for example due to a hardware fault) is usually detected in the power-up sequence. By examining the maintenance record logged in the event recorder, the nature of the detected fault can be determined.

For more information, refer to Self-Test Errors section.

## 21.6.5 MAL-OPERATION DURING TESTING

### 21.6.5.1 FAILURE OF RELAY OUTPUT CONTACTS

An apparent failure of the relay output contacts can be caused by the configuration. Perform the following tests to identify the real cause of the failure. The self-tests verify that the coils of the output relay contacts have been energised. An error is displayed if there is a fault in the input/output board.

Test	Check	Action
1	Is the Out of Service LED ON?	If this LED is ON, the relay may be not programmed (out of service by setting), in test mode or the protection has been disabled due to a hardware verify error. Verify if the Device InService setting at <b>SETPOINTS\DEVICE\INSTALLATION</b> menu is set to Ready. Verify if the Simulation State setting at <b>SETPOINTS\TESTING\SIMULATION\SETUP</b> menu is set to Disabled. Verify that there is not Major Self-Test Error, this can be checked at <b>TARGETS</b> menu or at <b>RECORDS\EVENTS</b> menu
2	Examine the relay output contact status in the <b>DEVICE STATUS\RELAY OUTPUTS</b> menu.	The relay output contacts can be forced using the test mode of the device to check its correct operation (besides the assignation for the protection element operation). If the relay contact output status are operated, go to test 4; if not, go to test 3.
3	Examine the event recorder or the fault record or use the engineering port to check if the protection element is operating correctly.	If the protection element does not operate, check if the test is correctly applied. If the protection element operates, check the protection element settings and the Flexlogic Equation Editor to make sure the relay output contacts (Relay O/P) are correctly selected and configured.
4	Using the <b>Relay Outputs</b> settings per each relay output contact under the <b>SETPOINTS\TESTING</b> menu, apply a test pattern to the relevant relay output contacts. Take into account that to force any relay output contact status in the IED, the <b>Simulation State</b> setting under <b>SETPOINTS\TESTING\SIMULATION\SETUP</b> menu should be set to any value but Disabled and that the <b>Force Relays</b> setting under <b>SETPOINTS\TESTING\SIMULATION\SETUP</b> menu should be set to Enabled. Refer to Commissioning Test Menu section in Commissioning Instructions chapter for more information. Consult the correct external connection diagram and use a continuity tester at the rear of the relay to check the IED output contacts operate.	If the relay output contacty operates, the problem must be in the external wiring to the IED. If the output relay does not operate the output relay contacts may have failed (the self-tests verify that the relay coil is being energised). Ensure the closed resistance is not too high for the continuity tester to detect. When the tests are finished (if the testing mode has been used), ensure that all the testing settings under <b>SETPOINTS\TESTING</b> menu have been set to its default values.

### 21.6.5.2 FAILURE OF OPTO-INPUTS

The opto-isolated inputs can be mapped onto the IEDs internal signals using the Flexlogic Equation Editor. If an input is not recognised by the scheme logic, use the Opto Inputs settings per each opto-input under the **SETPOINTS\TESTING** menu to check whether the problem is in the opto-input itself, or the mapping of its signal to the scheme logic functions. Take into account that to use the Opto Inputs settings under the **SETPOINT\TESTING** menu, the Simulation State setting under the **SETPOINTS\TESTING\SIMULATION\SETUP** menu should be set to any value but Disabled. After testing, ensure that all the Testing settings under the **SETPOINTS\TESTING** menu have been set to its default values.

For more information, refer to Commissioning Test Menu section in Commissioning Instructions chapter .

If the device does not correctly read the opto-input state, test the applied signal. Verify the connections to the opto-input using the wiring diagram and the nominal voltage settings in **OPTO CONFIG**. To do this:

1. Select the nominal battery voltage for all opto-inputs by selecting one of the five standard ratings in the **Global Nominal V** setting in the **SETPOINTS\INPUTS\OPTO CONFIG** menu
2. Using a voltmeter, check that the voltage on its input terminals is greater than the minimum pickup level (See the Technical Specifications chapter for opto-input pickup levels).

If the signal is correctly applied, this indicates failure of an opto-input, in which case the complete cradle should be replaced.

### 21.6.5.3 INCORRECT ANALOGUE SIGNALS

If the measured analogue quantities do not seem correct, use the measurement function to determine the type of problem.

1. Compare the displayed measured values with the actual magnitudes at the terminals.
2. Check the correct terminals are used.
3. Check the CT and VT ratios set are correct.
4. Check the phase displacement to confirm the inputs are correctly connected.

---

### 21.6.6 FLEXLOGIC EQUATION EDITOR TROUBLESHOOTING

A failure to open a connection could be due to one or more of the following:

- The IED address is not valid
- Password in not valid
- Communication set-up is not correct
- Transaction values are not suitable for the IED or the type of connection
- The connection cable is not wired correctly or broken
- If any communications hardware medium converter is used, it may be incorrectly set.

---

### 21.6.7 USB PORT TROUBLESHOOTING

If it is not possible to communicate with the IED using the USB port, do the following checks to troubleshoot the issue:

- Verify the USB settings at **DEVICE\COMMUNICATIONS\USB** path
  - Verify that the **USB Port** setting is set to Enabled.
  - Verify that the **USB IP Addr** and **USB Subnet Mask** settings are set properly and match the ones being used to access to the device through the EnerVista Configuration software.

In case the USB settings would be properly set and the port enabled and the communication still not be able to be established:

- Verify that the USB cable is ok.
- If the cable is ok, verify that the USB Driver "GE RNDIS Device" is visible under Network adapters at Device Manager on your computer (Control Panel\System and Security\System, under System Tools)

---

### 21.6.8 REPAIR AND MODIFICATION PROCEDURE

Please follow these steps to return a product to us:

1. Get the Repair and Modification Return Authorization (RMA) form  
An electronic version of the RMA form is available from the following:  
[GA.support@gevernova.com](mailto:GA.support@gevernova.com)
2. Fill in the RMA form  
Fill in only the white part of the form.  
If an RCA (root cause analysis) is required, indicate it on the RMA form.  
Please ensure that all fields marked **(M)** are completed such as:
  - Equipment model
  - Model No. and Serial No.
  - Description of failure or modification required (please be specific)
  - Value for customs (in case the product requires export)
  - Delivery and invoice addresses
  - Contact details

3. Please ensure that all required files for RMA investigation are provided:
  - CID file (setting and configuration file)
  - Event Recorder (SOE)
  - Disturbance Recorder (Waveform Capture)
  - Service Report (where available).
4. Send the RMA form to your local contact  
For a list of local service contacts worldwide, email us at:  
[GA.support@gevernova.com](mailto:GA.support@gevernova.com)
5. The local service contact provides the shipping information  
Your local service contact provides you with all the information needed to ship the product:
  - Pricing details
  - RMA number
  - Repair centre address

If required, an acceptance of the quote must be delivered before going to the next stage.
6. Send the product to the repair centre
  - Address the shipment to the repair centre specified by your local contact
  - Make sure all items are packaged in an anti-static bag and foam protection
  - Make sure the shipment is properly packaged, any damage during transportation may void the warranty
  - Make sure a copy of the import invoice is attached with the returned unit
  - Make sure a copy of the RMA form is attached with the returned unit
  - E-mail or fax a copy of the import invoice and airway bill document to your local contact.



## CHAPTER 22

# TECHNICAL SPECIFICATIONS

## 22.1 CHAPTER OVERVIEW

This chapter describes the technical specifications of the product.

**Note:**

*To obtain the total operating time, i.e. from the presence of a trip condition to initiation of a trip, add 8 ms output relay time to the operate times listed below.*

*Metering and protection level accuracy apply at standard state conditions (25°C, 1 atm).*

This chapter contains the following sections:

Chapter Overview	508
Interfaces	509
Performance of Motor Protection Functions	511
Performance of Current Protection Functions	516
Performance of Voltage Protection Functions	518
Power Protection Functions	520
Performance of Frequency Protection Functions	521
Performance of Monitoring and Control Functions	522
Measurements and Recording	527
Regulatory Compliance	529
Ratings	531
Power Supply	532
Input/Output Connections	533
Environmental Conditions	536
Type Tests	537
Electromagnetic Compatibility	538

## 22.2 INTERFACES

### 22.2.1 FRONT USB PORT

Front USB Port	
Use	For local connection to laptop for configuration purposes and firmware downloads
Connector	USB type B
Supported protocols	Modbus TCP, DNP3oE, IEC 61850-Ed2 (*)
Isolation	Isolation to PELV level
Constraints	Maximum cable length 5 m

### 22.2.2 REAR SERIAL PORT 1 (COM1)

Rear Serial Port 1 (COM1)	
Use	For SCADA communications (multi-drop)
Standard	EIA(RS)485, IRIG-B
Connector	General purpose pluggable terminal block, 3.5 mm screws (3 wire)
Cable	Screened twisted pair (STP)
Supported protocols	Modbus RTU, DNP3 Serial, IEC 60870-5-103
Isolation	Isolation to PELV level
Constraints	Maximum cable length 1000 m

### 22.2.3 REAR SERIAL PORT 2 (COM2)

Optional Rear Serial Port 2 (COM2) *	
Use	For SCADA communications (multi-drop)
Standard	EIA(RS)485
Connector	General purpose pluggable terminal block, 3.5 mm screws (3 wire)
Cable	Screened twisted pair (STP)
Supported protocols	Modbus RTU, DNP3 Serial, IEC 60870-5-103
Isolation	Isolation to PELV level
Constraints	Maximum cable length 1000 m
* Hardware selection is Cortec dependant. See ordering options for more details.	

### 22.2.4 IRIG-B PORT (SHARED WITH REAR SERIAL PORT COM1)

IRIG-B Interface (De-modulated)	
Use	External clock synchronization signal
Standard	IRIG 200-98 format B00X
Connector	Rear serial port 1
Cable type	Screened twisted pair (STP)
Accuracy	< ±1 s per day

### 22.2.5 REAR ETHERNET PORTS COPPER (ETH1, ETH2, ETH3)

Rear Ethernet Ports Using CAT 5/6/7 Wiring *	
Use	Substation Ethernet communications/engineering port
Communication protocol	10BaseT/100BaseTX
Connector	RJ45
Cable type	Screened twisted pair (STP)
Isolation	1 kV
Supported protocols*	Modbus TCP, DNP3oE, IEC 61850-Ed2
Constraints	Maximum cable length 100 m
* Hardware selection and communication protocols supported for each IED are Cortec dependant. See ordering options for more details.	

### 22.2.6 REAR ETHERNET PORTS FIBRE (ETH1, ETH2, ETH3)

Rear Ethernet Ports Using Fibre-optic Cabling *	
Use	IEC 61850 or DNP3oE SCADA communications
Communication protocol	100BaseFX
Connector	UNI SONET OC-3 LC (1 each for Tx and Rx)
Fibre type	Multimode 50/125 µm or 62.5/125 µm
Supported protocols*	Modbus TCP, DNP3oE, IEC 61850-Ed2
Wavelength	1300 nm
* Hardware selection and communication protocols supported for each IED are Cortec dependant. See ordering options for more details.	

## 22.3 PERFORMANCE OF MOTOR PROTECTION FUNCTIONS

### 22.3.1 THERMAL MODEL

Thermal Model	
Thermal Overload Curves	Motor curve, User curves 1/2/3/4/OL, IEC curve
Motor Curve Time Multiplier (Time Dial)	0.00 to 25.00 in steps of 0.01
User Curve Time Multiplier (Time Dial)	0.00 to 600.00 in steps of 0.01
IEC Curve TC (Time Constant) 1(2)	0 to 1000 min. in steps of 1
Thermal Overload Pickup	Overload factor (OL) x FLA
Motor Overload Factor (OL) (*)	1.00 to 1.50 in steps of 0.01
Motor Full Load Current (FLA) (*)	1 to 5000 A in steps of 1

Standard Motor Overload Curve	$t_{\text{trip}} =$	$0.02530337 \times$	$\text{TDM} \times 2.2116623$ $2$ $I_{\text{motor}}^{-1} + 0.05054758 \times$ $\text{FLA}$	$I_{\text{motor}}$ $-1$ $\text{FLA}$
-------------------------------	---------------------	---------------------	---	--

Motor Rated Voltage (*)	1 to 50000 V in steps of 1
Thermal Model Biasing	Current unbalance
Thermal Model Update Rate	1 power cycle
Stopped/Running Cool Time Constants	1 to 1000 min. in steps of 1
Stopped/Running Cool Time Constant Decay	Exponential
Hot/Cold Safe Stall Ratio	0.01 to 1.00 in steps of 0.01
Current Accuracy	Per phase current inputs
Current Source	True RMS
Timer Accuracy	$\pm 100$ ms or $\pm 2\%$ , whichever is greater
Timer Accuracy for Voltage Dependant Overload	$\pm 100$ ms or $\pm 4\%$ , whichever is greater

**Note:**

Motor Overload Factor (OL), Motor Full Load Current (FLA) and Motor Rated Voltage values used at Thermal Model functions can be configured at **Motor OL Factor**, **Motor FL Amps** and **Motor Rated Volt** settings at **SETPOINTS\SYSTEM\MOTOR\SETUP** path.

### 22.3.2 CURRENT UNBALANCE

Current Unbalance	
Unbalance	$\text{Unbal} = (I_2/I_1) \times A_{\text{factor}} \times 100\%$ $A_{\text{factor}} = (I_{\text{avg}}/\text{FLA})$ if $I_{\text{avg}} < \text{FLA}$ $A_{\text{factor}} = 1$ if $I_{\text{avg}} \geq \text{FLA}$
Trip/Alarm Pickup Level (*1) (I2/I1> Trip Set/I2/I1> Alarm Set)	4.0 to 50.0% in steps of 0.1% 4.0 to 40.0% in steps of 0.1% when I2/I1> Input = Lookup Table

Current Unbalance	
Trip Operating Curves (I2/I1> Trip Crv)	Definite Time (DT): T= I2/I1> Trip Dly sec. Inverse Time (IDMT): T= (I2/I1> Trip TMS/[Unbal] <sup>2</sup> ) sec
Trip Time Delay (I2/I1> Trip Dly)	0.00 to 600.00 s in steps of 0.01 s when I2/I1> Trip Crv = DT (Definite Time)
Trip Time Dial Multiplier (TDM) (I2/I1> Trip TMS)	0.00 to 180.00 in steps of 0.01 when I2/I1> Trip Crv = IDMT (Inverse Time)
Trip Maximum Time (I2/I1> Trp MxDly)	0.00 to 1000.00 s in steps of 0.01 s when I2/I1> Trip Crv = IDMT (Inverse Time)
Trip Minimum Time (I2/I1> Trp MnDly)	0.00 to 1000.00 s in steps of 0.01 s when I2/I1> Trip Crv = IDMT (Inverse Time)
Trip Reset Time (I2/I1> Tr tRESET)	0.00 to 1000.00 s in steps of 0.01 s when I2/I1> Trip Crv = IDMT (Inverse Time) 0.00 to 180.00 s in steps of 0.01 s when I2/I1> Trip Crv = DT (Definite Time)
Alarm Time Delay (I2/I1> Alarm Dly)	0.00 to 600.00 s in steps of 0.01 s
Alarm Reset Time (I2/I1> Al tRESET)	0.00 to 180.00 s in steps of 0.01 s
Single Phasing Pickup Level (*2)	unbalance level > 40% or when I <sub>avg</sub> >=25%FLA and current in any phase is less than the cutoff current
Single Phasing Time Delay (*2)	2 seconds
Pickup Accuracy	±2% of reading
Operate Time	<3 cycles at 1.10 x pickup
Timing Accuracy	±3% of operate time or ±2 cycles, whichever is greater
Element	Trip and Alarm
Single Phasing Element	Trip

**Note:**

(\*1) These settings levels are defaulted to 15% and its range goes from 4.0 to 50.0% if VFD Function is set to Disabled at SETPOINT\SYSTEM\MOTOR\VFD path, or if VFD Function is set to Enabled and I2/I1> Input setting is set to I2/I1. If VFD Function is set to Enabled and I2/I1> Input is set to Lookup Table, I2/I1> Trip Set range is from 4.0 to 40.0%.

**Note:**

(\*2) If the unbalance level exceeds 40% or when I<sub>avg</sub> ≥ 25% FLA and current in any one phase is less than the cutoff current, the motor is considered to be single phasing and a trip occurs within 2 seconds. Single phasing protection is disabled if the unbalance trip feature is disabled when I2/I1> Trip setting is set to Disabled.

### 22.3.3 MECHANICAL JAM

Mechanical Jam	
Operating Condition	Phasor or RMS (*)
Arming Condition	Motor not starting or not stopped
Pickup Level (I>[X] MJam Set)	1.00 to 10.00 x FLA in steps of 0.01
Dropout Level	97 to 98% of Pickup

Mechanical Jam	
Level Accuracy	at 0.1 to 2.0 x CT: $\pm 0.5\%$ of reading. at > 2.0 x CT rating: $\pm 1.5\%$ of reading.
Time Delay ( $I > [X]$ MJam Delay)	0.10 to 180.00 s in steps of 0.01 s
Reset Time ( $I > [X]$ MJam tRESET)	0.00 to 180.00 s in steps of 0.01 s
Timer Accuracy	$\pm 3\%$ of delay setting time or $\pm 20$ ms, whichever is greater

**Note:**

(\*) In VFD application, phase currents are switched from Phasor to RMS when setpoint VFD **Function** is *Enabled* and operand 'VFD Not Bypassed' is asserted.

### 22.3.4 UNDERCURRENT

Undercurrent	
Operating Parameter	Per-phase current $I_a, I_b, I_c$ (Phasor or RMS) (*)
Trip/Alarm Pickup Level ( $I < 1$ Trip Set/ $I < 1$ Alarm Set)	0.10 to 0.99 x FLA in steps of 0.01 x FLA
Dropout Level	101 to 104% of Pickup
Trip/Alarm Time Delay ( $I < 1$ Trip Delay/ $I < 1$ Alarm Delay)	0.00 to 600.00 s in steps of 0.01 s
Trip/Alarm Reset Time ( $I < 1$ Trip tRESET/ $I < 1$ Alarm Treset)	0.00 to 180.00 s in steps of 0.01 s
Pickup Accuracy	For 0.1 to 2.0 x CT: $\pm 0.5\%$ of reading or $\pm 0.4\%$ of rated, whichever is greater
Operate Time	<45 ms at 60 Hz <50 ms at 50 Hz
Timer Accuracy	$\pm 3\%$ of delay setting or $\pm 2$ power cycles (whichever is greater) from pickup to operate
Stages:	Trip and Alarm

**Note:**

(\*) In VFD application, phase currents are switched from Phasor to RMS when setpoint VFD **Function** is *Enabled* and operand 'VFD Not Bypassed' is asserted.

### 22.3.5 OVERLOAD ALARM

Overload Alarm	
Operating Parameter	Average phase current (RMS) with ( $I_2/I_1$ ) bias
Pickup Level ( $I_{avg} > 1$ Set)	0.50 to 3.00 x FLA in steps of 0.01 x FLA
Dropout Level	97% to 98% of Pickup
Level Accuracy	For 0.1 to 2.0 x CT: $\pm 0.5\%$ of reading or $\pm 0.4\%$ of rated, whichever is greater For > 2.0 x CT rating $\pm 1.5\%$ of reading

Overload Alarm	
Time Delay ( <i>Iavg</i> >1 Time Dly)	0.00 to 180.00 s in steps of 0.01 s
Reset Time ( <i>Iavg</i> >Rst Time)	0.00 to 180.00 s in steps of 0.01 s
Timer Accuracy	±3% of delay setting or ±½ cycle (whichever is greater) from pickup to operate

### 22.3.6 SHORT CIRCUIT

Short Circuit	
Inputs	RMS Currents (*)
Pickup Level ( <i>I</i> >[X] SC Curr Set)	1.00 to 30.00 x CT in steps of 0.01 x CT
Dropout Level	96 to 99% of Pickup
Time Delay ( <i>I</i> >[X] SC Delay)	0.00 to 600.00 s in steps of 0.01 s
Reset Time ( <i>I</i> >[X] SC tRESET)	0.00 to 180.00 s in steps of 0.01 s
Level Accuracy	For 1.0 to 2.0 x CT: ±0.5% of reading or ±0.4% of rated, whichever is greater For > 2.0 x CT: ±1.5% of reading
Operate Time	< 12 ms at 2 × pickup at 60 Hz < 15 ms at 2 × pickup at 50 Hz
Timer Accuracy	±2% of operate time or ± 1/2 cycle (whichever is greater)
Elements	Trip or Alarm

**Note:**

(\*) In VFD application, currents are switched from RMS to Peak values when setpoint VFD **Function** is *Enabled* and operand 'VFD Not Bypassed' is asserted.

### 22.3.7 GROUND FAULT

Ground Fault	
Operating Parameter:	Ig RMS (IN1 for Standard Earth CT Type, ISEF for Sensitive Earth CT Type)
Trip/Alarm Pickup Level <i>IN1</i> >[X] GF Tr Set/ <i>IN1</i> >[X] GF AI Set	Standard Earth CT Type (1): 0.01 to 10.00 x CT in steps of 0.01 x CT  Sensitive Earth CT Type (2): 0.00100 to 3.00000 x CT in steps of 0.00001 x CT
Dropout Level:	96 to 99% of Pickup
Alarm Pickup Delay ( <i>IN1</i> >[X] GF AI Dly)	0.00 to 180.00 s in steps of 0.01 s
Trip Pickup Delay ( <i>IN1</i> >[X] GF Tr Dly)	0.00 to 1800.00 s in steps of 0.01 s
Level Accuracy:	Standard Earth CT Type (1): at 0.1 to 2.0 x CT: ±0.5% of reading or ±0.4% of rated (whichever is greater) at > 2.0 x CT: ±1.5% of reading > 2.0 x CT rating  Sensitive Earth CT Type ±3% of reading or ±0.5% of rated (whichever is greater)
Operate Time:	< 12 ms at 2 × pickup at 60 Hz < 15 ms at 2 × pickup at 50 Hz



**Ground Fault**

Timing Accuracy:	$\pm 2\%$ of delay setting at $\pm 1$ cycle (whichever is greater) from pickup to operate
------------------	---

**22.3.8 ACCELERATION TIME****Acceleration Time**

Acceleration Current (*)	1.00 to 10.00 x FLA in steps of 0.01
Operating Mode	Definite Time, Adaptive
Timing Accuracy	$\pm 100$ ms or $\pm 0.5\%$ of total time (whichever is greater), applicable to definite time mode only

*Note:*

(\*) *only used in the Adaptive mode.*

## 22.4 PERFORMANCE OF CURRENT PROTECTION FUNCTIONS

### 22.4.1 THREE-PHASE OVERCURRENT PROTECTION (DIRECTIONAL/NON-DIRECTIONAL)

Measured and Derived	
Level accuracy	For 0.1 to 2.0 x CT: $\pm 0.5\%$ of reading or $\pm 0.4\%$ of rated (whichever is greater) For > 2.0 x CT: $\pm 1.5\%$ of reading > 2.0 x CT rating
Dropoff (IDMT and DT)	96 to 99% of pickup
Curve timing accuracy	Currents > 1.03 to 20 x pickup: $\pm 3\%$ of operate time or $\pm 1$ cycle (whichever is greater) from pickup to operate
DT operate	< 12 ms at 2 x pickup at 60 Hz < 15 ms at 2 x pickup at 50 Hz
DT timer accuracy	$\pm 2\%$ of operate time or $\pm \frac{1}{2}$ cycle (whichever is greater) $\frac{1}{2}$
DT reset	Setting $\pm 5\%$
Disengagement	< 40 ms
Repeatability	$\pm 2.5\%$

#### 22.4.1.1 THREE-PHASE OVERCURRENT DIRECTIONAL PARAMETERS

Measured and Derived	
Directional boundary accuracy (RCA $\pm 90\%$ ) angle accuracy	$\pm 2^\circ$ for $I > 0.050 \times CT$ $\pm 5^\circ$ for $I < 0.050 \times CT$

### 22.4.2 EARTH FAULT PROTECTION (DIRECTIONAL/NON-DIRECTIONAL)

Measured and Derived	
Level accuracy	For 0.1 to 2.0 x CT, $\pm 0.5\%$ of reading or $\pm 0.4\%$ of rated (whichever is greater) For > 2.0 x CT, $\pm 1.5\%$ of reading > 2.0 x CT rating
Dropoff (IDMT and DT) for EF1	96 to 99% of pickup
Dropoff (IDMT and DT) for EF2	96 to 99% of pickup
IDMT operate (curve timing accuracy)	Currents > 1.03 to 20 x pickup: $\pm 3\%$ of operate time or $\pm 1$ cycle (whichever is greater) from pickup to operate
DT operate (EF 1)	< 12 ms, for > 2 x pickup at 60 Hz < 15 ms, for > 2 x pickup at 50 Hz
DT operate (EF 2)	< 12 ms, for > 2 x pickup at 60 Hz < 15 ms, for > 2 x pickup at 50 Hz
DT timer accuracy	$\pm 2\%$ of operate time or $\pm \frac{1}{2}$ cycle (whichever is greater)
DT reset	Setting $\pm 5\%$
Repeatability	$\pm 2.5\%$

### 22.4.2.1 EARTH FAULT DIRECTIONAL PARAMETERS

Derived	
Directional boundary pickup (RCA $\pm 90^\circ$ ) angle accuracy	$\pm 2^\circ$ for $I_g > 0.050 \times CT$ $\pm 5^\circ$ for $I_g < 0.050 \times CT$

### 22.4.3 SENSITIVE EARTH FAULT PROTECTION (NON-DIRECTIONAL)

Level accuracy	$\pm 3\%$ of reading or $\pm 0.5\%$ of rated (whichever is greater)
Dropoff (IDMT and DT)	96 to 99% of pickup
IDMT operate (curve timing accuracy)	$> 1.03$ to $20 \times$ pickup: $\pm 3\%$ of operate time or $\pm 1$ cycle (whichever is greater) from pickup to operate
DT operate	$< 12$ ms, for $> 2 \times$ pickup at 60 Hz $< 15$ ms, for $> 2 \times$ pickup at 50 Hz
DT timer accuracy	3% of operate time or $\pm 1$ cycle (whichever is greater)
DT reset	Setting $\pm 5\%$
Disengagement	$< 40$ ms
Repeatability	$\pm 5\%$

### 22.4.4 RESTRICTED EARTH FAULT PROTECTION

High/Low Impedance Restricted Earth Fault (REF) Accuracy	
Pickup	0.050 to 30.000 $\times$ CT in steps of 0.001 $\times$ CT (phase CT)
Level accuracy	For 0.1 to 2.0 $\times$ CT: $\pm 0.5\%$ of reading or $\pm 0.4\%$ of rated (whichever is greater) For $> 2.0 \times$ CT: $\pm 1.5\%$ of reading
Dropoff	96 to 99% of pickup
Operating time	$< 25$ ms at $1.1 \times$ slope $\times I_{max}$ at 60 Hz $< 30$ ms at $1.1 \times$ slope $\times I_{max}$ at 50 Hz
High pickup	Setting $\pm 5\%$
Timer accuracy	$\pm 3\%$ of delay setting or $\pm \frac{1}{2}$ cycle (whichever is greater) from pickup to operate
Repeatability	$< 15\%$

## 22.5 PERFORMANCE OF VOLTAGE PROTECTION FUNCTIONS

### 22.5.1 PHASE REVERSAL

Phase Reversal	
Phase Reversal Condition:	$V_2/V_1=100\%$ when phase to phase voltages are greater than 50% of VT $I_2/I_1=100\%$ when currents are greater than 5% of CT
Configuration:	ABC or ACB phase rotation
Pickup ( <i>Delay</i> )/Dropout ( <i>tRESET</i> ) Time Delay:	0.00 to 180.00 s in steps of 0.01 s
Timer Accuracy:	$\pm 3\%$ of delay setting or $\pm 1\%$ cycle (whichever is greater) from pickup to operate

### 22.5.2 UNDERVOLTAGE PROTECTION

Pickup level	0.00 to 1.50 (VT) in steps of 0.01 VT
Level accuracy (IDMT and DT)	$\pm 0.5\%$ of reading or 0.3 V (whichever is greater) from 10 to 240 V
Dropoff (IDMT and DT)	103 to 105% of pickup or 101 to 103% of pickup (**)
Operate time	< 25 ms at 2 x pickup at 60Hz < 30 ms at 2 x pickup at 50Hz
Timer accuracy	< 0.8 x pickup, $\pm 3\%$ of operate time or 1 cycle (whichever is greater)
Disengagement	< 40 ms
Repeatability	$\pm 1\%$

(\*) The dropoff voltage range is selectable under the **Setpoints\Device\Installation\OV/UV DPO** Range.

### 22.5.3 OVERVOLTAGE PROTECTION

Pickup level	0.02 to 3.00 (VT) in steps of 0.01 VT
Level accuracy (IDMT and DT)	$\pm 0.5\%$ of reading or 0.3 V (whichever is greater) from 10 to 240 V
Dropoff (IDMT and DT)	95 to 97% of pickup or 97 to 99% of Pickup (*)
Operate time	< 25 ms at 2 x pickup at 60Hz < 30 ms at 2 x pickup at 50Hz
Timer accuracy	> 1.2 x pickup, $\pm 3\%$ of operate time or 1 cycle (whichever is greater)
DT reset	Setting $\pm 5\%$
Disengagement	< 40 ms
Repeatability	$\pm 5\%$

(\*) The dropoff voltage range is selectable under the **Setpoints\Device\Installation\OV/UV DPO** Range.

### 22.5.4 RESIDUAL OVERVOLTAGE PROTECTION (DERIVED)

Derived	
Pickup	$\pm 0.5\%$ of reading or 0.3 V (whichever is greater) from 10 to 240 V

Derived	
Dropoff (IDMT and DT)	95 to 97% of pickup or 97 to 99% of Pickup (*)
Operate time	< 25 ms at 2 x pickup at 60Hz < 30 ms at 2 x pickup at 50Hz
Timer accuracy	> 1.2 x pickup, $\pm 3\%$ of operate time or 1 cycle (whichever is greater)
DT reset	Setting $\pm 5\%$
Disengagement	< 40 ms
(*) The dropoff voltage range is selectable under the <b>Setpoints\Device\Installation\OV/UV DPO</b> Range.	

### 22.5.5 POSITIVE SEQUENCE VOLTAGE PROTECTION (UV)

Positive Sequence Undervoltage	
Pick up level	0.00 to 3.00 (VT) in steps of 0.01 x VT
Level accuracy	$\pm 1\%$ of reading or 0.3 V (whichever is greater) from 10 to 208 V
Dropoff (UV)	103 to 105% of pickup or 101 to 103% of Pickup (*)
Operate time	< 25 ms at 2 x pickup at 60Hz < 30 ms at 2 x pickup at 50Hz
Timer accuracy (UV)	< 0.9 x pickup, $\pm 3\%$ of operate time or 1 cycle (whichever is greater) from pickup to operate
(*) The dropoff voltage range is selectable under the <b>Setpoints\Device\Installation\OV/UV DPO</b> Range.	

### 22.5.6 NEGATIVE SEQUENCE VOLTAGE PROTECTION (OV)

Negative Sequence Overvoltage	
Pickup level	0.00 to 3.00 (VT) in steps of 0.01 x VT
Level accuracy	$\pm 1\%$ of reading or 0.3 V (whichever is greater) from 10 to 208 V
Dropoff	95 to 97% of pickup or 97 to 99% of pickup (*)
Operate time	< 25 ms at 2 x pickup at 60Hz < 30 ms at 2 x pickup at 50Hz
Timer accuracy	> 1.2 x pickup, $\pm 3\%$ of operate time or 1 cycle (whichever is greater)
Disengagement	< 35 ms
Repeatability	< 10%
(*) The dropoff voltage range is selectable under the <b>Setpoints\Device\Installation\OV/UV DPO</b> Range.	

## 22.6 POWER PROTECTION FUNCTIONS

### 22.6.1 OVERPOWER/UNDERPOWER PROTECTION

Pickup level	0.000 to 1.200 x Rated Power in steps of 0.001
Level accuracy	$\pm 1.5\%$ or $\pm 0.005$ x Rated Power (whichever is greater)
Hysteresis	2% or 0.001 x Rated Power (whichever is greater)
Operate time	< 50 ms at 1.1 x pickup at 60 Hz < 60 ms at 1.1 x pickup at 50 Hz
Timer accuracy	$\pm 2\%$ or 50ms (whichever is greater)
tRESET	$\pm 5\%$
Disengagement time	< 50 ms
Repeatability	< 10%

## 22.7 PERFORMANCE OF FREQUENCY PROTECTION FUNCTIONS

### 22.7.1 OVERFREQUENCY PROTECTION

Pickup Level	
Normal frequency input	20.00 to 65.00 Hz in steps of 0.01
High-speed freq input	40.00 to 65.00 Hz in steps of 0.01
Level Accuracy	
Normal frequency input	±0.01 Hz (frequency between 40 to 70Hz)
High-speed freq input	±0.02 Hz (frequency between 40 to 70Hz)
Dropoff	Pickup - 0.03 Hz
Timer Accuracy	
Normal frequency input	±2% of delay setting or ±50 ms (whichever is greater) from pickup to operate
High-speed freq input	±2% of delay setting or ±50 ms (whichever is greater)
Operating and Reset Time	
Operating time (0.1 Hz/s change)	Typically 7.5 cycles
Operating time (0.3 Hz/s change)	Typically 7.0 cycles
Operating time (0.5 Hz/s change)	Typically 6.5 cycles

Typical times are average operate times including variables such as frequency change instance, test method, etc., and may vary by ±0.5 cycles.

### 22.7.2 UNDERFREQUENCY PROTECTION

Pickup Level	
Normal frequency input	15.00 to 65.00 Hz in steps of 0.01
High-speed freq input	40.00 to 65.00 Hz in steps of 0.01
Level Accuracy	
Normal frequency input	±0.01 Hz (frequency between 40 to 70Hz)
High-speed freq input	±0.02 Hz (frequency between 40 to 70Hz)
Dropoff	Pickup + 0.03 Hz
Timer Accuracy	
Normal frequency input	±2% of delay setting or ±50 ms (whichever is greater) from pickup to operate
High-speed freq input	±2% of delay setting or ±50 ms (whichever is greater)
Operating and Reset Time	
Operating time (0.1 Hz/s change)	Typically 7.5 cycles
Operating time (0.3 Hz/s change)	Typically 7.0 cycles
Operating time (0.5 Hz/s change)	Typically 6.5 cycles

## 22.8 PERFORMANCE OF MONITORING AND CONTROL FUNCTIONS

### 22.8.1 MOTOR CONTROL (MOTORSTARTING)

#### 22.8.1.1 THERMAL INHIBIT

Thermal Inhibit	
Thermal Inhibit Margin	0 to 25% in steps of 1%
Thermal Capacity Required to Start	0 to 85% in steps of 1%
Timer Accuracy	$\pm 2$ s or $\pm 1\%$ of total time (whichever is greater)

#### 22.8.1.2 MAXIMUM STARTING RATE

Maximum Starting Rate	
Monitored Time Interval	1 to 300 min in steps of 1 min
Maximum Number of Starts	1 to 16 starts in steps of 1
Timer Accuracy	$\pm 2$ s or $\pm 1\%$ of total time (whichever is greater)

#### 22.8.1.3 MAXIMUM COLD/HOT STARTING RATE

Maximum Hot or Cold Start Rate	
Monitored Time Interval	1 to 300 min in steps of 1 min
Maximum Number of Cold Starts	1 to 16 starts in steps of 1
Maximum Number of Hot Starts	1 to 16 starts in steps of 1
Timer Accuracy	$\pm 2$ s or $\pm 1\%$ of total time (whichever is greater)

#### 22.8.1.4 TIME BETWEEN STARTS

Time Between Starts	
Time Between Starts (Minimum Time)	0 to 300 min in steps of 1 min
Timer Accuracy	$\pm 2$ s or $\pm 1\%$ of total time (whichever is greater)

#### 22.8.1.5 RESTART DELAY

Restart Delay	
Restart Delay (Minimum Time)	0 to 65000s in steps of 1 s
Timer Accuracy	$\pm 2$ s or $\pm 1\%$ of total time (whichever is greater)



### 22.8.1.6 REDUCED VOLTAGE START

Reduced Voltage Start	
Transition Mode:	Current Only, Current or Timer, Current and Timer
Start Current Level (Start Curr Set)	0.25 to 3.00 of FLA, in steps of 0.01
Start Timer	1.0 to 600.0 s in steps of 0.1 s

### 22.8.1.7 BREAKER/CONTACTOR CONTROL

Breaker/Contactor Control	
Function	Opens (Stops)/Closes (Starts), blocks, Interlocks to the breaker/contactors

### 22.8.1.8 LOCAL CONTROL MODE (WITH SELECT BEFORE OPERATE)

Local Control Mode (Select Before Operate)	
Number of Elements	1
Select Before Operate Mode	Disabled, Enabled
Mode:	Local Mode ON, Local Mode OFF
Display Status	LM (Local Mode) displayed in banner

### 22.8.1.9 SWITCH CONTROL

Switch Control	
Function	Opens/Closes, blocks, Interlocks to the disconnect switch

### 22.8.1.10 CURRENT TRANSFORMER SUPERVISION

3I0 pickup level	0.050 to 30.000 x CT in steps of 0.001 x CT (phase CT)
IG pickup level	0.050 to 30.000 x CT in steps of 0.001 x CT (ground CT)
3V0 pickup level	0.02 to 3.00 x VT in steps of 0.01 x VT (phase VT)
CTS diff. pickup level	0.050 to 30.000 x CT in steps of 0.001 x CT
Slope range	0 to 100% in steps of 1%
Quotient pickup level	0.00 to 1.00 (I <sub>min</sub> /I <sub>max</sub> )
Dropoff	97 to 98% of Pickup
Level accuracy	For 0.1 to 2 x CT: $\pm 0.5\%$ of reading or $\pm 0.4\%$ of rated (whichever is greater) For > 2 x CT: $\pm 1.5\%$ of reading
Operate time	< 12 ms typical at 3 x pickup at 60 Hz < 15 ms typical at 3 x pickup at 50 Hz
Timer accuracy	$\pm 3\%$ delay setting or $\pm 1/4$ cycle (whichever is greater) from pickup to operate
CTS reset	< 40 ms

**22.8.1.11 VOLTAGE TRANSFORMER SUPERVISION**

Fast block operation	< 25 ms
Fast block reset	< 40 ms
Time delay	±2% or 40 ms, whichever is greater

**22.8.1.12 BREAKER/CONTACTOR STATE AND CONDITION MONITORING**

Operate Condition	Current and breaker/contactator status condition
Monitor Delay	0.0 to 60.0 in steps of 0.1 s
Timing accuracy	±100 ms or ±0.5% of total time (whichever is greater)

**22.8.1.13 FLEXLOGIC TIMERS**

Number of timers	64
Pickup delay	0 to 14400000 ms in steps of 1 ms
Dropout delay	0 to 14400000 ms in steps of 1 ms
Output conditioner timer	Setting ±2% or 50 ms, whichever is greater
Dwell conditioner timer	Setting ±2% or 50 ms, whichever is greater
Pulse conditioner timer	Setting ±2% or 50 ms, whichever is greater

**22.8.1.14 DC SUPPLY MONITOR**

Measuring range	19 V to 300 V
Tolerance	±5% or 1.5V (whichever is greater)
Pickup	100% of Setting ± Tolerance *
Dropoff	Hysteresis 2% 102% of Setting ± Tolerance for the upper limit * 98% of Setting ± Tolerance for the lower limit *
Operate time	Setting ±2% or 500 ms (whichever is greater)
Disengagement time	< 250 ms
* Tested at 21°C	

**22.8.1.15 POWER FACTOR**

Lead/Lag Trip/Alarm pickup level (Set):	0.05 to 0.99 in steps of 0.01, lead and lag
Lead/Lag Trip/Alarm time delay:	0.00 to 600.00 s in steps of 0.01 s
Start block delay	0.00 to 5000.00 s in steps of 0.01 s
Reset time (tRESET)	0.00 to 600.00 s in steps of 0.01 s

Minimum operating voltage (V threshold)	0.00 to 1.25 x VT in steps of 0.01 x VT
Minimum operating current (I threshold)	0.00 to 10.00 x CT in steps of 0.01 x CT
Level accuracy	±0.02
Timer accuracy	±3% of delay setting or ±1¼ cycle (whichever is greater) from pickup to operate
Stages	Trip and alarm

### 22.8.1.16 BREAKER ARCING CURRENT

Alarm level	0 to 50000 kA <sup>2</sup> -cycle in steps of 1 kA <sup>2</sup> -cycle
Delay	0.000 to 6000.000 s in steps of 0.001 s
Timer accuracy	±3% of delay setting or ±160 ms (whichever is greater) from pickup to operate

### 22.8.1.17 BREAKER HEALTH

Timers accuracy	±160 ms or 3%, whichever is greater
-----------------	-------------------------------------

### 22.8.1.18 DEMAND

Demand	
Measured values	RMS Phase A/B/C present and maximum current, three-phase present, maximum real/reactive/apparent power, minimum real/reactive/apparent power
Measurement type	Thermal Exponential: 90% response time (programmed): 5 to 90 min in steps of 1 min. Fixed Demand (Block Interval), Rolling Demand: Demand Period (programmed): 5 to 90 min in steps of 1 min.
Current pickup Level	0 to 65000 A in steps of 1 A
Real power pickup level	0.1 to 300000.0 kW in steps of 0.1 kW
Reactive power pickup level	0.1 to 300000.0 kVar in steps of 0.1 kVar
Apparent power pickup level	0.1 to 300000.0 kVA in steps of 0.1 kVA
Dropout level:	96-98% of Pickup level
Level accuracy:	±2%

### 22.8.1.19 HARMONIC DETECTION

Operating parameter	Current 2nd, 3rd, 4th, 5th harmonic or THD per phase
Timer accuracy	Harmonic: ±3% of delay setting or ±¼ cycle (whichever is greater) from pickup to operate THD: ±3% of delay setting or ±3 cycle (whichever is greater) from pickup to operate
Operating time	Less than 1½ cycles

**22.8.1.20 CIRCUIT BREAKER FAIL**

Pickup level	0.001 to 30.000 x CT in steps of 0.001 x CT
Level accuracy	For 0.1 to 2.0 x CT: $\pm 0.5\%$ of reading or $\pm 0.4\%$ of rated (whichever is greater) For > 2.0 x CT: $\pm 1.5\%$ of reading
Dropoff	96 to 99% of pickup
Timer accuracy	$\pm 3\%$ or 1 cycle (whichever is greater) from pickup to operate

**22.8.1.21 TRIP BUS (TRIP WITHOUT FLEXLOGIC)**

Trip Bus	
Number of elements:	6
Number of inputs	16
Pickup time delay:	0.000 to 6000.000 s in steps of 0.001 s
Dropout time delay:	0.000 to 6000.000 s in steps of 0.001 s
Operate time:	< 2 ms at 60 Hz
Timer accuracy	$\pm 3\%$ of delay time or $\pm 1/4$ cycle (whichever is greater) from pickup to operate

**22.8.1.22 DIGITAL ELEMENTS**

Digital Elements	
Number of elements:	64
Operating signal:	Any FlexLogic operand
Operate time:	Digital Elements are processed once per cycle (16 ms at 60 Hz, 20 ms at 50 Hz)
Pickup delay:	0.000 to 6000.000 s in steps of 0.001 s
Dropout delay:	0.000 to 6000.000 s in steps of 0.001 s
Timer accuracy	$\pm 3\%$ of delay setting or $\pm 1/4$ cycle (whichever is greater) from pickup to operate

## 22.9 MEASUREMENTS AND RECORDING

### 22.9.1 MOTOR MEASUREMENTS

Motor Measurements	
Parameters	Motor Load Thr Mod Bias Ld (Thermal Model Biased Load) FLT D Motor Load (Filtered Motor Load) FLT D RMS Cur A, B, C (Filtered RMS Phase A, B, C Currents) FLT D MAG Cur A, B, C (Filtered Phasor Magnitude Phase A, B, C Currents)
RMS accuracy	$\pm 0.2\%$ of reading or $\pm 0.2\%$ of rated (whichever is greater) from 0.1 to 2.0 x CT $\pm 0.25\%$ of reading > 2.0 x CT
Magnitude accuracy	$\pm 0.5\%$ of reading or $\pm 0.2\%$ of rated (whichever is greater) from 0.1 to 2.0 x CT. $\pm 0.4\%$ of reading > 2.0 x CT

### 22.9.2 OTHER MEASUREMENTS (CURRENTS, VOLTAGES, FREQUENCY, POWER)

Parameter	RANGE		% TOLERANCE	ABS TOLERANCE
	LOW	HIGH		
Current mag	0.05 x I <sub>n</sub>	2 x I <sub>n</sub>	0,50%	0.002 x I <sub>n</sub>
	2 x I <sub>n</sub>	30 x I <sub>n</sub>	1,00%	---
Sens current mag	0.002 x I <sub>n</sub>	0.2 x I <sub>n</sub>	0,50%	0.001 x I <sub>n</sub>
	0.2 x I <sub>n</sub>	3 x I <sub>n</sub> (if CT sec = 1 A) 0.6 x I <sub>n</sub> (if CT sec = 5 A)	1,00%	---
Voltage mag (measured)	10 V	300 V	0,5%	0.3 V
Current mag (derived)	0.05 x I <sub>n</sub>	30 x I <sub>n</sub>	2%	2% Rated
Voltage mag (derived)	10 V	300 V	2%	2% Rated
Current ang	0.05 x I <sub>n</sub>	30 x I <sub>n</sub>	---	1°
Voltage ang	10 V	300 V	---	1°
Frequency	40 Hz	70 Hz	---	0.01Hz
Real power (watts)	-0.8 < PF ≤ -1.0 and 0.8 < PF < 1.0		±1.5% of reading	0.005 * rated kW
Reactive power (Vars)	-0.2 < PF ≤ 0.2		±1.5% of reading	0.005 * rated kVAr

### 22.9.3 DISTURBANCE RECORDS

Disturbance Records Measurement Accuracy	
Number of records	1 to 16
Sampling rate (samples/cycle)	128\64\32\16\8
Magnitude and relative phases accuracy	±5% of applied quantities
Trigger position accuracy	±2%

## 22.9.4 EVENT AND FAULT RECORDS

Event & Fault Records	
Record location	Flash memory
Viewing method	Front panel display or EnerVista Configuration
Extraction method	Extracted via the USB or Ethernet port
Number of event records	Up to 2048 time tagged event records
Number of fault records	Up to 25

## 22.9.5 MOTOR RECORDS

### 22.9.5.1 MOTOR START RECORDS

Motor Start Records	
Length:	6 records, each containing a total of 60 seconds of motor starting data
Trigger:	Motor starting status
Trigger Position:	1 second pre-trigger duration
Sample Rate:	1 sample/100 ms

### 22.9.5.2 MOTOR START STATISTICS

Motor Start Statistics	
Number of records	5
Content	Start Date/Time, Start Acceleration Time, Start Effective Current, Start Peak Current
Number of records	Non-volatile memory

### 22.9.5.3 LEARNED DATA

Motor Learned Data	
Number of records	250
Content	Learned/last acceleration time, learned/last starting current, learned/last start TCU, learned average load, learned average real power, learned average reactive power, learned average power factor, average run time (days/hours/ minutes), maximum speed, analog input minimum/maximum values, RTD maximum temperature, Learned/Last Start SM SC TCU
Data Storage	LDR File, CSV Format
Learned acceleration time accuracy	3%
Learned starting current accuracy	1%

## 22.10 REGULATORY COMPLIANCE

Compliance with the European Commission Direction on EMC, LVD and RoHS is via the self certification route.



### 22.10.1 EMC COMPLIANCE: 2014/30/EU

The product specific Declaration of Conformity (DoC) lists the relevant harmonised standard(s) or conformity assessment used to demonstrate compliance with the EMC directive.

### 22.10.2 EMC COMPLIANCE: 2574-14 OF RAMADAN 1436

The product specific Declaration of Conformity (DoC) lists the relevant harmonised standard(s) or conformity assessment used to demonstrate compliance with the EMC directive.

### 22.10.3 LVD COMPLIANCE: 2014/35/EU

The product specific Declaration of Conformity (DoC) lists the relevant harmonized standard(s) or conformity assessment used to demonstrate compliance with the LVD directive.

Safety related information, such as the installation I overvoltage category, pollution degree and operating temperature ranges are specified in the Technical Data section of the relevant product documentation and/or on the product labelling.

Unless otherwise stated in the Technical Data section of the relevant product documentation, the equipment is intended for indoor use only. Where the equipment is required for use in an outdoor location, it must be mounted in a specific cabinet or housing to provide the equipment with the appropriate level of protection from the expected outdoor environment.

### 22.10.4 LVD COMPLIANCE: 2573-14 OF RAMADAN 1436

The product specific Declaration of Conformity (DoC) lists the relevant harmonized standard(s) or conformity assessment used to demonstrate compliance with the LVD directive.

### 22.10.5 ROHS COMPLIANCE 2011/65/EU AND (EU) 2015/863

The product complies with the directive of the Council of the European Communities on harmonization of the laws of the Member States concerning restriction on usage of hazardous substances in electrical and electronic equipment (RoHS Directive 2011/65/EU). This conformity has been proved by tests performed according to the Council Directive in accordance with the standard EN 50581.

## 22.10.6 MECHANICAL SPECIFICATIONS

### 22.10.6.1 PHYSICAL PARAMETERS

Physical Measurements	
Case types	20TE
Weight (20TE case)	1.5 kg - 2 kg (depending on configuration options)
Dimensions in mm (w x h x l) (20TE case)	W: 102.4 mm H: 177.0 mm D: 185.6 mm

Physical Measurements	
Mounting	Panel, rack

Physical Measurements	
Case types	30TE
Weight (30TE case)	1.5 kg - 2.75 kg (depending on configuration options)
Dimensions in mm (w x h x l) (30TE case)	W: 154.2 mm H: 177.0 mm D: 185.6mm
Mounting	Panel, rack

### 22.10.6.2 ENCLOSURE PROTECTION

Against dust and dripping water (front face)	IP52 (20TE), IP54 (30TE) as per IEC 60529:2013
Protection for rear of the case	IP20 as per IEC 60529:2013
Noise	0 dB



**Caution:**  
To maintain IP20 protection, the rear cover must be re-installed as per the provided instructions after wiring is complete.

### 22.10.6.3 MECHANICAL ROBUSTNESS

Vibration test per EN 60255-21-1:1988	Response: class 2, Endurance: class2
Shock and bump immunity per EN 60255-21-2:1988	Shock response: class 2, Shock withstand: class 1, Bump withstand: class 1
Seismic test per EN 60255-21-3: 1995	Class 2

### 22.10.6.4 TRANSIT PACKAGING PERFORMANCE

Primary packaging carton protection	ISTA 1C
Compression test	1.4 x Calculated force
Vibration tests	4 Orientations, Random frequency, 22.45mm amplitude, 1.15 G
Shock test	10 drops from 760mm on multiple carton faces, edges and corners



## 22.11 RATINGS

### 22.11.1 AC MEASURING INPUTS

AC Measuring Inputs	
Nominal frequency	50 Hz or 60 Hz (settable)
Operating range	40 Hz to 70 Hz
Phase rotation	ABC or ACB

### 22.11.2 CURRENT TRANSFORMER INPUTS

AC Current	
Nominal current (I <sub>n</sub> )	1 A and 5 A dual rated*
Nominal burden per phase	< 0.05 VA at I <sub>n</sub>
AC current thermal withstand	Continuous: 4 x I <sub>n</sub> 10 s: 30 x I <sub>n</sub> 1 s: 100 x I <sub>n</sub> Linear to 40 x I <sub>n</sub> (non-offset ac current)

**Note:**

A single input is used for both 1 A and 5 A applications. 1 A or 5 A operation is determined by means of software in the product's database.

**Note:**

These specifications are applicable to all CTs.

### 22.11.3 VOLTAGE TRANSFORMER INPUTS

AC Voltage	
Nominal voltage	100 V to 120 V
Nominal burden per phase	< 0.1 VA at V <sub>n</sub>
Thermal withstand	Continuous: 4 x V <sub>n</sub> , 10 s: 5 x V <sub>n</sub>

## 22.12 POWER SUPPLY

### 22.12.1 AUXILIARY POWER SUPPLY VOLTAGE

Nominal operating range	24 to 250 V DC $\pm 20\%$ 110 to 240 V AC -20% + 10%
Maximum operating range	19 to 300 V DC
Frequency range for AC supply	45 to 70 Hz
Ripple	<15% for a DC supply (compliant with IEC 60255-26:2013)

### 22.12.2 NOMINAL BURDEN

Quiescent burden in 20TE	8W
Quiescent burden in 30TE	12W
Additions for energised relay outputs	0.2 W per output relay for trip contacts 0.14 W per output relay for auxiliary contacts
Opto-input burden	2 mA DC per each input

### 22.12.3 AUXILIARY POWER SUPPLY INTERRUPTION

Standard	IEC 60255-26: 2013
----------	--------------------

Supply Voltage	Quiescent/Half Load	Full Load
24 V DC	100 ms	100 ms
48 V DC	100 ms	100 ms
110 V DC	100 ms	100 ms
220 V DC	200 ms	200 ms

**Note:**

Maximum loading = all inputs/outputs energised. Quiescent or 1/2 loading = 1/2 of all inputs/outputs energised.

## 22.13 INPUT/OUTPUT CONNECTIONS

### 22.13.1 OPTO-ISOLATED DIGITAL INPUTS

Opto-isolated Digital Inputs (Opto-inputs)	
Compliance	ESI 48-4
Rated nominal voltage	24 to 250 V DC
Withstand	300 V dc
Recognition time without debounce time setting	< 1 ms
Debounce time setting	from 1 to 50 ms in steps of 1 ms
Continuous current draw (burden)	2 mA

#### 22.13.1.1 NOMINAL PICKUP AND RESET THRESHOLDS

Selectable threshold voltage (PU level) *	24, 30, 48, 110, 220 V DC
DO level	fixed -20% of PU level

**Note:**

\* There are different Inputs settings options depending on the Cortec selection.

For options B, D and J (only inputs from I/O type 1 in SLOT C & D. See wiring diagrams for 30TE): One Opto Config setting range (Global Nominal Voltage & Characteristic settings) available.

For options C, E, F, G and H: Two Opto Config X setting ranges available 1 and 2 (Global Nominal Voltage X & Characteristic settings X).

Refer to Configuring the Opto-Inputs section in the Digital I/O and Flexlogic Equation Editor chapter for more detailed information.

**Note:**

Debounce time setting is required to make the opto-inputs immune to induced AC voltages.

#### 22.13.1.2 OPTO-ISOLATED TRIP CIRCUIT SUPERVISION INPUTS (TCS)\*

Opto-isolated Trip Circuit Supervision Digital Inputs (TCS opto-inputs)	
Compliance	ESI 48-4
Rated nominal voltage	24 to 250 V DC
Voltage threshold for TCS inputs *	Fixed or configurable (Cortec dependant)
Withstand	300 V DC
Recognition time without debounce time setting	<1 ms
Continuous current draw (burden)	1 to 2.5 mA

**Note:**

\* For options B, D and J (only inputs from I/O type 1 in SLOT C & D. See wiring diagrams for 30TE): TCS inputs (4 and 5) have fixed DC voltage level as 5V, with no hysteresis.

For options C, E, F, G and H: TCS inputs (4 and 5) Global Nominal Voltage & Characteristic settings are configurable as per Normal opto-isolated digital inputs with two range options available (Opto Config 1 and Opto Config 2).

**Note:**

\* See wiring diagram for the location of these inputs.

### 22.13.2 RL1, RL2, AND RL3 OUTPUT CONTACTS\*

Compliance	In accordance with IEC 60255-1:2009
Use	General purpose relay outputs for tripping, opening and closing
Rated voltage	300 V
Maximum continuous current	10 A
Short duration withstand carry	30 A for 3 s 250 A for 30 ms
Make and break, dc resistive	50 W
Make and break, dc inductive	62.5 W (L/R = 50 ms)
Make and break, ac resistive	2500 VA resistive (cos phi = unity)
Make and break, ac inductive	2500 VA inductive (cos phi = 0.7)
Make and carry, dc resistive	30 A for 3 s, 10000 operations (subject to a maximum load of 7500W))
Make, carry and break, dc resistive	4 A for 1.5 s, 10000 operations (subject to the above limit for make and break, dc resistive load)
Make, carry and break, dc inductive	0.5 A for 1 s, 10000 operations (subject to the above limit for make and break, dc inductive load)
Make, carry and break ac resistive	30 A for 200 ms, 2000 operations (subject to the above limits)
Make, carry and break ac inductive	10 A for 1.5 s, 10000 operations (subject to the above limits)
Loaded contact	10000 operations min.
Unloaded contact	100000 operations min.
Operate time	< 5 ms
Reset time	< 5 ms

**Note:**

\* For 30TE, RL1, RL2 & RL3 are only applicable to I/O type 1 & 2. See wiring diagram for 30TE for more detailed information.

### 22.13.3 AUXILIARY OUTPUT CONTACTS

Compliance	In accordance with IEC 60255-1:2009
Use	General purpose relay outputs for signalling
Rated voltage	300 V
Maximum continuous current	5 A
Short duration withstand carry	10 A for 3 s
Make and break, dc resistive	24 W
Make and carry, dc resistive	10 A for 3 s
Operate time	< 5 ms
Reset time	< 5 ms

## 22.13.4 WATCHDOG CONTACT

Use	Normally closed non-programmable contacts for relay healthy/relay fail indication
Breaking capacity, dc resistive	24 W

*Note:*

*Relay output 8 or 6 ("Critical Fail" as per the wiring diagrams) is the watchdog contact relay for Multilin Agile.*

## 22.14 ENVIRONMENTAL CONDITIONS

### 22.14.1 AMBIENT TEMPERATURE RANGE

Compliance	IEC 60255-27: 2014
Test method	IEC 60068-2-1:2007 and IEC 60068-2-2 2007
Operating temperature range	-25°C to +60°C (continuous)
Storage and transit temperature range	-40°C to +85°C (continuous)
Altitude	up to 2000 m

### 22.14.2 TEMPERATURE ENDURANCE TEST

Temperature Endurance Test	
Test method	IEC 60068-2-1: 2007 and 60068-2-2: 2007
Operating temperature range	-25°C (96 hours) +60°C (96 hours)
Storage and transit temperature range	-40°C (96 hours) +85°C (96 hours)

### 22.14.3 AMBIENT HUMIDITY RANGE

Compliance	IEC 60068-2-78: 2013 and IEC 60068-2-30: 2005
Durability	56 days at 93% relative humidity and +40°C
Damp heat cyclic	six (12 + 12) hour cycles, 93% RH, +25 to +55°C

## 22.15 TYPE TESTS

### 22.15.1 INSULATION

Compliance	IEC 60255-27: 2014
Insulation resistance	> 100 M ohm at 500 V DC (Using only electronic/brushless insulation tester)

### 22.15.2 CREEPAGE DISTANCES AND CLEARANCES

Compliance	IEC 60255-27: 2014
Pollution degree	2
Overvoltage category	III
Impulse test voltage (not RJ45)	5 kV
Impulse test voltage (RJ45)	1 kV

### 22.15.3 HIGH VOLTAGE (DIELECTRIC) WITHSTAND

IEC compliance	IEC 60255-27: 2014
Between all independent circuits	2 kV ac rms for 1 minute
Across open watchdog contacts	1 kV ac rms for 1 minute
Between all RJ45 contacts and protective earth terminal	1 kV ac rms for 1 minute
ANSI/IEEE compliance	ANSI/IEEE C37.90-2005
Across open contacts of normally open output relays (RL1 to 3)	1.5 kV ac rms for 1 minute
Across open contacts of normally open changeover output relays (other relay contacts)	1 kV ac rms for 1 minute
Across open watchdog contacts	1 kV ac rms for 1 minute

### 22.15.4 IMPULSE VOLTAGE WITHSTAND TEST

Compliance	IEC 60255-27: 2014
Between terminals of all independent circuits	Front time: 1.2 $\mu$ s, Time to half-value: 50 $\mu$ s, Peak value: 5 kV, 0.5 J
Between Ethernet communications and protective earth	Front time: 1.2 $\mu$ s, Time to half-value: 50 $\mu$ s, Peak value: 1 kV

**Note:**

*Exceptions are communications ports and normally-open output contacts, where applicable.*

## 22.16 ELECTROMAGNETIC COMPATIBILITY

### 22.16.1 1 MHZ BURST HIGH FREQUENCY DISTURBANCE TEST

Compliance	IEC 60255-26:2013
Common-mode test voltage	2.5 kV
Differential test voltage	1.0 kV

### 22.16.2 DAMPED OSCILLATORY TEST

Compliance	EN61000-4-18: 2011: Level 4: 3MHz, 10MHz and 30MHz
Common-mode test voltage	4.0 kV

### 22.16.3 IMMUNITY TO ELECTROSTATIC DISCHARGE

Compliance	IEC 60255-26:2013
Class 4 condition	15 kV discharge in air to user interface, display, and communication port
Class 4 condition	8 kV discharge in contact to exposed metalwork and communication port.

### 22.16.4 ELECTRICAL FAST TRANSIENT OR BURST REQUIREMENTS

Compliance	EN61000-4-4:2012. Test severity level III and IV, IEC 60255-26:2013
Applied to communication inputs	Amplitude: 2 kV, burst frequency 5 kHz and 100 KHz (level 4)
Applied to power supply and all other inputs except for communication inputs	Amplitude: 4 kV, burst frequency 5 kHz and 100 KHz (level 4)

### 22.16.5 SURGE WITHSTAND CAPABILITY

Compliance	IEEE/ANSI C37.90.1: 2012
Condition 1	4 kV fast transient and 2.5 kV oscillatory applied common mode and differential mode to opto inputs, output relays, CTs, VTs, power supply
Condition 2	4 kV fast transient and 2.5 kV oscillatory applied common mode to Ethernet communications

### 22.16.6 SURGE IMMUNITY TEST

Compliance 61000-4-5:2014	IEC 61000-4-5:2014 Level 4, IEC60255-26:2013
Pulse duration	Time to half-value: 1.2/50 $\mu$ s



Between all groups and protective earth conductor terminal	Amplitude 4 kV
Between terminals of each group (excluding communications ports, where applicable)	Amplitude 2 kV

### 22.16.7 IMMUNITY TO RADIATED ELECTROMAGNETIC ENERGY

Compliance	IEC 60255-26:2013
Frequency band	80 MHz to 1.0 GHz
Spot tests at	80, 160, 380, 450, 900, 1850, 2150 MHz
Test field strength	10 V/m
Test using AM	1 kHz @ 80%
Compliance	IEEE/ANSI C37.90.2: 2004
Frequency band	80 MHz to 1 GHz
Spot tests at	80MHz, 160MHz, 450MHz, 900MHz and 900MHz
Waveform	1 kHz @ 80% am and pulse modulated
Field strength	35 V/m

### 22.16.8 RADIATED IMMUNITY FROM DIGITAL COMMUNICATIONS

Compliance	IEC 61000-4-3: 2006, Level 4, IEC 60255-26:2013
Frequency bands	800 to 960 MHz, 1.4 to 2.7 GHz
Test field strength	10 V/m
Test using AM	1 kHz / 80%

### 22.16.9 IMMUNITY TO CONDUCTED DISTURBANCES INDUCED BY RADIO FREQUENCY FIELDS

Compliance	IEC 60255-26:2013, IEC 61000-4-6:2013 Level 3
Frequency bands	150 kHz to 80 MHz
Test disturbance voltage	10 V rms
Test using AM	1 kHz @ 80%
Spot tests	27 MHz and 68 MHz

### 22.16.10 MAGNETIC FIELD IMMUNITY

Compliance	IEC 61000-4-8:2010 Level 5 IEC61000-4-9:2016 IEC61000-4-110:2017 Level 5
IEC 61000-4-8 test	100 A/m applied continuously, 1000 A/m applied for 3 s
IEC 61000-4-9 test	1000 A/m applied in all planes

IEC 61000-4-10 test	100 A/m applied in all planes at 100 kHz/1 MHz with a burst duration of 2 seconds
---------------------	---

**Note:**

Power frequency magnetic field testing in accordance with IEC 61000-4-8 increases the voltage measurement accuracy to 1%.

### 22.16.11 CONDUCTED EMISSIONS

Compliance	IEC 60255-26:2013, EN 55016-2-1:2014
Power supply test 1	0.15 - 0.5 MHz, 79 dB $\mu$ V (quasi peak) 66 dB $\mu$ V (average)
Power supply test 2	0.5 – 30 MHz, 73 dB $\mu$ V (quasi peak) 60 dB $\mu$ V (average)

### 22.16.12 RADIATED EMISSIONS

Compliance	EN 55022: 2010, IEC 60255-26:2013
Test 1	30 - 230 MHz, 40 dB $\mu$ V/m at 10 m measurement distance
Test 2	230 - 1 GHz, 47 dB $\mu$ V/m at 10 m measurement distance
Test 3	1 - 6 GHz, 76 dB $\mu$ V/m at 10 m measurement distance

### 22.16.13 POWER FREQUENCY

Compliance	IEC 60255-26:2013
Opto-inputs	300 V common-mode (Class A) 150 V differential mode (Class A)

## **APPENDIX A**

# **ORDERING OPTIONS**



Information Required with Order:

Variants	Order Number											
	1 - 4	5	6	7	8	9	10	11	12-13	14	15	
<b>Multilin Agile Motor Application</b>												
Motor Protection Relay - Non directional	P24N											
Motor Protection Relay - Directional	P24D											
<b>Application Package Options</b>												
Base			B									
<b>Current/Voltage Inputs</b>												
Standard Earth (Ground) CT	P24D/N			1								
Sensitive Earth (Ground) Fault CT	P24D/N			2								
<b>Hardware Options</b>												
EIA RS485 serial comms - with RJ45 Engineering Port (only)	20TE/30TE					2						
EIA RS485 serial comms and station bus Ethernet - Single channel RJ45 copper	20TE/30TE					5						
EIA RS485 serial comms and station bus Ethernet - Single channel 2x RJ45	20TE/30TE					6						
EIA RS485 serial, 2x RJ45 Ethernet (configurable PRP/HSR/LLA) and 1x RJ45	20TE					A						
2x EIA RS485 serial, 2x fiber Ethernet (configurable PRP/HSR/LLA) and 1x RJ45	20TE					B						
2x EIA RS485 serial, 2x fiber Ethernet (configurable PRP/HSR/LLA) and 1x fiber	20TE					C						
1x EIA RS485 serial, 2x RJ45 Ethernet (configurable PRP/HSR/LLA) and 1x RJ45	30TE					D						
1x EIA RS485 serial, 2x fiber Ethernet (configurable PRP/HSR/LLA) and 1x RJ45	30TE					E						
1x EIA RS485 serial, 2x fiber Ethernet (configurable PRP/HSR/LLA) and 1x fiber	30TE					F						
<b>Binary Input/Output Options</b>												
	<b>Case</b>											
5 inputs (2 for Trip Circuit Supervision) + 7 outputs + 1 watchdog	20TE							B				
8 inputs (2 for Trip Circuit Supervision) + 5 outputs + 1 watchdog	20TE							C				
11 inputs (2 for Trip Circuit Supervision) + 11 outputs + 1 watchdog	20TE/30TE							D				
14 inputs (2 for Trip Circuit Supervision) + 9 outputs + 1 watchdog	20TE/30TE							E				
16 inputs (4 for Trip Circuit Supervision) + 11 outputs + 1 watchdog	30TE							F				
22 inputs (4 for Trip Circuit Supervision) + 15 outputs + 1 watchdog	30TE							G				
30 inputs (6 for Trip Circuit Supervision) + 21 outputs + 1 watchdog	30TE							H				
24 inputs (6 for Trip Circuit Supervision) + 25 outputs + 1 watchdog	30TE							J				
16 inputs (3 for Trip Circuit Supervision) + 11 outputs + 1 watchdog (Ring Terminals)	30TE							P				
22 inputs (4 for Trip Circuit Supervision) + 15 outputs + 1 watchdog (Ring + Pin hybrid terminals)	30TE							R				

Variants	Order Number											
	1 - 4	5	6	7	8	9	10	11	12-13	14	15	
<b>Communication protocols/Cybersecurity</b>												
DNP3.0/Modbus/IEC 60870-5-103							2					
IEC 61850/DNP3.0/Modbus/IEC 60870-5-103							3					
IEC 61850/DNP3.0/Modbus/IEC 60870-5-103 + advanced cyber Level 2							4					
<b>Case</b>												
20TE Flush (4 inch width) with text display								B				
30TE Flush (6"), 6 function keys, 16 programmable LEDs and Color Graphical HMI (IEC version)*								C				
30TE Flush (6"), 6 function keys, 16 programmable LEDs and Color Graphical HMI (ANSI version)*								E				
30TE Flush (6"), 6 function keys, 16 programmable LEDs, Color Graphical HMI & Bay Control (IEC version)								G				
30TE Flush (6"), 6 function keys, 16 programmable LEDs, Color Graphical HMI & Bay Control (ANSI version)								N				
Software upgrade only (via After Sales)								0				
<b>Language</b>												
English (UK)/English (US)/French/Spanish/Russian/Turkish								0				
English (UK)/English (US)/Polish/German								1				
<b>Software Version</b>												
08: Initial release										08		
<b>Customization/Regionalization</b>												
Regular (IEC standards and 50Hz/1 amp based default settings)											0	
IEEE market default configuration - US English, 60Hz and 5 amp preconfiguration											6	
Customer specific											A	
<b>Hardware design suffix</b>												
Enhanced model												E

**Note:**

- \* Offers a single line diagram for control, but with a basic, fixed bay template only. **G** and **N** options are required for a configurable mimic diagram.

## **APPENDIX B**

# **SETTINGS AND SIGNALS**

Tables, containing a full list of settings for each model, are provided in a separate Excel file attached as an embedded resource. To access the spreadsheet file, click on the button below.

**This Settings and Signals file covers software version 08A for both Feeder and Motor devices.**

*Note:*

*An Open File dialogue box may open with a warning message about potential harm from programs, macros or viruses. The file supplied does not contain any harmful content, and may be safely opened.*



## **APPENDIX C**

# **WIRING DIAGRAMS**



REV	ITR	ECO #	DESCRIPTION	DDMMYY	APPROVED
B	2	T202407010	FIRST ISSUE	04/07/24	I. M.

REVISION HISTORY	
DDMMYY	DESCRIPTION
04/07/24	FIRST ISSUE

FIG. 9




Table 3

COMMUNICATIONS					
CORTEC DIGIT 7	COM 1	COM 2	ETH1	ETH 2	ETH3
2	EIA RS485/IRIG-B	-	RJ45 ENG PORT	-	-
5	EIA RS485/IRIG-B	-	RJ45	-	-
6	EIA RS485/IRIG-B	-	Fiber	-	-
A	EIA RS485/IRIG-B	EIA RS485	RJ45	RJ45	RJ45
B	EIA RS485/IRIG-B	EIA RS485	RJ45	Fiber	Fiber
C	EIA RS485/IRIG-B	EIA RS485	Fiber	Fiber	Fiber

Table 4

ORDER CODE DIGIT (8)	DESCRIPTION	INPUT/OUTPUT	
		D	C
B	5 inputs (2 for Trip Circuit Supervision) + 7 outputs +1 Watchdog	I/O TYPE 1	N/A
C	8 inputs (2 for Trip Circuit Supervision) + 5 outputs +1 Watchdog	I/O TYPE 2	N/A
D	11 inputs (2 for Trip Circuit Supervision) + 11 outputs +1 Watchdog	I/O TYPE 1	I/O TYPE 4
E	14 inputs (2 for Trip Circuit Supervision) + 9 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 4

Table 1 BINARY INPUT / OUTPUT OPTIONS (ORDER CODE DIGIT 8)

I/O TYPE 1			I/O TYPE 2			I/O TYPE 4		
(*)1	+	Opto I/P 1	(*)1	+	Opto I/P 1	(*)1	+	Opto I/P 1
(*)2	+	Opto I/P 2	(*)2	+	Opto I/P 2	(*)2	+	Opto I/P 2
(*)3	+	Opto I/P 3	(*)3	+	Opto I/P 3	(*)3	+	Opto I/P 3
(*)4	-	Opto I/P 1,2,3	(*)4	-	Opto I/P 1,2,3	(*)4	-	Opto I/P 1,2,3
(*)5	+	Opto I/P 4	(*)5	+	Opto I/P 4	(*)5	+	Opto I/P 4
(*)6	-	Opto I/P 5	(*)6	-	Opto I/P 5	(*)6	+	Opto I/P 5
(*)7	+	Opto I/P 6	(*)7	+	Opto I/P 6	(*)7	+	Opto I/P 6
(*)8	-	Opto I/P 7	(*)8	-	Opto I/P 7	(*)8	-	Opto I/P 4,5,6
(*)9	+	Relay O/P 1	(*)9	+	Relay O/P 6	(*)9	+	Relay O/P 1
(*)10	+	Relay O/P 2	(*)10	+	Relay O/P 7	(*)10	+	Relay O/P 2
(*)11	+	Relay O/P 3	(*)11	+	Relay O/P 8	(*)11	+	Relay O/P 3
(*)12	-	Relay O/P 4	(*)12	-	Relay O/P 1	(*)12	-	Relay O/P 3
(*)13	-	Relay O/P 5	(*)13	-	Relay O/P 2	(*)13	-	Relay O/P 4
(*)14	-	Relay O/P 6	(*)14	-	Relay O/P 3	(*)14	-	Relay O/P 4
(*)15	-	Relay O/P 7	(*)15	-	Relay O/P 4	(*)15	-	Relay O/P 4
(*)16	-	Relay O/P 8	(*)16	-	Relay O/P 5	(*)16	-	Relay O/P 4
(*)17	-	Critical Fail/Relay O/P 8	(*)17	-	Relay O/P 6	(*)17	-	Relay O/P 4
(*)18	-	Critical Fail/Relay O/P 8	(*)18	-	Relay O/P 7	(*)18	-	Relay O/P 4
(*)19	-	Critical Fail/Relay O/P 8	(*)19	-	Relay O/P 8	(*)19	-	Relay O/P 4
(*)20	-	Critical Fail/Relay O/P 8	(*)20	-	Critical Fail/Relay O/P 6	(*)20	-	Relay O/P 4
(*)21	-	Critical Fail/Relay O/P 8	(*)21	-	Critical Fail/Relay O/P 6	(*)21	-	Relay O/P 4
(*)22	-	Critical Fail/Relay O/P 8	(*)22	-	Critical Fail/Relay O/P 6	(*)22	-	Relay O/P 4
(*)23	-	Critical Fail/Relay O/P 8	(*)23	-	Critical Fail/Relay O/P 6	(*)23	-	Relay O/P 4
(*)24	-	Critical Fail/Relay O/P 8	(*)24	-	Critical Fail/Relay O/P 6	(*)24	-	Relay O/P 4

- Notes
- Standard Earth (Ground) Fault CT typical connections (Order code digit '6', option '1'). For Sensitive Earth (Ground) Fault CT connections (Order code digit '6', option '2'), refer Table 1.
  - Wye VT typical connections. For Delta connections, refer Table 2.
  - For Communication interface options, refer to Table 3.
  - For Input/Output options, refer to Table 4.
  - (\*) To be replaced by Slot digit (e.g. C1 for using Slot C in first input).
  - Outputs working as "Relay 1 - Trip" and "Critical Fail" only in I/O when located in Slot D.
  - Maximum continuous current supported by outputs 1, 2 and 3 of I/O type 1 and 2 is 10A. For all other outputs of different I/O types, it is 5A.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE (TBS)

INTERPRET DIM TOLERANCE PER ASME Y14.5/ISO 8015

TOLERANCE MM:  
1 PL +/- X  
2 PL +/- .XX  
3 PL +/- .XXX  
ANGLE +/- 0.5 DEG

THIRD ANGLE PROJECTION

CTQ (Critical to Quality)

MAJOR TSD

INSPECTION TBD

SCALE: NEXT STAGE: 10

FINISH:

NAME DDMMYY

DRAWN  
CHECKED  
APPROVED  
MATERIAL:

I. M. 04/07/24

TITLE: P24D DIRECTIONAL PHASE OVERCURRENT IED, 20TE CASE

STATUS:

Grid Solutions  
GE Power Management  
AV. PINOIA 10-48170,ZAMUDIC (SPAIN)

SIZE: DWGS NO. C154209  
REV B  
PART NUMBER: C1542P9 REV B2

REVISION HISTORY


DDMMYY DESCRIPTION APPROVED

04/07/24 FIRST ISSUE I. M.

20 19 18 17 16 15 14 13 12 11

E C D C B A

### FIG. 10



REVISION HISTORY		DDMMYY		APPROVED	
REV	ITR	ECO #	DESCRIPTION	DDMMYY	APPROVED
B	2	T2024070010	FIRST ISSUE	04/07/24	I. M.

**Table 2**

CORTEC DIGIT 7	COMMUNICATIONS				
	COM 1	COM 2	ETH1	ETH 2	ETH3
2	EIA RS485/IRIG-B	-	RJ45 ENG PORT	-	-
5	EIA RS485/IRIG-B	-	RJ45	-	-
6	EIA RS485/IRIG-B	-	Fiber	-	-
A	EIA RS485/IRIG-B	EIA RS485	RJ45	RJ45	RJ45
B	EIA RS485/IRIG-B	EIA RS485	RJ45	Fiber	Fiber
C	EIA RS485/IRIG-B	EIA RS485	Fiber	Fiber	Fiber


## P24N

**Table 3**

ORDER CODE DIGIT (3)	DESCRIPTION	INPUT/OUTPUT	
		D	C
B	5 inputs (2 for Trip Circuit Supervision) + 7 outputs +1 Watchdog	I/O TYPE 1	N/A
C	8 inputs (2 for Trip Circuit Supervision) + 5 outputs +1 Watchdog	I/O TYPE 2	N/A
D	11 inputs (2 for Trip Circuit Supervision) + 11 outputs +1 Watchdog	I/O TYPE 1	I/O TYPE 4
E	14 inputs (2 for Trip Circuit Supervision) + 9 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 4

**Notes**

- Standard Earth (Ground) Fault CT typical connections (Order code digit '6', option '1'). For Sensitive Earth (Ground) Fault CT connections (Order code digit '6', option '2'), refer Table 1.
- For Communication interface options, refer to Table 2.
- For Input/Output options, refer to Table 3.
- (\*) To be replaced by Slot digit (e.g. C1 for using Slot C in first input).
- Outputs working as "Relay 1 - Trip" and "Critical Fail" only in I/O when located in Slot D.
- Maximum continuous current supported by outputs 1, 2 and 3 of I/O type 1 and 2 is 10A. For all other outputs of different I/O types, it is 5A.

**Table 1****BINARY INPUT / OUTPUT OPTIONS (ORDER CODE DIGIT 8)**

I/O TYPE 1	I/O TYPE 2	I/O TYPE 4
<p>BINARY INPUTS</p> <p>(*)1 + Opto I/P 1            (*)2 + Opto I/P 2            (*)3 + Opto I/P 3            (*)4 - Opto I/P 1,2,3</p> <p>OPTO ISOLATED BINARY INPUTS</p> <p>(*)5 + Opto I/P 4            (*)6 - Opto I/P 5            (*)7 + Opto I/P 6            (*)8 - Opto I/P 4,5,6</p> <p>TCS INPUTS</p> <p>(*)9 Relay 1 - Trip / Relay O/P 1            (*)10 Relay O/P 2            (*)11 Relay O/P 3            (*)12 Relay O/P 4            (*)13 Relay O/P 5            (*)14 Relay O/P 6            (*)15 Relay O/P 7            (*)16 Relay O/P 8            (*)17 Relay O/P 9            (*)18 Relay O/P 10            (*)19 Relay O/P 11            (*)20 Relay O/P 12            (*)21 Relay O/P 13            (*)22 Relay O/P 14            (*)23 Relay O/P 15            (*)24 Relay O/P 16</p> <p>RELAY OUTPUT CONTACTS</p> <p>(*)9 Relay O/P 1            (*)10 Relay O/P 2            (*)11 Relay O/P 3            (*)12 Relay O/P 4            (*)13 Relay O/P 5            (*)14 Relay O/P 6            (*)15 Relay O/P 7            (*)16 Relay O/P 8            (*)17 Relay O/P 9            (*)18 Relay O/P 10            (*)19 Relay O/P 11            (*)20 Relay O/P 12            (*)21 Relay O/P 13            (*)22 Relay O/P 14            (*)23 Relay O/P 15            (*)24 Relay O/P 16</p>	<p>BINARY INPUTS</p> <p>(*)1 + Opto I/P 1            (*)2 + Opto I/P 2            (*)3 + Opto I/P 3            (*)4 - Opto I/P 1,2,3</p> <p>OPTO ISOLATED BINARY INPUTS</p> <p>(*)5 + Opto I/P 4            (*)6 - Opto I/P 5            (*)7 + Opto I/P 6            (*)8 - Opto I/P 4,5,6</p> <p>TCS INPUTS</p> <p>(*)9 Relay 1 - Trip / Relay O/P 1            (*)10 Relay O/P 2            (*)11 Relay O/P 3            (*)12 Relay O/P 4            (*)13 Relay O/P 5            (*)14 Relay O/P 6            (*)15 Relay O/P 7            (*)16 Relay O/P 8            (*)17 Relay O/P 9            (*)18 Relay O/P 10            (*)19 Relay O/P 11            (*)20 Relay O/P 12            (*)21 Relay O/P 13            (*)22 Relay O/P 14            (*)23 Relay O/P 15            (*)24 Relay O/P 16</p> <p>RELAY OUTPUT CONTACTS</p> <p>(*)9 Relay O/P 1            (*)10 Relay O/P 2            (*)11 Relay O/P 3            (*)12 Relay O/P 4            (*)13 Relay O/P 5            (*)14 Relay O/P 6            (*)15 Relay O/P 7            (*)16 Relay O/P 8            (*)17 Relay O/P 9            (*)18 Relay O/P 10            (*)19 Relay O/P 11            (*)20 Relay O/P 12            (*)21 Relay O/P 13            (*)22 Relay O/P 14            (*)23 Relay O/P 15            (*)24 Relay O/P 16</p>	<p>BINARY INPUTS</p> <p>(*)1 + Opto I/P 1            (*)2 + Opto I/P 2            (*)3 + Opto I/P 3            (*)4 - Opto I/P 1,2,3</p> <p>OPTO ISOLATED BINARY INPUTS</p> <p>(*)5 + Opto I/P 4            (*)6 - Opto I/P 5            (*)7 + Opto I/P 6            (*)8 - Opto I/P 4,5,6</p> <p>TCS INPUTS</p> <p>(*)9 Relay 1 - Trip / Relay O/P 1            (*)10 Relay O/P 2            (*)11 Relay O/P 3            (*)12 Relay O/P 4            (*)13 Relay O/P 5            (*)14 Relay O/P 6            (*)15 Relay O/P 7            (*)16 Relay O/P 8            (*)17 Relay O/P 9            (*)18 Relay O/P 10            (*)19 Relay O/P 11            (*)20 Relay O/P 12            (*)21 Relay O/P 13            (*)22 Relay O/P 14            (*)23 Relay O/P 15            (*)24 Relay O/P 16</p> <p>RELAY OUTPUT CONTACTS</p> <p>(*)9 Relay O/P 1            (*)10 Relay O/P 2            (*)11 Relay O/P 3            (*)12 Relay O/P 4            (*)13 Relay O/P 5            (*)14 Relay O/P 6            (*)15 Relay O/P 7            (*)16 Relay O/P 8            (*)17 Relay O/P 9            (*)18 Relay O/P 10            (*)19 Relay O/P 11            (*)20 Relay O/P 12            (*)21 Relay O/P 13            (*)22 Relay O/P 14            (*)23 Relay O/P 15            (*)24 Relay O/P 16</p>

GE Vernova PROPRIETARY AND CONFIDENTIAL INFORMATION  
 This document is the property of GE Vernova and contains proprietary information of GE Vernova, and that the information shall be used by the recipient only as approved expressly by GE Vernova. This document shall be returned to GE Vernova upon its request. This document may be subject to certain restrictions under U.S. export control laws and regulations. © GE Vernova, GE Vernova CONFIDENTIAL UNPUBLISHED WORK.

20 19 18 17 16 15 14 13 12 11

**FIG. 11**

REVISION HISTORY		DDMMYY		APPROVED	
REV	ITR	ECO #	DESCRIPTION	DATE	I. M.
B	2	T202407010	FIRST ISSUE	04/07/24	


**Table 3**

COMMUNICATIONS				
ORDER CODE DIGIT 7	COM 1	ETH1	ETH 2	ETH3
2	EIA RS-485	RJ45 ENG PORT	-	-
5	EIA RS-485	RJ45	-	-
6	EIA RS-485	Fiber	-	-
D	EIA RS-485	RJ45	RJ45	RJ45
E	EIA RS-485	RJ45	Fiber	Fiber
F	EIA RS-485	Fiber	Fiber	Fiber



**Table 4**

ORDER CODE DIGIT (8)	DESCRIPTION	INPUT/OUTPUT				
		F	E	D	C	
D	11 inputs (2 for Trip Circuit Supervision) + 11 outputs +1 Watchdog	I/O TYPE 1	I/O TYPE 3	NA	NA	NA
E	14 inputs (2 for Trip Circuit Supervision) + 9 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 3	NA	NA	NA
F	16 inputs (4 for Trip Circuit Supervision) + 11 outputs +1 Watchdog	I/O TYPE 2	NA	I/O TYPE 2	NA	NA
G	22 inputs (4 for Trip Circuit Supervision) + 15 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 3	I/O TYPE 2	NA	NA
H	30 inputs (6 for Trip Circuit Supervision) + 21 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 3	I/O TYPE 2	I/O TYPE 2	I/O TYPE 1
J	24 inputs (6 for Trip Circuit Supervision) + 25 outputs +1 Watchdog	I/O TYPE 2	N/A	N/A	I/O TYPE 2	I/O TYPE 2
P	16 inputs (4 for Trip Circuit Supervision) + 11 outputs + 1 watchdog (Ring terminals)	I/O TYPE 2	I/O TYPE 3	NA	N/A	I/O TYPE 2
R	22 inputs (4 for Trip Circuit Supervision) + 15 outputs + 1 watchdog (Ring + Pin hybrid terminals)	I/O TYPE 2	I/O TYPE 3	N/A	N/A	I/O TYPE 2

**Table 1**



**Table 2**



BINARY INPUT / OUTPUT OPTIONS (ORDER CODE DIGIT 8)			
	I/O TYPE 1	I/O TYPE 2	I/O TYPE 3
BINARY INPUTS	(*1) + Opto I/P 1 (*2) + Opto I/P 2 (*3) + Opto I/P 3 (*4) - Opto I/P 1,2,3 (*5) + Opto I/P 4 (*6) - Opto I/P 5 (*7) + Opto I/P 6 (*8) - Opto I/P 4,5,6	(*1) + Opto I/P 1 (*2) + Opto I/P 2 (*3) + Opto I/P 3 (*4) - Opto I/P 1,2,3 (*5) + Opto I/P 4 (*6) - Opto I/P 5 (*7) + Opto I/P 6 (*8) - Opto I/P 4,5,6	(*1) + Opto I/P 1 (*2) + Opto I/P 2 (*3) + Opto I/P 3 (*4) - Opto I/P 1,2,3 (*5) + Opto I/P 4 (*6) - Opto I/P 5 (*7) + Opto I/P 6 (*8) - Opto I/P 4,5,6
TCS INPUTS	Opto I/P 4	Opto I/P 4	Opto I/P 4
RELAY OUTPUT CONTACTS	(*9) Relay 1 - Trip / Relay O/P 1 (*10) Relay O/P 1 (*11) Relay O/P 2 (*12) Relay O/P 3 (*13) Relay O/P 4 (*14) Relay O/P 5 (*15) Relay O/P 6 (*16) Relay O/P 7 (*17) Relay O/P 8 (*18) Critical Fail/Relay O/P 8	(*9) Relay 1 - Trip / Relay O/P 1 (*10) Relay O/P 1 (*11) Relay O/P 2 (*12) Relay O/P 3 (*13) Relay O/P 4 (*14) Relay O/P 5 (*15) Relay O/P 6 (*16) Relay O/P 7 (*17) Relay O/P 8 (*18) Critical Fail/Relay O/P 5 (*19) Critical Fail/Relay O/P 6	(*9) Relay O/P 1 (*10) Relay O/P 2 (*11) Relay O/P 3 (*12) Relay O/P 4 (*13) Relay O/P 1 - Trip / Relay O/P 1 (*14) Relay O/P 2 (*15) Relay O/P 3 (*16) Relay O/P 4 (*17) Relay O/P 5 (*18) Relay O/P 6 (*19) Relay O/P 7 (*20) Relay O/P 8 (*21) Critical Fail/Relay O/P 5 (*22) Critical Fail/Relay O/P 6

**Notes**

- Earth fault typical CT connections (Order Code Digit 6, option 1). For Sensitive Earth Fault CT option (Order Code Digit 6, option 2) see table 1.
- Wye VT typical connections. For Delta connections see table 2.
- For Order Code Communication options see table 3.
- For Order Code input/output options see table 4. N/A (not available)
- (\*) To be replaced by Slot digit (e.g. C1 for using Slot C in first input).
- Outputs working as "Relay 1 - Trip" and "Critical Fail" only in I/O when located in Slot F.
- Maximum continuous current supported by outputs 1, 2 and 3 of I/O type 1 and 2 is 10A. For all other outputs of different I/O types, it is 5A.

**Grid Solutions**  
GE Power Management  
AV. PINKA 10.-48170 ZAMUDIC (SPAIN)

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE (TBS)

INTERPRET DIM TOLERANCE PER ASME Y14.5/ISO 80088

TOLERANCE MM:  
1 PL +/- .X  
2 PL +/- .XX  
3 PL +/- .XXX  
ANGLE +/- 0.5 DEG

THIRD ANGLE PROJECTION










CTO (Critical to Quality)  
MAJOR TBD  
INSPECTION TBD

NAME DDMMYY  
DRAWN  
CHECKED  
APPROVED I. M.  
MATERIAL:  
FINISH:

TITLE:  
P24D DIRECTIONAL PHASE OVERCURRENT IED\_30TTE CASE

STATUS:  
NEXT STAGE: 12  
SCALE:  
PART NUMBER: C1542P11 REV B2

REV ITR  
C154211  
B 2



**FIG. 12**

Table 2

ORDER CODE DIGIT 7	COMMUNICATIONS		
	COM 1	ETH1	ETH2
2	EIA RS-485	RJ45 ENG PORT	-
5	EIA RS-485	RJ45	-
6	EIA RS-485	Fiber	-
D	EIA RS-485	RJ45	RJ45
E	EIA RS-485	RJ45	Fiber
F	EIA RS-485	Fiber	Fiber

Table 3

ORDER CODE DIGIT (8)	DESCRIPTION	INPUT/OUTPUT		
		F	E	D
D	11 inputs (2 for Trip Circuit Supervision) + 11 outputs +1 Watchdog	I/O TYPE 1	I/O TYPE 3	NA
E	14 inputs (2 for Trip Circuit Supervision) + 9 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 3	NA
F	16 inputs (4 for Trip Circuit Supervision) + 11 outputs +1 Watchdog	I/O TYPE 2	NA	I/O TYPE 2
G	22 inputs (4 for Trip Circuit Supervision) + 15 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 3	I/O TYPE 2
H	30 inputs (6 for Trip Circuit Supervision) + 21 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 3	I/O TYPE 2
J	24 inputs (6 for Trip Circuit Supervision) + 25 outputs +1 Watchdog	I/O TYPE 2	I/O TYPE 3	I/O TYPE 1
P	16 inputs (4 for Trip Circuit Supervision) + 11 outputs +1 watchdog (Ring terminals)	I/O TYPE 2	N/A	I/O TYPE 2
R	22 inputs (4 for Trip Circuit Supervision) + 15 outputs +1 watchdog (Ring + Pin hybrid terminals)	I/O TYPE 2	I/O TYPE 3	I/O TYPE 2

**Notes**

- Earth fault typical CT connections (Order Code Digit 6, option 1). For Sensitive Earth Fault CT option (Order Code Digit 6, option 2) see table 1.
- For Order Code Communication options see table 2.
- For Order Code input/output options see table 3. N/A (not available).
- (\*) To be replaced by Slot digit (e.g. C1 for using Slot C in first input).
- Outputs working as "Relay 1 - Trip" and "Critical Fail" only in I/O when located in Slot F.
- Maximum continuous current supported by outputs 1, 2 and 3 of I/O type 1 and 2 is 10A. For all other outputs of different I/O types, it is 5A.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE (TBS)		NAME	DDMMYY
INTERPRET DIM TOLERANCE PER ASME Y14.5/ISO 8013	DRAWN	CHECKED	
TOLERANCE MM: 1 Pl +/- .X 2 Pl +/- .XX 3 Pl +/- .XXX ANGLE +/- .5 DEG	APPROVED	I. M.	04/07/24
THIRD ANGLE PROJECTION	MATERIAL:		
CTO (Critical to Quality)	INSPECTION		
MAJOR TBD	TBD		
STATUS:	TITLE:	P24N NON-DIRECTIONAL PHASE OVERCURRENT IED, 30TE CASE	
	FINISH:	SIZE:	C C154212
		SCALE:	13
		PART NUMBER:	C1542P12 REV B2
		REV	B 2
		SHEET	12

## **APPENDIX D**

# **I/O POPULATION - TYPE OF BOARDS (USAGE AND CONFIGURATION)**

Tables, containing a full list of settings for each model, are provided in a separate Excel file attached as an embedded resource. To access the spreadsheet file, click on the button below.

*Note:*

*An Open File dialogue box may open with a warning message about potential harm from programs, macros or viruses. The file supplied does not contain any harmful content, and may be safely opened.*







GE VERNOVA