

GE
Digital Energy

PMCS



Instruction manual

PMCS software revision: 7.00

GE publication code: 1601-0269-A1 (GEK-119548)

GE Digital Energy
650 Markland Street
Markham, Ontario
Canada L6C 0M1
Tel: +1 905 927 7070 Fax: +1 905 927 5098
Internet: <http://www.GEDigitalEnergy.com>



Copyright © 2013 GE Multilin Inc. All rights reserved.

Power Management Control System (PMCS) software revision 7.00.

EnerVista, Integrator, POWER LEADER, Digital Energy, Multilin, and GE Multilin are trademarks or registered trademarks of GE Multilin Inc.

The contents of this manual are the property of GE Multilin Inc. This documentation is furnished on license and may not be reproduced in whole or in part without the permission of GE Multilin. The manual is for informational use only and is subject to change without notice.

Part number: 1601-0269-A1 (May 2013)

PMCS

Table of contents

GLOSSARY	Glossary	1
INTRODUCTION	Overview	5
	Features.....	5
	HMI application size.....	6
	Special application issues	6
	Performance.....	6
	OPC client data items size.....	6
	Devices supported	7
	For further assistance	9
CONFIGURE CIMPLICITY	Add PMCS project in CIMPLICITY	11
POWERBUILDER WINDOW	PowerBuilder window explained	17
	Settings	18
	Buttons	22
DEVICE INFORMATION	469.....	25
	Overview tab.....	25
	Metering tab	27
	RTD tab.....	28
	Maintenance tab	29
	Learned tab.....	30
	Settings tab	31
	Commands tab.....	32
	489.....	33
	Overview tab.....	33
	Metering tab	34
	RTD tab.....	35
	Maintenance tab	36

Learned tab	37
Settings tab.....	38
Commands tab	39
735/737	40
Overview tab	40
Trip Data tab	41
Settings tab.....	42
Commands tab	43
745.....	44
Overview tab	44
Harmonics tab.....	45
Analysis tab.....	46
IO tab	47
Settings tab.....	48
Commands tab	49
750/760.....	50
Overview tab	50
Demand tab.....	51
Analysis tab.....	52
Synchro tab.....	53
IO tab	54
Settings tab.....	55
Commands tab	56
ELVS.....	57
Overview tab	57
Analysis tab.....	58
Demand tab.....	59
Preventative Maintenance tab	60
Contact Input tab.....	61
Contact Output tab	62
System Health tab	63
Relay Protection tab	64
Settings tab.....	65
EMVTC	66
Overview tab	66
Settings tab.....	67
Commands tab	68
EMVTD	69
Overview tab	69
Settings tab.....	70
Commands tab	71
EPM9650/EPM9450.....	72
Overview tab	72
Analysis tab.....	73
Demand tab.....	74
Digital tab	75
Max Data tab	76
Settings tab.....	77
Commands tab	78
GTU.....	79
Overview tab	79
Status tab	80
Statistics tab.....	81
Settings tab.....	82
Commands tab	83

TABLE OF CONTENTS

MVT	84
Overview tab.....	84
Settings tab	85
PQM/PQMII.....	86
Overview tab.....	86
Analysis tab.....	87
Maximum tab.....	88
Settings tab	89
Commands tab.....	90
UR	91
Overview tab.....	91
Analysis tab.....	92
Synchro tab.....	93
Contact Input tab.....	94
Contact Output tab.....	95
Settings tab	96
Commands tab.....	97
<hr/>	
SOFTWARE AND LICENSE MANAGEMENT	
Manage activation code.....	99
Transfer software license	100
Update software	101
Uninstall software	102

TABLE OF CONTENTS

PMCS

Glossary

Glossary

Baud rate	A measurement of a communication channel's signaling rate or information-carrying capacity. Communicating devices typically have configurable baud rates to provide compatibility with various speed communication networks. Higher baud rates generally provide faster data-refresh times.
CIMPLICITY HMI	An industry-standard supervisory control and data acquisition (SCADA) software package [®] providing flexible, accurate, and easy-to-use graphics. CIMPLICITY [™] HMI is based on client-server architecture, consisting of Servers and Viewer workstations. Servers are responsible for the collection and distribution of data. Viewer workstations connect into Servers and have full access to the collected data for viewing and control actions. Servers and Viewer workstations can be easily networked together to share data without the need to replicate your database from node to node.
CIMPLICITY HMI Server Development	Allows you to create new projects and can also function as a runtime system
CIMPLICITY HMI Server Runtime	Can be used as runtime systems only. They do not support project configuration.
CIMPLICITY HMI Viewer Runtime	Connects to Servers for viewing data and control actions
Communication network	A physical standard for wiring and interconnection of communicating devices. A communication network standard usually includes specifications of voltages, maximum cable-run lengths, shielding, termination, and cable requirements. RS485 and Ethernet are examples of communication-network standards.
Communication protocol	A language or convention used for reliable transmission and reception of binary data. A communication protocol is often independent of the physical method or network used for transmission. Modbus and TCP/IP are examples of communication protocol standards.
DDE	Dynamic data exchange. A Microsoft Windows standard for efficient sharing of data between applications on the same computer

DDE/OPC Server	A software application that typically runs in the background, gathering information from the network and providing the information in dynamic data exchange (DDE) and object linking and embedding for process control (OPC) format for use by one or more applications. The PMCS DDE/OPC Server is included in the PMCS Network & Device Configurator and comes in versions optimized for Ethernet TCP/IP or RS485 Modbus networks.
Ethernet	An industry-standard communication network commonly used for local-area networks (LANs) of computers. Ethernet-based PMCS systems provide high-speed, reliable communications at 10 megabits per second.
Ethernet gateway	The gateway increases performance of a PMCS system through multiple Modbus networks and reduces overall wiring costs through reuse of existing Ethernet LAN wiring
Event logger	A standard PMCS application that efficiently analyzes, sorts, and logs unusual system behavior, such as circuit breaker trips, undervoltages, and overcurrents. Extensive data-logging capabilities make it a useful tool for analyzing and predicting system maintenance patterns.
Host computer	The computer running the PMCS DDE Server. All other computers running PMCS client programs are referred to as Remote Viewers, viewer workstations, or networked computers.
IED	Intelligent electronic device
Interface Toolkit	An optional PMCS tool used to quickly generate accurate and friendly graphical user interfaces. The Interface Toolkit provides dozens of wizards to efficiently create intelligent one-line diagrams and tabular displays.
Modbus RTU	An industry-standard, nonproprietary communications protocol typically used in medium-speed networks (up to 38.4 kpbs) on RS485
Multinet	An Ethernet communications module that allows connection for up to 32 Modbus devices, providing Modbus TCP/IP communications for these devices over Ethernet. This allows connection to fiber optic LAN and WAN systems for remote access to data.
NetBEUI	A network protocol usually used in small, department-size local-area networks of 1 to 200 clients
NetDDE	A version of dynamic data exchange (DDE) that allows communications between applications running on different computers over network connections
ODBC	Open database connectivity. An inter-application communication protocol required for certain PMCS client applications to share data. Automatically installed and configured as part of the PMCS installation.
PMCS	Power Management Control System. GE's high-performance power-management system for Windows, including open network protocols, waveform capture and analysis, and event logging.
PLC	Programmable logic controller
RELT	Reduced energy let-through instantaneous protection. A measurement displayed in PMCS for GTU devices.
RS485	An industry-standard communication network supporting up to 32 networked devices. RS485 provides medium-speed, reliable communication transport through shielding, balanced transmission voltages, and termination.
RTD	Resistive temperature device. This function varies resistance based on temperature.

RTU	Remote terminal unit. A microprocessor based device, such as a relay.
SCADA	Supervisory control and data acquisition. A category of systems that primarily acquires data for logging and analysis, as well as providing supervisory control in applications without time-critical requirements. Power-management systems are a direct application of SCADA technology.
TCP/IP	Transmission control protocol / Internet protocol. An industry-standard protocol typically used on Ethernet or token-ring LANs.
Waveform capture	A standard PMCS application that provides a window into power-quality data in an electrical system. Waveform capture is used to view snapshots of voltage and current waveforms from various points in an electrical system to analyze harmonics and unusual system behavior.

PMCS

Chapter 1: Introduction

Overview

The Power Management Control System (PMCS) accesses GE Multilin™ and third-party devices in a substation and provides graphical representations of status and energy trends, remote control, and automated responses. By optimizing methods used to control both processes and equipment, energy efficiency is realized.

PMCS is intended for installation with CIMPACTIVITY® HMI. The wizards contained in the PMCS software allow you to quickly build accurate and friendly user interfaces with CIMPACTIVITY. Installation of PMCS adds PMCS and EnerVista™ Integrator™ functionality to CIMPACTIVITY, where EnerVista Integrator integrates the comprehensive line of POWER LEADER™ devices, as well as many new Modbus remote terminal unit (RTU) devices and systems.

PMCS supports Ethernet and baud rates of up to 38.4 kbps on a Modbus-based network and 10 Mbps on an Ethernet TCP/IP network. This results in near real-time screen viewing and immediate access to critical event and alarm data.

This document provides an introduction to PMCS and outlines how to configure CIMPACTIVITY for PMCS and how to view information for devices. For information on devices supported, installation, and starting the software, see the PMCS Quickstart Guide.

Features

PMCS includes the following features that make the system powerful and easy to use:

- Compatible with industry-standard third-party supervisory control and data acquisition (SCADA) platforms
- Built-in Modbus RTU network compatibility for an open network architecture and high-speed communications
- Built-in Ethernet TCP/IP network compatibility for high-speed communication and reduced wiring costs
- 3D virtual-device interaction with accurately reproduced device look and feel
- Improved waveform capture, including extensive analysis tools
- Comprehensive alarm and event reporting for immediate diagnosis of electrical system problems

HMI application size

- 20,000 points/tags in human machine interface (HMI) database (30,000 maximum)
- 600 HMI alarms configured maximum
- 600 trended points (eight maximum per device)
- HMI I/O rates, alarm rates, and logging rates not to exceed 750 pts/sec
- 17 device types supported with two wizard types (Basic and Advanced) that can be configured using PowerBuilder
- 10% of tags connected to enterprise solution
- Web-enabled only via CIMPICITY WebView; no waveform or event viewers

Special application issues

- No redundancy

Performance

Response times:

- One second or less to open an HMI screen
- One second update time to populate a screen per device per serial port (except for UR-series and ELVS400 devices)
- 4 to 7 second time delay to display event in PMCS Event Viewer
- One second response time to make device change (settings/command coil) not including device feedback
- 1000 device events/sec burst support

Configuration:

- Maximum 15 devices per serial port
- Device baud rates set to maximum
- CIMPICITY HMI points set for on-demand
- Devices supporting 125 register block reads
- Average CPU utilization <35%
- 99% system uptime

OPC client data items size

- Up to 65,000 points/tags in OPC clients
- 10% of tags connected to enterprise solution

Devices supported

PMCS supports GE Multilin and third-party devices, including Modbus-based devices.

The table outlines the devices supported. The numbered products 239, 339, and so on, are also referred to as SR239, SR339, and so on. Firmware revisions other than those listed may not be compatible. When in doubt, contact your GE Sales Representative or GE Digital Energy as outlined in the [For further assistance](#) section.

Table 1: Devices supported by PMCS Devices

Device family	Device	Firmware
ATS	MX150	5.4x, 6.0x
	MX250	5.4x, 6.0x
	MX350	1.2x
UPS	UPS, UPS LP, UPS SG	1.0
Trip Units/Switchgear	Spectra MicroVersa Trip	5.1x
	Enhanced MicroVersa Trip C	4.1x
	Enhanced MicroVersa Trip D	4.1x
	GTU (EntelliGuard TU Trip Unit)	7.0x
	ELVS (Entellisys)	4.5x
	MET	12.02.02
Meters/Switches	PQM	3.3x to 3.6x
	PQMII	1.0x to 2.2x
	EPM1000	3.8x
	EPM2000	1.0x
	EPM2200	1.0x
	EPM4000	3.8x
	EPM5000P	2.4x
	EPM5300P	2.4x
	EPM5350P	2.4x
	EPM6000	1.0x
	EPM9450Q	2.1x
	EPM9650Q	2.1x
	EPM9800	6.1x
	ML2400	3.0x
Distribution Feeder	350	1.2x to 1.4x
	F35	2.6x to 5.9x
	F60	2.6x to 5.9x
	F650	1.6x to 5.4x
	MIF 2	4.0
	735/737	1.5x
	750/760	3.6x to 7.4x
	G30	4.4x to 5.9x
	G60	2.6x to 5.9x
Generator	489	1.3x to 4.03x
	D30	5.0x to 5.9x
	D60	2.6x to 5.9x
	D90 ^{Plus}	1.8x

Device family	Device	Firmware
Line Current Differential Protection	L30	5.6x to 5.9x
	L60	2.6x to 5.9x
	L90	2.6x to 5.9x
Transformer	745	2.4x to 5.2x
	T35	2.6x to 5.9x
	T60	2.6x to 5.9x
	345	1.3x to 1.4x
Motor	239	2.3x to 2.7x
	269+	6.0x
	339	1.3x to 1.4x
	369	1.6x to 3.4x
	469	2.5x to 5.1x
	MM200	1.0x to 1.2x
	MM300	1.2x to 1.5x
	MMII	4.0x to 5.2x
	MMIII	1.0 to 1.2x
	RRTD	1.4x, 1.5x
	SPM	2.0x, 2.1x
	M60	2.6x to 5.9x
Network	N60	3.4x to 5.9x
Bus	B30	2.6x to 5.9x
	B90	4.8x to 5.9x
Specialized	C30	2.6x to 5.9x
	C60	2.6x to 5.9x
	C90 ^{Plus}	1.6x to 1.8x
Miscellaneous	MRPO	1.0
	FIRETRACER	1.0
	VERSAMAX	1.0

PMCS includes a set of customized wizard screens for the devices listed in the following table.

Table 2: Customized wizard screens

Device family	Device
Trip Units/Switchgear	Spectra MicroVersa Trip
	Enhanced MicroVersa Trip C
	Enhanced MicroVersa Trip D
	GTU (EntelliGuard TU Trip Unit)
	ELVS (Entellisys)
Meters	PQM
	PQMII
	EPM9450Q
	EPM9650Q
Distribution Feeder	735/737
	750/760

Device family	Device
Generator	489
Transformer	745
Motor	469
Universal Relays	UR

For further assistance

For product support, contact the information and call center as follows. Have your software key(s) ready.

GE Digital Energy

650 Markland Street

Markham, Ontario

Canada L6C 0M1

Worldwide telephone: +1 905 927 7070

Europe/Middle East/Africa telephone: +34 94 4854 88 54

North America toll-free: 1 877 547 8630

Fax: +1 905 927 5098

E-mail: multilin.tech@ge.com

Website: <http://gedigitalenergy.com/multilin>

Comments about new features or modifications for specific requirements are welcome.

FOR FURTHER ASSISTANCE

CHAPTER 1: INTRODUCTION

PMCS

Chapter 2: Configure CIMPLICITY

To use PMCS in CIMPLICITY, the latter needs to be configured for it. This chapter outlines how to add a project for PMCS in CIMPLICITY.


Add PMCS project in CIMPLICITY

This section outlines how to place and configure a PMCS wizard in CIMPLICITY HMI. You do this by adding a project in CIMPLICITY for PMCS.

To add a PMCS project in CIMPLICITY:

1. In CIMPLICITY HMI, create a new project by clicking the **New Project** button or selecting **File > New Project**. A window opens.
2. Enter a **Project Name** and select a folder in which to store the project (usually in the `cimlicity\hmi\projects\` folder). Under **Options**, select **PMCS PowerBuilder** and under **Protocols**, select **OPC Client**. Click the **Create** button to write the project file to disk and open the Project Properties window. See the following figure.

Figure 1: Creating a new project in CIMPICITY




3. In the Project Properties window, click the **Options** tab, and select the **Enable project broadcast** checkbox if you want to use CIMPICITY HMI remote view nodes. Ensure that the **Computer name** field matches the name of the host machine. Disregard the **Startup timeout** field and the **General** tab. Click **OK** to open the CIMPICITY HMI Project Wizard.

Figure 2: Project Properties window




4. Complete the CIMPICITY Project Wizard. At the end, click **Finish** to complete the setup.

Figure 3: CIMPICITY Project Wizard




5. Access the CIMPICITY Workbench view for the project.

Figure 4: CIMPICITY Workbench window



6. With CIMPICITY Project no longer running, double-click the **PMCS PowerBuilder** item. When CIMPICITY Project is still running, the following error message displays; close the project window. Once PMCS PowerBuilder has launched, you can view device data as outlined in the next chapter.

Figure 5: Error message when CIMPICITY still running



With successful launch of PMCS PowerBuilder, any supported devices configured in the PMCS configurator display in a list. If this configuration has not been done, do so now using the Quickstart Guide, then run PowerBuilder after device configuration is complete.

On first run, PowerBuilder reads the device configuration details from the server topic files (TOPIC.CFG). It populates the list with configured devices in the default one-line options, as shown in the following figure.

On next run, PowerBuilder loads the device details from the topic files and sets the one-line preferences of already configured devices as per previous configuration. The **Created** check box is enabled for these devices.

The next chapter explains how to use the main PowerBuilder window and the information available for various devices.

Figure 6: Devices listed in PMCS PowerBuilder

The screenshot shows a software window titled "PMCSPowerBuilder - C:\Manoj_work\Work\PMCS 7\Test Cim Projects\PowerBuilderTestProj\POWERBUILDERTESTPROJ.gef". The main title bar is "Select Devices to be Configured in Cimplicity Project". The table has columns: Device Name, Device Type, Server, Wizard, Created, and OPC Port. The "Created" column contains checkboxes, and the "OPC Port" column contains text entries. The data is as follows:

Device Name	Device Type	Server	Wizard	Created	OPC Port
EM_ELVS400	ELVS400	GE32MTCP	Basic	<input checked="" type="checkbox"/>	OPC_0
EM_EMVTC	EMVTC	GE32MTCP	Basic	<input checked="" type="checkbox"/>	OPC_0
EM_EMVTD	EMVTD	GE32MTCP	Basic	<input checked="" type="checkbox"/>	OPC_0
EM_GTU	GTU	GE32MODB	Basic	<input checked="" type="checkbox"/>	OPC_0
EM_MLPQMII	MLPQMII	GE32MTCP	Basic	<input checked="" type="checkbox"/>	OPC_0
LAB_ML489	ML489	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0
LAB_ML745	ML745	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0
LAB_ML750	ML750	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0
LAB_ML760	ML760	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0
LAB_MLPQM	MLPQM	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0

PMCS


Chapter 3: PowerBuilder window

The main window PMCS PowerBuilder allows access to device information. This chapter explains the window. The information displayed was entered during installation of PMCS; to add devices, see the PMCS Quickstart Guide.

PowerBuilder window explained

To launch PowerBuilder, double-click the **PMCS PowerBuilder** menu item as outlined at the end of the previous chapter.

Figure 7: CIMPACT Workbench window



The following figure shows an example of the main PMCS PowerBuilder window. Devices with an ML prefix refer to GE Multilin products. Such products are referred to elsewhere in this document without the prefix, for example 369 instead of ML369.

Figure 8: Devices listed in PMCS PowerBuilder

The screenshot shows a software interface titled "PMCSPowerBuilder - C:\Manoj_work\Work\PMCS 7\Test Cim Projects\PowerBuilderTestProj\POWERBUILDERTESTPROJ.gef". The main window is a table titled "Select Devices to be Configured in Cimplicity Project". The columns are: Device Name, Device Type, Server, Wizard, Created, OPC Port, Faceplate, Symbol, and Data Table. There are 12 rows of data. The "Created" column contains checkboxes, with the first one checked. The "OPC Port" column contains "OPC_0" for most rows, except for the last two which have "None". The "Data Table" column contains "4 Lines" for the first row, "2 Lines" for the second, "2 Lines" for the third, "3 Lines" for the fourth, "None" for the fifth, "None" for the sixth, "3 Lines" for the seventh, "3 Lines" for the eighth, "4 Lines" for the ninth, and "2 Lines" for the tenth. The bottom of the window has buttons for "Preferences", "Help", "Generate", and "Cancel".

Select Devices to be Configured in Cimplicity Project									Select All Devices	Clear All Devices
Device Name	Device Type	Server	Wizard	Created	OPC Port	Faceplate	Symbol	Data Table		
EM_ELV400	ELVS400	GE32MTCP	Basic	<input checked="" type="checkbox"/>	OPC_0	Style 1	Style 3	4 Lines		
EM_EMVTC	EMVTC	GE32MTCP	Basic	<input checked="" type="checkbox"/>	OPC_0	None	Style 3	2 Lines		
EM_EMVTD	EMVTD	GE32MTCP	Basic	<input checked="" type="checkbox"/>	OPC_0	Style 1	Style 1	2 Lines		
EM_GTU	GTU	GE32MODB	Basic	<input checked="" type="checkbox"/>	OPC_0	Style 1	Style 1	3 Lines		
EM_MLPQMII	MLPQMII	GE32MTCP	Basic	<input checked="" type="checkbox"/>	OPC_0	Style 1	None	None		
LAB_ML489	ML489	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0	Style 1	None	None		
LAB_ML745	ML745	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0	Style 2	None	3 Lines		
LAB_ML750	ML750	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0	Style 1	Style 2	3 Lines		
LAB_ML760	ML760	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0	Style 1	Style 2	4 Lines		
LAB_MLPQM	MLPQM	GE32MTCP	Basic	<input type="checkbox"/>	OPC_0	Style 1	None	2 Lines		

Settings

The following settings are available in the PowerBuilder window.

Device Name

This is a read-only field populated from the device name topic file. An example is Mill_Relay.

Device Type

This is a read-only field populated from the device type topic file. An example is EMVTC.

Server

This is a read-only field populated from the device name and based on the Server (GE32MTCP/GE32MODB) topic file.

Wizard

Two types of wizards are available: basic and advanced. This field indicates the available wizard. By default, basic is selected. The basic wizard contains a single **Overview** tab, which consists metering data and device front panel LED status. The advanced wizard contains multiple tabs, including the **Overview**, **Settings**, **Commands**, **IO**, and **Analysis** tabs.

Created

When a checkbox is already selected, it means that the device has already been configured in CIMPLICITY Project. To configure any additional devices, enable the appropriate checkbox.

Normally, after first installation, you ensure that all checkboxes are selected so that all devices are configured. Then when you later add devices, you select the checkboxes here, then click the **Generate** button to proceed with configuration. The **Generate** button is explained later in this chapter.

OPC Port

The object linking and embedding for process control (OPC) port. The default is OPC_0.

This setting controls how CIMPACTY manages devices. Giving several devices the same OPC Port, such as OPC_0, means that there is a collection of devices in a virtual port, similar to a group devices.

Faceplate

The faceplate style available. The default value is taken from the preference option for that device type:

- None
- Style 1
- Style 2

This setting is not for setting the faceplates displayed in the windows for each device (as shown in the next chapter).

Table 3: Faceplate styles

Device name	Style 1 - 2D small faceplate	Style 2 - 3D small faceplate
GTU		
MVT		
EMVT		
469		
489		

Device name	Style 1 - 2D small faceplate	Style 2 - 3D small faceplate
735/737		
745		
750/760		
PQM		
PQMII		
UR		
EPM9450		
EPM9650		
ELVS400		

Symbol

The list of available symbol options. The default value is taken from the preference option for that device type:

- None
- Style 1
- Style 2
- Style 3

Table 4: Symbols

Style	No communication	Breaker open	Breaker closed	Breaker trip	Breaker racked out
None					
Style 1					
Style 2					
Style 3					

Data Table

The available data display options. The default value is taken from the preference option for that device type.

Table 5: Data Table

Data Table option	Data displayed
None	
2 Lines	Line 1, 2
3 Lines	Line 1, 2, 3
4 Lines	Line 1, 2, 3, 4
5 Lines	Line 1, 2, 3, 4, 5

Table 6: Data Table lines

Device	Line 1	Line 2	Line 3	Line 4	Line 5
ELVS	Real Power	Avg Current	Avg Voltage	% LOAD	FREQ
EMVTC	Real Power	Avg Current	Avg Voltage	% LOAD	Avg PF
EMVTD	Real Power	Avg Current	Avg Voltage	% LOAD	Avg PF
MVT	Real Power	Avg Current	Avg Voltage	% LOAD	Avg PF
GTU	Real Power	Avg Current	Avg Voltage	% LOAD	Avg PF
PQM	Real Power	Avg Current	Avg Voltage	FREQ	Avg PF
PQMII	Real Power	Avg Current	Avg Voltage	FREQ	Avg PF
EPM9650/9450	Real Power	Avg Current	Avg Voltage	FREQ	Avg PF
469	Real Power	Avg Current	Avg Voltage	RPM	Thermal Capacity
489	Generator Load	Avg Current	Avg Voltage	RPM	GEN LOAD
735/737	Average Current	Ground Current	--	--	--
745	W1 Real Power	W1 Avg Current	W2 Real Power	W2 Avg Current	FREQ
750/760	Real Power	Avg Current	Avg Voltage	% LOAD	FREQ
UR	Src1 Real Power	Src1 Avg Current	Src1 Avg Voltage	AvgPF	FREQ

The figure shows the formats for the two to five-line options, followed by an example.

Figure 9: Two to five-line formats



Figure 10: Two to five-line examples

-0.03 kW 0.19 A	-0.03 kW 0.19 A 55.63 V	-0.03 kW 0.19 A 55.63 V 0.96 Lag	-0.03 kW 0.19 A 55.63 V 0.96 Lag 49.89 Hz
--------------------	-------------------------------	---	---

The 735 and 737 have two lines of data available, these being average and ground current.

Figure 11: Display for 735/737





Figure 12: Example for 735/737



Buttons

The following buttons are available in the PowerBuilder window.

Select All Devices

Sets the **Created** checkboxes for all the devices to the checked state.


Clear All Devices

Sets the **Created** checkboxes for all the devices to the unchecked state.

ELVS Device Name

ELVS devices have a button beside the device name. Click the button to show the Entellisys breaker configuration window, where you specify the number of breakers and a name for each. The default name for each breaker is in the form BKR1, BKR2, and so on. To change the name, type in the field. The information is used in class object creation and passed on to the respective CIMPPLICITY screens. When the number of breakers specified is greater than the actual number, blank rows appear at the end. When the number of breakers specified is less than the actual number, rows are removed from the end.


Figure 13: Entellysis breaker configuration window



Preferences

Opens the Preferences window to configure the default one-line options for each device type supported in PMCS. To change a value, type in the field.

Figure 14: Set default values in Preferences window



Help


Opens the PMCS online help window.

Generate

Initiates CIMPICITY project creation and includes all the devices that have the **Created** checkbox enabled. It also removes any devices that were configured in the project and have the **Created** checkbox unselected. See the previous chapter for instruction on creating a project.

Once the **Generate** button is clicked, it generates a MainMenu.cim file, which can be viewed by clicking the **Screens** menu item.

Figure 15: Viewing the MainMenu.cim file



For devices with the **Created** checkbox enabled, based on the default options set, such as Faceplate, Symbol, and Data Table, the options generate as objects in the **MainMenu.cim** file and are overlaid on one another.

Figure 16: Objects in the MainMenu.cim file

**Cancel**

Discards any changes done in the configuration options and closes the PowerBuilder window.

PMCS

Chapter 4: Device information

This chapter explains the information displayed for several devices.

The windows vary with device. Content can include the following:

- Tabs with data
- Event log button, including the ability to clear the logs
- Trend data button
- Waveform button

The buttons are inactive when not applicable, for example when no trend window was specified in the Objects Properties window or when waveform capture is not supported by a device.

Content also varies with security level. When security is enabled in your application, the user must have an access level greater than or equal to the access level configured for each tabular wizard in order to issue device commands. See the CIMPACT documentation for information on how to use security features.

469

This section explains the information displayed in PMCS for 469 motor management relays, which are also referred to as ML469 and SR469.


Overview tab

This tab displays

- Current
- Voltage
- Power
- System frequency
- Motor data
- Digital input status
- Relay status
- Motor status

- Hottest stator
 - Output status

Figure 17: 469 Overview tab



Metering tab

This tab displays

- Differential currents
- Demand metering
- Energy consumption of the 469

Figure 18: 469 Metering tab

The screenshot shows the GE Power Management System (PMCS) interface for a device named MOTORMNGMENTRLYML469. The top navigation bar includes tabs for Overview, Metering (which is selected), RTD, Maintenance, Learned, Settings, and Commands. An alarm status indicator shows 71 UnAcknowleged Alarms. The main content area is divided into several sections:

- Differential Currents:** A table showing Current (Amps) for phases Ia, Ib, and Ic, all of which are 0.
- Demand Metering:** A table showing Demand and Peak values for Current (Amps), Real (kW), Reactive (kvar), and Apparent (kVA). The peak current is 755 Amps.
- Energy:** A table showing Positive WattHours (MWh), Positive VarHours (Mvarh), and Negative VarHours (Mvarh). The total positive watt hours are 0.000 MWh.

On the left side, there is a sidebar with device configuration parameters:

Device Name	MOTORMNGMENTRLYML469
Device Type	ML469
Hardware Revision	I
Firmware Revision	5.01
Boot Program Revision	4.00
VT Connection Type	Wye


At the bottom of the interface are buttons for Events, Trend, Wave, and Exit.

RTD tab

This tab displays

- Resistive temperature device (RTD) information

Figure 19: 469 RTD tab



Maintenance tab

This tab displays

- Trip data
- General timers and counters

Figure 20: 469 Maintenance tab

The screenshot shows the TEST software interface with the following details:

Device Information:

- Device Name: MOTORMNGMENTRLYML469
- Device Type: ML469
- Hardware Revision: 1
- Firmware Revision: 5.01
- Boot Program Revision: 4.00
- VT Connection Type: Wye

Maintenance Tab Content:

- Trip Data:**

Total Number of Trips	2
Cause of Last Trip	Volt. Frequency Trip
Date and Time of Last Trip	12/01/2012 18:19:25
- General Counters:**

Number of Motor Starts	3
Number of Emergency Restarts	0
Number of Starter Operations	2
- Timers:**

Motor Running Hours	309
Time Between Starts Timer	11

Bottom Navigation:

- Events
- Trend
- Wave
- Exit

Learned tab

This tab displays

- Learned motor starting data
- Learned motor load
- Learned analog input data
- Learned resistive temperature device (RTD) data

Figure 21: 469 Learned tab

The screenshot shows the GE Motor Management software interface. At the top, there's a header with the GE logo, the word "TEST", and a timestamp "12/05/2012 15:19:51". Below the header, the title bar reads "MOTORMNGMENTRLYML469". The main window has several tabs: Overview, Metering, RTD, Maintenance, Learned (which is selected and highlighted in blue), Settings, and Commands. On the left, there's a sidebar with device details: Device Name (MOTORMNGMENTRLYML469), Device Type (ML469), Hardware Revision (I), Firmware Revision (5.01), Boot Program Revision (4.00), and VT Connection Type (Wye). The central content area contains three tables under the Learned tab:

Learned Motor Starting Data		Learned RTD Data °F	
Acceleration Time (s)	1.3	RTD 1	No RTD
Starting Current (A)	179	RTD 2	No RTD
Starting Capacity (%)	0	RTD 3	No RTD
Last Acceleration Time (s)	1.3	RTD 4	No RTD
Last Starting Current (A)	375	RTD 5	No RTD
Last Starting Capacity (%)	0	RTD 6	No RTD
		RTD 7	No RTD
		RTD 8	No RTD
		RTD 9	No RTD
		RTD 10	No RTD
		RTD 11	No RTD
		RTD 12	No RTD

Learned Motor Load		
Average Motor Load	0.13 FLA	

Learned Analog Input Data		
	Minimum	Maximum
Analog Input 1	-50000	2000
Analog Input 2	-50000	200
Analog Input 3	N/A	N/A
Analog Input 4	N/A	N/A

At the bottom of the interface, there are buttons for Events, Trend, Wave, and Exit.

Settings tab

This tab displays

- System setup
- Thermal model

Figure 22: 469 Settings tab

The screenshot shows the TEST software interface with the following details:

Top Bar: TEST, MOTORMNGMENTRLYML469, Alarm Status (7 UnAcknowledged Alarms), 12/05/2012 15:20:04, and a Help icon.

Left Sidebar: Displays a thumbnail image of the device and a table with the following device information:

Device Name	MOTORMNGMENTRLYML469
Device Type	ML469
Hardware Revision	I
Firmware Revision	5.01
Boot Program Revision	4.00
VT Connection Type	Wye

Main Content Area: The Settings tab is selected, showing two tables: System Setup and Thermal Model.

System Setup Table:

System Setup	
Phase CT Primary (Amps)	2500
Motor Full Load Amps (Amps)	2770
Ground CT Type	50/0.025 CT
Ground CT Primary (Amps)	100
Phase Diff. CT Type	1 A Secondary
Phase Differential CT Primary (Amps)	10
Enable Two Speed Motor Option	On
Speed Two Phase CT Primary (Amps)	100
Speed Two Motor Full Load (Amps)	1
VT Connection Type	Wye
One VT Connection	Off
Voltage Transformer Ratio	35.00
Motor Nameplate Voltage (Volts)	100
Nominal Frequency	50 Hz
System Phase Sequence	ABC
Serial Communication Control	On

Thermal Model Table:

Thermal Model	
Curve Style	Standard
Overload Pickup Level (FLA)	1.25
Unbalance k Factor	2
Cool Time Constant Running (min)	1
Cool Time Constant Stopped (min)	1
Hot/Cold Safe Stall Ratio	1.00
RTD Biasing	On
RTD Bias Minimum (°C)	40
RTD Bias Center Point (°C)	130
RTD Bias Maximum (°C)	155
Thermal Capacity Alarm	Off
Thermal Capacity Alarm Relays	Alarm
Thermal Capacity Level (% used)	100
Thermal Capacity Events	Off
Overload Trip Relays	Trip

Bottom Navigation: Events, Trend, Wave, Exit.

Commands tab

The following functions are available.

Table 7: 469 commands available

Button	Function
Reset Device	Issues a reset command to the 469
Motor Start	Issues Motor Start command
Motor Stop	Issues Motor Stop command
Reset MWh & Mvarh	Clears these values from the 469 memory
Clear Peak Demand	Clears this data from memory
Clear Analog Input Min/Max	Clears this data from memory
Clear RTD Maximums	Resets the RTD maximums data
Clear Trip Counters	Clears the trip count data from memory
Clear Last Trip Data	Clears this data from memory
Reset Starter Information	Clears motor start information from memory

Figure 23: 469 Commands tab



489


This section explains the information displayed in PMCS for 489 generator management relays, which are also referred to as ML489 and SR489.

Overview tab

This tab displays

- Current
- Voltage
- Power
- Voltage data
- System frequency
- Generator data
- Digital input status
- Relay status
- Generator status
- Hottest stator
- Output status

Figure 24: 489 Overview tab



Metering tab

- This tab displays
- Differential currents
 - Demand metering
 - Energy

Figure 25: 489 Metering tab

The screenshot shows the GE Power Management System (PMCS) interface for a device named "GENERATORMNGMNTML489". The "TEST" tab is active. The "Metering" tab is selected. The interface includes a device image, a status bar with "Alarm Status" (71 UnAcknowledged Alarms) and date/time (12/05/2012 15:15:24), and a navigation menu with tabs: Overview, Metering, RTD, Maintenance, Learned, Settings, and Commands.

Differential Currents

	I _a	I _b	I _c
Current (Amps)	14896	1176	7546
Angle (Deg)	0	0	0

Demand Metering

	Demand	Peak
Current (Amps)	14862	15075
Real (MW)	0.000	0.000
Reactive (Mvar)	0.395	0.506
Apparent (MVA)	3.389	4.116

Energy

Positive Watthours (MWh)	0.000
Positive Varhours (Mvarh)	344.424
Negative Varhours (Mvarh)	0.596


At the bottom left are buttons for Events, Trend, Wave, and Exit.

RTD tab

This tab displays

- Resistive temperature device (RTD) information, where this function varies resistance based on temperature

Figure 26: 489 RTD tab



Maintenance tab

This tab displays

- Trip data
- General timers and counters

Figure 27: 489 Maintenance tab

The screenshot shows the GE Power Management System (PMCS) interface. At the top, there's a header bar with the GE logo, the word "TEST", the device name "GENERATORMNGMNTML489", and an "Alarm Status" indicator showing 71 Unacknowledged Alarms. The date and time "12/05/2012 15:15:51" are also displayed. Below the header is a navigation menu with tabs: Overview, Metering, RTD, Maintenance (which is selected), Learned, Settings, and Commands. On the left side, there's a sidebar with a thumbnail image of a control panel and a list of device parameters:

Device Name	GENERATORMNGMNTML489
Device Type	ML489
Hardware Revision	K
Firmware Revision	32K403A8.000
Boot Program Revision	32K401A0.000
VT Connection Type	Open Delta

Below the sidebar, the main content area is titled "TEST" and shows three sections: "Trip Data", "General Counters", and "Timers".

Trip Data:

Total Number of Trips	0
Cause of Last Trip	No Event
Date and Time of Last Trip	01/01/2000 09:00:00

General Counters:

Number of Breaker Operations	0
Number of Thermal Resets	0

Timers:

Generator Hours Online	0 hrs
------------------------	-------

At the bottom left of the main content area, there are four buttons: Events, Trend, Wave, and Exit.

Learned tab

This tab displays

- Learned parameter averages
- Learned analog input data
- Learned resistive temperature device (RTD) data

Figure 28: 489 Learned tab

The screenshot shows the GE PMCS software interface for a device named "GENERATORMNGMNTML489". The main window title is "TEST" and the sub-title is "GENERATORMNGMNTML489". The interface is divided into several sections:

- Left Sidebar:** Displays a thumbnail image of the device hardware and a table with the following device details:

Device Name	GENERATORMNGMNTML489
Device Type	ML489
Hardware Revision	K
Firmware Revision	32K403A8.000
Boot Program Revision	32K401A0.000
VT Connection Type	Open Delta
- Main Panel:** Contains several tables under the "Learned" tab:
 - Learned Parameter Averages:**

Generator Load	2 % FLA
Negative Sequence Current	2 % FLA
Phase to Phase Voltage	N/A
 - Learned Analog Input Data:**

	Minimum	Maximum
Analog Input 1	N/A	N/A
Analog Input 2	0	0
Analog Input 3	0	0
Analog Input 4	0	0
 - Learned RTD Data °C:**

RTD	RTD Status
RTD 1	No RTD
RTD 2	No RTD
RTD 3	No RTD
RTD 4	No RTD
RTD 5	No RTD
RTD 6	No RTD
RTD 7	No RTD
RTD 8	No RTD
RTD 9	No RTD
RTD 10	No RTD
RTD 11	No RTD
RTD 12	No RTD
- Bottom Navigation:** Buttons for "Events", "Trend", "Wave", and "Exit".

Settings tab

- This tab displays
- System setpoints
 - Thermal model

Figure 29: 489 Settings tab

The screenshot shows the PMCS software interface with the title bar "TEST" and "GENERATORMNGMNTML489". The top right corner displays "Alarm Status" with 71 UnAcknowledged Alarms and the date/time "12/05/2012 15:16:11". The main window has a navigation bar with tabs: Overview, Metering, RTD, Maintenance, Learned, Settings (selected), and Commands. Below the tabs is a sidebar with device information: Device Name (GENERATORMNGMNTML489), Device Type (ML489), Hardware Revision (K), Firmware Revision (32K403A8.000), Boot Program Revision (32K401A0.000), and VT Connection Type (Open Delta). The main content area is divided into two tables: "System Setpoints" and "Thermal Model".

System Setpoints		Thermal Model	
Phase CT Primary (Amps)	N/A	Curve Style	Standard
Ground CT Type	1 A Secondary	Overload Pickup Level (FLA)	1.01
Ground CT Ratio	100 :1	Unbalance Bias K Factor	0
VT Connection Type	Open Delta	Cool Time Constant Online (min)	15
Voltage Transformer Ratio	5.00:1	Cool Time Constant Offline (min)	30
Neutral VT Ratio	5.00:1	Hot/Cold Safe Stall Ratio	1.00
Voltage Lower Limit	10 %	RTD Biasing	On
Voltage Level (x rated)	0.70	RTD Bias Minimum (°C)	40
Generator Rated MVA (MVA)	50.000	RTD Bias Center Point (°C)	130
Generator Rated PF	0.99	RTD Bias Maximum (°C)	155
Generator Voltage Phase-Phase (Volts)	100	Thermal Model Alarm	Latched
Generator Nominal Frequency (Hz)	60 Hz	Thermal Model Alarm Relays	Relay 5
Generator Phase Sequence	ABC	Thermal Alarm Level (% used)	75
Step Up Transformer Setup	None	Thermal Model Alarm Events	On
Pulse Width	200	Thermal Model Trip	Latched
		Thermal Model Trip Relays	Relay 1

At the bottom left of the main content area are four buttons: Events, Trend, Wave, and Exit.


Commands tab

The following functions are available.

Table 8: 489 commands available

Button	Function
Reset Device	Issues a reset command to the 489
Reset Breaker Information	Clears the breaker data from memory
Reset Generator Information	Clears the generator data from memory
Clear RTD Maximums	Clears the maximum RTD data from memory
Reset MWh & Mvarh Data	Clears the MWh and Mvarh data from memory
Clear Peak Demand Data	Clears the peak demand data from memory
Clear Analog Input Min/Max	Clears the analog input minimum/maximum data from memory
Clear Trip Counters	Clears the trip counter data from memory
Clear Last Trip Data	Clears the last trip data from memory

Figure 30: 489 Commands tab



735/737


This section explains the information displayed in PMCS for 735 and 737 products, which are also referred to as ML735/ML737 and SR735/SR737.

Overview tab

This tab displays

- Phase currents
- Status
- Output relays
- Trip
- Current level

Figure 31: 737 Overview tab



Trip Data tab

This tab displays

- Pre-trip current
- Trip cause

Figure 32: 737 Trip Data tab

The screenshot shows the 'TEST' interface for the device 'FEEDERPROTECTN_ML737'. The 'Trip Data' tab is active. On the left, there's a small image of the device and a table with device details. The main area has tabs for 'Overview', 'Trip Data', 'Settings', and 'Commands'. The 'Trip Data' tab is selected, showing two tables: 'Pre-Trip Current' and 'Trip Cause'. The 'Pre-Trip Current' table has four rows: Phase A (% of CT) 40, Phase B (% of CT) 41, Phase C (% of CT) 40, and Ground (% of CT) 40. The 'Trip Cause' table has six rows: Cause of Last Trip (Time OC trip: Phase A,B,C 98 milliseconds), Last OC Trip Time, Cause of 2nd Last Trip, Cause of 3rd Last Trip, Cause of 4th Last Trip, and Cause of 5th Last Trip.

Pre-Trip Current	
Phase A (% of CT)	40
Phase B (% of CT)	41
Phase C (% of CT)	40
Ground (% of CT)	40

Trip Cause	
Cause of Last Trip	Time OC trip: Phase A,B,C 98 milliseconds
Last OC Trip Time	
Cause of 2nd Last Trip	Time OC trip: Phase A,B,C
Cause of 3rd Last Trip	Time OC trip: Phase A,B,C
Cause of 4th Last Trip	Time OC trip: Phase A,B,C
Cause of 5th Last Trip	Time OC trip: Phase A,B,C

Settings tab

This tab displays

- Dial settings
- Option switches

Figure 33: 737 Settings tab

The screenshot shows the GE Power Management Control System (PMCS) interface for a device named FEEDERPROTECTN_ML737. The main window title is "TEST" and the sub-device name is "FEEDERPROTECTN_ML737". The top right corner shows "Alarm Status" with 711 UnAcknowledeged Alarms and the date/time "12/05/2012 15:14:34".

The interface has four tabs: "Overview", "Trip Data", "Settings" (which is selected and highlighted in blue), and "Commands".

The "Settings" tab is further divided into two sections:

- Dial Settings:** This section contains the following configuration parameters:

Phase Pickup (% of CT)	30
Phase Curve Shape	Definite time (low)
Phase Time Multiplier	1
Phase Instantaneous (x CT)	4
Ground Pickup (% of CT)	15
Ground Curve Shape	Definite time (low)
Ground Time Multiplier	1
Ground Instantaneous (x CT)	OFF
- Option Switches:** This section contains the following configuration parameters:

Phase Time Overcurrent Shift Multiplier	1.0
Ground Time Overcurrent Shift Multiplier	1.0
System Frequency (Hz)	60
Custom Scheme	Disabled

At the bottom left of the main window, there are four buttons: "Events", "Trend", "Wave", and "Exit".


Commands tab

The following functions are available.

Table 9: 735/737 commands available

Button	Function
Reset/Clear Device	Issues a reset command to the device.
Clear Last 5 Trip Causes	Clears the last five trip causes from the device

Figure 34: 737 Commands tab



745


This section explains the information displayed in PMCS for 745 transformer management relays, which are also referred to as ML745 and SR745.

Overview tab

This tab displays

- Current
- Power
- Demand
- Energy
- Voltage information
- System frequency
- Relay status
- System status
- Conditions
- Transformer data

Figure 35: 745 Overview tab




Harmonics tab

This tab displays

- Winding 1 - Total harmonic distortion (THD)
- Winding 1 - Harmonics
- Winding 1 - Current demand

Figure 36: 745 Harmonics tab




Analysis tab

This tab displays

- Winding 1 - Current symmetrical components
- Differential currents
- Restraint currents

Figure 37: 745 Analysis tab



IO tab

This tab displays

- Logic inputs
- Virtual inputs
- Output relays
- Virtual outputs

Figure 38: 745 IO tab

The screenshot shows the 'TEST' software interface for a device named 'TRANSFORMERPROML745'. The main window has tabs for Overview, Harmonics, Analysis, IO, Settings, and Commands. The IO tab is active, displaying four sections: Logic Inputs, Virtual Inputs, Output Relays, and Virtual Outputs.

Logic Inputs:

Logic Input Name	Status
Logic Input 1 Name	Orange
Logic Input 2 Name	Orange
Logic Input 3 Name	Orange
Logic Input 4	Blue
Logic Input 5	Blue
Logic Input 6	Blue
Logic Input 7	Blue
Logic Input 8	Blue
Logic Input 9	Blue
Logic Input 10	Blue
Logic Input 11	Blue
Logic Input 12	Blue
Logic Input 13	Blue
Logic Input 14	Blue
Logic Input 15	Blue
Logic Input 16	Blue

Virtual Inputs:

Virtual Input Name	Status
Virtual Input 1	Orange
Virtual Input 2	Blue
Virtual Input 3	Blue
Virtual Input 4	Blue
Virtual Input 5	Blue
Virtual Input 6	Blue
Virtual Input 7	Blue
Virtual Input 8	Blue
Virtual Input 9	Blue
Virtual Input 10	Blue
Virtual Input 11	Blue
Virtual Input 12	Blue
Virtual Input 13	Blue
Virtual Input 14	Blue
Virtual Input 15	Blue
Virtual Input 16	Blue

Output Relays:

Output Relay Name	Status
Solid State Trip	Blue
Trip 1	Blue
Trip 2	Blue
Volts/Hertz Trip	Blue
Overflux Alarm	Blue
Frequency Trip 1	Blue
Frequency Trip 2	Blue
Frequency Trip 3	Blue
Self-Test Relay	Blue

Virtual Outputs:

Virtual Output Name	Status
Virtual Output 1	Orange
Virtual Output 2	Orange
Virtual Output 3	Blue
Virtual Output 4	Blue
Virtual Output 5	Blue

At the bottom left, there are buttons for Winding 1, Winding 2, Winding 3, Events, Trend, Wave, and Exit.

Settings tab

This tab displays

- System setup
- Analog outputs

Figure 39: 745 Settings tab

System Setup		Analog Outputs	
Nominal Phase to Phase Voltage (kV)	220.0	Analog Output 1	W1 øA Current
Rated Load (MVA)	100.0	Analog Output 2	W1 øA Current
Series 3 Phase Resistance (Ohms)	10.700	Analog Output 3	W1 øA Current
Transformer Type	Y/d30°	Analog Output 4	W1 øA Current
Phase Sequence	ABC	Analog Output 5	W1 øA Current
Nominal Frequency (Hz)	60	Analog Output 6	W1 øA Current
Voltage Sensing	Enabled	Analog Output 7	W1 øA Current
Nominal VT Secondary Volts	120.0		
VT Ratio	100:1		
Winding with Tap Changer	Winding 1		
# of Tap Positions	50		
Active Setpoints Group	4		

Commands tab

The following functions are available.

Table 10: 745 commands available

Button	Function
Reset Relay	Issues a reset command to the device
Reset Peak Demand	Clears the maximum demand data from the 745 memory
Reset Energy	Resets the energy counters to zero
Reset Loss of Life	Clears loss-of-life data from the 745 memory

Figure 40: 745 Commands tab



750/760


This section explains the information displayed in PMCS for 750 and 760 feeder management relays, which are also referred to as ML750/ML760 and SR750/SR760.

Overview tab

This tab displays

- Current
- Energy
- Voltage
- Power

Figure 41: 750 Overview tab



Demand tab

This tab displays

- Current demand
- Three-phase power demand

Figure 42: 750 Demand tab

The screenshot shows the GE Power Management System (PMCS) Demand tab. On the left, there is a sidebar with device information:

Device Name	FEEDERMNGMNTRLYML750
Device Type	SR750
Hardware Revision	L
Software Revision	7.31
Boot Program	6.01
VT Connection Type	Delta
Mod File Number	0
Manufacture date	05 / 13 / 2011

At the top, there is a navigation bar with tabs: Overview, Demand, Analysis, Synchro, IO, Settings, and Commands. The Demand tab is selected. Below the navigation bar, there are two tables:

Current Demand			
	Present	Maximum	Time of Maximum
Phase A (Amps)	14924	17670	09/28/2012 09:18:37.341
Phase B (Amps)	1227	10996	11/07/2012 12:35:28.313
Phase C (Amps)	7580	16998	09/13/2012 19:50:17.208

3 Phase Power Demand			
	Present	Maximum	Time of Maximum
Real (MW)	-90.80	-367.30	11/20/2012 23:20:00.410
Reactive (Mvar)	8.40	17.30	10/09/2012 16:20:00.269
Apparent (MVA)	91.20	367.40	11/20/2012 23:20:00.410


At the bottom, there are four buttons: Events, Trend, Wave, and Exit.

Analysis tab

This tab displays

- Current symmetrical components
- Bus voltage symmetrical components

Figure 43: 750 Analysis tab




Synchro tab

This tab displays

- Voltage phasor
- Frequencies
- Phase difference
- Frequency difference
- Synchronous voltages difference

Figure 44: 750 Synchro tab



IO tab

This tab displays

- Contact inputs
- Contact outputs
- Virtual inputs

Figure 45: 750 IO tab

The screenshot shows the GE Power PMCS software interface for a device named FEEDERMNGMNTRLYML750. The main window title is "TEST". The "IO" tab is selected. On the left, there's a device image and a table of device parameters. The central area contains three main tables:

- Contact Inputs:** A 7x4 grid where each row represents a contact input from 1 to 7, and each column represents a contact output from 8 to 14. All cells are empty (white).
- Contact Outputs:** A 7x2 grid where each row represents a contact output type (Trip, Close, AUXILIARY, AUXILIARY, AUXILIARY, AUXILIARY, Self Test Warning) and each column represents a trip or close status. Most cells are empty, except for "Self Test Warning" which has a yellow background.
- Virtual Inputs:** A 10x4 grid where each row represents a virtual input from 1 to 10, and each column represents a virtual output from 11 to 14. All cells are empty.

At the bottom left, there are buttons for Events, Trend, Wave, and Exit.

Settings tab

This tab displays

- System setup

Figure 46: 750 Settings tab

The screenshot shows the GE Power Systems PMCS software interface. At the top, there's a header bar with the GE logo, the word "TEST", and an "Alarm Status" indicator showing 73 Unacknowledged Alarms. The date and time are listed as 12/05/2012 15:07:23. Below the header is a navigation bar with tabs: Overview, Demand, Analysis, Synchro, IO, Settings (which is selected), and Commands. A question mark icon is also present in the top right corner.

The main area is titled "FEEDERMNGMNTRLYML750". On the left, there's a sidebar with a thumbnail image of the device and a table of device parameters:

Device Name	FEEDERMNGMNTRLYML750
Device Type	SR750
Hardware Revision	L
Software Revision	7.31
Boot Program	6.01
VT Connection Type	Delta
Mod File Number	0
Manufacture date	05 / 13 / 2011

Below the sidebar is a large table titled "System Setup" containing various configuration parameters:

System Setup	
Phase CT Primary [Amps]	50000
Ground CT Primary [Amps]	50
VT Connection Type	Delta
Nominal VT Secondary Voltage [Volts]	120.9
Voltage Transformer Ratio	120.0
Nominal Frequency [Hz]	60
Line VT Connection	Vab
Line Nominal VT Secondary Voltage [Volts]	120.9
Line VT Ratio	120.0
Phase Sequence	ACB
Sensitive Gnd. CT Primary [Amps]	1000

At the bottom left of the main area, there are four buttons: Events, Trend, Wave, and Exit.


Commands tab

The following functions are available.

Table 11: 750/760 commands available

Button	Function
Reset Device	Issues a reset command to the 750/760
Reset Energy	Resets the energy counters to zero
Open Breaker	Issues Open Breaker command
Close Breaker	Issues Close Breaker command
Reset Trip Counters	Resets the 750/760 trip counters to zero
Reset Max Demand	Clears the maximum demand data from the 750/760 memory
Reset Arcing Current	Resets the arcing current data

Figure 47: 750 Commands tab



ELVS


This section explains the information displayed in PMCS for EntellisysLVS (ELVS) products.

Overview tab

This tab displays

- Current
- Voltage
- System frequency
- Breaker status
- Energy
- Demand

Figure 48: ELVS Overview tab




Analysis tab

This tab displays

- Current total harmonic distortion (THD)
- Voltage THD
- K factor

Figure 49: ELVS Analysis tab



Demand tab

This tab displays

- Demand
- Power factor
- Energy

Figure 50: ELVS Demand tab

The screenshot shows the 'Demand' tab of the ELVS software interface. At the top, there's a header bar with the text 'TEST', 'Alarm Status' (71 UnAcknowledged Alarms), and the date '12/05/2012 15:27:27'. Below the header is a navigation bar with tabs: Overview, Analysis, Demand, Preventative Maintenance, Contact Input, Contact Output, System Health, Relay Protection, and Settings. The 'Demand' tab is currently selected.

The main area is divided into three sections:

- Demand:** This section contains three tables. The first table shows Real Power, Reactive Power, and Apparent Power with their respective previous intervals, maximum values, and times of maximum. The second table shows Power Factor for Phase A, Phase B, Phase C, and 3 Phase. The third table shows Energy consumption for Positive Real Energy, Negative Real Energy, Positive Reactive Energy, Negative Reactive Energy, and Apparent Energy across phases A, B, C, and 3 Phase.
- System Health:** This section displays various device status parameters such as Device Name (LOVOLTSWIGEARELVS400), CPU Name (CPU-A), CPU/Messenger Protocol Version Number (1.00), Hardware Version (2.00), Firmware Version (4.81), Boot Code Version (2.00), Modbus Address (1), IP Address (192.168.1.107), Synchronization Hardware OK (green checkmark), Node Installed (green checkmark), and Node Commissioned (green checkmark).
- Events and Trend:** At the bottom left, there are two buttons: 'Events' and 'Trend'. Under 'Events', there are 'Wave' and 'Exit' buttons. Under 'Trend', there are 'Events' and 'Trend' buttons.

Preventative Maintenance tab

This tab displays

- Operation and preventative maintenance information
- Line up options
- Per breaker options

Figure 51: Preventative Maintenance tab

Preventive Maintenance	
Total Operations As per ANSI/IEEE C37.13 & C37.16	39
Total No-Load Operations As per ANSI/IEEE C37.13 & C37.16	31
Total Load Operations As per ANSI/IEEE C37.13 & C37.16	8
Total Fault Operations As per ANSI/IEEE C37.13 & C37.16	6
Breaker Percent Load Life As per ANSI C37.50	7.99
Percent Mechanical Life As per ANSI C37.50	0.31
Date of Initial Energization	11/10/2009 10:40:30
Hours of Operations	58963
Date of Last Operation	08/17/2012 14:50:00

Line Up Options		Per Breaker Options	
Synch Check Relay		Expanded Metering Count	9
Bus Differential Relay		Demand Metering Count	9
Multi Source Ground Fault		Advanced Metering Count	9
ZSI		Voltage Relay Count	9
High Resistance Ground Fault		High Current Relay Count	9
Waveform Capture		Frequency & Reverse power Relay Count	9

Events		Trend	
Wave	Exit		

Contact Input tab

- This tab displays
- Contact inputs

Figure 52: ELVS Contact Input tab

The screenshot shows the ELVS software interface for a Breaker # 1 BKR1. The main title is LOVOLTSWIGEARELVS400. The top menu bar includes Overview, Analysis, Demand, Preventative Maintenance, Contact Input (which is selected), Contact Output, System Health, Relay Protection, and Settings. The status bar at the top right shows Alarm Status (7 Un-Acknowledged Alarms) and the date/time 12/05/2012 15:27:58.

The central part of the screen is a table titled "Contact Inputs". The table has two columns: "Name" and "State". The "Name" column lists 32 entries from 1 to 32, all labeled "Entellisys Contact Input 0000xx". The "State" column contains 32 checkboxes, all of which are checked (filled with blue).

Contact Inputs					
	Name	State		Name	State
1	Entellisys Contact Input 000001	<input checked="" type="checkbox"/>	17	Entellisys Contact Input 000017	<input checked="" type="checkbox"/>
2	Entellisys Contact Input 000002	<input checked="" type="checkbox"/>	18	Entellisys Contact Input 000018	<input checked="" type="checkbox"/>
3	Entellisys Contact Input 000003	<input checked="" type="checkbox"/>	19	Entellisys Contact Input 000019	<input checked="" type="checkbox"/>
4	Entellisys Contact Input 000004	<input checked="" type="checkbox"/>	20	Entellisys Contact Input 000020	<input checked="" type="checkbox"/>
5	Entellisys Contact Input 000005	<input checked="" type="checkbox"/>	21	Entellisys Contact Input 000021	<input checked="" type="checkbox"/>
6	Entellisys Contact Input 000006	<input checked="" type="checkbox"/>	22	Entellisys Contact Input 000022	<input checked="" type="checkbox"/>
7	Entellisys Contact Input 000007	<input checked="" type="checkbox"/>	23	Entellisys Contact Input 000023	<input checked="" type="checkbox"/>
8	Entellisys Contact Input 000008	<input checked="" type="checkbox"/>	24	Entellisys Contact Input 000024	<input checked="" type="checkbox"/>
9	Entellisys Contact Input 000009	<input checked="" type="checkbox"/>	25	Entellisys Contact Input 000025	<input checked="" type="checkbox"/>
10	Entellisys Contact Input 000010	<input checked="" type="checkbox"/>	26	Entellisys Contact Input 000026	<input checked="" type="checkbox"/>
11	Entellisys Contact Input 000011	<input checked="" type="checkbox"/>	27	Entellisys Contact Input 000027	<input checked="" type="checkbox"/>
12	Entellisys Contact Input 000012	<input checked="" type="checkbox"/>	28	Entellisys Contact Input 000028	<input checked="" type="checkbox"/>
13	Entellisys Contact Input 000013	<input checked="" type="checkbox"/>	29	Entellisys Contact Input 000029	<input checked="" type="checkbox"/>
14	Entellisys Contact Input 000014	<input checked="" type="checkbox"/>	30	Entellisys Contact Input 000030	<input checked="" type="checkbox"/>
15	Entellisys Contact Input 000015	<input checked="" type="checkbox"/>	31	Entellisys Contact Input 000031	<input checked="" type="checkbox"/>
16	Entellisys Contact Input 000016	<input checked="" type="checkbox"/>	32	Entellisys Contact Input 000032	<input checked="" type="checkbox"/>

At the bottom left, there are buttons for Events, Trend, Wave, and Exit. On the right side, there are buttons for Prev, Next, and a page indicator showing 1 of 4.

Contact Output tab

This tab displays

- Contact outputs

Figure 53: ELVS Contact Output tab

The screenshot shows the 'Contact Output' tab of the ELVS software interface. At the top, there's a navigation bar with tabs: Overview, Analysis, Demand, Preventative Maintenance, Contact Input, Contact Output (which is selected), System Health, Relay Protection, and Settings. Below the navigation bar is a sub-navigation bar with tabs: Overview, Analysis, Demand, Preventative Maintenance, Contact Input, Contact Output, System Health, Relay Protection, and Settings. The main area contains a table titled 'Contact Outputs'. The table has two columns: 'Name' and 'State'. The 'Name' column lists 32 entries, each corresponding to an Entellisys Contact Output. The 'State' column shows the current state of each output. The table is paginated at the bottom right, showing '1 of 4'. On the left side of the interface, there's a sidebar with various device information and status indicators, including a small image of the physical breaker unit.


Contact Outputs					
	Name	State	Name	State	
1	Entellisys Contact Output 00001	<input type="checkbox"/>	17	Entellisys Contact Output 00017	<input type="checkbox"/>
2	Entellisys Contact Output 00002	<input type="checkbox"/>	18	Entellisys Contact Output 00018	<input type="checkbox"/>
3	Entellisys Contact Output 00003	<input type="checkbox"/>	19	Entellisys Contact Output 00019	<input type="checkbox"/>
4	Entellisys Contact Output 00004	<input type="checkbox"/>	20	Entellisys Contact Output 00020	<input type="checkbox"/>
5	Entellisys Contact Output 00005	<input type="checkbox"/>	21	Entellisys Contact Output 00021	<input type="checkbox"/>
6	Entellisys Contact Output 00006	<input type="checkbox"/>	22	Entellisys Contact Output 00022	<input type="checkbox"/>
7	Entellisys Contact Output 00007	<input type="checkbox"/>	23	Entellisys Contact Output 00023	<input type="checkbox"/>
8	Entellisys Contact Output 00008	<input type="checkbox"/>	24	Entellisys Contact Output 00024	<input type="checkbox"/>
9	Entellisys Contact Output 00009	<input type="checkbox"/>	25	Entellisys Contact Output 00025	<input type="checkbox"/>
10	Entellisys Contact Output 00010	<input type="checkbox"/>	26	Entellisys Contact Output 00026	<input type="checkbox"/>
11	Entellisys Contact Output 00011	<input type="checkbox"/>	27	Entellisys Contact Output 00027	<input type="checkbox"/>
12	Entellisys Contact Output 00012	<input type="checkbox"/>	28	Entellisys Contact Output 00028	<input type="checkbox"/>
13	Entellisys Contact Output 00013	<input type="checkbox"/>	29	Entellisys Contact Output 00029	<input type="checkbox"/>
14	Entellisys Contact Output 00014	<input type="checkbox"/>	30	Entellisys Contact Output 00030	<input type="checkbox"/>
15	Entellisys Contact Output 00015	<input type="checkbox"/>	31	Entellisys Contact Output 00031	<input type="checkbox"/>
16	Entellisys Contact Output 00016	<input type="checkbox"/>	32	Entellisys Contact Output 00032	<input type="checkbox"/>

System Health tab

This tab displays

- Messenger hardware health
- Messenger settings validation
- Messenger communication status
- Messenger control power

Figure 54: ELVS System Health tab



Relay Protection tab

This tab displays

- Over voltage
- Over frequency
- Under voltage
- Under frequency
- Reverse power
- Phase loss
- High current
- High resistance ground fault

Figure 55: ELVS Relay Protection tab

The screenshot shows the GE Power PMCS software interface for the Breaker # 1 BKR1. The main title bar says "TEST". The top navigation bar includes "Alarm Status" (71 UnAcknowledeged Alarms) and the date "12/05/2012 15:28:37". Below the title bar, there are tabs: Overview, Analysis, Demand, Preventative Maintenance, Contact Input, Contact Output, System Health, Relay Protection, and Settings. The "Relay Protection" tab is selected.

The left side of the screen displays device configuration details:

Device Name	LOVOLTSWIGEARELVS400
CPU Name	CPU-A
CPU/Messenger Protocol Version Number	1.00
Hardware Version	2.00
Firmware Version	4.81
Boot Code Version	2.00
Modbus Address	1
IP Address	192.168.1.107
Synchronization Hardware OK	[Green LED icon]
Node Installed	[Green LED icon]
Node Commissioned	[Green LED icon]

Below the configuration details are four small buttons: Events, Trend, Wave, and Exit.

The main area of the screen is divided into several sections for different protection types:

- Over Voltage:** Includes fields for Pickup Setting (%), Time Delay (Seconds), Phase Requirement, and Open/Trip. Trip conditions: 1 Phase Violates Threshold, Trip & Activate Lockout.
- Over Frequency:** Includes fields for Pickup Setting (Hz), Time Delay (Seconds), Blocking Voltage Sett. (%), and Open/Trip. Trip conditions: Open & Don't Activate Lockout.
- Under Voltage:** Includes fields for Curve Type, Pickup Setting (%), Time Delay (Seconds), Phase Requirement, Blocking Voltage Sett. (%), and Open/Trip. Trip conditions: 1 Phase Violates Threshold, 1 Phase Violates Threshold, 5.0, Open & Don't Activate Lockout.
- Under Frequency:** Includes fields for Pickup Setting (Hz), Time Delay (Seconds), Blocking Voltage Sett. (%), and Open/Trip. Trip conditions: Open & Don't Activate Lockout.
- Reverse Power:** Includes fields for Pickup Setting (kW), Time Delay (Seconds), and Open/Trip. Trip conditions: 100.0, 200.0, 10.0, Open & Don't Activate Lockout.
- Phase Loss:** Includes fields for Pickup Setting (%V), Time Delay (Seconds), Blocking Voltage Sett. (%), and Open/Trip. Trip conditions: 8.0, 12.0, 10.0, 20.0, 5.0, Open & Don't Activate Lockout.
- High Current:** Includes fields for Pickup Setting (% LT Pkp) and Time Delay (Seconds). Trip conditions: 200.0, 15.0.
- High Resistance Ground Fault:** Includes fields for Pickup Setting (Amps), Time Delay (Seconds), Ground Resistance (Ohms), and Ground CT Rating (Amps). Trip conditions: 2.0, 0.5, 5, 10.

Settings tab

This tab displays

- Breaker configuration
- Long time protection
- Ground fault alarm protection
- Short time protection
- Ground fault trip protection
- Instantaneous protection

Figure 56: ELVS Settings tab

The screenshot shows the 'TEST' software interface for an ELVS breaker. The top navigation bar includes 'Alarm Status' (7 acknowledged alarms) and the date '12/05/2012 15:29:14'. The main window is titled 'Breaker # 1 BKR1' and 'LOVOLTSWIGEARELVS400'. The 'Settings' tab is selected, displaying several tabs: Overview, Analysis, Demand, Preventative Maintenance, Contact Input, Contact Output, System Health, Relay Protection, and Settings. The 'Settings' tab is further divided into sections: Breaker Configuration, Long Time Protection, Short Time Protection, Ground Fault Alarm Protection, and Ground Fault Trip Protection. The 'Breaker Configuration' section lists parameters like Frame Rating (900), Sensor Rating (200), PT Rating (600 V Delta), Breaker Type (ANSI), Hardware Version (1.00), Firmware Version (5.01), Serial Number (MF0A04000216), and Breaker Topology (1). The 'Long Time Protection' section shows settings for Rating (Amps) (80), LT Setting (1.00), Current Setting (Amps) (80.00), and Delay Band (BAND 4). The 'Short Time Protection' section shows settings for Short Time (Enabled), Pickup Setting (x LT Pickup) (1.5), Curve I_{2T} (Disabled), and Delay Band (BAND 1). The 'Ground Fault Alarm Protection' section shows settings for Alarm Enabled (Enabled), Pickup Setting (x CT) (0.20), Curve I_{2T} (Disabled), and Delay Band (BAND 1). The 'Ground Fault Trip Protection' section shows settings for Pickup Setting (x CT) (0.20), Curve I_{2T} (Disabled), and Delay Band (BAND 1). The 'Instantaneous Protection' section shows settings for Instantaneous Overcurrent (Disabled) and Pickup (x Rating) (6.0). On the left side, there is a sidebar with device information (Device Name: LOVOLTSWIGEARELVS400, CPU Name: CPU-A) and various status indicators (CPU/Messenger Protocol Version Number: 1.00, Hardware Version: 2.00, Firmware Version: 4.81, Boot Code Version: 2.00, Modbus Address: 1, IP Address: 192.168.1.107, Synchronization Hardware OK: green checkmark, Node Installed: green checkmark, Node Commissioned: green checkmark). At the bottom, there are buttons for Events, Trend, Wave, and Exit.

EMVTC


This section explains the information displayed in PMCS for Enhanced MicroVersa Trip C (EMVTC) products.

Overview tab

This tab displays

- Current
- Voltage
- System frequency
- Status
- Power factor
- Energy
- Real power demand

Figure 57: EMVTC Overview tab



Settings tab

This tab displays

- Breaker configuration
- Long time protection
- Short time protection
- Instantaneous protection
- Protective relays
- Ground fault protection

Figure 58: EMVTC Settings tab

Breaker Configuration			
Current Sensor Rating	1500		
Targets	Enabled		
Power Flow Direction	Line to Load		
Neutral Protection Factor	Off		
Wire Mode	3 Wire		
Demand Interval	15 Min.		
Trip Operation Counter	Enabled		
Sw. Inst/Short Time	Disabled		
Current Unbalance Relay	Disabled		
Gnd Fault ZS1 Selected	Disabled		
Short Time ZS1 Selected	Disabled		

Long Time Protection	
Pickup	0.65
Delay	3
Overcurrent	Enabled

Short Time Protection	
Short Time	Disabled
Pickup	7.00
Pickup Config	Long Time
Delay	1, OUT

Instantaneous Protection	
Instantaneous Overcurrent	Enabled
Pickup	2.5

Protective Relays			
	Protection	Setpoint	Delay
Undervoltage	Disabled	50 %	0 Sec.
Overvoltage	Disabled	150 %	0 Sec.
Volts Unbalance	Disabled	50 %	0 Sec.
Amps Unbalance	Disabled	50 %	0 Sec.
Power Reversal	Disabled	300 kW	0 Sec.

Commands tab

The following functions are available.

Table 12: EMVTC commands available

Button	Function
Reset Energy	Clears energy data in the device
Reset Peak Demand	Clears peak demand data in the device
Reset Instantaneous Trip Counter	Clears instantaneous trip counters from the device
Reset Short Time Trip Counter	Clears short time trip counters from the device
Reset Long Time Trip Counter	Clears long time trip counters from the device
Reset Ground Fault Trip Counter	Clears ground fault trip counters from the device

Figure 59: EMVTC Commands tab



EMVTD


This section explains the information displayed in PMCS for the Enhanced MicroVersa Trip D (EMVTD) products.

Overview tab

This tab displays

- Current
- Voltage
- System frequency
- Status
- Power factor
- Energy
- Real power demand

Figure 60: EMVTD Overview tab



Settings tab

This tab displays

- Breaker configuration
- Long time protection
- Short time protection
- Instantaneous protection
- Protective relays
- Ground fault protection

Figure 61: EMVTD Settings tab

The screenshot shows the 'TEST' software interface for the 'SENHANCEMICROVERSATD' device. The main window is divided into several sections:

- Overview:** Displays a small image of the device and its basic parameters:

Device Name	SENHANCEMICROVERSATD
PT Connection	Wye
Frame Size	3200 A
Rating Plug	2000 A
PT Rating	122 V
Commnet Address	303
Modbus Address	36
Software Revision	4.00
Product Revision	RMS9C
- Settings:** Contains tabs for 'Breaker Configuration', 'Long Time Protection', 'Short Time Protection', 'Instantaneous Protection', and 'Protective Relays'.
- Commands:** A section for sending commands to the device.
- Alarm Status:** Shows 71 unacknowledged alarms.
- Time:** 12/05/2012 15:18:20
- Help:** A question mark icon.


Commands tab

The following functions are available.

Table 13: EMVTD commands available

Button	Function
Reset Energy	Clears energy data in the device
Reset Peak Demand	Clears peak demand data in the device
Reset Instantaneous Trip Counter	Clears instantaneous trip counters from the device
Reset Short Time Trip Counter	Clears short time trip counters from the device
Reset Long Time Trip Counter	Clears long time trip counters from the device
Reset Ground Fault Trip Counter	Clears ground fault trip counters from the device

Figure 62: EMVTD Commands tab



EPM9650/EPM9450


This section explains the information displayed in PMCS for EPM9650 and EPM9450 meters.

Overview tab

This tab displays

- Currents
- Voltages
- Energy
- Power
- System frequency

Figure 63: EPM9650 Overview tab




Analysis tab

This tab displays present, maximum, and timestamp of maximum of

- Currents - Total harmonic distortion (THD)
- Phase Voltage - THD
- K-factor currents

Figure 64: EPM9650 Analysis tab



Demand tab

This tab displays

- Fixed window power
- Predictive sliding window

Figure 65: EPM9650 Demand tab

The screenshot shows the 'Demand' tab of the EPM9650 software interface. At the top, there's a navigation bar with tabs for Overview, Analysis, Demand (which is selected), Digital, Max Data, Settings, and Commands. Below the navigation bar is a status bar showing 'Alarm Status' with 1 Unacknowledged Alarms and the date/time '12/12/2012 12:19:35'.

Block (Fixed) Window:

	Instantaneous	Maximum	Time of Maximum
Positive Real (kW)	0.00	0.00	09/26/2012 09:14:59.06
Negative Real (kW)	N/A	-3.77	11/08/2012 02:59:59.06
Positive Reactive (kvar)	0.00	0.01	11/01/2012 05:29:59.06
Negative Reactive (kvar)	N/A	-0.01	11/11/2012 00:14:59.06
Apparent (kVA)	0.00	3.77	11/08/2012 02:59:59.06

Rolling (Sliding) Window:

	Instantaneous	Maximum	Time of Maximum
Positive Real (kW)	0.00	0.00	09/26/2012 09:19:59.06
Negative Real (kW)	N/A	-3.77	11/08/2012 03:09:59.05
Positive Reactive (kvar)	0.00	0.01	11/01/2012 05:24:59.05
Negative Reactive (kvar)	N/A	-0.01	11/08/2012 10:09:59.05
Apparent (kVA)	0.00	3.77	11/08/2012 03:09:59.05

Device Information:

Device Name	EPM9650_Markham
Boot Version Number	6.0.1
Runtime Version Number	6.1.9
DSP Boot Version No.	6.0.0
DSP Runtime Version No.	6.3.3
Serial Number	145115
VT Connection Type	Wye
On Time	12/03/2012 13:19:42.570
Current Time	12/12/2012 12:19:23.640

Buttons:

Events | Trend | Wave | Exit

Digital tab

This tab displays

- Digital inputs

Figure 66: EPM9650 Digital tab



Max Data tab

This tab displays the maximum and its time stamp of

- Currents
- Voltages
- Positive real power
- Negative real power
- Positive reactive power
- Negative reactive power
- Apparent power

Figure 67: EPM9650 Max Data tab

Current			Voltage		
	Maximum	Time of Maximum		Maximum	Time of Maximum
A (Amps)	42.26	11/08/2012 03:22:44.06	Van (Volts)	116.51	02/28/2007 15:02:01.05
B (Amps)	42.26	11/08/2012 03:22:44.06	Vbn (Volts)	116.51	02/28/2007 15:02:01.05
C (Amps)	42.28	11/08/2012 03:22:44.06	Vcn (Volts)	116.51	02/28/2007 15:02:01.05
N (Amps)	0.00	02/28/2007 15:01:14.06	Vaux	0.00	02/28/2007 15:01:14.06
N (calc)	126.94	11/08/2012 03:22:45.04			

Positive Real Power (kW)			Positive Reactive Power (kvar)			Apparent Power (kVA)		
	Maximum	Time of Maximum		Maximum	Time of Maximum		Maximum	Time of Maximum
Phase A	0.00	02/28/2007 15:01:14.07	Phase A	0.00	11/05/2012 02:50:09.03	Phase A	1.26	11/08/2012 03:22:45.04
Phase B	0.00	02/28/2007 15:01:14.07	Phase B	0.00	10/30/2012 11:38:43.04	Phase B	1.26	11/08/2012 03:22:45.04
Phase C	0.00	02/28/2007 15:01:14.07	Phase C	0.01	10/30/2012 23:15:54.03	Phase C	1.26	11/08/2012 03:22:45.05
3 Phase	0.00	02/28/2007 15:01:14.07	3 Phase	0.01	11/01/2012 05:41:01.10	3 Phase	3.77	11/08/2012 03:22:45.05

Negative Real Power (kW)			Negative Reactive Power (kvar)		
	Maximum	Time of Maximum		Maximum	Time of Maximum
Phase A	-1.26	11/08/2012 03:22:45.05	Phase A	-0.01	11/11/2012 03:36:15.06
Phase B	-1.26	11/08/2012 03:22:45.05	Phase B	-0.01	11/09/2012 16:53:05.05
Phase C	-1.26	11/08/2012 03:22:45.05	Phase C	-0.01	11/11/2012 00:11:48.05
3 Phase	-3.77	11/08/2012 03:22:45.05	3 Phase	-0.01	11/09/2012 03:43:34.05

Settings tab

This tab displays

- Current setpoints
- Voltage setpoints
- Voltage phase sequence
- CT ratio
- PT ratio
- Time settings, including time zone

Figure 68: EPM9650 Settings tab

CT Ratio		
	Phase	Neutral
Numerator	100.00	5.00
Denominator	5.00	5.00

PT Ratio		
	Phase	Auxiliary
Numerator	120.00	120.00
Denominator	120.00	120.00

Voltage Phase Sequence	A-C-B
------------------------	-------

Time settings		
Time Zone	ZD650.4	
DST Enabled	Auto DST	
DST Start	Auto	
DST End	Auto	

Demand Integration Intervals		
Thermal Averaging Time Interval Window	0h 15m 0s	
Block Averaging Time Interval Window	0h 15m 0s	
Rolling Averaging Sub-Interval Window	0h 5m 0s	
Rolling Sub-Intervals	3	
Predictive Rolling Window Average (%)	100.00	


Commands tab

The following functions are available.

Table 14: EPM9650 commands available

Button	Function
Reset Energy	Clears the energy counters
Reset Maximums	Clears the maximum values from memory
Reset Minimums	Clears the minimum values from memory

Figure 69: EPM9650 Commands tab



GTU


This section explains the information displayed in PMCS for Entelliguard Trip Unit (GTU) products.

Overview tab

This tab displays

- Currents
- Voltages
- System frequency
- Status
- Energy
- Real power demand

Figure 70: GTU Overview tab



Status tab

This tab displays

- Trip status
- Breaker status
- Alarm status
- Primary protection
- Waveform capture data
- Relays
- Inputs
- Shunts
- Undervoltage release (UVR)

Figure 71: GTU Status tab

The screenshot displays the 'Status' tab of the GE Power Management System (PMCS) interface for a GTU device. The main window is titled 'TEST' and contains several status panels:

- Trip Status:** Shows 'GTU Tripped' with an orange square indicator.
- Relays:** Displays four relays (Relay 1 to Relay 4) with status indicators.
- Breaker Status:** Shows 'Breaker Position' and other breaker-related status.
- Primary Protection:** Monitors Long Time Pickup and Short Time Pickup.
- Inputs:** Monitors four inputs (Input 1 to Input 4).
- Shunts:** Monitors two shunts (Shunt 1 and Shunt 2).
- UVRs:** Monitors two Undervoltage Release units (UVR 1 and UVR 2).
- Alarm Status:** A detailed table showing alarm pickup and active status for various events like Voltage Unbalance, Under Voltage, Over Voltage, etc.

A legend in the bottom right corner defines the color coding: orange for 'Trip' and grey for 'Not Available'.

Statistics tab

This tab displays

- Trip counts

Figure 72: GTU Statistics tab

The screenshot shows the GE Test software interface for a GTU device. The top navigation bar includes tabs for Overview, Status, Statistics (which is selected), Settings, and Commands. A sub-header 'TEST' is displayed above the main content area. On the left, there is a sidebar with a device image and a table of device parameters. The main content area displays a table titled 'Trip Counts' with the following data:

Trip Counts	
Long Time Trips	0
Short Time Trips	5
Instantaneous Trips	8
Ground Fault Sum Trips	0
Power Reversal Trips	7
Current Unbalance Trips	0
Voltage Unbalance Trips	0
Over Voltage Trips	3
Under Voltage Trips	0
Under Voltage Release 1 Trips	N/A
Under Voltage Release 2 Trips	N/A
Shunt 1 Trips	N/A
Shunt 2 Trips	N/A


At the bottom left of the main area, there are buttons for Events, Trend, Wave, and Exit.

Settings tab

This tab displays

- Breaker configuration
- Long time protection configuration
- Short time protection configuration
- Instantaneous protection configuration
- Reduced energy let-through (RELT) instantaneous protection configuration
- Protective relays
- Ground fault protection configuration

Figure 73: GTU Settings tab




Commands tab

The following functions are available.

Table 15: GTU commands available

Button	Function
Reset Instantaneous Trip Counter	Clears Instantaneous trip counter data
Reset Short Time Trip Counter	Clears short time trip counter data
Reset Long Time Trip Counter	Clears long time trip counter data
Reset Ground Fault Trip Counter	Clears ground fault trip counter data
Reset RELT	Resets RELT
Reset Total Energy	Clears total energy

Figure 74: GTU Commands tab



MVT


This section explains the information displayed in PMCS for MicroVersa Trip (MVT) products, excluding EMVTC and EMVTD.

Overview tab

This tab displays

- Current
- Voltage
- System frequency
- Status
- Power factor
- Energy
- Real power demand

Figure 75: MVT Overview tab



Settings tab

This tab displays

- Breaker configuration
- Long time protection
- Short time protection
- Instantaneous protection
- Protective relays
- Ground fault protection

Figure 76: MVT Settings tab

The screenshot shows the 'TEST' software interface for a 'MICROVERSATIPUNIT_1' device. The main window is titled 'TEST' and has a sub-header 'MICROVERSATIPUNIT_1'. The left sidebar contains a device image and a table of device parameters:

Device Name	MICROVERSATIPUNIT_1
PT Connection	Wye
Frame Type	F Frame
Current Sensor	2000 A
Rating Plug	1100 A
PT Rating	120 V
Commnet Address	347
Modbus Address	80
Software Revision	4.0D
Product Revision	0.0F

The main content area is divided into several tabs: 'Overview' (selected), 'Settings', 'Breaker Configuration', 'Long Time Protection', 'Ground Fault Protection', 'Short Time Protection', 'Instantaneous Protection', and 'Protective Relays'. The 'Breaker Configuration' tab shows the following settings:

Current Sensor Rating	5000 Amps
Targets	Enabled
Power Flow Direction	Load to line
Relay Option	Wye

The 'Long Time Protection' tab shows:

Fixed Pickup	Disabled
Fixed Delay	Disabled
Overcurrent	Enabled

The 'Ground Fault Protection' tab shows:

Ground Fault	Disabled
Pickup	0.20
Delay	1, IN

The 'Short Time Protection' tab shows:

Short Time	Disabled
Pickup	7.0
Delay	1, OUT

The 'Instantaneous Protection' tab shows:

Instantaneous Function	Enabled
Instantaneous Limited	Disabled
Pickup	10.0

The 'Protective Relays' tab shows:

	Setpoint	Delay
Undervoltage	50 %	OFF secs
Oversupply	150 %	OFF secs
Volts Unbalance	50 %	OFF secs
Amps Unbalance	50 %	OFF secs
Power Reversal	1368 kW	OFF secs

At the bottom of the main window are buttons for 'Events', 'Trend', 'Wave', and 'Exit'.

PQM/PQMII


This section explains the information displayed in PMCS for power quality meter (PQM) and PQMII products.

Overview tab

This tab displays

- Current
- Voltage
- Power
- Energy
- Demand
- Contact outputs
- Switch inputs

Figure 77: PQMII Overview tab




Analysis tab

This tab displays

- Currents - Total harmonic distortion (THD) (present and maximum values)
- Phase voltages - THD (present and maximum values)
- Power quality values

Figure 78: PQMII Analysis tab



Maximum tab

This tab displays

- Current (present value, maximum value, and time stamp of maximum value)
- Voltage (present value, maximum value, and time stamp of maximum value)
- Three-phase power (present value, maximum value, and time stamp of maximum value)
- Current demand (present value, maximum value, and time stamp of maximum value)
- Three-phase power demand (present value, maximum value, and time stamp of maximum value)

Figure 79: PQMII Maximum tab

The screenshot shows the GE Power Quality Monitor (PQMII) software interface. At the top, there's a header with the GE logo, the word "TEST", and an "Alarm Status" indicator showing 71 UnAcknowledged Alarms. The date and time are listed as 12/05/2012 15:23:24.

The main area features a navigation bar with tabs: Overview, Analysis, Maximum (which is selected and highlighted in blue), Settings, and Commands. Below this is a large data grid divided into sections:

- Current:** Shows Present, Maximum, and Time of Maximum values for phases A, B, C, and N in Amps.
- Current Demand:** Shows Present, Maximum, and Time of Maximum values for phases A, B, C, and N in Amps.
- Voltage:** Shows Present, Maximum, and Time of Maximum values for phase-to-phase voltages Vab, Vbc, Vca in Volts, and Unb (%) in percentage.
- 3 Phase Power:** Shows Present, Maximum, and Time of Maximum values for Real (kW), Reactive (kvar), and Apparent (kVA).
- 3 Phase Power Demand:** Shows Present, Maximum, and Time of Maximum values for Real (kW), Reactive (kvar), and Apparent (kVA).

On the left side, there's a sidebar with device information: Device Name (POWERQUALITYMETER_II), Device Type (PQM II), Hardware Revision (D), Main Program Revision (2.24), Boot Program Revision (3.00), Supervisor Revision (0.00), VT Connection Type (3 Wire Delta/2 VTs), Modbus Address (3), and Mod File Numbers (1, 2, 3, 4, 5). Below this is a table for analog inputs (A1-A6) with values 000 000 000 000 000 000.


At the bottom left are buttons for Events, Trend, Wave, and Exit.

Settings tab

This tab displays

- System setup

Figure 80: PQMII Settings tab



Commands tab

The following functions are available.

Table 16: PQMII commands available

Button	Function
Reset Device	Issues a reset command to the PQM/PQMII
Reset Energy	Clears the PQM/PQMII energy counters
Reset Frequency Values	Clears the PQM/PQMII maximum frequency values from memory
Reset Pulse Counters	Resets the PQM/PQMII pulse counter
Reset Max THD Values	Clears the PQM/PQMII maximum total harmonic distortion values from memory
Reset Max Demand Values	Clears the PQM/PQMII maximum demand values from memory
Reset Current Min/Max Values	Clears the PQM/PQMII current minimum and maximum values from memory
Reset Voltage Min/Max Values	Clears the PQM/PQMII voltage minimum and maximum values from memory
Reset Power Min/Max Values	Clears the PQM/PQMII power minimum and maximum values from memory

Figure 81: PQMII Commands tab



UR


This section explains the information displayed in PMCS for the Universal Relay (UR) series, such as the B30, C30, C60, and D30. Due to the number of products available, a UR wizard can display between one and eight screens of data; the number of screens is determined by the user during wizard configuration. There are 23 tab variations possible in PMCS, depending on the type of UR device connected. For example, the C30 device does not support metering functions, so the metering and source tabs are not available for this device.

Overview tab

This tab displays

- Currents
- Voltages
- Energy
- Demand
- System frequency
- Status
- Event cause

Figure 82: UR Overview tab




Analysis tab

This tab displays

- Current symmetrical components
- Voltage symmetrical components
- Breaker arcing current

Figure 83: UR Analysis tab




Synchro tab

This tab displays

- Synchrocheck 1
- Synchrocheck 2

Figure 84: UR Synchro tab



Contact Input tab

- This tab displays
- Contact inputs

Figure 85: UR Contact Input tab

The screenshot shows the GE Test software interface for a device named "UNIVERSALRELAYVER550". The device has the following specifications:

- Order Code: G30-H03-HCH-FBF+H4L-M6N -P6D-U6B-W7W
- Product Version: 6
- Serial Number: MAHC05111111
- Manufacturing Date: 05/05/2006
- Modification Number: 0
- Modbus Addr: 254
- IP Address: 3.188.104.55
- Prog. State: Not Programmed
- Relay: Relay-1

The Contact Inputs table lists 32 contacts, each with a name and state indicator:

	Name	State		Name	State
1	Cont Ip 1	<input type="checkbox"/>	17	Cont Ip 17	<input type="checkbox"/>
2	Cont Ip 2	<input type="checkbox"/>	18	Cont Ip 18	<input type="checkbox"/>
3	Cont Ip 3	<input type="checkbox"/>	19	Cont Ip 19	<input type="checkbox"/>
4	Cont Ip 4	<input type="checkbox"/>	20	Cont Ip 20	<input type="checkbox"/>
5	Cont Ip 5	<input type="checkbox"/>	21	Cont Ip 21	<input type="checkbox"/>
6	Cont Ip 6	<input type="checkbox"/>	22	Cont Ip 22	<input type="checkbox"/>
7	Cont Ip 7	<input type="checkbox"/>	23	Cont Ip 23	<input type="checkbox"/>
8	Cont Ip 8	<input type="checkbox"/>	24	Cont Ip 24	<input type="checkbox"/>
9	Cont Ip 9	<input type="checkbox"/>	25	Cont Ip 25	<input type="checkbox"/>
10	Cont Ip 10	<input type="checkbox"/>	26	Cont Ip 26	<input type="checkbox"/>
11	Cont Ip 11	<input type="checkbox"/>	27	Cont Ip 27	<input type="checkbox"/>
12	Cont Ip 12	<input type="checkbox"/>	28	Cont Ip 28	<input type="checkbox"/>
13	Cont Ip 13	<input type="checkbox"/>	29	Not Available	<input type="checkbox"/>
14	Cont Ip 14	<input type="checkbox"/>	30	Not Available	<input type="checkbox"/>
15	Cont Ip 15	<input type="checkbox"/>	31	Not Available	<input type="checkbox"/>
16	Cont Ip 16	<input type="checkbox"/>	32	Not Available	<input type="checkbox"/>

Buttons at the bottom left include: Source 1, Source 2, Source 3, Source 4, Source 5, Source 6, Events, Trend, Wave, and Exit.

Contact Output tab

This tab displays

- Contact outputs

Figure 86: UR Contact Output tab


Contact Outputs						
	Name	State		Name	State	
1	Cont Op 1			17	Cont Op 17	
2	Cont Op 2			18	Cont Op 18	
3	Cont Op 3			19	Cont Op 19	
4	Cont Op 4			20	Cont Op 20	
5	Cont Op 5			21	Cont Op 21	
6	Cont Op 6			22	Cont Op 22	
7	Cont Op 7			23	Cont Op 23	
8	Cont Op 8			24	Cont Op 24	
9	Cont Op 9			25	Not Available	
10	Cont Op 10			26	Not Available	
11	Cont Op 11			27	Not Available	
12	Cont Op 12			28	Not Available	
13	Cont Op 13			29	Not Available	
14	Cont Op 14			30	Not Available	
15	Cont Op 15			31	Not Available	
16	Cont Op 16			32	Not Available	

Settings tab

This tab displays

- Current transformer settings
- Voltage transformer settings
- Power system settings

Figure 87: UR Settings tab




Commands tab

The following functions are available.

Table 17: UR commands available

Button	Function
Reset Device	Issues a reset command to the UR device
Clear Demand	Clears Demand data from the device
Clear Energy	Clears Energy data from the device

Figure 88: UR Commands tab



PMCS

Chapter 5: Software and license management

The following actions can be performed by the Administrator for software and license management:


- Manage activation code
- Transfer software license
- Update software
- Uninstall software

Manage activation code

The software license allows for installation on one computer. After installing PMCS on a computer, use the procedure here to generate an activation code and enter it. There is no prompt to do so; the software does not work unless the code is entered.

To unlock an installation:

1. Launch the Configurator application by clicking **Start > All Programs > EnerVista Integrator > EnerVista Configurator**.
2. Click **Help > License Manager**. The License Manager window opens, shown as follows.

Figure 89: Activating a PMCS software license

3. Obtain the **Site ID** and **Machine ID** from the window.
4. Generate an activation code as follows. Log in to <http://apps.gedigitalenergy.com/swmgr> using the following credentials:
Order number: nnnnnnnn
Password: nnnnnnnn
Enter the **Site ID** and **Machine ID**, and generate the CD activation code. Record the number.
5. Enter the code in the **Activation Code** field, and click the **Unlock** button. This unlocks both PMCS and EnerVista Integrator.

Transfer software license


The license does not allow installation on more than one computer, but you can move the software license from one PMCS installation to another. You cannot move a complete installation with its database to another computer.

You look up the **Site ID** of the license being moved, then transfer it.

To view a Site ID:

1. At the computer on which the license is installed, launch the Configurator application.
2. Click **Help > License Manager**. The License Manager window opens, shown as follows.

Figure 90: Transferring a PMCS software license



3. Obtain the **Site ID** from the window.

To transfer the license:

1. At the computer on which you want to install the license, log in as Administrator.
2. Launch the Configurator application.
3. Click **Help > License Manager**. The License Manager window opens.
4. Enter the Site ID in the **New Site ID** field.
5. Click the **Transfer** button.

Update software

After initial activation, if PMCS license manager detects any license options still available for upgrade, the license upgrade section is enabled in the license management window. Updates are free for a year after purchase. Download them from the GE Multilin website at <http://gedigitalenergy.com/multilin> or ask for a new CD using the contact information contained in the **For further assistance** section.

Based on the license purchased, PMCS limits the number of installations. The license can be upgraded by entering a new activation code. See the **Manage activation code** section.

Uninstall software

If required, the PMCS software can be uninstalled.

Uninstalling the PMCS software deletes configuration information too. It does not delete some files, such as error logs, system logs, and configuration records, which are created after the PMCS installation is complete. Since these files are not part of the initial installation, they are not removed by the uninstaller, and must be deleted manually. The SQL Express database remains.

To uninstall PMCS software:

1. Click **Start > Control Panel**.
2. Click **Programs and Features**.
3. Click the PMCS application.
4. Click **Uninstall**, and confirm the deletion. The PMCS software is deleted as outlined.

PMCS

Index

Numerics

239	7
269Plus	7
339	7
345	7
350	7
369	7
469	7, 25
489	7, 33
735 and 737	7, 40
745	7, 44
750 and 760	7, 50

A

Activation code	99
-----------------------	----

B

B30	7, 91
B90	7, 91
Baud rate	5
Breaker configuration	22

C

C30	7, 91
C60	7, 91
C70	7, 91
CIMPLICITY	
defined	1
project setup for PMCS	11
Workbench window	13
Clear All Devices	22
Created checkbox	18, 22, 24

D

D30	7, 91
D60	7, 91
Data display defaults	21
Data Table field	21, 23
Default data display	23
Device Name field	18
Device Type field	18
Devices supported	7
Devices, add	17

E

ELVS	7, 57
Device Name field	22
EMVTC	7, 66
EMVTD	7, 69
Entelguard	7, 79
EntellisysLVS	7, 57
EPM1000	7
EPM1500	7
EPM2000	7
EPM2200	7
EPM4000	7
EPM4500	7
EPM5000P	7
EPM5200P	7
EPM5300P	7
EPM5350P	7
EPM6000	7
EPM9450	7, 72
EPM9650	7, 72
EPM9800	7
Error message	14

F

F35	7, 91
F60	7, 91
F650	7
Faceplate field	19, 23
FIRETRACER	7
For further assistance	9

G

G30	7, 91
G60	7, 91
Generate button	24
GTU	7, 79

H

Help, getting	9
---------------------	---

L

L30	7, 91
L60	7, 91
L90	7, 91
License	
key entry	99
Site ID	100
transfer	100

M

M60	7, 91
MainMenu.cif file	24
MET	7
MIFII	7
ML2400	7
ML469	25
ML489	33
ML735 and ML737	7, 40
ML745	44
ML750 and ML760	7, 50
MM200	7
MM300	7
MMII	7
MMIII	7
MN1000	7
MPRO	7
MVT	7, 84
MX150	7
MX250	7
MX350	7

N

N60	7, 91
-----------	-------

O

OPC Port field	19
----------------------	----

P

PLEPM	7
PowerBuilder	
configuration error	14
device list	17
window explained	17
PQM and PQMII	7, 86
Preferences	23
Project Properties window	13
Project setup	11
Project Wizard	13

R

RELT	82
RRTD	7
RTD	35

S

SCADA, defined	3
Screens menu	24
Select All Devices	22
Server field	18
Site ID	100
SMR2	7
Software	
install	5
key entry	99
transfer license	100
uninstall	102
update	101
Speed	5
SPM	7
SR469	25
SR489	33
SR735 and SR737	7, 40
SR745	44
SR750 and SR760	7, 50
Styles	
faceplates	19
symbol	21
Supported devices	7
Symbol field	21, 23
Synch. Voltages Difference	53

T

T35	7, 91
T60	7, 91
Technical support	9
Transfer software license	100
Troubleshooting error message	14

U

Uninstall	102
Universal relay devices	91
Update software	101
UPSLP	7
UPSSG	7
UR devices	7, 91
URPlus	7
UVR	80

V

VERSAMAX	7
----------------	---

W

Wizard field	18
Workbench window	13

