



GE VERNOVA

PROFICY® SOFTWARE & SERVICES

PROFICY BATCH EXECUTION 5.6

Equipment Configuration Manual

Proprietary Notice

The information contained in this publication is believed to be accurate and reliable. However, GE Vernova assumes no responsibilities for any errors, omissions or inaccuracies. Information contained in the publication is subject to change without notice.

No part of this publication may be reproduced in any form, or stored in a database or retrieval system, or transmitted or distributed in any form by any means, electronic, mechanical photocopying, recording or otherwise, without the prior written permission of GE Vernova. Information contained herein is subject to change without notice.

© 2024 GE Vernova and/or its affiliates. All rights reserved.

Trademark Notices

“VERNOVA” is a registered trademark of GE Vernova. “GE VERNOVA” is a registered trademark of GE Aerospace exclusively licensed to GE Vernova. The terms “GE” and the GE Monogram are trademarks of GE Aerospace, and are used with permission. All other trademarks are the property of their respective owners.

Microsoft® is a registered trademark of Microsoft Corporation, in the United States and/or other countries.

All other trademarks are the property of their respective owners.

We want to hear from you. If you have any comments, questions, or suggestions about our documentation, send them to the following email address:
doc@ge.com

Table of Contents

About This Guide	1
Reference Documents	1
Introduction	1
Graphical Interface	2
S88.01-Aware	2
Open Architecture	2
Integration with iFIX	2
Maximizing Equipment Usage	2
Interoperability with Batch Execution	3
Understanding the S88.01 Physical Model	3
Example: Equipment Hierarchy in Batch Execution	3
Implementation Strategies	4
Partitioning Plant Equipment	4
General Definition Guidelines	5
Partitioning Process Cells	5
Partitioning Units	6
Identifying Common Resources	7
Implementing a Class-Based Design	9
Implementing Class-Based Units	9
Example: Class-Based Units	9
Implementing Active Binding	10
Implementing Equipment Pathing	10
Implementing Equipment Capacity	11
Implementing Equipment Status Tags	11
Example: Active Binding	11

Getting Started.....	14
Understanding the Area Model.....	14
Exporting and Importing Area Models	14
The Equipment Editor Window	15
Using the Navigation Tools.....	15
Customizing the Window	15
Using the Toolbar	16
Prerequisites.....	16
Introducing the Sample Application	17
Process and Instrumentation Drawing.....	17
Equipment Hierarchy	18
Execution Paths.....	21
Task Overview: Equipment Configuration	25
Configuring Enumerations	26
Configuring and Implementing Enumerations	26
Example: Configuring and Implementing Enumerations	27
Pre-Defined Enumeration Sets.....	28
PHASE_FAILURES Enumeration Set.....	29
UNIT_OF_MEASURE Enumeration Set.....	29
Overview: Defining Enumerations	30
Prerequisites.....	31
Overview: Maintaining Enumerations	31
Maintenance Guidelines	32
Configuring Equipment.....	32
Overview: Configuring Equipment.....	33
Defining an Area	33
Example: Area Model	33
Defining Process Cells	33

Overview: Configuring Process Cells	34
Defining Units	34
Design Strategies	34
Overview: Configuring Units	35
Configuring Equipment Pathing	36
Example: Equipment Pathing	38
Defining a Unit's Equipment Capacity	38
Understanding Unit Tags	40
Standard Equipment Phases	40
Prerequisites	41
Understanding How Standard Equipment Phases Work	41
Overview: Configuring Standard Phases	42
Standard Phase Template	43
Standard Phase Class Properties	44
Parameters	44
Phase Reports	46
Operator Messages	46
Phase Partners	48
Requests	48
Tying Standard Phases to Equipment	48
Understanding Data Servers	50
Assigning iFIX Database Tags to Equipment Phases	50
Batch Direct Equipment Phases	52
Prerequisites	53
What You Need to Know About State Blocks	53
What You Need to Know About Standard Equipment Tags	54
Standard PLI Structure vs. Batch Direct PLI Structure	54
Standard PLI Structure	55

Batch Direct PLI Structure	55
Differences Between Direct and Standard Phases	56
Where Batch Direct Phase Information Appears in the Product	59
Equipment Editor/WorkSpace	60
Recipe Editor	61
Batch Execution Client.....	61
Understanding How Batch Direct Phases Work.....	63
Default Settings for a Batch Direct Phase	64
State Blocks and Equipment Phase Tags	64
Tags for Each State Block	66
State Blocks and Tag Combinations	66
The Data Server for Batch Direct Phases	69
Overview: Configuring Direct Phases.....	70
TIP: Direct Phase Naming Convention.....	71
Direct Phase Template	71
Direct Phase Class Properties.....	73
Batch Direct Blocks and Tags	73
Tying Batch Direct Phases to Equipment.....	74
FAQ on Batch Direct Phases.....	76
Question 1: How do I enable Batch Direct state blocks for a phase instance?.....	76
Question 2: How do configure the Enter, Exit, and Status Tags for a Batch Direct phase? ..	76
Question 3: What happens when there is no aborting logic defined?	77
Question 4: What happens when there is no stopping logic defined?	77
Question 5: What happens when there is no holding logic defined?	77
Question 6: I have lots of iFIX tags to enter for my phases, is there an easy way to do this?	77
Advanced Topics	77
Configuring Control Modules.....	77

Configuring Shared Equipment	78
Configuring Arbitration for Shared and Common Resources.....	78
Understanding Equipment IDs.....	79
Understanding Maximum Owners	79
Understanding Equipment Needed	79
Examples: Equipment Arbitration	79
Using Unit Tags	80
Configuring the UNIT_READY and UNIT_PRIORITY Tags.....	81
Configuring Scalable Parameters.....	83
Equipment Editor Dialog Boxes.....	84
Add Control Module Dialog Box	86
Name	86
Class.....	86
Arbitration	86
Add Control Modules Class Dialog Box	87
Name	87
Audit Information Dialog Box	87
Audit Version	87
Unique Identifier (GUID)	87
Performed By.....	87
Verified By	88
Browse OPC Items Dialog Box.....	89
Select an Item.....	89
Item ID	89
Filter String	89
Connection Properties Dialog Box.....	90
Name	90
Label.....	90

Origin	90
Destination.....	90
Arbitration	90
Create Direct Equipment Phase Class Dialog Box	91
General Tab.....	91
Parameters Tab.....	91
Reports Tab.....	92
Enable Tags.....	93
Create Enumeration Dialog Box	93
Enumeration	93
Ordinal	93
Create Enumeration Set Dialog Box.....	94
Enumeration Set.....	94
Create Enumeration Sets and Enumerations Dialog Box	94
Enumeration Sets	94
Enumerations.....	94
Sets.....	94
Enumerations.....	95
Create Equipment Phase Class Dialog Box.....	95
General Tab.....	95
Parameters Tab.....	96
Reports Tab.....	97
Operator Messages Tab.....	97
Create OPC Server Dialog Box.....	98
Select a Server	98
Server Name.....	98
Alias	98
BadValue	99

Watchdog.....	99
DLL	99
Default Refresh Rate	99
Create Process Cell Class Dialog Box	99
Name	99
Icon	99
Create Unit Class Dialog Box	99
Name	99
Icon	100
Tag Classes.....	100
Create Unit Tag Dialog Box.....	100
Name	100
Tag Class.....	100
Type.....	100
Item.....	100
Server	101
Direct Phase Tag Template Dialog Box	101
Enter Tag.....	101
Exit Tag.....	102
Status Tag	103
Direct Tag Template Dialog Box.....	104
Direct Tags	104
Standard Tags	105
Node	105
Use Server Alias	105
Edit Area Dialog Box	106
Name	106
Version.....	106

Edit Control Modules Dialog Box.....	106
Control Module Classes	106
Control Modules.....	106
Classes	106
Control Modules.....	107
Edit Direct Equipment Phase Class Dialog Box	107
General Tab.....	107
Parameters Tab.....	108
Reports Tab.....	109
Enable Tags Tab	109
Edit Direct Phase Tags Dialog Box	110
Enter Tag	110
Exit Tag.....	111
Status Tag	112
Edit Enumeration In Dialog Box.....	113
Enumeration	113
Ordinal	113
Edit Enumeration Set Name Dialog Box	113
Enumeration Set.....	113
Edit Equipment Phase Class Dialog Box	113
General Tab.....	113
Parameters Tab.....	114
Reports Tab.....	115
Operator Messages Tab.....	116
Edit Equipment Phase Dialog Box.....	116
Name	116
Phase.....	117
Icon	117

Equipment Phase Tags	117
Arbitration	117
Edit Equipment Phase Tag Dialog Box	118
Name	118
Class	118
Type	118
Item	118
Browse	119
Server	119
Edit Operator Message Dialog Box	119
Name	119
ID	119
Edit Phase Parameter Dialog Box	119
Name	119
ID	120
Type	120
Eng. Units	120
High	120
Low	120
Default	120
Scale	120
Edit Phase Report Dialog Box	120
Name	120
ID	120
Type	120
Eng. Units	121
Edit Process Cell Class Dialog Box	121
Name	121

Icon	121
Edit Process Cell Dialog Box.....	121
Name	121
Class.....	121
Icon	121
Arbitration	121
HMI Process Cell Picture.....	122
Edit Servers Dialog Box.....	122
Servers	122
Alias	123
Watchdog.....	123
Bad Value String.....	123
Server Type	123
Default Server	123
Edit Server	123
Delete Server.....	123
New Server	123
Edit Tags Dialog Box	124
Tag Classes.....	124
Tags.....	124
Edit Tag	124
Edit Unit Class Dialog Box.....	124
Name	124
Icon.....	124
Tag Classes.....	124
Edit Unit Tag Dialog Box	124
Name	124
Tag Class.....	125

Type	125
Item	125
Browse (...)	125
Server	125
Enumeration Set Modification Dialog Box	126
Tags	126
Parameters	126
Report Parameters	126
File Export As Dialog Box	126
Save In	126
Location	127
Shortcuts	127
File Name	127
Save As Type	127
File Import Dialog Box	127
Look In	127
Location	127
Shortcuts	127
File Name	128
Files of Type	128
Import Equipment Model XML File Dialog Box	128
Look In	128
Location	128
Shortcuts	128
File Name	128
Files of Type	129
Manifold Properties Dialog Box	129
Name	129

Orientation Group	129
Arbitration	129
Print Setup Dialog Box	130
Name	130
Properties	130
Paper	130
Orientation	131
Select Directories Dialog Box	131
Process Cell Class Icons	131
Unit Class Icons	131
Phase Icons	131
Manifold Icons	131
Select Equipment Dialog Box	131
Select Equipment	132
Select HMI Picture Dialog Box	132
Look In	132
Location	132
Shortcuts	132
File Name	132
Files of Type	132
Set Tag Server Dialog Box	133
Name	133
Watchdog	133
Change All Tags	133
Share Equipment Phase Dialog Box	133
Share Equipment Phase List Box	133
Share Unit Dialog Box	133
Share Unit List Box	133

Standard Phase Template Dialog Box	134
Command Row	134
Failure Row.....	134
Owner Row	135
Pause Row	135
Paused Row	136
Request Row	137
Single_Step Row	137
Status Row	138
Step Index Row	138
Unit Row	139
Parameter Row.....	140
Report Row.....	140
Request Tag Row.....	141
Use Server Alias	141
Tag Template Dialog Box	142
Server Alias	142
Phase.....	142
Suffix.....	142
Extension	142
Unit Properties Dialog Box	142
General Tab.....	142
Equipment Capacity Tab	143
Unit Tags Tab	144
Arbitration Tab	145
Zoom Dialog Box	146
Scale	146
Default	147

How Do I.....	147
Configuring an Area Model.....	147
Overview: Configuring an Area Model.....	148
Importing a .TXT Version of the Area Model.....	148
Importing an .XML Version of the Area Model.....	148
Exporting the Area Model.....	149
Viewing Audit Versioning Information.....	149
Defining Data Servers.....	150
Defining an OPC Data Server.....	150
Selecting a Default Data Server.....	150
Selecting the Equipment Phase Data Server.....	151
Configuring Areas.....	151
Configuring Process Cells.....	151
Overview: Configuring Process Cells.....	151
Configuring Process Cell Classes.....	152
Configuring Process Cell Instances.....	152
Configuring Process Cell Instances to Toggle to an iFIX Picture.....	152
Maintaining Process Cells.....	152
Configuring Units.....	153
Overview: Configuring Units.....	153
Configuring a Unit Class.....	154
Configuring Unit Instances.....	154
Configuring Unit Capacity.....	154
Connecting Units.....	155
Configuring Unit Tags.....	155
Maintaining Units.....	158
Configuring Unit Connections.....	158
Connecting Units.....	158

Configuring Connection Properties.....	159
Configuring Manifold Properties	159
Configuring Equipment Phases.....	159
Configuring the Standard Tag Template	160
Configuring the Direct Phase Template.....	160
Overview: Configuring Equipment Phases.....	161
Configuring Equipment Phase Classes	161
Configuring Equipment Phase Parameters	162
Configuring Equipment Phase Reports	162
Configuring Operator Messages.....	163
Configuring Equipment Phase Instances	163
Updating the Edit Equipment Phase Dialog Box	163
Tying Equipment to the Data	164
Adding an equipment phase tag to an iFIX Database.....	164
Assigning OPC Data Items to Equipment Phase Tags	164
Editing the Enter, Exit, and Status tags for a State Block in a Direct Phase.....	165
Modifying the Standard Tags for a Direct Phase.....	165
Modifying the Direct Phase Tags in the Template.....	166
Maintaining Equipment Phases	166
Configuring Control Modules.....	168
Configuring Control Modules	168
Deleting Control Modules	169
Modifying Control Modules	169
Configuring Enumerations	169
Overview: Defining Enumerations	169
Defining Enumeration Sets.....	170
Defining Enumerations	170
Modifying Enumeration Set Names.....	171

Configuring the UNIT_OF_MEASURE Enumeration Set	171
Deleting Enumeration Sets	171
Configuring Arbitration	172
Configuring Arbitration	172
Configuring Needed Equipment	172
Configuring Shared Resources	173
Sharing Resources	173
Sharing Units Between Process Cells	174
Sharing Equipment Phases Between Units	174
Defining a Master Process Cell for Shared Units	174
Deleting a Master Shared Unit	175
Deleting a Shared Unit Instance	175
Index	177

About This Guide

The Proficy Batch Execution Equipment Configuration Manual describes the tasks associated with configuring equipment entities in the Equipment Editor application. This manual is intended for use by individuals who perform the engineering duties of automated batch operations using Batch Execution. This manual assumes the reader is familiar with the equipment, resources, and phase logic for the plant in which Batch Execution is running.

Reference Documents

Refer to following documents for additional information:

- ANSI/ISA-S88.01 Batch Control, Part 1: Models and Terminology
- System Configuration Manual
- Recipe Development Manual
- Phase Programming Manual
- PLI Development Manual
- Application Guide

Introduction

The Equipment Editor is a graphical tool for configuring and maintaining one or more *area models*. Within an area model you define the following equipment entities:

- Area
- Process Cells
- Units
- Equipment Phases
- Control Modules

Batch Execution uses the equipment defined within an area model to:

- Construct recipes.
- Execute batches.

The Equipment Editor is integrated into the Proficy Batch Execution WorkSpace application, providing a central location for all your development needs. The following subsections highlight some of the key benefits that the Equipment Editor provides.

Graphical Interface

The Equipment Editor provides a graphical, hierarchical representation of the equipment in your plant. Icons represent each piece of equipment, providing an immediate association between the equipment on the plant floor and the equipment configured in the Equipment Editor. Users can easily examine equipment by drilling up and down through the equipment hierarchy.

S88.01-Aware

The terminology and equipment hierarchy in Batch Execution is based on the widely accepted industry-standard ISA S88.01 Batch Control Models and Terminology. Standard S88.01 terms, such as process cell and unit, are used throughout the Equipment Editor. Users that apply the standard to their process can easily identify these equipment entities in Batch Execution.

Open Architecture

The Batch Execution Server is an OPC-enabled client. This lets you retrieve data from any OPC (OLE for Process Control) compliant data server, such as GE's iFIX® software. Based on Microsoft's® OLE (Object Linking and Embedding) technology, OPC provides greater interoperability between control applications, field systems and devices, and Office/BackOffice applications. OPC servers of real-time information, such as DCS, PLCs, smart field devices, and analyzers can communicate directly with the Batch Execution Server.

Integration with iFIX

In addition to being able to retrieve data from GE's iFIX software, the Equipment Editor also lets you associate an iFIX picture with the equipment configured in Batch Execution. Operators can access these pictures from the Batch Execution Client to view real-time process values for the associated equipment.

Maximizing Equipment Usage

Batch Execution supports Active Binding™, which allows Batch Execution to bind and re-bind units at multiple stages in a batch's life cycle including when a batch is created, started, or in production. Recipe authors can configure recipes to automatically allocate equipment to batches based on the:

- Properties of the equipment entities.
- Real-time conditions on the plant floor.

Your area model can incorporate features such as class-based units, equipment pathing within a process cell, unit capacity, and unit status to provide Batch Execution with a host of information to perform Active Binding.

Interoperability with Batch Execution

The area model configuration affects other areas of Batch Execution including:

Recipe Development – your area model configuration affects the configuration of recipes in the Recipe Editor. For example, in order for a recipe author to build a recipe that can run on multiple units, you must configure class-based units.

Batch Execution – your area model configuration affects what equipment the Batch Execution Server can allocate to batches. During batch execution, the Batch Execution Server verifies that the selected equipment is part of a valid equipment path, meets the capacity requirements, and is available for use. The Batch Execution Server also allocates all equipment that was specified as "needed" in the Equipment Editor. This reserves the needed equipment so that other batches cannot use the same equipment at the same time.


Understanding the S88.01 Physical Model

The equipment hierarchy in Batch Execution is based on the ISA S88.01 Physical Model. The *Physical Model* defines a hierarchy consisting of several levels that identifies the equipment within an enterprise. Equipment is grouped together at a lower level to create a piece of equipment in the next higher level.

The objective of the Physical Model is to define equipment entities that can be grouped together to perform specific process activities. Performing this task requires you to have a clear understanding and definition of each piece of equipment in your plant. Refer to the Batch Execution Application Guide for more information on the Physical Model.

Example: Equipment Hierarchy in Batch Execution

The following figure illustrates a sample equipment hierarchy. Refer to the Getting Started section for more information on the sample application that uses this area model.



Sample Application Equipment Hierarchy

Implementation Strategies

The sections that follow provide strategies for configuring equipment in the Batch Execution Equipment Editor, including:

- Partitioning your plant equipment.
- Implementing a class-based design.
- Implementing Active Binding.

Partitioning Plant Equipment

Prior to configuring equipment in the Equipment Editor, partition your equipment for maximum productivity. This includes identifying:

- The units and other equipment that make up a process cell.
- The equipment phases and other related equipment that make up a unit.
- The phases within a unit.
- Common resources.

NOTE: To optimize new process designs or modifications to existing processes, include equipment partitioning in the design specifications of the process.

General Definition Guidelines

To achieve the most efficient and easily maintained equipment, use the following guidelines:

- Define equipment without a particular product in mind. This way, when you make a change in the product or process, it is less likely you will need to change the equipment definitions.
- Define each piece of equipment to work independently.

Partitioning Process Cells

A *process cell* consists of the production and supporting equipment necessary to make a batch. In Batch Execution, a process cell can contain units, equipment phases, and control modules. Two major factors determine how you partition process cells. These factors are the:

- Number of different products manufactured.
- Physical structure of your equipment.

The following subsections describe each condition.

Number of Products

The ISA S88.01 Batch Control Standard defines process cells as either *single-product* or *multi-product*. A single-product process cell produces the same product in each batch. A multi-product process cell can produce different products. Batch Execution supports both single-product and multi-product process cells.

Physical Structure

The ISA S88.01 Batch Control Standard defines three types of process cell structures:

- Single path.
- Multiple path.
- Network path.

A single path structure is a group of units through which a batch passes sequentially. A multiple path structure consists of several single path structures in parallel, with no product transfer between them. In a network structure, the paths may be either fixed or variable. If the path is variable, the path is determined at batch run-time. Batch Execution supports all three pathing structures.

Equipment Pathing

Within a process cell, Batch Execution lets you configure the physical connections between units to ensure that batches execute on a valid equipment path. Refer to Implementing Active Binding section for more information on equipment pathing.

Partitioning Units


An integral part of your control strategy is deciding what pieces of equipment make up a unit. A *unit* is a major piece of equipment in a process cell that performs a specific task. It consists of all the equipment modules and control modules that the unit needs to perform this task. Equipment phases control the equipment that makes up a unit. Note that units:

- Only run one batch at a time.
- Operate independently of each other.

You cannot effectively configure a unit in Batch Execution until you have a complete understanding of the equipment and control modules that make up the unit.

Example: Defining the MIXER Unit

The following figure illustrates how the MIXER and RAW unit classes in the sample toothpaste application are partitioned. The mixer contains the equipment modules (such as the agitator) and control modules that operate the mixer. In this case, it is clear that the control modules that make up the agitator equipment module should be defined as part of the MIXER unit. However, it may be less clear to determine which unit certain equipment (such as the valve connecting the RAW and MIXER units) belongs to. In the case of the sample toothpaste application, the valve is included in the MIXER unit.



Sample MIXER Equipment Phases

Identifying Common Resources

In complex batch processes, you may have equipment that more than one resource uses. This type of equipment is called a *common resource*. Typically, a common resource is either a control module or an equipment module that more than one unit can request. In Batch Execution, other resources or the operator can make requests for resources. In order for Batch Execution to allocate resources appropriately, you can designate common resources as either exclusive-use or shared-use resources. Only one requestor can use an exclusive-use resource at one time. Multiple requestors can use a shared-use resource simultaneously.

Examples of common resources include:

- A pump that is shared between two units. If the pump can only be used by one unit at one time, you would designate the pump as an exclusive-use resource.
- A process heater that can heat multiple units simultaneously. In this case, you would designate the heater as a shared-use resource.


Batch Execution provides several options for configuring common resources:

If the common resource is a...	Batch Execution lets you...
Unit	Share the unit between two or more process cells.
Equipment Phase	Share the equipment phase between two or more units.
Control Module	Assign the control module as a needed resource to each piece of equipment that requires the control module to execute.

NOTE: For more information on configuring and arbitrating common resources, including shared-use and exclusive-use resources, refer to the *Advanced Topics* section.

Example: Configuring Equipment Phases as Common Resources


In the sample toothpaste application, the Flavoring and Whitener units share a valve that transfers material into a mixer. The equipment phase, XFER_OUT7 is designated as an exclusive-use resource. The following figure illustrates this configuration.



Configuring Equipment Phases as Common Resource

Example: Configuring Control Modules as Common Resources

The following figure shows a pneumatic conveying system. In this system, the blower is a common control module that is a common resource. The blower is assigned to BIN1 and BIN2 as needed equipment.



Configuring Control Modules as Common Resources

Implementing a Class-Based Design

The ability to create class-based equipment entities ties in with the overall goal of creating reusable and maintainable equipment. In Batch Execution, process cells, units, and phases are defined at both the class-level and the instance-level.

The *class-level* defines common properties that apply to all instances of that equipment entity. The *instance-level* defines information that ties a specific entity to its physical equipment. Implementing a class-based design is especially effective when configuring units.

Implementing Class-Based Units


Implementing class-based units allows recipe authors to build class-based recipes. *Class-based recipes* are recipes that can execute on any unit within a class of units. Depending on how the recipe is configured, the Batch Execution Server can:

- Automatically select the specific unit instance.
- Prompt the operator to select the unit when the recipe executes.

For more information on class-based recipes and configuring recipes for automatic unit allocation, refer to the Recipe Development Manual.

Example: Class-Based Units

Use a class-based design when a process cell contains several similar units, such as mixers or storage tanks. As illustrated in the following figure, the process cell contains seven storage tanks, three mixers, and two reactors. Rather than defining twelve unique units, you can define three unit classes and then configure the I/O points for each unit instance. Using this class-based configuration, the recipe author can build one class-based recipe that runs on any unit instance in the raw, mixer, and reactor classes.



Unit Classes and Instances

Implementing Active Binding

Batch Execution supports Active Binding. *Active Binding* encompasses all aspects of binding a unit procedure to a physical unit. Batch Execution can bind and re-bind unit procedures to units at multiple stages in a batch's life cycle including when a batch is:

- Created (added to the batch list).
- In production.

To provide Batch Execution with information to intelligently bind an appropriate unit, you can implement the following functionality in your area model:

Equipment pathing – Within a process cell, you can specify the physical connections between units. When the unit procedure executes, the selected unit must be within a valid equipment path.

Equipment capacity – For each unit, you can specify the unit's maximum capacity. When the recipe executes, the selected unit must meet the capacity requirement defined for the unit procedure.

Equipment status tags – For each unit, you can specify a Unit Ready status and a Unit Priority status, which indicate the unit's current availability and priority rating. When the recipe executes, the unit selected by the Batch Execution Server must be in a ready status. If more than one unit is ready, the Batch Execution Server selects the unit with the highest priority.

Implementing Equipment Pathing

Within a process cell, you can define the physical connections between units. During equipment configuration, you graphically configure these connections using drawing tools provided in the Equipment Editor. The Batch Execution Server uses these connections to ensure that a batch executes on a valid path in the process cell. Implementing equipment pathing:

- Prevents the Batch Execution Server or the operator from allocating units to batches that are not part of a valid execution path.
- Verifies that the Jacobson Links™ defined in recipes are valid based on the pathing defined in the area model. *Jacobson Links* are connections that are drawn within a recipe's sequential function chart (SFC) to graphically represent a necessary physical connection between unit procedures. Refer to the Recipe Development Manual for more information on Jacobson Links.

For example, if the recipe requirements specify that two units must be connected, the Batch Execution Server ensures that the execution path for the batch contains two connected units.

Equipment pathing is especially important if, during a batch, material is transferred between units. Without this pathing, any unit within a unit class may be considered valid, regardless of whether it is physically connected to another unit.

Implementation Guidelines

When configuring your equipment paths, consider the following guidelines:

- Only connect units that are physically connected on the plant floor.
- Bi-directional connections between two units require two separate connections. An example of a bi-directional connection is when material can be transferred to and from two connected units.

For more information on configuring equipment pathing, refer to the Configuring Equipment section.

Implementing Equipment Capacity

Equipment capacity defines the maximum capacity that a unit can contain, transfer, or process during production. The capacity definition for a unit coupled with the minimum capacity requirement defined for a unit procedure recipe ensures that only those units with the required capacity are allocated to batches.

A unit's capacity can also be incorporated into VBIS scheduling applications to schedule batches based upon capacity plans. For more information on VBIS, refer to the Custom Applications manual.

For more information on configuring a unit's equipment capacity, refer to the Configuring Equipment section.

Implementing Equipment Status Tags

Batch Execution supplies two pre-defined unit tags, Unit Ready and Unit Priority, which you can use to indicate the current status of a unit.

Unit Ready tag – indicates whether the unit is ready for use. A value of zero (0) indicates the unit is ready and can be used by a batch. A non-zero value indicates the unit is not currently available. Batch Execution will not allocate a unit with a non-zero Unit Ready tag to a batch.

Unit Priority tag – indicates the priority of the unit, as compared to other units in the same unit class. If multiple units are available for a batch, Batch Execution selects the unit with the highest priority value.

How you implement these tags depends on your particular process and requires you to program your process controller or HMI to set these tags as appropriate. For more information on using these tags, refer to the Advanced Topics section.

Example: Active Binding

The equipment configuration for the sample toothpaste application uses equipment pathing, equipment capacity, and equipment status tags to provide Batch Execution with data to ensure that suitable units are allocated to batches. The following table lists the equipment capacity settings and the current equipment status for each unit instance in the MIXER class.


Sample Unit Equipment Capacity and Status		
Unit Instance	Equipment Capacity	Current Equipment Status
MIX1	1000 Liters	MIX1_READY=1 MIX1_PRIORITY=3
MIX2	600 Liters	MIX2_READY=0 MIX2_PRIORITY=1
MIX3	1000 Liters	MIX3_READY=0 MIX3_PRIORITY=3

Recipe Requirements

Assume that the following equipment requirements exist for the MAKE_BASE and MAKE_ADDITIVE unit procedures in the sample application.

Sample Recipe Equipment Requirements			
Unit Procedure	Unit Class	Capacity Requirement	Bind Type
MAKE_BASE	MIXER	1000 Liters	Automatic
MAKE_ADDITIVE	MIXER	200 Liters	Automatic

Based on the requirements and equipment configurations listed in the previous tables, the Batch Execution Server selects the path shown in the following figure.



Unit Classes and Instances

The Batch Execution Server performs the following process of elimination to select the equipment path shown in this figure:

1. Batch Execution eliminates MIX1 because the MIX1_READY tag indicates that it is currently offline. This narrows the choice to MIX2 and MIX3.
2. Batch Execution selects MIX3 for the MAKE_BASE unit procedure because:
 - Its Unit Ready tag indicates it is online.
 - It meets the minimum capacity requirement defined in the unit procedure.
 - MIX3 is physically connected to the transferring units.
3. Batch Execution selects MIX2 for the MAKE_ADDITIVE unit procedure, because:
 - Its Unit Ready tag indicates it is online.
 - It meets the minimum capacity requirement defined in the unit procedure.
 - MIX2 is physically connected to the transferring units.
4. Batch Execution selects the REACTFLAVOR unit for the MAKE_FINAL unit procedure because this is the only reactor that is physically connected to MIX2 and MIX3.

For more information on configuring recipes for Active Binding, refer to the Recipe Development Manual.

Getting Started

To help you get started creating your area model, the sections that follow describe basic Equipment Editor concepts. It also introduces the sample application's equipment configuration, which is used as the basis for most examples in this manual.

You can access the Equipment Editor application either from the Proficiency Batch Execution WorkSpace or by double-clicking the Equipment Editor icon in the Batch Execution program group. Refer to the Application Guide for more information on using the Proficiency Batch Execution WorkSpace.

Understanding the Area Model

The Equipment Editor is the application used to configure an *area model*. The area model contains configuration information for the equipment within an area. For each area model you create, the Equipment Editor creates a CFG file.

For example, the DEMO.CFG file is the sample application's area model. This file contains all the equipment configuration information for the sample application's AREA1 area model.

When you start the Batch Execution Server or the Recipe Editor, it loads the area model, which is referenced during recipe creation and batch execution. The Batch Execution Server reads the area model file once, at the time a batch is created in the Batch Execution Client. Likewise, the Recipe Editor reads the area model once when you first start the Recipe Editor.

IMPORTANT: *To view any changes you make to the area model while a batch is running, you need to shut down and restart the Server and Soft Phase Server. Similarly, if you make changes to the area model while the Recipe Editor is running, you need to shut down and restart the Recipe Editor in order to view the changes.*

Exporting and Importing Area Models

The information within your project's area model is stored in binary format. You can export the area model to a text (.txt) or XML file. You could also modify this area model, and import the file back into the Proficiency Batch Execution product.

The Export command is available from both the Proficiency Batch Execution Workspace and in the Equipment Editor. To access the Export command in the WorkSpace, on the Area menu choose Export and the format type (Text or XML). To access the Export command in the Equipment Editor, on the File menu click Export and the file type.

Be aware that Import command is only available from the Equipment Editor. The Proficiency Batch Execution WorkSpace does not display the Import option. To use the Import command in the Equipment Editor, on the File menu, click Import.

IMPORTANT: *You cannot merge area model files if you use default equipment IDs. This is because default IDs are not unique and the duplicate IDs will not appear in the merged area model.*

The Equipment Editor Window

The Equipment Editor provides an easy-to-use, graphical interface that includes features such as right mouse button support and toolbar buttons.

The Equipment Editor window contains the following items:

- Toolbar
- Configured Classes window
- Work Area
- Location bar (not available when running the Equipment Editor from the Proficy Batch Execution WorkSpace)
- Status bar (not available when running the Equipment Editor from the Proficy Batch Execution WorkSpace)
- Proficy Batch Execution WorkSpace system tree (only available when running the Equipment Editor from the Proficy Batch Execution WorkSpace)

Using the Navigation Tools

The Equipment Editor contains several tools for navigating through the equipment hierarchy. The following table describes each tool.

Use the...	To...
Up Arrow and Down Arrow buttons on the toolbar. Proficy Batch Execution WorkSpace system tree.	Move up and down through the equipment hierarchy.
Location bar. Status bar.	View what level of the hierarchy you are currently in.

Customizing the Window


You can customize the window layout to best suit your needs. You can:

- Resize and move the toolbar and configured classes window to different locations by selecting the tool and dragging it to the desired location.
- Toggle the display of the toolbar, configured classes window, and location bar by selecting the appropriate command from the View menu.

Using the Toolbar

The Equipment Editor toolbar provides a faster alternative to using most of the menu commands. To learn what each button does, position the cursor on a button. A ToolTip identifies each button's function.

The following figure illustrates the Equipment Editor window from within the Proficy Batch Execution WorkSpace.



Equipment Editor Window

Prerequisites

As you build the area model, it is important to keep in mind that you can only implement those features that have already been programmed in the process controller. The Equipment Editor does not allow you to define new equipment or phases; it simply provides a graphical, easy-to-understand representation of the existing equipment on the plant floor and the existing phase logic programmed in the process controller. All equipment definitions in the Equipment Editor must be compatible with how the equipment is programmed in the process controller.

To configure the actual process requirements, you need to:

- Understand the equipment you are defining. Refer to your plant's P&ID drawing.
- Program the process controller with the Phase Logic Interface (PLI) and the project-specific phase logic. Refer to the PLI Development Manual and the Phase Programming Manual for more information.
- Identify the tags your process requires. For example, if you are using iFIX, identify the database tags (PDB) that are required for your process. Note that Batch Execution lets you add tags to the iFIX database during area model configuration.
- Obtain the following information for each unit and have it available during equipment configuration:
 - Unit's capacity and unit of measure
 - Unit Ready and Unit Priority tag names and addresses
- Obtain the following information for each equipment phase and have it available during equipment configuration:
 - Tag names and addresses
 - Phase parameters defined in the phase logic
 - Request variables defined in the phase logic
 - Operator messages defined in the phase logic
 - Number of phase partners defined in the phase logic
 - Phase class type
- Define the OPC servers for your process data. Refer to the System Configuration Manual for configuration instructions.

See the Application Guide for an overview of Batch Execution development tasks.

Introducing the Sample Application

The equipment defined for the sample toothpaste application provides examples that you can view and explore in the Batch Execution Equipment Editor. The following sections describe the sample application's equipment configuration:

- Process and Instrumentation Drawing
- Equipment Hierarchy
- Execution Paths

Process and Instrumentation Drawing

Typically, a process engineer uses the plant's Process and Instrumentation Drawing (P&ID) as a reference when configuring the equipment. The Sample P&ID Drawing shown in the Equipment Hierarchy section is a P&ID representation of the equipment used in the sample application.

Equipment Hierarchy


Based on the P&ID diagram in the following figure, the equipment hierarchy for the sample application is partitioned as follows:

Area – The area name for the sample toothpaste application uses the default name, AREA1.

Process Cell – AREA1 contains one process cell called TOOTHPASTE. This process cell contains all of the equipment required to make batches of toothpaste.

Units – The TOOTHPASTE process cell contains three unit classes:


This Unit Class...	Defines these Unit Instances...
MIXER	MIX1, MIX2, MIX3
REACTOR	REACTPLAIN, REACTFLAVOR
RAW	WATER, BAKINGSODA, GUM, FLUORIDE, PH_ADDITIVE, FLAVORING, WHITENER



Sample P&ID Drawing

MIXER Equipment Phases


As shown in the following figure, each instance of the MIXER unit class contains equipment-specific instances of the ADD_INGS, AGITATE, COOL, and XFER_OUT equipment phase classes.



Sample MIXER Phases

RAW Equipment Phases


As shown in the following figure, each instance of the RAW unit class contains the XFER_OUT equipment phase.



RAW Phases

REACTOR Equipment Phases

As shown in the following figure, each instance of the REACTOR unit class contains equipment-specific instances of the XFER_IN and AGITATE equipment phase classes.



Sample REACTOR Phases

Execution Paths

The sample toothpaste application uses a multi-product, network path process cell. The equipment pathing defined for the sample application's process cell determines the valid batch execution paths. Batch Execution uses Active Binding to select the path at run-time. Refer to the Implementation Strategies section for more information on Active Binding.


The execution flow for the sample toothpaste application is as follows:

1. Transfer the base ingredients into a mixer where they are agitated. The base ingredients (water, baking soda, gum, fluoride, and Ph_additive) are on one header feeding MIX1, MIX2 and MIX3.
2. Transfer the additive ingredients into a mixer where they are agitated. The additive ingredients (flavoring and whitener) are on a second header that feeds into MIX2 and MIX3.
3. Transfer the additive and base mixtures into one of the reactors where they are combined to produce the final product. All three mixers feed into the REACTFLAVOR unit while the REACTPLAIN unit is fed only by MIX1.

NOTE: The REACTPLAIN unit is used when making a batch of the base mixture, without the additive ingredients.


The following figures illustrate the possible execution paths for the sample toothpaste application. For information on configuring equipment paths, refer to the Configuring Equipment section.

The following figure illustrates the execution path when the Batch Execution Server selects MIX2 for the MAKE_BASE unit procedure and MIX3 for the MAKE_ADDITIVE unit procedure.




Sample Execution Path Using MIX2 and MIX3

The following figure illustrates the execution path when the Batch Execution Server selects MIX2 for the MAKE_ADDITIVE unit procedure and MIX3 for the MAKE_BASE unit procedure.




Sample Execution Path Using MIX2 and MIX3

The following figure illustrates the batch's execution path when the Batch Execution Server selects MIX1 for the MAKE_BASE unit procedure and MIX3 for the MAKE_ADDITIVE unit procedure.



Sample Execution Path Using MIX1 and MIX3

The following figure illustrates the execution path when making a batch of toothpaste without the flavoring or whitener additives. This process requires the batch to use the REACTPLAIN unit. Therefore, the recipe author configures the recipe to select MIX1 for the MAKE_BASE unit procedure, because this is the only mixer connected to the REACTPLAIN unit.



Sample Execution Path Using REACTPLAIN

Task Overview: Equipment Configuration

The following tasks are required to create an area model. Each task is described in detail in the upcoming sections.

1. Configure an area.
2. Configure enumeration sets and enumerations.
3. Configure process cell classes and instances.
4. Configure unit classes and instances.
5. Configure equipment pathing within process cells.
6. Configure equipment phase classes and equipment phases.
7. Configure control modules as resources.

Configuring Enumerations

The following sections provide information on how to configure and implement enumerations in your process.

An *enumeration* is a process variable that is assigned an ordinal (numeric) value. These enumeration strings become easily-understandable choices for recipe authors and operators when setting values for phase parameters, phase reports, or unit tags. The enumeration string corresponds to the ordinal value that is used by the phase logic in the process controller.

Typically, you use enumerations when the recipe author or operator needs to specify an ingredient type. The following table shows a FLAVORS enumeration set. The operator or recipe author only needs to select the appropriate flavor name; Batch Execution automatically supplies the corresponding numeric value required by the phase logic.

FLAVORS Enumeration Set	
Enumeration string...	Can correspond to ordinal value (used by phase logic)...
WINTERGREEN	0
SPEARMINT	1
PEPPERMINT	2

Valid entries for enumeration strings include: A - Z, 0 - 9, and the underscore character. Enumeration strings should not contain spaces or these characters: !@#%&^*()

Configuring and Implementing Enumerations

Configuring and implementing enumerations spans several Batch Execution applications. These tasks are grouped into two categories:

- Configuration tasks
- Implementation tasks

Configuration Tasks

Configuring enumerations consists of the following tasks:

1. In the Equipment Editor, define enumeration sets and enumerations based on the phase logic defined in the process controller.
2. In the Equipment Editor, configure equipment phase parameters, equipment phase reports, and unit tags with an enumeration data type as appropriate.

Refer to the Standard Equipment Phases section for information on configuring equipment phase parameters and equipment phase reports.


Implementation Tasks

Once enumerations are configured, recipe authors can use them as follows:

1. During recipe development, authors can select from a list of enumeration strings to assign phase parameter values to a recipe.
2. During batch execution, operators can select from a list of enumeration strings to supply parameter values for a batch.

Example: Configuring and Implementing Enumerations

The following figure illustrates how enumerations are configured and implemented in the sample toothpaste application. In this example, the recipe author takes advantage of the flexibility built into the XFER_IN equipment phase. This phase uses a FLAVORS enumeration set, which enables the recipe formulator to build one recipe that can produce several flavors of toothpaste. Enumerations are used to select the appropriate flavor additive depending on the type of toothpaste being made. For example, if the operator selects WINTERGREEN as the ingredient, Batch Execution sends a value 0 to the phase logic, which instructs the phase logic to open the valve for the tank containing the WINTERGREEN flavoring.



Configuring and Implementing Enumerations

Pre-Defined Enumeration Sets

Batch Execution supplies two pre-defined enumeration sets:

- PHASE_FAILURES enumeration set
- UNIT_OF_MEASURE enumeration set

The following subsections describe each enumeration set.

PHASE_FAILURES Enumeration Set

The Equipment Editor supplies a pre-defined PHASE_FAILURES enumeration set. This enumeration set links to the failure register (PHASE_F) in the Phase Logic Interface (PLI). When a failure register is set, the Batch Execution Client's Alarm Summary window displays the failure register's associated enumeration string.

It is recommended that you create enumerations specific to your process. For instance, the sample toothpaste application could include the following enumeration strings:

Enumeration String...	Can correspond to Ordinal Value (used by phase logic)...
PHASE EXCEED TEMP	1
AGITATE FAILED	2

In the example above, when PHASE_F is set to 1, the string PHASE EXCEED TEMP is sent to the Alarm Summary window in the Batch Execution Client.

NOTE: If you do not define any enumerations for the PHASE_FAILURES enumeration set, operators will see the following message when failures occur:

```
CONFIG ERROR - 0 not defined in PHASE FAILURES enumeration set - unable
to locate failure description: 10phase failed.
```

UNIT_OF_MEASURE Enumeration Set

The Equipment Editor supplies a pre-defined UNIT_OF_MEASURE enumeration set. Batch Execution supplies the most commonly used units of measure in this set. However, you can define additional units of measure required for your particular process. This enumeration set contains the following pre-defined units of measure:

UNIT_OF_MEASURE Enumeration Set	
Standard	Unit of Measure
Metric (Mass)	<ul style="list-style-type: none"> • Milligrams • Grams • Kilograms • Tonnes - 1000 KG
US (Mass)	<ul style="list-style-type: none"> • Ounces • Pounds • Tons - 2000 LB

UNIT_OF_MEASURE Enumeration Set	
Standard	Unit of Measure
Metric (Volume)	<ul style="list-style-type: none"> • Milliliters • Liters • Kiloliters
US (Volume)	<ul style="list-style-type: none"> • Fluid Ounces • Pints • Quarts • Gallons

Batch Execution uses the UNIT_OF_MEASURE enumeration set to assign units of measure to the:

- Maximum equipment capacity for a unit. You define this capacity in the Equipment Editor.
- Capacity requirement for a recipe's unit procedure. You define this requirement during recipe configuration in the Recipe Editor.
- The default batch size defined for a recipe. You define this size during recipe configuration in the Recipe Editor.

When assigning a unit of measure to these items, you can select from a predefined list. This ensures that the same units of measure are used across all Batch Execution applications. When specifying UOMs in the Equipment Editor, if the unit of measure does not exist in this list, you can add new units of measure to the UNIT_OF_MEASURE enumeration set. You can define any unit of measure required for your process. For example, you can define Packages, Pieces, Cartons, and so on.

IMPORTANT: *If you want Batch Execution to use equipment capacity as part of its Active Binding selection criteria, assign the same UOM to (1) all units within a unit class and (2) the unit procedure's capacity requirement. If the unit procedure's capacity requirement and the unit's capacity amount have different UOMs, Batch Execution ignores the unit's capacity amount during Active Binding. For details on configuring a unit's equipment capacity, refer to the Configuring Equipment section.*

Overview: Defining Enumerations

Defining enumerations consists of:

1. Defining enumeration sets (except when defining enumerations for the PHASE_FAILURES and the UNIT_OF_MEASURE enumeration sets).
2. Defining enumerations strings and their corresponding ordinal values.

NOTE: *For existing enumeration sets, you can add new enumerations strings on the fly, while the Batch Server is running; you do not have to restart the Batch Server for your changes to be recognized. Saving the Equipment Model is all that is required. The new enumerations that you add do not apply to batches you already scheduled, only to new, subsequently added, batches.*

You can only add a new enumeration to the set, not remove or modify an existing enumeration on the fly. For example, you cannot change the ordinal number or string name for an enumeration while the Batch Server is running and expect it to get applied without restarting the Server. If you want to delete an enumeration or change an existing one, you must stop and restart the Batch Server for your changes to get applied.

For example, if your existing enumeration set is A = 0, B = 1, C = 2, you can make the following type of changes while the Batch Server is running: A = 0, B = 1, C = 2, D = 3 (D added). But, these types of on the fly changes are invalid: A = 0, B = 1, C = 3 (value of C changed); A = 0, B = 1 (C removed).

These limitations apply only to changes made to existing enumeration sets on the fly and not to changes made during configuration.

Prerequisites

Before defining enumerations, the following tasks must be complete:

- The phase programmer must configure the phase logic to support enumerations.
- The ordinal values you enter must match the values configured in the phase logic.

NOTE: *The UNIT_OF_MEASURE enumeration set does not require any programming in your phase logic.*

Overview: Maintaining Enumerations

If necessary, you can modify and delete enumeration sets. You may need to perform one or more of the following maintenance tasks:

- Modify enumeration set names.
- Modify enumeration strings and their corresponding ordinal values.
- Delete enumeration sets.
- Delete enumeration strings and their corresponding ordinal values.

NOTE: *You cannot delete or rename the PHASE_FAILURES or the UNIT_OF_MEASURE enumeration sets.*

Important Information for Working with Enumerations

For existing enumeration sets, you can add new enumerations strings on the fly, while the Batch Server is running; you do not have to restart the Batch Server for your changes to be recognized. Saving the Equipment Model is all that is required. The new enumerations that you add do not apply to batches you already scheduled, only to new, subsequently added, batches.

You can only add a new enumeration to the set, not remove or modify an existing enumeration on the fly. For example, you cannot change the ordinal number or string name for an enumeration while the Batch Server is running and expect it to get applied without restarting the Server. If you want to delete an enumeration or change an existing one, you must stop and restart the Batch Server for your changes to get applied.

For example, if your existing enumeration set is A = 0, B = 1, C = 2, you can make the following type of changes while the Batch Server is running: A = 0, B = 1, C = 2, D = 3 (D added). But, these types of on the fly changes are invalid: A = 0, B = 1, C = 3 (value of C changed); A = 0, B = 1 (C removed).

These limitations apply only to changes made to existing enumeration sets on the fly and not to changes made during configuration.

Maintenance Guidelines

When you modify or delete enumerations that are currently used by equipment phases, you may need to re-configure the phase parameters.

If you ...	Then...
Modify or delete an enumeration string that is used as the default value for an equipment phase parameter.	You must modify the equipment phase parameter to use a new default enumeration string.
Delete an enumeration set that is used by any equipment phase.	The data type of the affected equipment phase parameters, tags, and reports changes from enumeration to integer.
Modify or delete a unit of measure that is assigned to a: Unit's equipment capacity. Unit procedure's minimum equipment capacity. Recipe's default batch size.	You must change the assigned unit of measure to one that exists in the UNIT_OF_MEASURE enumeration set.

***NOTE:** Batch Execution displays the Enumeration Set Modification dialog box that describes the tags, parameters, and reports that will change based on modification of the selected enumeration set.*

Configuring Equipment

The sections that follow describe how to configure areas, process cells, and units in the Batch Execution Equipment Editor. Before you begin defining this equipment, you need to have a complete understanding of the physical layout of the equipment in your plant. All definitions in the Equipment Editor must match the physical equipment in your plant. Refer to your plant's P&ID drawing, if necessary.

Overview: Configuring Equipment

The steps that follow describe how to define an area model.

►To define an area model:

1. Define an area to represent the area model for your plant.
2. In the area, define one or more process cells to contain the equipment to produce a batch of your product.
3. In the process cell, define the units that reside in the process cell.
4. Define the physical connections between units within the process cell.
5. For each unit, define the equipment phases that execute on the unit.

For information on equipment phases, refer to the Standard Equipment Phases section.

Defining an Area

An *area* represents a physical, geographical, or logical grouping of equipment. In Batch Execution, an area can contain the following equipment:

- Process cells
- Units
- Equipment phases
- Control modules

In Batch Execution, the equipment defined within an area is called the area model. Recipes are built and executed based on the equipment defined in a specific process cell within the area model. An area model contains all of the equipment necessary to produce all products at a plant.

When you start the Equipment Editor or you define a new project, Batch Execution automatically creates a default empty area called AREA1. This provides a starting point for all equipment definitions in this area. You may, however, want to change the name of the area based on your plant's needs.

Example: Area Model

Typically, you define one area model that contains all of the equipment at your plant. For example, the sample plant, which can produce both toothpaste and mouthwash, is represented by one area model called AREA1. This area model contains the equipment required to produce both products.

Defining Process Cells

Depending on how your equipment is partitioned, you can define one or more process cells in your area model. A process cell consists of all the production and supporting equipment necessary to make a batch. It may include one or more production lines, which are used to produce more than one product.

For more information on partitioning process cells, refer to the Implementation Strategies section.

Overview: Configuring Process Cells

The steps that follow explain how to configure process cells.

►To configure a process cell:

1. Define a process cell class and specify the icon and class name for the process cell.
2. Define a process cell and specify the cell instance name and optionally, equipment arbitration information.
3. Optionally, specify the iFIX picture associated with the process cell.

Example: Process Cells

Using the sample toothpaste application as an example, the AREA1 area contains the process cell class called TOOTHPASTE. The TOOTHPASTE process cell contains all the equipment necessary to make all flavors of toothpaste.

Defining more than one process cell may be appropriate if your plant makes multiple products that share some, but not all, equipment in an area. For example, if the sample plant produced toothpaste and mouthwash, it is likely that some equipment may be shared across the two processes. In this case, you could create two process cells, one containing the equipment to produce toothpaste and another containing the equipment to produce mouthwash. However, if the majority of the equipment is shared, then it may still be appropriate to just have one process cell for both products.

Defining Units

A *unit* is a major piece of equipment in a process cell that performs a specific task. It consists of all the equipment and control modules that a unit needs to perform this task. An integral part of your control strategy is defining what pieces of equipment make up a unit. This strategy should be defined before you begin configuring units in your plant.

Design Strategies

There are several strategies to consider when designing your units:

Class-Based Units

If you have several similar units in your plant, you may want to implement a class-based unit strategy. This strategy lets recipe authors build class-based recipes.

Equipment Pathing

Once you have defined your units, you can define the physical connections between the units. Batch Execution can use these connections to ensure that a batch executes on a valid path.

Equipment Capacity

For each unit instance, you can define the maximum capacity that the unit can contain, transfer, or process during production. Recipe authors can then indicate the minimum capacity required for a unit procedure and Batch Execution will ensure that an appropriate unit is selected during batch production.

Unit Ready and Unit Priority Tags

You may want to incorporate Unit Ready and Unit Priority tags into your process to prevent the allocation of unavailable or undesired units to batches.

For more information on implementing these strategies, refer to the Implementation Strategies section.

Overview: Configuring Units

Configuring units consists of the following tasks:

1. Create a unit class for each class of unit in your plant; for example, mixers, heaters, and reactors.
2. For each unit class, define the class properties including the class name and icon.
3. Create a unit instance for each physical unit in the appropriate process cell.
4. For each unit, define the unit properties including the name, equipment capacity, and arbitration information.
5. Optionally, specify the iFIX picture associated with the unit.
6. Optionally, use the Link tool to draw connections between physically connected units to form an equipment path.
7. If appropriate, define unit tags. Refer to the Advanced Topics section for information on unit tags.
8. If the unit is shared by another process cell, share the unit. Refer to the Advanced Topics section for instructions on sharing equipment.

Example: Configuring Units


The TOOTHPASTE process cell in the sample application contains twelve units. In the Equipment Editor, the units are configured as follows:

- A RAW unit class is defined for seven storage tanks.
- A MIXER unit class is defined for three mixers.
- A REACTOR unit class is defined for two reactors.

Individual instances of each unit class are created to represent the physical equipment in the plant:

- Seven instances of the RAW class are defined as WATER, BAKINGSODA, FLUORIDE, WHITENER, GUM, PH_ADDITIVE and FLAVORING.
- Three instances of the MIXER class are defined as MIX1, MIX2, and MIX3.
- Two instances of the REACTOR class are defined as REACTFLAVOR and REACTPLAIN.

The following figure illustrates the unit classes and instances in the TOOTHPASTE process cell.



Sample Application Unit Configuration

Configuring Equipment Pathing


Once you have added units to your process cell, you can link physically connected units to form one or more equipment paths within a process cell. You configure these connections graphically using the following tools:

Link Units tool – puts you in linking mode and allows you to draw the links between physically connected units.

Manifold tool – drops in a manifold that lets you connect multiple units together.

Understanding Origin and Destination Units

A connection between two units results in both an *origin* and a *destination* unit. This determines the direction of the connection. For example, if a reactor feeds into a fermentor, the reactor is the origin unit and the fermentor is the destination unit. If the fermentor can also feed into the reactor, you must draw another connection where the fermentor is the origin unit and the reactor is the destination unit. The following figure illustrates this configuration.




Connecting Origin and Destination Units

Using Manifolds

Manifold objects:

- Let you easily connect multiple units.
- Can be configured as a common resource.

For example, assume that your plant contains a manifold that is a single pipe with inlets fed from two material tanks, TANK1 and TANK2, and outlets feeding into two mixers, MIX1 and MIX2. Assume that you only want one tank feeding into a mixer at one time. You can configure the manifold as a common, exclusive-use resource that is allocated to the transfer out phase on each tank. The following figure illustrates this example:




Using Manifolds

You can also configure the connection lines as common resources. For more information on configuring manifolds and connection lines as common resources, refer to the Advanced Topics section.

Example: Equipment Pathing

Configuring equipment paths ensures that the units selected for a batch are within a valid execution path. For example, in the sample toothpaste application, if MIX2 and MIX3 are selected for the MAKE_BASE and MAKE_ADDITIVE unit procedures, then Batch Execution determines that it must select the REACTFLAVOR reactor for the MAKE_FINAL unit procedure because neither MIX2 nor MIX3 are connected to the REACTPLAIN unit. The following figure illustrates this execution path.



Sample Execution Path

Refer to the Implementation Strategies section for more information on equipment paths.

Defining a Unit's Equipment Capacity

For each unit instance, you can define the unit's equipment capacity. You specify this value as an amount and a unit of measure to represent the maximum capacity that the unit can contain, transfer, or process during production. The capacity amount for a unit coupled with the minimum capacity requirement defined for a recipe's unit procedure ensures that only those units with the required capacity are allocated to batches.

Configuration Guidelines

Use the following guidelines to define a unit's equipment capacity:

- Unit instances within the same class can have different capacity amounts. For example, you may have two mixers of the same class; however, one may hold 600 Liters and the other may hold up to 1000 Liters.
- You can select the unit of measure (UOM) for the capacity amount from a pre-defined list. The entries in this list are defined in the UNIT_OF_MEASURE enumeration set. If the required UOM is not in this list, you can add new units of measure to this enumeration set.
- If you want Batch Execution to consider unit capacity as part of its unit selection criteria, assign the same UOM to:
 - All units within the same unit class.
 - The unit procedure's minimum capacity requirement.

IMPORTANT: If a unit has a different UOM than the UOM specified for the unit procedure's capacity requirement, Batch Execution ignores the unit's capacity amount as part of the selection criteria.

Example: Equipment Capacity and Unit of Measure

Assume the capacities listed in the following table are defined for the units within the MIXER class.

Sample Unit Capacities for MIXER Class of Units		
Unit Instance	Capacity Amount	Capacity UOM
MIX1	2000	Liters
MIX2	1000	Liters
MIX3	1000	Liters

Now, assume that the MAKE_BASE unit procedure has the equipment requirements listed in the following table.

Sample Unit Procedure Equipment Requirements			
Unit Class	Bind Type	Minimum Capacity Amount	Minimum Capacity UOM
MIXER	Automatic	2000	Liters

Using the configurations in the previous two tables, Batch Execution sees that MIX1 is the only unit within the MIXER class that meets the minimum capacity requirement defined for the unit procedure. Assuming all other criteria are met, Batch Execution will allocate MIX1 to the unit procedure.

Now, assume that a different UOM is assigned to the MIX3 unit in the MIXER class, as shown in the following table.

Sample Unit Capacities for MIXER Class of Units		
Unit Instance	Capacity Amount	Capacity UOM
MIX1	2000	Liters
MIX2	1000	Liters
MIX3	1000	Pounds

Using the configurations in this table, Batch Execution ignores the capacity setting for MIX3 because the UOM is different from the unit procedure's capacity requirement (Liters). Therefore, Batch Execution considers MIX3 a valid unit even though it may not be large enough to handle the unit procedure. Batch Execution will allocate either MIX1 or MIX3 based on other selection criteria, such as equipment pathing and the unit's equipment status.

Understanding Unit Tags

Unit tags are tags that are associated with a unit, such as temperature and level indicators. Unit tags, accessible to all phases on that unit, are typically used to implement class-based recipes.

Batch Execution also supplies two pre-defined unit tags, UNIT_READY and UNIT_PRIORITY, which Batch Execution uses to check a unit's equipment status during Active Binding.

For more information on configuring and using unit tags, refer to the Advanced Topics section. For more information on Active Binding, refer to the Implementation Strategies section.

Standard Equipment Phases

=Phases configured in the Equipment Editor are equipment-centric, meaning that you are not defining the control logic for the phase; instead, you are configuring the equipment on which the equipment phase executes. This type of phase is called an *equipment phase*. The actual control logic for an equipment phase resides in the process controller, not in the Equipment Editor.

Your task in the Equipment Editor is to create a representation of each equipment phase in the process controller and tie it to the equipment on which the equipment phase executes. In order to do this, you must have a complete understanding of how the equipment phases are programmed in the process controller.

Prerequisites

Before you can begin configuring equipment phases, gather the following information, as appropriate, about how the phase logic is programmed in the process controller:

- The equipment phase parameters required by the phase logic, including the parameter IDs, data types, and high and low limits.
- The equipment phase reports required by the phase logic, including the report IDs and data types.
- The operator messages required by the equipment phase, including the message ID.
- The number of phase partners required by the phase logic.
- The number of requests required by the phase logic.
- The phase class type.
- The I/O address for each equipment phase tag. If you are using the iFIX database, tag addresses reference a node.tag.field.


Understanding How Standard Equipment Phases Work

In the Equipment Editor or WorkSpace, you configure equipment phases at two levels:

Equipment Phase Class – defines generic information that applies to all instances of this phase. This generic information includes the parameters, reports, and operator messages required by the equipment phase.

Equipment Phase – defines the equipment-specific instance of an equipment phase and ties the equipment phase to the physical equipment (a unit) by specifying the equipment phase tags.


The following figure illustrates how the AGITATE equipment phase in the sample toothpaste application is configured. In this example, three equipment-specific instances of the AGITATE equipment phase class are configured and tied to the physical equipment in the plant.



Sample AGITATE Phase Configuration

Overview: Configuring Standard Phases

The following illustration provides an overview on how to configure a standard phase in the Proficiency Batch Execution WorkSpace or Equipment Editor.



Standard Phase Template

The Standard Phase Template allows you to change the default tag settings. The equipment tags for a standard phase include: Command, Failure, Owner, Pause, Paused, Request, Single Step, Status, Step Index, Unit, Parameter, Report, and Request Tags. You can configure the default node name, tag name, and tag type for each tag.

By changing the default tags to your custom settings, creating and maintaining batch projects with lots of equipment phases can be easier and faster. If you enter your default settings into the template when you first create your project, you will not need to edit each tag individually when you add a new phase to your project, especially if you are using iFIX as your SCADA software. In the iFIX product, the tags are formatted as Node.Tag.Field.

Any modifications you make to the Standard Phase Template apply to standard phases you add to your project after making the template updates. The values that you enter into the template do not change the equipment phase tags in pre-existing equipment phases.

To access the Standard Phase Template dialog box from the Edit menu, click Tag Template. The following figure illustrates an example of this dialog box.


Standard Tags	Server Alias	Phase	Suffix	Extension
Command	NODE1.	PHASE	_VC	.A_CV
Failure	NODE1.	PHASE	_F	.F_CV
Owner	NODE1.	PHASE	_W	.F_CV
Pause	NODE1.	PHASE	_P	.F_CV
Paused	NODE1.	PHASE	_PD	.F_CV
Request	NODE1.	PHASE	_RQ	.F_CV
Single_Step	NODE1.	PHASE	_SS	.F_CV
Status	NODE1.	PHASE	_ST	.F_CV
Step_Index	NODE1.	PHASE	_SI	.F_CV
Unit	NODE1.	PHASE	_UN	.F_CV
Parameter	NODE1.	PHASE	P	.F_CV
Report	NODE1.	PHASE	R	.F_CV
Request Tag	NODE1.	PHASE	Q	.F_CV

Standard Phase Template Dialog Box

Only the first Node field is available for editing in this dialog box. When you edit the Node field for the Command tag, all tags are automatically populated with the name you enter. This is because all tags for a phase must have the same node name. If you select the Use Server Alias button, all of the Server name fields are filled with the "#ALIAS#" text. The #ALIAS# syntax allows you to use the Alias configured in the Create OPC Server dialog box.

Be aware that you cannot edit the Phase field from the Standard Phase Template dialog box. The Phase name field is just a placeholder for information that gets added when you actually add the phase; the Phase name field gets modified when you add or modify equipment phases in the Equipment Editor or WorkSpace.

For example, with the entries for the Standard Tag Template above, the Command tag for a phase named AIR3 appears like this in the Edit Equipment Phase dialog box:



In this example, the PHASE field gets replaced with AIR3. The _VC represents the tag name (the third column in the template), and A_CV represents the tag type (the fourth column). In iFIX, _VC represents the PLI command register and A_CV represents the current value of a block displayed as text.

For an example of using the Standard Phase Template dialog box with Proficiency Process Systems, refer to the More on the Standard Phase Template section.

Standard Phase Class Properties

For each phase class, you can configure the following class properties:

- Parameters
- Reports
- Operator messages
- Number of requests
- Number of phase partners
- Type

The class properties apply to all instances of the equipment phase and are tied to the physical equipment by specifying the equipment phase tag address for each property.

Parameters

Equipment phase parameters specify values that the Batch Execution Server downloads to the phase logic in the process controller. Registers in the process controller store these values that the phase logic uses to ultimately control the equipment. Recipes can specify parameter values, or Batch Execution can request the operator to specify parameter values at run-time.

IMPORTANT: Be aware that phase parameters for Batch Direct phases are only downloaded at the start of a phase.

You define phase parameters in the equipment phase class. For each parameter you define, the Equipment Editor creates a corresponding parameter index tag in the equipment phase instance. For example, assume that you define two phase parameters (SPEED and TIME) for the AGITATE phase class. For each instance of the AGITATE phase, Batch Execution creates two parameter tags. You can then configure each parameter tag in the equipment phase instance by associating the parameter tag with an I/O address:

This parameter name and ID...	Corresponds to this parameter tag index...	And corresponds to an I/O address such as...
Name: SPEED ID: 10	PARMTR01	FIX.SPEED.F_CV
Name: TIME ID: 25	PARMTR02	FIX.TIME.F_CV

Parameter Data Types

You must specify the parameter data type as it corresponds to the phase logic in the process controller. You can specify the following data types:

- Real
- Integer
- String
- Enumeration

If the parameter has an enumeration data type, you must configure enumeration sets. Refer to the Configuring Enumerations section for more information.

Scaling Parameters

Batch Execution lets you enable scaling for phase parameters with an integer or a real data type. Scaling should only be enabled if it is appropriate. Typically, you may want to enable scaling for parameters that specify an ingredient amount. For information on configuring scalable parameters, refer to the Advanced Topics section.

Example: Equipment Phase Parameters

In the sample application, the AGITATE equipment phase class contains the following equipment phase parameters:

- SPEED specifies the agitation speed.
- TIME specifies the duration of time to agitate.

Phase Reports

You typically use phase reports to report the actual process values or batch values used by the equipment phase. Registers in the process controller store these values. After a phase completes, the phase logic in the process controller uploads report values to the Batch Execution Server.

IMPORTANT: *Be aware that for Batch Direct phases the phase reports are only uploaded upon completion of a phase.*

You define phase reports in the equipment phase class. For each report you define, the Equipment Editor creates a corresponding report index tag in the equipment phase instance. For example, assume that you define two phase reports (ACT_SPEED and ACT_TIME) for the AGITATE phase class. For each instance of the AGITATE phase, Batch Execution creates two report tags. You can then configure each report tag in the equipment phase instance by associating the report parameter tag with an I/O address:

This report name and ID...	Corresponds to this report tag index...	And corresponds to an I/O address such as...
Name: ACT_SPEED ID: 12	REPORT01	FIX.ACTSPEED.F_CV
Name: ACT_TIME ID: 14	REPORT02	FIX.ACTTIME.F_CV

Phase Report Data Types

You must specify the report data type as it corresponds to the phase logic in the process controller. You can specify the following data types:

- Real
- Integer
- String
- Enumeration

If the report has an enumeration data type, you must configure enumeration sets. Refer to the Configuring Enumerations section for more information.

Example: Phase Reports

In the sample application, the COOL equipment phase class contains the COOL_TEMP phase report. The phase logic records the actual settings and then uploads them to the Batch Execution Server where they can be analyzed.

Operator Messages

You can program the phase logic in the process controller to make a request to send a message to the operator.

Operator messages are:

- Displayed to the operator when the phase is executed manually by the operator.
- Sent to the batch event journal. Every batch produces a batch event journal file. This file is in ASCII format and is accessed from the Batch Execution Client.

You must configure the operator messages required by the phase as follows:


- Define the text of the message and its associated message ID as defined in the phase logic.
- For each operator message you enter, increment the Request tag number by one.

Example: Operator Messages

For example, assume that you want to configure operator messages for the Agitate phase. To do so:

- The phase logic programmer needs to define Send Message requests in the Agitate phase logic in the process controller. For more information on programming requests in the phase logic, refer to the Phase Programming Manual.
- In the Equipment Editor for the Agitate phase class, define the text of the messages that will be displayed to the operator and sent to the event journal.

In the following figure, the Agitate phase requests the Batch Execution Server to send the STARTING_AGITATE message when the phase begins execution. When the phase completes, the phase requests the Batch Execution Server to send the AGITATE_COMPLETE message.



Sending Operator Messages

Phase Partners

Phase partners are phases that communicate with other phases. During equipment phase class configuration, you must specify the number of partners with which the phase can communicate. Based on the number of partners you specify, the recipe author can build a *phase link group*, which lists the phases in the recipe that can communicate with each other.

Typically, a phase link group contains phases that must be synchronized. For example, you may want to synchronize transferring material out of one unit and into another. The synchronization is programmed in the phase logic by sending a message from one phase to another. When the message is received by its phase partner, the phases are synchronized and the phases can begin execution.

Requests

In addition to downloading phase parameter values, uploading phase report values, and sending operator messages, Batch Execution provides a series of request functions. These functions enable the phase logic to request the Batch Execution Server to perform specific actions, such as acquiring and releasing equipment and sending phase messages. If the phase logic is programmed with any of these additional requests, you must perform the following tasks:

- In the equipment phase class property settings, you must specify the number of requests required by the phase. A Request Data register is created for each request. Refer to the equipment phase tags table in the Tying Standard Phases to Equipment section for more information on the phase tags.
- In the equipment phase, tie each Request Data register to the I/O address.

For more information on programming requests in the phase logic, refer to the Phase Programming Manual.

Tying Standard Phases to Equipment

In Batch Execution, you tie equipment phases to the equipment by specifying the equipment-specific addresses for ten standard tags plus any parameter, report, and request tags required by the phase. By specifying these tags, you are configuring a unit's equipment phase. The Phase Logic Interface (PLI) requires these tags. The PLI is programmed in the process controller and provides a standard interface between the Batch Execution Server and the equipment phase. For more information on programming the PLI, refer to the PLI Development Manual. The following table describes each tag.


Equipment Phase Tags		
Equipment Phase Tag	Equivalent PLI Register	Description
COMMAND	Command Register (PHASE_VC)	Commands a phase to transition from one state to another.
FAILURE	Failure Register (PHASE_F)	Indicates whether a failure has occurred. When the register is set to 0, no failure has occurred.

Equipment Phase Tags		
Equipment Phase Tag	Equivalent PLI Register	Description
OWNER	Owner Register (PHASE_W)	Indicates whether Batch Execution or an external interface is commanding the phase.
PARMTR0 n	Parameter Value Register (PHASEP0 n)	Stores parameter values that are downloaded to the phase logic.
REQUEST	Request Register (PHASE_RQ)	Initiates a request from phase logic to the Batch Execution Server.
REQUEST0 n	Request Data Register (PHASEQ0 n)	Specifies additional information about the request.
REPORT0 n	Report Value Register (PHASER0 n)	Stores report values, which are uploaded to the Batch Execution Server.
PAUSE	Pause Register (PHASE_P)	Allows the equipment phase to pause at the next programmed transition.
PAUSED	Paused Register (PHASE_PD)	Indicates that the equipment phase has paused at the programmed transition.
STATUS	Status Register (PHASE_ST)	Indicates the state of the equipment phase.
SINGLE STEP	Single Step Register (PHASE_SS)	Indicates when the equipment phase is in single step mode. Single step mode causes the equipment phase to transition to the next programmed pause and waits for the operator to issue a resume command.
UNIT	Unit Register (PHASE_UN)	Indicates the current unit.
STEP INDEX	Step Index Register (PHASE_SI)	Indicates the step index of the equipment phase.

Understanding Data Servers

Before you can tie equipment phases to equipment, you must configure a process data server. Batch Execution supports OPC data servers. The **OPC** data server lets you retrieve data from your iFIX process database or any OPC-aware process hardware. OPC (OLE for Process Control) defines standard objects, methods, and properties for meeting the interoperability requirements of real-time process automation applications. For information on configuring OPC servers, refer to the System Configuration Manual.

The following figure illustrates the layers of communication when using OPC to retrieve data from iFIX.



OPC Communication

Assigning iFIX Database Tags to Equipment Phases

Batch Execution lets you assign iFIX database tags to Batch Execution equipment phase tags. The table that follows after the general guidelines lists the recommended tag types and EGU ranges to assign to Equipment Phase tags.

General Guidelines

The following are general guidelines regarding the information in the following table.

- You can replace any tag recommended as AR with an AO/AI pair of tags. In the Equipment Editor you would specify the AO tag.
- You can replace any tag recommended as DR with a DO/DI pair of tags. In the Equipment Editor, you would specify the DO tag.

- You can replace any digital tag type with an analog tag type.
- Certain tag values and EGU ranges are specified as "project-specific." This means that the tag type or EGU range you assign depends on your particular application.

Recommended iFIX Tag Types and EGU Ranges				
Equipment Phase Tag	Equivalent PLI Register	Possible Values	Possible Tag Type	Recommended EGU Range
COMMAND	Command Register (PHASE_VC)	Project-specific	Analog Input (AI)	0 – 65,535 Batch Execution uses the upper byte of the command register for sequencing information. The recommended EGU range reflects this.
FAILURE	Failure Register (PHASE_F)	Project-specific	Analog Input (AI)	0 – 65,535
OWNER	Owner Register (PHASE_W)	0 – 1	Digital Input (DI)	0 – 1
PARMTR0n	Parameter Value Register (PHASEP0n)	Project-specific	Analog Input (AI) or Analog Register (AR)	Project-specific
REQUEST	Request Register (PHASE_RQ)	0 – 8,000	Analog Input (AI)	0 – 65,535
REQUEST0n	Request Data Register (PHASEQ0n)	0 – 8,000	Analog Input (AI)	0 – 65,535
REPORT0n	Report Value Register (PHASER0n)	Project-specific	Analog Input (AI)	Project-specific
PAUSE	Pause Register (PHASE_P)	0 – 1	Digital Input (DI)	0 – 1

Recommended iFIX Tag Types and EGU Ranges				
Equipment Phase Tag	Equivalent PLI Register	Possible Values	Possible Tag Type	Recommended EGU Range
PAUSED	Paused Register (PHASE_PD)	0 – 1	Digital Input (DI)	0 – 1
STATUS	Status Register (PHASE_ST)	0 – 100	Analog Input (AI)	0 – 65,535
SINGLE STEP	Single Step Register (PHASE_SS)	0 – 1	Digital Input (DI)	0 – 1
UNIT	Unit Register (PHASE_UN)	Project-specific (This value is the equipment ID assigned to the unit.)	Analog Input (AI)	0 – 65,535
STEP INDEX	Step Index Register (PHASE_SI)	Project-specific	Analog Input (AI)	0 – 65,535

NOTE: GE recommends the use of Analog Input (AI) blocks.

Browsing and Adding Tags to iFIX Databases

Batch Execution lets you browse through and select tags from multiple iFIX databases. If the tag does not exist in the database, Batch Execution lets you add a new tag to the database whenever you enter an undefined tagname. For example, as you configure an equipment phase and assign a tagname to the Command register, you can add the target tag to the database and place it on scan without having to exit the Equipment Editor application.

For more information on the iFIX database, refer to the iFIX *Building a SCADA System* manual.

Batch Direct Equipment Phases

With Batch Direct phases, the PLI logic is built directly into the phase and maintained by the Batch Execution Server. This PLI logic provides a standard interface between the Batch Execution Server and the equipment phase. What that means, is that you can use Batch Direct phases to directly communicate with existing PLC programs located on your process controllers, without having to rewrite any additional PLI logic. With Batch Direct phases, you have a simpler interface to the process

controller.

In your Proficy Batch Execution projects you can:

- Choose to use only Batch Direct phases in your projects. For instance, for smaller Batch Execution systems that do not require full PLIs, using the simpler batch direct phases can save implementation time.
- Use Batch Direct phases along-side standard equipment phases in new or existing projects. This also can reduce your project complexity and implementation costs, by allowing you to reuse older projects without extensive control logic changes.
- Maintain the standard Batch Execution System (BES) functionality with seamless integration of the Batch Direct phases within your batch applications. For instance, when developing Batch Direct phases, a simple sigma icon denotes a batch direct phase in the WorkSpace or Recipe Editor. Also, the look and feel of the operator screens in the Client is virtually the same for both batch direct and standard phases.

Prerequisites

Before using Batch Direct phases in your project, you need to have an understanding of your control logic. Gather the following information, as appropriate, about how the phase logic is programmed in the process controller:

- The equipment phase parameters required by the phase logic, including the parameter IDs, data types, and high and low limits.
- The equipment phase reports required by the phase logic, including the report IDs and data types.
- The I/O addresses required for each equipment phase tag, as well as for the Enter, Exit, and Status tags for Batch Direct phases and their values.

For each Batch Direct phase, there are six state blocks and six equipment phase tags available. Only the Running state block is required, however. You may decide to include more than just the Running state block. Knowing beforehand what state blocks and equipment phase tags that you want to configure in each Batch Direct phase will assist you in batch project development.

Although you do not need to know how to program the phase logic, you still need to be familiar with the I/O memory addresses in the controller (or how to access these addresses through your controller software) to configure tags in your Batch Direct phases and configure the expected values that are required for each state block.

With proper preparation, tag names for each state in your Batch Direct phase can be configured to match the ones in your process control software. By using the same naming convention, you can simplify your project further.

What You Need to Know About State Blocks...

The six state blocks for Batch Direct phases include:

- Running
- Holding

- Held
- Restarting
- Stopping
- Aborting

For each of enabled state blocks, you can enter the Enter, Exit, and Status tags (memory addresses in the process controller) and the corresponding values, if there are deviations from the default. The default value for each tag is 1. For the active level, the acceptable values are 0 to 65,534. For the inactive level, the acceptable values are any value other than the value chosen for the active level. You need to determine what values you need, and what their memory addresses are in the process controller.

IMPORTANT: For the Enter, Exit and Status tags, GE strongly recommends using *Unsigned Integer* as the data type for the destination addresses in the process controller. Use of any other data type may yield unexpected and inconsistent Batch Direct phase results.

For example, if you are using an iFIX database, the I/O addresses for the tags use the format of Node.Tag.Field. For example, for the Running state block for the Enter tag in the iFIX database, the I/O address might look something like this: NODE1.PHASE1_RE.F_CV. Addressing is specific to the controller and you must have familiarity with your controller.

These two examples highlight some of the differences that you can encounter. However, the I/O address format is specific to your controller. Therefore, it is imperative that you know what the addresses are, and their format.

What You Need to Know About Standard Equipment Tags...

The six standard equipment tags for Batch Direct phases may include:

- Failure
- Pause
- Paused
- Single Step
- Step Index
- Unit


For each tag that you choose to enable in your Batch Direct phase, you must enter a memory I/O address from the process controller. You must know this value, or how to access it from the process controller software.

Standard PLI Structure vs. Batch Direct PLI Structure

With Batch Direct phases, the PLI functionality is split between the Batch Execution System (BES) and the control logic. The figures that follow explain where these splits occur – in both the standard and Batch Direct phases.


Standard PLI Structure

The following illustration depicts the standard PLI structure, without the Batch Direct functionality. In this figure you find both the PLI and equipment phase logic located on the controller (the middle two rectangles).



Batch Direct PLI Structure

The following illustration depicts the Batch Direct PLI structure. In this figure, you find the PLI located on the same computer as the Batch Execution Server, while only the equipment phase logic runs on the controller (the third rectangle).



Differences Between Direct and Standard Phases


Unlike standard phases, Batch Direct phases do not support:

- Message Requests
- Soft Phase Server

Since message requests are not supported, this also means that:

- Batch direct phases do not support message partners.
- Batch direct phases do not support electronic work instructions (EWIs).
- Phase parameters are only downloaded at the start of a phase.
- Phase reports are only uploaded upon completion of a phase.

The way in which you configure Batch Direct phases in the Batch Equipment Editor or WorkSpace is very similar to standard equipment phase configuration. The only difference in the phase class dialog box is that instead of an Operator Messages tab, an Enable Tags tab appears, as shown in the following figure.




Edit Direct Equipment Phase Class Dialog Box

For each state block enabled in the above dialog box, you configure the Enter, Exit, and Status tags and their values when you create the Batch Direct phase instance. The following figure shows an example of how you configure these tags for a state block. This example shows the tags for the Aborting state block. The Enter tag is configured with a specific address and value, the Exit tag is configured to be the inverse of the Enter tag, and the Status tag is configured to be the same as the Enter tag.

Be aware that as a batch developer, the only visible change in your area model view will be the appearance of a sigma symbol in the upper left corner of your Batch Direct phase icon. In the Client, the changes are even more subtle. A user can only see a difference in the SFC screen, for instance, if you named your phase as a Batch Direct phase (using a specific naming convention).

One Tag Example

The following dialog box shows an example of the Running state with the Enter, Exit, and Status tags configured as the same tag.




Edit Direct Phase Tags Dialog Box, 1 Tag Example

In this example, when the Enter phase starts, all parameters are downloaded, and then a 1 is written to the Enter tag. The phase logic executes and the phase state should go to Running. When the phase has run to completion, the phase logic must write a value not equal to 1 to the Status tag. The Server will detect this as completed phase and upload all configured report tag values. Finally, the Server will write a 0 to the Exit tag.

Three Tags Example

The following dialog box shows an example of the Running state with the Enter, Exit, and Status Tags as unique tags.



Edit Direct Phase Tags Dialog Box, 3 Tags Example

In this example, when the Enter phase starts, all parameters are downloaded, and then a 1 is written to the Enter tag. The phase logic executes and writes a 12 to the Status tag. The phase state should then go to Running. When the phase logic has run to completion, the phase logic must then write a value other than 12 to the Status tag. The Server will detect this as completed phase and upload all configured report tag values. Finally, the Server will write a 4 to the Exit tag.

Where Batch Direct Phase Information Appears in the Product

The integration of the Batch Direct functionality into the Proficy Batch Execution product is practically seamless. For batch developers and operators, who are already familiar with working with the Proficy Batch Execution product, it should take you little time to get familiar with the batch direct functionality.

As a Batch Execution project developer, you can identify Batch Direct phases in the Equipment Editor, WorkSpace, or Recipe Editor by the sigma symbol that appears in the top left corner of the phase name.


As an operator, the only difference you can expect to see will be in the naming convention of the phases used in the SFC, if you the developer chooses to use one.

The following sections describe, in detail, where Batch Direct user interface differences can be expected:



- Equipment Editor/WorkSpace
- Recipe Editor
- Batch Execution Client

Equipment Editor/WorkSpace

The following figure shows where the user interface differences for Batch Direct occur in the Equipment Editor and Workspace.




<p>1</p>		<p>A sigma icon in the upper left corner of the phase name in the tree view indicates that the equipment phase is a direct phase.</p>
<p>2</p>		<p>A sigma icon in the upper left corner of the phase instance indicates that the phase instance is a direct phase.</p> <p>Double-click this phase instance icon to open the Edit Equipment Phase dialog box. Double-click a state block in the list box to open the Edit Direct Phase Tags dialog box.</p>

3		<p>The toolbar button with the red plus sign opens the Create Direct Equipment Phase dialog box. This button appears directly next to the Add Standard Equipment Phase button in the default toolbar.</p> <p>NOTE: You must have an OPC Server configured as your default server in order to add a direct phase to the Workspace area. For more information, refer to <i>The Data Server for Batch Direct Phases</i> section.</p>
4	 XFER_OUT_LINK	<p>A sigma icon in the upper left corner of the phase class indicates that the phase class is a direct phase class.</p> <p>Double-click this phase class icon to open the Edit Direct Equipment Phase dialog box. Click the Enable Tags tab to identify the tags you want to enable for all phases in this class.</p>

Recipe Editor

The only visual difference in the Recipe Editor is that a sigma icon appears in the upper left corner of the Batch Direct phase name in the Recipe Editor's tree view, as shown in the following figure.



Batch Direct Phase in the Recipe Editor Tree

Additionally, since Batch Direct phases do not support electronic work instructions or message requests, the EWI feature is unavailable from the right-click menu of the recipe step. Instead, when you open the right-click menu for a step that uses a batch direct phase, it appears shaded.

Batch Execution Client


As an operator, the only difference you can expect to see in the Batch Execution Client will be in the naming convention of the phases that appear in the SFC View screen.





TIP: For phase logic programmers not familiar with the batch nomenclature, be aware that the Semi-Automatic mode button on the Add Batch toolbar is the Proficy Batch Execution name for Single Step mode. So, if you want to use Single Step mode, use the Semi-Automatic mode button.

If your Batch Execution project developer chooses not to use a naming convention for Batch Direct phases when creating your area model, there are no visible differences in the Client application.

For example, say you (as a developer) enter BD_ at the beginning of each direct phase name that you create in the area model in the Equipment Editor or WorkSpace. When you add a batch in the Client (as an operator) that includes those direct phases, the BD_ appears in the phase names displayed in the

SFC View screen, as shown in numbered areas of the following figure.



1		<p>In this example, the BD_ that appears in front of the phase name in the Table View indicates that this step uses a batch direct phase.</p>
2		<p>In this example, the BD_ that appears in front of the phase name in the SFC View indicates that this step uses a Batch Direct phase.</p>
3		<p>In this example, the BD_ that appears next to the step name in the transition indicates that the step listed in the transition uses a Batch Direct phase.</p>
4		<p>In this example, the BD_ that appears in front of the step name in the Status bar, indicates that this step uses a batch direct phase.</p>

NOTE: If the Batch Execution project developer does not use a naming convention, no differences appear in the SFC View screen.


Understanding How Batch Direct Phases Work

In the Equipment Editor or WorkSpace, you configure Batch Direct phases at two levels:

Equipment Phase Class defines generic information that applies to all instances of the Batch Direct phase. This generic information includes the parameters, reports, and the enabled Batch Direct state blocks required by the equipment phase.

Equipment Phase defines the equipment-specific instance of a Batch Direct equipment phase and ties the equipment phase to the physical equipment (a unit) by specifying the equipment phase tags.

The following figure illustrates how the BD_XFER_OUT equipment phase class is configured. In this example, three equipment-specific instances of the BD_XFER_OUT equipment phase class are configured and tied to the physical equipment in the plant.



Batch direct phase classes and instances have almost the same configuration steps as those for standard phases. The main difference is that for Batch Direct phases, you can configure Enter, Exit, and Status tags for each state block you choose to enable. Another difference is that operator messages and message partnering are not supported in Batch Direct phases.

For more information on types of tags and state blocks that you can configure for Batch Direct phases, refer to the following sections:

- States Blocks and Equipment Phase Tags
- Tags for Each State Block
- State Blocks and Tag Combinations

For more information on what is supported in Batch Direct phases, refer to the Differences Between Direct and Standard Phases section.

Default Settings for a Batch Direct Phase

By default, Batch Direct phases have the Running state block enabled. The Running state block is the minimum requirement for all Batch Direct phases. For the Running state block, you assign Enter, Exit, and Status tags. At a minimum, you need to configure the Enter tag value.

Running State Block Example

Say you enter an I/O address for the Enter tag of the Running state block. For the Exit tag, select the Inverse of Enter tag option. For the Status tag, select the Same as Enter Tag option.

In this scenario, you would expect the following to occur:

- Proficy Batch Execution writes to the RUNNING_ENTER tag to start the phase.
- When the RUNNING_STATUS tag is configured with the same address as the RUNNING_ENTER tag, Proficy Batch Execution interprets the RUNNING_ENTER status as the RUNNING_STATUS. In other words, the phase is assumed to be running once signaled.
- The phase remains in the running state until the process controller sets the address to a non-active level. Proficy Batch Execution then interprets the inactive, RUNNING_STATUS level and sets the phase to complete.

State Blocks and Equipment Phase Tags

The following table provides descriptions of the state blocks that you can enable in Batch Direct phases.

State Blocks Available for a Batch Direct Phase	
State Block	Description
Running	Starts and monitors the Batch Direct equipment phases. This state block is required.
Stopping	Commands a Batch Direct equipment phase to Stop, and monitors its status. This state block is optional.
Aborting	Commands a Batch Direct equipment phase to Abort, and monitors its status. This state block is optional.
Holding	Commands a Batch Direct equipment phase to Hold, and monitors its status. This state block is optional.
Held	Commands the Held state, and monitors the status. This state block is optional.

State Blocks Available for a Batch Direct Phase	
State Block	Description
Restarting	Starts and monitors the transition of the Restarting state into the Held state. This state block is optional.

The following table provides descriptions of the optional equipment phase tags that you can define for the Batch Direct phase.

Optional Equipment Phase Tags Available for a Batch Direct Phase	
Equipment Phase Tag	Description
FAILURE	Indicates whether a failure has occurred in the batch direct phase. When the register is set to 0, no failure has occurred.
PAUSE	Allows the Batch Direct phase to pause at the next programmed transition.
PAUSED	Indicates that the Batch Direct phase has paused at the programmed transition.
SINGLE STEP	Indicates when the Batch Direct phase is in single step mode. Single step mode causes the equipment phase to transition to the next programmed pause and waits for the operator to issue a resume command.
STEP INDEX	Indicates the step index of the Batch Direct equipment phase.
UNIT	Indicates the current unit number for the Batch Direct equipment phase.

Tags for Each State Block

Each of the state blocks (Running, Stopping, Aborting, Holding, Held, and Restarting) has three tags. The following table describes these tags.

Tags Available for Each Block	
Tag	Description
Enter	<p>The Enter tag must be mapped to a unique I/O address. Proficy Batch Execution sets the Enter tag at the start of the command.</p> <p>Proficy Batch Execution sets the state block to indicate that a phase should Run, Stop, Abort, Hold, be Held, or Restart. If you configure the Enter, Exit, and Status tags to the same address, Proficy Batch Execution sets the Enter tag at the start of the command, and the controller logic resets it when the command completes.</p>
Exit	<p>Proficy Batch Execution uses the Exit tag value to command a phase to stop and exit from its current state. When the state terminates, the controller logic resets the Enter tag.</p>
Status	<p>The controller logic sets the Status tag, informing Proficy Batch Execution when the state is active. When the command completes, the controller resets the Status tag. Proficy Batch Execution then resets the Enter tag.</p>

State Blocks and Tag Combinations

For each state block you configure Enter, Exit, and Status tags. You enter an I/O address and value for each tag. The Exit and Status tags can be configured to the same value as the Enter tag.

The following table outlines the actions between Proficy Batch Execution and the PLC when different combinations of Enter, Exit, and Status tags are configured for each state block.

Batch Direct Tags	Aborting State Block	Running, Stopping, Holding, and Restarting State Blocks	Held State Block
Enter	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the current state (either the Held, Running, Stopping, Holding, or Restarting state) to the Aborting state.</p> <p>The phase logic then resets the Enter tag to indicate that the controller completed the execution of the logic associated with this state.</p>	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the current state to the Running, Stopping, Holding, or Restarting state.</p> <p>If Proficiency Batch Execution receives a valid stop, abort, or hold command while one of these states is active, then Proficiency Batch Execution resets the Enter tag.</p> <p>IMPORTANT: <i>If the running logic completes normally, then the phase logic resets the Enter tag.</i></p>	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the Holding state to the Held state.</p> <p>Proficiency Batch Execution then resets the Enter tag value to indicate that a valid restart, abort, or stop command has been received.</p>
Enter and Exit	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the current state (either the Held, Running, Stopping, Holding, or Restarting state) to the Aborting state.</p> <p>The phase logic then resets the Enter tag to indicate that the controller completed the execution of the logic associated with this state.</p> <p>The Exit Tag is never used for the Aborting state, and should not be configured for this state.</p>	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the current state to the Running, Stopping, Holding, or Restarting state.</p> <p>If Proficiency Batch Execution receives a valid stop, abort, or hold command while one of these states is active, then Proficiency Batch Execution sets the Exit tag and resets the Enter tag.</p> <p>IMPORTANT: <i>If the running logic completes normally, then the phase logic resets the Enter tag.</i></p>	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the Holding state to the Held state.</p> <p>Proficiency Batch Execution then resets the Enter tag and sets the Exit tag value to indicate that a valid restart, abort, or stop command has been received.</p>

Batch Direct Tags	Aborting State Block	Running, Stopping, Holding, and Restarting State Blocks	Held State Block
Enter and Status	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the current state (either the Held, Running, Stopping, Holding, or Restarting state) to the Aborting state.</p> <p>When this state becomes active, the phase logic sets the Status tag and executes the associated logic.</p> <p>When the logic completes, the phase logic in the controller resets the Status tag.</p> <p>Proficiency Batch Execution then resets the Enter tag based on the value of the Status tag.</p>	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the current state to the Running, Stopping, Holding, or Restarting state.</p> <p>Once one of these states is active, the phase logic sets the Status tag to indicate such.</p> <p>If Proficiency Batch Execution receives a valid stop, abort, or hold command while one of these states is active, then Proficiency Batch Execution resets the Enter tag. This causes the phase logic to reset the Status tag and stop executing the logic.</p> <p><i>IMPORTANT:</i> <i>If the running logic completes normally, then the phase logic resets the Status tag to indicate such. Proficiency Batch Execution then resets the Enter tag.</i></p>	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the Holding state to the Held state. Once in the Held state, the phase logic sets the Status tag to indicate such.</p> <p>Proficiency Batch Execution then resets the Enter tag and sets the Exit tag value to indicate that a valid restart, abort, or stop command has been received.</p> <p>In response to this action, Proficiency Batch Execution resets the Status tag.</p>

Batch Direct Tags	Aborting State Block	Running, Stopping, Holding, and Restarting State Blocks	Held State Block
Enter, Exit, and Status	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the current state (either the Held, Running, Stopping, Holding, or Restarting state) to the Aborting state.</p> <p>When this state becomes active, the phase logic sets the Status tag and executes the associated logic.</p> <p>When the phase logic completes, the phase logic normally resets the Status tag. Proficiency Batch Execution then resets the Enter tag based on the Status tag value.</p> <p>The Exit Tag is never used for the Aborting state, and should not be configured for this state.</p>	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the current state to the Running, Stopping, Holding, or Restarting state.</p> <p>Once one of these states is active, the phase logic sets the Status tag to indicate such.</p> <p>If Proficiency Batch Execution receives a valid stop, abort, or hold command while one of these states is active, then Proficiency Batch Execution sets the Exit tag. This causes the phase logic to reset the Status tag and stop executing.</p> <p>IMPORTANT: <i>If the state's logic completes normally, the phase logic resets the Status tag to indicate such. Proficiency Batch Execution then resets the Enter tag.</i></p>	<p>Proficiency Batch Execution sets the Enter tag to initiate the transition from the Holding state to the Held state. Once in the Held state, the phase logic sets the Status tag to indicate such.</p> <p>Proficiency Batch Execution then resets the Enter tag and sets the Exit tag value to indicate that a valid restart, abort, or stop command has been received.</p> <p>In response to this action, the Proficiency Batch Execution resets the Status tag.</p>

IMPORTANT: *If the Holding and Restarting states are not configured for a phase, then a Hold command does not change the Running state.*

The Data Server for Batch Direct Phases

The supported data server for Batch Direct phases is the OPC data server. The OPC data server allows you to retrieve data from your iFIX process database or any OPC-aware process hardware. OPC (OLE for Process Control) defines standard objects, methods, and properties for meeting the interoperability requirements of real-time process automation applications.


Before adding a direct phase class to your project, you must configure the OPC data server and designate it as your project's default data server. Once configured, you can add Batch Direct phase classes and tie equipment phases to the actual equipment.

To configure the OPC data server for Batch Direct phases, use the Edit Servers dialog box. Access this dialog box from the Edit Servers button on the toolbar, or from the Edit menu, choose Servers.

Be aware that the OPC data server should reside on the same computer as the Batch Server that interfaces with the phase logic for the batch direct functionality.

Overview: Configuring Direct Phases

The following illustration provides an overview on how to configure a Batch Direct phase from the Proficiency Batch Execution WorkSpace or Equipment Editor.



TIP: Direct Phase Naming Convention

When adding direct phase classes and instances to your Proficy Batch Execution projects, consider using a naming convention. For instance, you may want to add a prefix such as BD_ to all Batch Direct phase classes and instances. Here is an example of a Batch Direct phase class for the transfer out step:

```
BD_XFER_OUT
```

When you add a batch in the Client that includes this Batch Direct phase, the BD_ name appears in the phase names displayed in the SFC View screen. For more information, refer to the Batch Execution Client section.

Direct Phase Template


The Direct Phase Template allows you to change the default tag settings. The equipment tags for a Batch Direct phase include: Failure, Pause, Paused, Single Step, Step Index, and Unit. The state blocks for a Batch Direct state include: Running, Holding, Held, Restarting, Stopping, and Aborting.

By changing the default tags to your custom settings, creating and maintaining batch projects with lots of equipment phases can be easier and faster. If you enter your default settings into the template when you first create your project, you will not need to edit each tag individually when you add a new phase to your project, especially if you are using iFIX as your SCADA software. In the iFIX product, the tags are formatted as Node.Tag.Field, which is also the tag format the template is geared for.

TIP: *If you are not using iFIX tags, try to use a naming convention that will be easy to modify later. Most likely, without iFIX, you will have to enter manual changes in your tag names.*

Any modifications you make to the Direct Phase Template apply to direct phases you add to your project after making the template updates. The values that you enter into the template do not change the equipment phase tags in pre-existing equipment phases.

To access the Direct Phase Template dialog box from the Edit menu, click Direct Tag Template. The following figure illustrates an example of this dialog box.




Direct Phase Template Dialog Box


When you edit the Node field, all tags for each state block are automatically populated with the name you enter. This is because all tags for a phase must have the same node name. If you select the Use Server Alias button, all of the Server name fields are filled with the "#ALIAS#" text. The #ALIAS# syntax allows you to use the Alias configured in the Create OPC Server dialog box.

Be aware that you cannot edit the Phase field from this dialog box or from the Direct Phase Tag Template dialog box, which you access by clicking the browse button next to the state block. The Phase name field is just a placeholder for information that gets added when you actually add the phase; the Phase name field gets modified when you add or modify equipment phases. If you do not use iFIX, you can change this value later, when you add the direct phase instance to your project in the Equipment Editor or WorkSpace.

For example, if you leave the default settings for the Running tag in the Standard Tag Template, as shown in the following figure:



The tag information for a phase, named PHASE11, appears like this in the Edit Equipment Phase dialog box:



In this example, the PHASE field gets replaced with PHASE11 for the Enter, Exit, and Status tags. The _RE indicates the Running Enter block, the _RX indicates the Running Exit block, and the _RS indicates the Running Status block. In iFIX, F_CV represents the current value of a block displayed as a number.

Direct Phase Class Properties

For each phase class, you can configure the following class properties:

- Parameters
- Phase Reports
- Batch Direct Blocks and Tags

The class properties that you define apply to all instances of the direct phase class. Each instance is tied to the physical equipment by specifying the address of the Batch Direct tags.

Standard phases can also include parameters and phase reports. Refer to the Standard Phase Class Properties section for more information. The following section describes the class properties specific to only batch direct phases.


Batch Direct Blocks and Tags

The state blocks that you choose to enable for a Batch Direct phase class are based on your individual project needs. For each of the state blocks you enable at the class level, you configure tags at the phase instance level. The state blocks that you can enable include the:

- Running State
- Holding, Held, and Restarting State
- Stopping State
- Aborting State
- Failure
- Pause and Paused
- Single Step
- Step Index
- Unit

Only the Running State is required. Holding, Held, and Restarting States cannot be individually selected; you must enable all three at once.

To enable state blocks at the phase class level, use the Enable Tags tab of the Create or Edit Direct Equipment Phase Class dialog box. The following figure shows an example of this dialog box, with the minimum state block enabled – the Running state.



Edit Direct Equipment Phase Class Dialog Box with the Minimum Configuration

Tying Batch Direct Phases to Equipment

In Proficiency Batch Execution, you tie Batch Direct phases to the equipment by specifying the equipment-specific addresses for the Enter, Exit, and Status tags associated with the Batch Direct phase along with any standard equipment phase tags. Additionally, you configure any parameter, report, and request tags required by the phase. By specifying these tags, at the phase instance level, you are configuring a unit's equipment phase.


To configure tags at the phase instance level, use the Edit Equipment Phase dialog box. Double-click a state block or phase tag from the list box to open a dialog box that allows you to configure the required tag or tags.

The following figure shows an example of the dialog box that you use to configure the tags for a Batch Direct phase. In this example, only the Running state appears enabled in the list box (the default). The default values for the Enter, Exit, and Status tags appear under the Type field, in the right side of the dialog box.

Edit Equipment Phase

Name:

Phase:

Σ 

OK
Cancel
Help

Equipment Phase Tags

RUNNING

Server
Defaults

Name:

Type:

Enter:NODE.BD_MIX11_RE.F_CV
Exit:NODE.BD_MIX11_RX.F_CV
Status:NODE.BD_MIX11_RS.F_CV

Arbitration

Equipment ID:


Max Owners:

Equipment Needed

Add
Remove

Edit Equipment Phase Dialog Box

Double-click the Running state block to open the Edit Direct Phase Tags dialog box, where you can modify the Enter, Exit, and Status tags. The following figure shows an example of the Edit Direct Phase Tags dialog box. In this example, only the Enter and Exit tag are configured. The Status tag is left with the default value.



Edit Direct Phase Tags Dialog Box

FAQ on Batch Direct Phases

The questions and answers outlined below describe some commonly asked questions about the Batch Direct functionality.

Question 1: How do I enable Batch Direct state blocks for a phase instance?

Open the Edit Direct Equipment Phase Class dialog box. Click the Enable Tags tab to make your selections.

For an illustration of the Edit Direct Equipment Phase Class dialog box with the Enable Tags tab selected, refer to the Differences Between Direct and Standard Phases section. For more information on the steps to configure Batch Direct phases refer to the Overview: Configuring Direct Phases section.

Question 2: How do configure the Enter, Exit, and Status Tags for a Batch Direct phase?

Double-click the Batch Direct phase instance in the work area. Double-click any of the state blocks that appear in the list box to display the Edit Direct Phase Tags dialog box. From this dialog box, you can enter your modifications to the Enter, Exit, and Status tags.

For an illustration of the Edit Direct Phase Tags dialog box, refer to the Differences Between Direct and Standard Phases section. For more information on the steps to configure Batch Direct phases refer to the Overview: Configuring Direct Phases section.

Question 3: What happens when there is no aborting logic defined?

In this scenario, abort commands issued by the operator in the Client cause Proficiency Batch Execution to signal the controller to exit the Running block.

Question 4: What happens when there is no stopping logic defined?

Stop commands from the operator cause Proficiency Batch Execution to signal the controller to exit the Running block.

Question 5: What happens when there is no holding logic defined?

In this scenario, Hold commands from the operator are ignored by the PLI in Proficiency Batch Execution. The phase continues to run until completion. The status of a batch remains as Running until the Batch Direct phase completes.

Question 6: I have lots of iFIX tags to enter for my phases, is there an easy way to do this?

Yes. Use the Direct Phase Template. For more information, refer to the Direct Phase Template section.

Advanced Topics

The sections that follow discuss several advanced features in the Equipment Editor including:

- Configuring control modules as resources.
- Creating shared resources.
- Configuring and arbitrating common resources.
- Configuring unit tags, including the UNIT_READY and the UNIT_PRIORITY tags.
- Configuring scalable parameters.

Configuring Control Modules

A *control module* consists of sensors and other control modules that together perform a specific task. Control modules are the smaller pieces of equipment that make up an equipment module. If your process contains control modules that are required by other resources, you can:

- Define the control modules as a resource in Batch Execution.
- Assign the control module as needed equipment to other resources.

Once you define the control modules as a resource, Batch Execution can acquire and allocate the equipment when needed. Additionally, Batch Execution considers any Manifolds and Connector lines contained within a process cell as control modules that you can assign to other resources.

Aside from Manifolds and Connector lines, control module resources are not represented graphically in the Equipment Editor. Instead, you define control modules using the Edit Control Module command. This makes the resource available to assign to other resources.

Configuring Shared Equipment

Sharing equipment lets you define the shared equipment once and then share it wherever necessary. All changes made to shared equipment are automatically updated in all shared instances. Batch Execution lets you share:

- A unit between process cells.
- An equipment module between units.

►To configure shared equipment:

1. Configure the unit or equipment phase.
2. Add the shared equipment to the appropriate process cells or units.
3. Configure the arbitration settings for the shared equipment.

Configuring Arbitration for Shared and Common Resources

Common resources are equipment that more than one resource can use. In Batch Execution a common resource can be:

- A unit that is shared between process cells.
- An equipment phase that is shared between units.
- A control module that is common to multiple resources.

In order to determine how Batch Execution handles multiple requests for the same resource, you must configure equipment arbitration. Equipment arbitration coordinates how Batch Execution allocates resources when there are more requests for the resource than can be accommodated at one time.

Configuring arbitration consists of defining the following information for each piece of equipment in your plant:

- Equipment ID
- Maximum Owners
- Equipment Needed

The following sections describe each component.

Understanding Equipment IDs

All equipment configured in the Equipment Editor is assigned a unique equipment ID. Batch Execution uses this ID to:

- Arbitrate equipment.
- Service requests from the phase logic to acquire and release equipment.

Understanding Maximum Owners

The maximum number of owners setting determines whether a common resource is an exclusive-use or shared-use resource. If the resource is exclusive-use, set the maximum number of owners to one (the default). This indicates that only one requester can use this piece of equipment at any one time. If the resource is shared-use, set the maximum number of owners to the number of requesters that can simultaneously use this resource. The shared-use equipment must be physically capable of being used by multiple requesters at one time. For more information on common resources, refer to the Implementation Strategies section.

Understanding Equipment Needed

The equipment needed setting specifies any additional resources that this equipment requires in order to execute. You can assign needed equipment to a process cell, a unit, an equipment phase, or a control module. You must configure the needed equipment as a process cell, unit, equipment phase, or control module. The following table describes the arbitration results of assigning needed equipment.

Assigning Needed Equipment		
When you assign a needed resource to...	The resource is acquired when the...	The resource is released when the...
An equipment phase or a control module	Recipe phase begins.	Recipe phase is reset.
A unit	Unit procedure begins.	Unit procedure is reset.

Phase Request Logic

If you need a resource for just a small portion of a phase, you may want to acquire and release the equipment in the phase logic, rather than configure the equipment as a needed resource. The benefit of programming equipment requests in the phase logic is that you can release the resource prior to the completion of the phase, making it available to other requesters. Otherwise, the resource is owned by the phase for the entire execution of the phase. For more information on programming requests, refer to the Phase Programming Manual.


Examples: Equipment Arbitration

The following figure shows an example of two mixers sharing an equipment phase. In this example, the shared equipment phase is a valve. The valve executes an equipment phase that transfers material into either MIX1 or MIX2.

►To configure the equipment in this example as a common resource:


1. Share the equipment phase on both MIX1 and MIX2.
2. Assign the equipment phase as a needed resource to each unit.
3. If the valve can only be used by one unit at one time, set the maximum owners to one.

With this configuration, the valve is acquired by the first unit procedure that requests the valve. When the unit procedure completes, the valve is released and another unit procedure can acquire the valve.



Arbitrating Equipment Phases between Units

This figure shows an example of two equipment phases that require a control module to execute. In this example, the XFER_IN1 and XFER_IN2 equipment phases both use the same pump to transfer material. The pump is defined as a control module and is assigned as a needed resource to each equipment phase. Furthermore, if the pump can only be used by one equipment phase at one time, you need to set the maximum owners to one.



Arbitrating Control Modules between Equipment Phases


Using Unit Tags

Unit tags represent data that is associated with a specific unit, and all phases that execute on the unit can access these tags. Unit tags are used in recipe transitions, which define when a recipe moves from one step to another. For example, you may want to verify that the level of a mixer reaches a specific value before allowing the recipe to continue to the next step.

Batch Execution also lets you create unit tag classes, which are defined for a unit class. Unit tag classes provide an indirect reference to a group of specific unit tags. When building a class-based recipe, the recipe author references the tag class rather than the tag so the transition can apply to any instance of the unit class.

Example: Unit Tag Classes

In the example illustrated in the following figure, the MIXER class of units in the sample toothpaste application contains two unit tag classes: LEVEL and TEMP. These are variable names for the specific tags defined on each instance of the unit. The LEVEL tag class resolves to LI101, LI102, or LI103, and the TEMP tag class resolves to TI101, TI102, or TI103, depending on the current mixer.



Configuring the UNIT_READY and UNIT_PRIORITY Tags

When you create a unit instance, Batch Execution supplies two pre-defined unit tags that you can use to define the unit's equipment status. These tags can point to a register in your process controller or to a tag in your HMI. If your process uses these tags, during Active Binding, Batch Execution will select units based on these tag values. Each tag is described below.

Using the UNIT_READY Tag

The UNIT_READY tag indicates whether the unit is ready for use. UNIT_READY tag values can range from 0 (zero) to 32,767. A value of zero indicates the unit is ready and can be used by a batch. A non-zero value indicates the unit is not currently available. Batch Execution will not allow a unit with a non-zero Unit Ready tag value to be used by a batch. For example, the logic in your process controller could:

1. Detect if the operator switches a unit off.
2. If the unit is off, the logic in your process controller could set the UNIT_READY tag to a non-zero value, so that Batch Execution cannot allocate the unit to a batch.

Using the UNIT_PRIORITY Tag

The UNIT_PRIORITY tag indicates the priority of the unit, as compared to other units in the same unit class. If multiple units are available for a batch, Batch Execution selects the unit with the highest priority value. Unit Priority values can range from 0 (zero) to 32,767. You can associate any meaning with each priority value. Batch Execution simply treats the number as a priority and selects units with the highest UNIT_PRIORITY tag value.

For example, assume that your plant has two mixers, MIX1 and MIX2. In order to even the load between these two mixers, your logic in the process controller could:

1. Detect if the mixer was used for the previous batch. For this example, let's assume that the previous batch used MIX1.
2. Decrease the value of MIX1's unit priority tag, MIX1_PRIORITY, and increase the value of MIX2's tag, MIX2_PRIORITY.

During the next batch, Batch Execution checks the priority values of each mixer and select the unit with the highest priority. In this case, Batch Execution selects MIX2, because it has the highest priority tag value.

Assigning iFIX Tags to Equipment Status Tags

Batch Execution lets you assign iFIX database tags to both the UNIT_READY and UNIT_PRIORITY tags. The following table lists the iFIX tag type to assign to each tag.

iFIX Tag Types for Equipment Status Unit Tags	
For these tags...	Use this iFIX Database Tag Type...
UNIT_READY tags	Analog Input (AI) or Analog Register (AR)
UNIT_PRIORITY tags	Analog Input (AI) or Analog Register (AR)

NOTE: GE recommends the use of Analog Input (AI) blocks.

Configuring Static Values for Unit Ready and Unit Priority

If you choose not to configure points for the UNIT_READY and UNIT_PRIORITY tags, you can define static values for these items. Using static values as opposed to setting the tag values provides less flexibility in your process. However, with simpler processes you may find that using static values is the best method. With more complex processes you may find it necessary to configure the UNIT_READY and UNIT_PRIORITY tags.

Each static setting is described below.

Unit Ready – lets you select whether the unit is "always ready" (online) or "always not ready" (offline). The default setting is online. If you select offline, Batch Execution cannot allocate this unit to a batch. Typically, you will select online, making the unit available to batches. The default Unit Ready setting is online.

Unit Priority – lets you specify the unit's priority value (the higher the value, the higher the priority). Batch Execution will select the unit with the highest priority. The default priority value is 0 (zero).

Example: Using Unit Ready and Unit Priority

For example, assume the following conditions exist in the sample toothpaste application:

Mixers	UNIT_READY	UNIT_PRIORITY
MIX1	0 (online)	12
MIX2	0 (online)	25
MIX3	3 (offline)	2


Based on these conditions, Batch Execution performs the following process of elimination to decide which unit to allocate to the unit procedure:

1. Batch Execution checks the Unit Ready status of the mixers and eliminates MIX3 from the list of valid units because it is offline. The choice is now limited to MIX1 or MIX2.
2. Batch Execution checks the Unit priority status of MIX1 and MIX2 and selects MIX2 as the first choice because it has a higher priority value than MIX1.

Configuring Scalable Parameters

When you create a batch in the Batch Execution Client, you can scale the batch by a specified percentage. This percentage is then applied to all parameters that have scaling enabled. If you plan to scale batches, you need to enable scaling for those parameters that need to be scaled. Typically, parameters that specify ingredient amounts should have scaling enabled. For example, if the operator sets the batch scaling percentage to 50%, all ingredient amounts are cut in half.

You need to determine the scaling percentage value based on the desired batch size. For example, if the default batch size is 3000 and the operator needs to produce a batch of 2500, the operator would need to scale the batch by 83.3%. This requires you to calculate the percentage, as illustrated in the following table.



Understanding Parameter Scaling

Equipment Editor Dialog Boxes

The Equipment Editor application includes the following dialog boxes for working with equipment (listed in alphabetical order):

- Add Control Module Dialog Box
- Add Control Modules Class Dialog Box
- Audit Information Dialog Box
- Browse OPC Items Dialog Box
- Connection Properties Dialog Box
- Create Direct Equipment Phase Class Dialog Box
- Create Enumeration Dialog Box
- Create Enumeration Set Dialog Box
- Create Enumeration Sets and Enumerations Dialog Box
- Create Equipment Phase Class Dialog Box
- Create OPC Server Dialog Box
- Create Process Cell Class Dialog Box
- Create Unit Class Dialog Box
- Create Unit Tag Dialog Box
- Direct Phase Tag Template Dialog Box

- Direct Tag Template Dialog Box
- Edit Area Dialog Box
- Edit Control Modules Dialog Box
- Edit Direct Equipment Phase Class Dialog Box
- Edit Direct Phase Tags Dialog Box
- Edit Enumeration In Dialog Box
- Edit Enumeration Set Name Dialog Box
- Edit Equipment Phase Class Dialog Box
- Edit Equipment Phase Dialog Box
- Edit Equipment Phase Tag Dialog Box
- Edit Operator Message Dialog Box
- Edit Phase Parameter Dialog Box
- Edit Phase Report Dialog Box
- Edit Process Cell Class Dialog Box
- Edit Process Cell Dialog Box
- Edit Servers Dialog Box
- Edit Tags Dialog Box
- Edit Unit Class Dialog Box
- Edit Unit Tag Dialog Box
- Enumeration Set Modification Dialog Box
- File Export As Dialog Box
- File Import Dialog Box
- Import Equipment Model XML File Dialog Box
- Manifold Properties Dialog Box
- Print Setup Dialog Box
- Select Directories Dialog Box
- Select Equipment Dialog Box
- Select HMI Picture Dialog Box
- Set Tag Server Dialog Box
- Share Equipment Phase Dialog Box
- Share Unit Dialog Box
- Standard Phase Template Dialog Box
- Tag Template Dialog Box
- Unit Properties Dialog Box
- Zoom Dialog Box

Add Control Module Dialog Box

The Add Control Module dialog box displays the following items:

Name

Enter the name of the control module that you want to add. The system automatically assigns a name, or you can enter your own name. Control module names must be unique.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Class

Displays the class for the control module. You cannot edit this field.

Arbitration

The following table lists the contents of the Arbitration area:

Item	Description
Equipment ID	Enter the unique equipment ID to identify this control module.
Max Owners	Enter the maximum number of owners that may simultaneously own this control module.
Equipment Needed	Lists the equipment that this equipment needs to own exclusively in order to begin operation.
Add	Lets you add equipment to the Equipment Needed list box.
Remove	Deletes the selected equipment from the Equipment Needed list box.

Add Control Modules Class Dialog Box

The Add Control Modules Class dialog box displays the following item:

Name

Enter the name of the control module class that you want to add. The system automatically assigns a name, or you can enter your own name. Control module class names must be unique.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Audit Information Dialog Box

The Audit Information dialog box displays the following items:

Audit Version

Displays the audit version number of the currently configured area model file. The audit version number increases by one each time the area model is saved.

Unique Identifier (GUID)

Displays the unique, system-generated identifier for the area model. Proficiency Batch Execution generates the GUID when you create a new project for the first time, or use the Save As command to create a new project.

Performed By

The following table lists the contents of the Performed By area:

Item	Description
User Name	<p>Displays the Microsoft Windows user ID of the operator (from the Performed By group) who last authorized the saving of the area model.</p> <p>Information only appears in this field if you enabled auditing and configured Save or Save As signature requirements in the Proficiency Batch Execution WorkSpace, and then saved the area model with the required electronic signatures in the Proficiency Batch Execution Equipment Editor or WorkSpace.</p>

Item	Description
Full Name	<p>Displays the full user name of the operator (from the Performed By group) who last authorized the saving of the area model.</p> <p>Information only appears in this field if you enabled auditing and configured Save or Save As signature requirements in the Proficy Batch Execution WorkSpace, and then saved the area model with the required electronic signatures in the Proficy Batch Execution Equipment Editor or WorkSpace.</p>
Timestamp	<p>Displays the date and time when Proficy Batch Execution authenticated the electronic signature of the operator (from the Performed By group).</p> <p>Information only appears in this field if you enabled auditing and configured Save or Save As signature requirements in the Proficy Batch Execution WorkSpace, and then saved the area model with the required electronic signatures in the Proficy Batch Execution Equipment Editor or WorkSpace.</p>
Comment	<p>Displays any comments entered by the operator (from the Performed By group) who last authorized the saving of the recipe.</p> <p>Information only appears in this field if you enabled auditing and configured Save or Save As signature requirements in the Proficy Batch Execution WorkSpace, and then saved the area model with the required electronic signatures in the Proficy Batch Execution Equipment Editor or WorkSpace.</p>

Verified By

The following table lists the contents of the Verified By area:

Item	Description
User Name	<p>Displays the Windows user ID of the supervisor (from the Verified By group) who last authorized the saving of the area model.</p> <p>Information only appears in this field if you enabled auditing and configured Save or Save As signature requirements in the Proficy Batch Execution WorkSpace, and then saved the area model with the required electronic signatures in the Proficy Batch Execution Equipment Editor or WorkSpace.</p>

Item	Description
Full Name	<p>Displays the full user name of the supervisor (from the Verified By group) who last authorized the saving of the area model.</p> <p>Information only appears in this field if you enabled auditing and configured Save or Save As signature requirements in the Proficy Batch Execution WorkSpace, and then saved the area model with the required electronic signatures in the Proficy Batch Execution Equipment Editor or WorkSpace.</p>
Timestamp	<p>Displays the date and time when Proficy Batch Execution authenticated the electronic signature of the supervisor (from the Verified By group).</p> <p>Information only appears in this field if you enabled auditing and configured Save or Save As signature requirements in the Proficy Batch Execution WorkSpace, and then saved the area model with the required electronic signatures in the Proficy Batch Execution Equipment Editor or WorkSpace.</p>
Comment	<p>Displays any comments entered by the supervisor (from the Verified By group) who last authorized the saving of the recipe.</p> <p>Information only appears in this field if you enabled auditing and configured Save or Save As signature requirements in the Proficy Batch Execution WorkSpace, and then saved the area model with the required electronic signatures in the Proficy Batch Execution Equipment Editor or WorkSpace.</p>

Browse OPC Items Dialog Box

The Browse OPC Items dialog box displays the following items:

Select an Item

Select an OPC item from the list box.

Item ID

Enter an Item ID number.

Filter String

Enter a filter string to display only a subset of items in the Select and Item list.

Connection Properties Dialog Box

The Connection Properties dialog box displays the following items:

Name

Enter a unique name for the connection.

Label

Optionally enter a descriptive label for connection. This label appears on the connection line.

Origin

Displays the name of the origin unit.

Destination

Displays the name of the destination unit.

Arbitration

The following table lists the contents of the Arbitration area:

Item	Description
Equipment ID	Enter the unique equipment ID to identify this connection.
Max Owners	Enter the maximum number of owners that may simultaneously own this connection.
Equipment Needed	Lists the equipment that this equipment needs to own exclusively in order to begin operation.
Add	Lets you add equipment to the Equipment Needed list box.
Remove	Deletes the selected equipment from the Equipment Needed list box.

Create Direct Equipment Phase Class Dialog Box

The Create Direct Equipment Phase Class dialog box displays the following items:

General Tab

The following table lists the contents of the General tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Icon	Displays a list of available icons.

Parameters Tab

The following table lists the contents of the Parameters tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Phase Parameters	Lists the phase parameters that are currently configured for this equipment phase.

Item	Description
Add	Lets you add a parameter to the equipment phase.
Edit	Lets you edit the selected phase parameter.
Delete	Deletes the selected phase parameter.

Reports Tab

The following table lists the contents of the Reports tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Phase Reports	Lists the phase reports that are currently configured for this equipment phase.
Add	Lets you add a phase report to the equipment phase.
Edit	Click to edit the selected phase report.
Delete	Deletes the selected phase report.

Enable Tags

The following table lists contents of the Enable Tags Tab under the Direct Phase Tags area:

Item	Description
Running State	Select this check box to enable the Running state.
Hold, Held, and Restarting States	Select this check box to enable the Hold, Held, and Restarting states.
Stopping State	Select this check box to enable the Stopping state.
Aborting State	Select this check box to enable the Aborting state.
Failure	Select this check box to enable the Failure state.
Pause and Paused	Select this check box to enable the Pause and Paused states.
Single_Step	Select this check box to enable the Single_Step state.
Single_Index	Select this check box to enable the Single_Index state.
Unit	Select this check box to enable the Unit state.

Create Enumeration Dialog Box

The Create Enumeration dialog box displays the following items:

Enumeration

Enter the enumeration string for the corresponding ordinal value. This is the string displayed to recipe authors and operators. Enumeration string names must be unique within enumeration sets. Enumeration names should not contain spaces or these characters: !@#\$\$%^&*()

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: WINTERGREEN

Ordinal

Enter the ordinal or number that represents the enumeration. This number must match the number that is programmed into the phase logic in the process controller. Ordinals must be unique within enumeration sets.

Create Enumeration Set Dialog Box

The Create Enumeration Set dialog box displays the following item:

Enumeration Set

Enter the enumeration set name. Enumeration set names must be unique within enumeration sets. Enumeration set names should not contain spaces or these characters: !@#\$%^&*()"

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: FLAVOR

Create Enumeration Sets and Enumerations Dialog Box

The Create Enumeration Sets and Enumerations dialog box displays the following items:

Enumeration Sets

Lists the configured enumeration sets.

Enumerations

Lists the currently defined enumerations.

Sets

The following table lists the buttons to manipulate the Enumeration Sets:

Item	Description
New	Lets you create a new enumeration set.
Edit	Lets you change the name of the currently selected enumeration set.
Delete	Deletes the currently selected enumeration set.

Enumerations

The following table describes the buttons in the Enumerations area:

Item	Description
New	Lets you add a new enumeration to the currently selected enumeration set.
Edit	<p>Enter the enumeration string for the corresponding ordinal value. This is the string displayed to recipe authors and operators. Enumeration string names must be unique within enumeration sets. Enumeration names should not contain spaces or these characters: !@#\$\$%^&*()</p> <p>Valid Entries: A - Z, 0 - 9, and the underscore character.</p> <p>Example: WINTERGREEN</p>
Delete	Deletes the currently selected enumeration set.

Create Equipment Phase Class Dialog Box

The Create Equipment Phase Class dialog box displays the following items:

General Tab

The following table lists the contents of the General tab:

Item	Description
Name	<p>Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names.</p> <p>Valid Entries: A - Z, 0 - 9, and the underscore character.</p>
Type	Enter the equipment phase type or leave this field blank.

Item	Description
Icon	Displays a list of available icons.
Number of Request Tags	Enter the number of request tags required for this equipment phase. This number must match the number of requests that are made by the phase logic.
Number of Message Partners	Enter the number of phase partners that this equipment phase must communicate with.

Parameters Tab

The following table lists the contents of the Parameters tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Phase Parameters	Lists the phase parameters that are currently configured for this equipment phase.
Add	Lets you add a parameter to the equipment phase.
Edit	Lets you edit the selected phase parameter.
Delete	Deletes the selected phase parameter.

Reports Tab

The following table lists the contents of the Reports tab:

Item	Description
Name	<p>Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names.</p> <p>Valid Entries: A - Z, 0 - 9, and the underscore character.</p>
Type	<p>Enter the equipment phase type or leave this field blank.</p>
Phase Reports	<p>Lists the phase reports that are currently configured for this equipment phase.</p>
Add	<p>Lets you add a phase report to the equipment phase.</p>
Edit	<p>Lets you edit the selected phase report.</p>
Delete	<p>Deletes the selected phase report.</p>

Operator Messages Tab

The following table lists the contents of the Operator Messages tab:

Item	Description
Name	<p>Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names.</p> <p>Valid Entries: A - Z, 0 - 9, and the underscore character.</p>

Item	Description
Type	Enter the equipment phase type or leave this field blank.
Operator Messages	List the operator messages that are currently configured for this equipment phase. These messages are displayed to the operator during manual phase control.
Add	Lets you add an operator message to the equipment phase.
Edit	Lets you edit the selected operator message.
Delete	Deletes the selected operator message.

Create OPC Server Dialog Box

The Create OPC Server dialog box displays the following items:

Select a Server

Lists the currently configured servers.

Server Name

Enter a server name. Server names must be unique.

Valid Entries: A - Z, 0 - 9, and the underscore character. Valid Entries:

Alias

Enter an alternate name that you would like to associate with the active server. If you are using Batch Execution with Proficy Process Systems, enter the alternate name for the Proficy Process Systems active server; the format of this name is: Channel.Device. For example, for a channel named PAC1 and a device named D1, enter PAC1.D1 in this field. If you are using iFIX with Batch, the name you enter here is the Nodename. The name that you enter in the Alias field will later be substituted into the Tag Template, after the template is configured.

BadValue

Enter the bad value string sent from the application.

Watchdog

Enter a tag to act as a watchdog register.

NOTE: For Proficy Process Systems, the format of this name is: Channel.Device.WatchDog.WD. For example, for Proficy Process Systems, for channel named PAC1, a device named D1, and a Watchdog function block named WD5, enter PAC1.D1.WD5.WD in this field.

DLL

Displays the path and .DLL file name for the OPC server.

Default Refresh Rate

Enter the rate in milliseconds to refresh data from the OPC server. The default is 1000, which is equal to one second.

Create Process Cell Class Dialog Box

The Create Process Cell Class dialog box displays the following items:

Name

Enter the name of a new process cell class. Process cell class names must be unique within process cell classes.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: INTYPLANT

Icon

Displays a list of available icons.

Create Unit Class Dialog Box

The Create Unit Class dialog box displays the following items:

Name

Enter a name for the unit class. Unit class names must be unique within the unit classes.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: MIXER

Icon

Displays a list of available icons.

Tag Classes

Lists the unit tag classes for this unit class. A unit tag class is automatically created when the same class is assigned to more than one unit tag.

Create Unit Tag Dialog Box

The Create Unit Tag dialog box displays the following items:

Name

Enter the unit tag name.

Tag Class

Lists the unit tag classes for this unit tag. A unit tag class is automatically created when the same class is assigned to more than one unit tag.

Type

Identifies the data type of the equipment phase tag. The type assigned should correspond to the actual data type in the data server.

Valid Entries: Real, Integer, String, Enumeration

Item

Enter the OPC item for the tag. Make certain the appropriate OPC server is listed in the Server Name field. If you have defined an OPC server for the iFIX OPCEDA driver, you can click the ? button to browse through the database tags. If the tag you require does not exist, you can add a new tag to the database by entering the node.tag.field for the new tag in this field.

iFIX Database Tag Valid Entries: NODE.TAG.FIELD

Example: DEMO.AI1.F_CV

Server

The following table lists the contents of the Server area:

Item	Description
Name	Displays the server that is assigned to the equipment phase tag. Select the down-arrow button to select a different server.
App.	Display-only field.
Topic	Displays-only field.
Timeout	Displays the watchdog field name within the data server. Proficy Batch Execution sets the value to 1, then expects the process-connected device to clear this field within a specified time-out period. If the process-connected device fails to clear this field within the designated time-out period, Proficy Batch Execution assumes communication is lost.

Direct Phase Tag Template Dialog Box

The Direct Phase Tag Template dialog box displays the following items:

Enter Tag

The following table lists the contents of the Enter Tag area:

Item	Description
Alias	Placeholder for the node name. If you want to edit the name, close this dialog box and enter the new node name into the Node field in the Direct Phase Template dialog box.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.

Item	Description
Suffix	The Enter tag suffix. By default, this value is set to <code>_RE</code> for Running, <code>_OE</code> for Holding, <code>_HE</code> for Held, <code>_AE</code> for Aborting, <code>_PE</code> for Stopping, and <code>_TE</code> for Restarting.
Type	The Enter tag type. By default, the tag type is set to the current value, displayed as a number (F_CV).
Value	<p>Enter the value of the Enter tag. By default this value is set to 1.</p> <p>Valid Entries: For the active level, the acceptable values are 0 – 65534. For the inactive level, the acceptable values are 0 or 1.</p> <p>For example, when the controller indicates it is running, the controller sets the status to the active level. When complete, the controller sets the status back to a 0 if the active level was 1 – 65534. Otherwise if the active level is zero, the controller sets the status to 1.</p>

Exit Tag

The following table lists the contents of the Exit Tag area:

Item	Description
Inverse of Enter Tag	<p>Select this check box if you want the Exit tag to use the same address as the Enter tag, but invert the active level. For instance, if the Enter tag is equal to 1, the Exit tag would be set to 0.</p> <p>If you select this check box and the Enter tag is set to something other than a 1 or 0, the Exit tag is automatically set to 0.</p>
Alias	Placeholder for the node name. If you want to edit the name, close this dialog box and enter the new node name into the Node field in the Direct Phase Template dialog box.
Phase	<p>Placeholder for the actual phase name. You cannot edit this field.</p> <p>When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.</p>

Item	Description
Suffix	The Exit tag suffix. By default, this value is set to _RX for Running, _OX for Holding, _HX for Held, _AX for Aborting, _PX for Stopping, and _TX for Restarting.
Type	The Exit tag type. By default, the tag type is set to the current value, displayed as a number (F_CV).
Value	Enter the value of the Exit tag. By default this value is set to 1. Valid Entries: For the active level, the acceptable values are 0 – 65534. For the inactive level, the acceptable values are 0 or 1.

Status Tag

The following table lists the contents of the Status Tag area:

Item	Description
Same as Enter Tag	Select this check box to make the Status tag use the same address as the Enter tag.
Alias	Placeholder for the node name. If you want to edit the name, close this dialog box and enter the new node name into the Node field in the Direct Phase Template dialog box.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Status tag suffix. By default, the Status tag is set to _ST for standard phases. For Batch Direct phases, the Status tag is set to _RS for Running, _OS for Holding, _HS for Held, _AS for Aborting, _PS for Stopping, and _TS for Restarting.
Type	The Status tag type. By default, the tag type is set to the current value, displayed as a number (F_CV).

Item	Description
Operator	Select a logical operator from the drop-down list.
Value	Enter the value of the Status tag. By default this value is set to 1. Valid Entries: For the active level, the acceptable values are 0 – 65534. For the inactive level, the acceptable values are 0 or 1.

Direct Tag Template Dialog Box

The Direct Tag Template dialog box displays the following items:

Direct Tags

The following table lists the contents of the Direct Tags area:

Item	Description
Running	Select this check box to enable the Running tags, by default, for new Batch Direct phases that you create.
Holding	Select this check box to enable the Holding tags, by default, for new Batch Direct phases that you create.
And Held	Select this check box to enable the Held tags, by default, for new Batch Direct phases that you create.
And Restarting	Select this check box to enable the Restarting tags, by default, for new Batch Direct phases that you create.
Stopping	Select this check box to enable the Stopping tags, by default, for new Batch Direct phases that you create.
Aborting	Select this check box to enable the Aborting tags, by default, for new Batch Direct phases that you create.

Standard Tags

The following table lists the contents of the Standard Tags area:

Item	Description
Failure	Select this check box to enable the Failure tag, by default, for new Batch Direct phases that you create.
Pause	Select this check box to enable the Pause tag, by default, for new Batch Direct phases that you create.
Single_Step	Select this check box to enable the Single Step tag, by default, for new Batch Direct phases that you create.
Step_Index	Select this check box to enable the Step Index tag, by default, for new Batch Direct phases that you create.
Unit	Select this check box to enable the Unit tag, by default, for new Batch Direct phases that you create.

Node

Enter the server node name. The node you enter in this field is automatically entered into all the node fields for each tag. This is by design; all tags for a phase must have the same node name.

Use Server Alias

Click this button to populate all of the Server name fields with the "#ALIAS#" text. The #ALIAS# syntax allows you to use the Alias configured in the Create OPC Server dialog box.

NOTE: To access the Create OPC Server dialog box, on the Edit menu, select Server. Select a server and click Edit, or click Add to add a new one. The dialog that displays after you click Edit or Add will display the Alias field.

Edit Area Dialog Box

The Edit Area dialog box displays the following items:

Name

Enter the area name.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: AREA1

Version

Enter the version number for the area.

Edit Control Modules Dialog Box

The Edit Control Modules dialog box displays the following items:

Control Module Classes

Lists the configured control module classes.

Control Modules

Lists the configured control modules defined for the selected control module class.

Classes

The following table lists the buttons to manipulate the Control Module Classes:

Item	Description
Add	Lets you add a control module class.
Delete	Deletes the selected control module class.

Control Modules

The following table lists the buttons to work with Control Modules:

Item	Description
Add	Lets you add a new control module to the selected control module class.
Delete	Deletes the selected control module.

Edit Direct Equipment Phase Class Dialog Box

The Edit Equipment Phase Class dialog box displays the following items:

General Tab

The following table lists the contents of the General tab:

Item	Description
Name	Enter the direct equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the direct equipment phase type or leave this field blank.
Icon	Displays a list of available icons.
Number of Request Tags	Enter the number of request tags required for this equipment phase. This number must match the number of requests that are made by the phase logic.

Item	Description
Number of Message Partners	Enter the number of phase partners that this equipment phase must communicate with.

Parameters Tab

The following table lists the contents of the Parameters tab:

Item	Description
Name	<p>Enter the direct equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names.</p> <p>Valid Entries: A - Z, 0 - 9, and the underscore character.</p>
Type	Enter the equipment phase type or leave this field blank.
Phase Parameters	Lists the phase parameters that are currently configured for this equipment phase.
Add	Lets you add a parameter to the direct equipment phase.
Edit	Lets you edit the selected phase parameter.
Delete	Deletes the selected phase parameter.

Reports Tab

The following table lists the contents of the Reports tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Phase Reports	Lists the phase reports that are currently configured for this equipment phase.
Add	Lets you add a phase report to the direct equipment phase.
Edit	Lets you edit the selected phase report.
Delete	Deletes the selected phase report.

Enable Tags Tab

The following table lists the contents of the Enable Tags tab:

Item	Description
Running State	Select this check box to enable the Running state.
Hold, Held, and Restarting States	Select this check box to enable the Hold, Held, and Restarting states.
Stopping State	Select this check box to enable the Stopping state.
Aborting State	Select this check box to enable the Aborting state.

Item	Description
Failure	Select this check box to enable the Failure state.
Pause and Paused	Select this check box to enable the Pause and Paused states.
Single_Step	Select this check box to enable the Single_Step state.
Single_Index	Select this check box to enable the Single_Index state.
Unit	Select this check box to enable the Unit state.

Edit Direct Phase Tags Dialog Box

The Edit Direct Phase Tags dialog box displays the following items:

Enter Tag

The following table lists the contents of the Enter Tag area:

Item	Description
Alias	Placeholder for the node name. If you want to edit the name, close this dialog box and enter the new node name into the Node field in the Direct Phase Template dialog box.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Enter tag suffix. By default, this value is set to _RE for Running, _OE for Holding, _HE for Held, _AE for Aborting, _PE for Stopping, and _TE for Restarting.
Type	The Enter tag type. By default, the tag type is set to the current value, displayed as a number (F_CV).

Item	Description
Value	<p>Enter the value of the Enter tag. By default this value is set to 1.</p> <p>Valid Entries: For the active level, the acceptable values are 0 - 65534. For the inactive level, the acceptable values are 0 or 1.</p> <p>For example, when the controller indicates it is running, the controller sets the status to the active level. When complete, the controller sets the status back to a 0 if the active level was 1 - 65534. Otherwise if the active level is zero, the controller sets the status to 1.</p>

Exit Tag

The following table lists the contents of the Exit Tag area:

Item	Description
Inverse of Enter Tag	<p>Select this check box if you want the Exit tag to use the same address as the Enter tag, but invert the active level. For instance, if the Enter tag is equal to 1, the Exit tag would be set to 0.</p> <p>If you select this check box and the Enter tag is set to something other than a 1 or 0, the Exit tag is automatically set to 0.</p>
Alias	Placeholder for the node name. If you want to edit the name, close this dialog box and enter the new node name into the Node field in the Direct Phase Template dialog box.
Phase	<p>Placeholder for the actual phase name. You cannot edit this field.</p> <p>When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.</p>
Suffix	The Exit tag suffix. By default, this value is set to _RX for Running, _OX for Holding, _HX for Held, _AX for Aborting, _PX for Stopping, and _TX for Restarting.
Type	The Exit tag type. By default, the tag type is set to the current value, displayed as a number (F_CV).

Item	Description
Value	Enter the value of the Exit tag. By default this value is set to 1. Valid Entries: For the active level, the acceptable values are 0 - 65534. For the inactive level, the acceptable values are 0 or 1.

Status Tag

The following table lists the contents of the Status Tag area:

Item	Description
Same as Enter Tag	Select this check box to make the Status tag use the same address as the Enter tag.
Alias	Placeholder for the node name. If you want to edit the name, close this dialog box and enter the new node name into the Node field in the Direct Phase Template dialog box.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Status tag suffix. By default, the Status tag is set to _ST for standard phases. For Batch Direct phases, the Status tag is set to _RS for Running, _OS for Holding, _HS for Held, _AS for Aborting, _PS for Stopping, and _TS for Restarting.
Type	The Status tag type. By default, the tag type is set to the current value, displayed as a number (F_CV).
Operator	Select a logical operator from the drop-down list.
Value	Enter the value of the Status tag. By default this value is set to 1. Valid Entries: For the active level, the acceptable values are 0 - 65534. For the inactive level, the acceptable values are 0 or 1.

Edit Enumeration In Dialog Box

The Edit Enumeration In dialog box displays the following items:

Enumeration

Enter the enumeration string for the corresponding ordinal value. This is the string displayed to recipe authors and operators. Enumeration string names must be unique within enumeration sets. Enumeration names should not contain spaces or these characters: !@#%&*()

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: WINTERGREEN

Ordinal

Enter the ordinal or number that represents the enumeration. This number must match the number that is programmed into the phase logic in the process controller. Ordinals must be unique within enumeration sets.

Edit Enumeration Set Name Dialog Box

The Edit Enumeration Set Name dialog box displays the following item:

Enumeration Set

Enter the enumeration set name. Enumeration set names must be unique within enumeration sets. Enumeration set names should not contain spaces or these characters: !@#%&*()

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: FLAVOR

Edit Equipment Phase Class Dialog Box

The Edit Equipment Phase Class dialog box displays the following items:

General Tab

The following table lists the contents of the General tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Icon	Displays a list of available icons.
Number of Request Tags	Enter the number of request tags required for this equipment phase. This number must match the number of requests that are made by the phase logic.
Number of Message Partners	Enter the number of phase partners that this equipment phase must communicate with.

Parameters Tab

The following table lists the contents of the Parameters tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Phase Parameters	Lists the phase parameters that are currently configured for this equipment phase.

Item	Description
Add	Lets you add a parameter to the equipment phase.
Edit	Lets you edit the selected phase parameter.
Delete	Deletes the selected phase parameter.

Reports Tab

The following table lists the contents of the Reports tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Phase Reports	Lists the phase reports that are currently configured for this equipment phase.
Add	Lets you add a phase report to the equipment phase.
Edit	Lets you edit the selected phase report.
Delete	Deletes the selected phase report.

Operator Messages Tab

The following table lists the contents of the Operator Messages tab:

Item	Description
Name	Enter the equipment phase class name. Equipment phase names can be up to 255 characters and must be unique within equipment phase class names. Valid Entries: A - Z, 0 - 9, and the underscore character.
Type	Enter the equipment phase type or leave this field blank.
Operator Messages	List the operator messages that are currently configured for this equipment phase. These messages are displayed to the operator during manual phase control.
Add	Lets you add an operator message to the equipment phase.
Edit	Lets you edit the selected operator message.
Delete	Deletes the selected operator message.

Edit Equipment Phase Dialog Box

The Edit Equipment Phase dialog box displays the following items:

Name

Enter the equipment phase name. Equipment phase names must be unique within an area model.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Examples: COOL2, ADD_INGS2

Phase

Displays the equipment phase class for this equipment phase.

Icon

Displays the icon that represents this equipment phase.

Equipment Phase Tags

The following table lists the contents of the Equipment Phase Tags area:

Item	Description
Equipment Phase Tags list box	Lists the equipment phase tags for this equipment phase. Double-click a tag edit the tag.
Server	Lets you assign a server to all equipment phase tags.
Defaults	Resets all equipment phase tag names to the original Proficiency Batch Execution defaults.
Name	Displays the name of the selected equipment phase tag. To change the name, double-click the tag in the Equipment Phase Tags list box.
Type	Displays the data type of the selected equipment phase tag.
Description	Describes the selected equipment phase tag

Arbitration

The following table lists the contents of the Arbitration area:

Item	Description
Equipment ID	Enter the unique equipment ID to identify this equipment phase

Item	Description
Max Owners	Enter the maximum number of owners that can simultaneously own this equipment phase. If the phase is shared, the maximum number of owners must be 1.
Equipment Needed	Lists the equipment that this equipment needs to own exclusively in order to begin operation.
Add	Lets you add equipment to the Equipment Needed list box.
Remove	Deletes the selected equipment from the Equipment Needed list box.

Edit Equipment Phase Tag Dialog Box

The Edit Equipment Phase Tag dialog box displays the following items:

Name

Enter the unit tag name.

Class

Enter the tag class for the unit tag.

Type

Identifies the data type of the equipment phase tag. The type assigned should correspond to the actual data type in the data server.

Valid Entries: Real, Integer, String, Enumeration

Item

Enter the OPC item for the tag. Make certain the appropriate OPC server is listed in the Server Name field. If you have defined an OPC server for the iFIX OPCEDA driver, you can click the ? button to browse through the database tags. If the tag you require does not exist, you can add a new tag to the database by entering the node.tag.field for the new tag in this field.

iFIX Database Tag Valid Entries: NODE.TAG.FIELD

Example: DEMO.AI1.F_CV

Browse

Click to browse through and select from a list of tags. Note that this button is enabled only if you are using an OPC data server.

Server

The following table lists the contents of the Server area:

Item	Description
Name	Displays the server that is assigned to the equipment phase tag. Select the down-arrow button to select a different server.
Watchdog	Displays the watchdog field name within the data server. Proficy Batch Execution sets the value to 1, then expects the process-connected device to clear this field within a specified time-out period. If the process-connected device fails to clear this field within the designated time-out period, Proficy Batch Execution assumes communication is lost.

Edit Operator Message Dialog Box

The Edit Operator Message dialog box displays the following items:

Name

Enter the text of the operator message. This message is sent to the batch journal (.EVT file) and is displayed to the operator during manual phase control.

ID

Enter the operator message ID. Messages are identified by this ID in the phase logic.

Edit Phase Parameter Dialog Box

The Edit Phase Parameter dialog box displays the following items:

Name

Enter the name of the equipment phase parameter.

ID

Enter the phase parameter ID. This ID must match the ID that is required by the phase logic.

Type

Select the data type for the phase parameter.

Valid Entries: Real, Integer, Sting, Enumeration

Eng. Units

Enter the engineering units for the phase parameter.

High

Enter the highest value that this parameter can be set to.

Low

Enter the lowest value that this parameter can be set to.

Default

Enter a default value for this parameter.

Scale

Select this check box to enable scaling for this parameter.

Edit Phase Report Dialog Box

The Edit Phase Report dialog box displays the following items:

Name

Enter the phase report name.

ID

Enter the phase report ID. This ID must match the ID that is required by the phase logic.

Type

Select the data type for the phase report.

Valid Entries: Real, Integer, String, Enumeration

Eng. Units

Enter the engineering units for the phase parameter.

Edit Process Cell Class Dialog Box

The Edit Process Cell Class dialog box displays the following items:

Name

Enter the name of a new process cell class. Process cell class names must be unique within process cell classes.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: INTYPLANT

Icon

Displays a list of available icons.

Edit Process Cell Dialog Box

The Edit Process Cell dialog box displays the following items:

Name

Enter the name of the process cell. Process cell names must be unique.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: TOOTHPASTE

Class

Displays the name of the process cell class from which this process cell was created.

Icon

Icon representing the process cell to be edited.

Arbitration

The following table lists the contents of the Arbitration area:

Item	Description
Equipment ID	Enter the unique equipment ID to identify this piece of equipment.
Max Owners	Enter the maximum number of owners that can simultaneously own this process cell.
Equipment Needed	Lists the equipment that this equipment needs to own exclusively in order to begin operation.
Add	Lets you add equipment to the Equipment Needed list box.
Remove	Deletes the selected equipment from the Equipment Needed list box.

HMI Process Cell Picture

The following table lists the contents of the HMI Process Cell Picture area:

Item	Description
HMI Process Cell Picture	Enter the file name of the iFIX picture associated with this equipment entity. You can associate pictures with process cells and units. iFIX Examples: PLANT.GRF, MIX1.GRF
Browse	Browses directories for the HMI picture.

Edit Servers Dialog Box

The Edit Servers dialog box displays the following items:

Servers

Lists the currently configured data servers.

Alias

Displays an alternate name associates with the active server. If you are using Batch Execution with Proficy Process Systems, the alternate name for the Proficy Process Systems is the active server; the format of this name is: Channel.Device. For example, for a channel named PAC1 and a device named D1, enter PAC1.D1 in this field. If you are using iFIX with Batch, the name you enter here is the Nodename. The name that appears in the Alias field will later be substituted into the Tag Template, after the template is configured.

Watchdog

Displays the time-out field within the data server. Proficy Batch Execution sets the value of this field to 1, then expects the process-connected device to clear this field within the specified time-out period. If the process-connected device fails to clear this field within the designated time-out period, Proficy Batch Execution assumes communication is lost.

Bad Value String

Identifies the string to represent bad values sent from the application.

Server Type

List the type of Server. For example: OPC.

Default Server

Select this check box to make the selected server the default server. The equipment phases that you configure are assigned this server by default.

Edit Server

Click to edit the currently selected server.

Delete Server

Deletes the currently selected server.

New Server

Lets you configure a new server.

Edit Tags Dialog Box

The Edit Tags dialog box displays the following items:

Tag Classes

Contains the tag classes for the area.

Tags

Lists the equipment phase tags for the selected tag class.

Edit Tag

Lets you edit the selected equipment phase tag in the Tags list box.

Edit Unit Class Dialog Box

The Edit Unit Class dialog box displays the following items:

Name

Enter a name for the unit class. Unit class names must be unique within the unit classes.

Valid Entries: A - Z, 0 - 9, and the underscore character.

Example: MIXER

Icon

Displays a list of available icons.

Tag Classes

Lists the unit tag classes for this unit class. A unit tag class is automatically created when the same class is assigned to more than one unit tag.

Edit Unit Tag Dialog Box

The Edit Unit Tag dialog box displays the following items:

Name

Enter the unit tag name.

Tag Class

Enter the tag class for the unit tag.

Type

Identifies the data type of the equipment phase tag. The type assigned should correspond to the actual data type in the data server. Valid entries include: Real, Integer, String, Enumeration

Item

Enter the OPC item for the tag. Make certain the appropriate OPC server is listed in the Server Name field. If you have defined an OPC server for the iFIX OPCEDA driver, you can click the ? button to browse through the database tags. If the tag you require does not exist, you can add a new tag to the database by entering the node.tag.field for the new tag in this field.

iFIX Database Tag Valid Entries: NODE.TAG.FIELD

Example: DEMO.AI1.F_CV

Browse (...)

Click to browse through and select from a list of tags. Note that this button is enabled only if you are using an OPC data server.

Server

The following table lists the contents of the Server area:

Item	Description
Name	Displays the server that is assigned to the equipment phase tag. Select the down-arrow button to select a different server.
App.	Display-only value.
Topic	Display-only value.

Item	Description
Watchdog	Displays the watchdog field name within the data server. Proficy Batch Execution sets the value to 1, then expects the process-connected device to clear this field within a specified time-out period. If the process-connected device fails to clear this field within the designated time-out period, Proficy Batch Execution assumes communication is lost.

Enumeration Set Modification Dialog Box

The Enumeration Set Modification dialog box displays the following items:

Tags

Lists the equipment phase tags that are assigned to the enumeration set. Proficy Batch Execution automatically assigns the new enumeration set name to all equipment phase tags listed.

Parameters

Lists the phase parameters that are assigned to the enumeration set. Proficy Batch Execution automatically assigns the new enumeration set name to all phase parameters listed.

Example: FLAVOR_ADD_INGS indicates that the FLAVOR parameter in the ADD_INGS equipment phase class is assigned to the enumeration set.

Report Parameters

Lists the phase reports that are assigned to the enumeration set. Proficy Batch Execution automatically assigns the new enumeration set name to all phase reports listed.

Example: COOL_TEMP indicates that the COOL_TEMP report in the COOL phase class is assigned to the enumeration set.

File Export As Dialog Box

The File Export As dialog box displays the following items:

Save In

Specifies the location where you want to locate a file or folder. Click the arrow to select another location, or click the icon on the toolbar to move up levels. The box below lists the items in the selected location. To open a file, in the Open dialog box, double-click the name of the file you want to open. To save a file using an existing file name, in the Save dialog box, double-click the name of the file you want to save.

Location

Lists the folders and files in the selected location.

Shortcuts

Provides shortcuts to places on your computer or the network from which you can open a file, such as the History folder, the desktop, or My Network Places. When you click a location, it will appear in Look in, and the files and folders in the selected location will be listed at the right.

File Name

Provides a space for you to type the name of the file you want to open or save. To quickly find a file you've previously opened, click the file name in the drop-down list, if available:

- If you are searching for a file, you can use asterisks (*) as wildcards. For example, you can type *.* to see a list of all files. You can also type the full path of a file, for example, C:\Mydocs\Letter.doc.
- If you are saving a file, you cannot use a question mark (?) or an asterisk in the file name. If you use a question mark or asterisk and click Save, the file will not be saved and the dialog box will not close.

Save As Type

Specifies the type of file you are saving.

File Import Dialog Box

The File Import dialog box displays the following items:

Look In

Specifies the location where you want to locate a file or folder. Click the arrow to select another location, or click an icon on the toolbar to move up levels. The box below lists the items in the selected location. To open a file, in the Open dialog box, double-click the name of the file you want to open. To save a file using an existing file name, in the Save dialog box, double-click the name of the file you want to save.

Location

Lists the folders and files in the selected location.

Shortcuts

Provides shortcuts to places on your computer or the network from which you can open a file, such as the History folder, the desktop, or My Network Places. When you click a location, it will appear in Look in, and the files and folders in the selected location will be listed at the right.

File Name

Provides a space for you to type the name of the file you want to open or save. To quickly find a file you've previously opened, click the file name in the drop-down list, if available.

- If you are searching for a file, you can use asterisks (*) as wildcards. For example, you can type *.* to see a list of all files. You can also type the full path of a file, for example, C:\Mydocs\Letter.doc.
- If you are saving a file, you cannot use a question mark (?) or an asterisk in the file name. If you use a question mark or asterisk and click Save, the file will not be saved and the dialog box will not close.

Files of Type

Lists the types of files to display.

Import Equipment Model XML File Dialog Box

The Select HMI Picture dialog box displays the following Import Equipment Model XML items:

Look In

Specifies the location where you want to locate a file or folder. Click the arrow to select another location, or click an icon on the toolbar to move up levels. The box below lists the items in the selected location. To open a file, in the Open dialog box, double-click the name of the file you want to open. To save a file using an existing file name, in the Save dialog box, double-click the name of the file you want to save.

Location

Lists the folders and files in the selected location.

Shortcuts

Provides shortcuts to places on your computer or the network from which you can open a file, such as the History folder, the desktop, or My Network Places. When you click a location, it will appear in Look in, and the files and folders in the selected location will be listed at the right.

File Name

Provides a space for you to type the name of the file you want to open or save. To quickly find a file you've previously opened, click the file name in the drop-down list, if available.

- If you are searching for a file, you can use asterisks (*) as wildcards. For example, you can type *.* to see a list of all files. You can also type the full path of a file, for example, C:\Mydocs\Letter.doc.
- If you are saving a file, you cannot use a question mark (?) or an asterisk in the file name. If you use a question mark or asterisk and click Save, the file will not be saved and the dialog box will not close.

Files of Type

Lists the types of files to display.

Manifold Properties Dialog Box

The Manifold Properties dialog box displays the following items:

Name

Enter a unique name for the manifold.

Orientation Group

The following table lists the contents of the Orientation group:

Item	Description
Vertical	Select this option to display the manifold vertically.
Horizontal	Select this option to display the manifold horizontally.

Arbitration

The following table lists the contents of the Arbitration area:

Item	Description
Equipment ID	Enter the unique equipment ID to identify this manifold.
Max Owners	Lists the equipment that this equipment needs to own exclusively in order to begin operation.
Equipment Needed	Lists the equipment that this equipment needs to own exclusively in order to begin operation.
Add	Lets you add equipment to the Equipment Needed list box.

Item	Description
Remove	Deletes the selected equipment from the Equipment Needed list box.

Print Setup Dialog Box

The Print Setup dialog box displays the following items:

Name

Lists the printers that are connected to your computer.

Properties

Click to set up options for the printer. The options available depend on the printer's features.

Paper

The following table lists the contents of the Paper group:

Item	Description
Size	Specifies the size of the paper, envelope, or other print media you want to use.
Source	Specifies where the paper you want to use is located in the printer. Different printer models support different paper sources, such as the upper tray, envelope feed, and manual feed.

Orientation

The following table lists the contents of the Orientation group:

Item	Description
Portrait	Specifies whether the document should be printed with its top along the short side of the paper (Portrait).
Landscape	Specifies whether the document should be printed along the long side of the paper (Landscape).

Select Directories Dialog Box

The Select Directories dialog box displays the following items:

Process Cell Class Icons

Enter the path where process cell class icons are located. Typically this path is C:\Program Files\Proficy\Proficy Batch Execution\BMP\PROCCELL.

Unit Class Icons

Enter the path where unit class icons are located. Typically this path is C:\Program Files\Proficy\Proficy Batch Execution\BMP\UNIT.

Phase Icons

Enter the path where equipment phase icons are located. Typically this path is C:\Program Files\Proficy\Proficy Batch Execution\BMP\PHASE.

Manifold Icons

Enter the path where manifold icons are located. Typically this path is C:\Program Files\Proficy\Proficy Batch Execution\BMP\MANIFOLD.

Select Equipment Dialog Box

The Select Equipment dialog box displays the following item:

Select Equipment

Lists the configured equipment. Click the plus sign to expand the folder containing the equipment you want to assign as needed equipment.

Select HMI Picture Dialog Box

The Select HMI Picture dialog box displays the following items:

Look In

Specifies the location where you want to locate a file or folder. Click the arrow to select another location, or click an icon on the toolbar to move up levels. The box below lists the items in the selected location. To open a file, in the Open dialog box, double-click the name of the file you want to open. To save a file using an existing file name, in the Save dialog box, double-click the name of the file you want to save.

Location

Lists the folders and files in the selected location.

Shortcuts

Provides shortcuts to places on your computer or the network from which you can open a file, such as the History folder, the desktop, or My Network Places. When you click a location, it will appear in Look in, and the files and folders in the selected location will be listed at the right.

File Name

Provides a space for you to type the name of the file you want to open or save. To quickly find a file you've previously opened, click the file name in the drop-down list, if available.

- If you are searching for a file, you can use asterisks (*) as wildcards. For example, you can type *.* to see a list of all files. You can also type the full path of a file, for example, C:\Mydocs\Letter.doc.
- If you are saving a file, you cannot use a question mark (?) or an asterisk in the file name. If you use a question mark or asterisk and click Save, the file will not be saved and the dialog box will not close.

Files of Type

Lists the types of files to display.

Set Tag Server Dialog Box

The Set Tag Server dialog box displays the following items:

Name

Displays the server that is assigned to the equipment phase tag. Select the down-arrow button to select a different server.

Watchdog

Displays the watchdog field name within the data server. Proficiency Batch Execution sets the value to 1, then expects the process-connected device to clear this field within a specified time-out period. If the process-connected device fails to clear this field within the designated time-out period, Proficiency Batch Execution assumes communication is lost.

Change All Tags

Changes the server for all of the equipment phase's tags.

Share Equipment Phase Dialog Box

The Share Equipment Phase dialog box displays the following item:

Share Equipment Phase List Box

Click the plus sign (+) next to the equipment entity that contains the equipment you want to share. Then, double-click the equipment entity you want to share.

Share Unit Dialog Box

The Share Unit dialog box displays the following item:

Share Unit List Box

Click the plus sign (+) next to the equipment entity that contains the equipment you want to share. Then, double-click the equipment entity you want to share.

Standard Phase Template Dialog Box

The Standard Phase Template dialog box displays the following items:

Command Row

The following table lists the contents of the Command Row:

Item	Description
Server Alias	The SCADA server node name. The node you enter in this field is automatically entered into all the other node fields. This is by design; all tags for a phase must have the same node name.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Command register in the PLI. By default, the Command register is set to <code>_VC</code> .
Extension	The field type. By default, the field type is set to the current value, displayed as a number (<code>F_CV</code>).

Failure Row

The following table lists the contents of the Failure Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.

Item	Description
Suffix	The Failure register in the PLI. By default, the Failure register is set to <code>_F</code> .
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Owner Row

The following table lists the contents of the Owner Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Owner register in the PLI. By default, the Owner register is set to <code>_W</code> .
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Pause Row

The following table lists the contents of the Pause Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.

Item	Description
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Pause register in the PLI. By default, the Pause register is set to _P.
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Paused Row

The following table lists the contents of the Paused Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Paused register in the PLI. By default, the Paused register is set to _PD.
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Request Row

The following table lists the contents of the Request Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Request register in the PLI. By default, the Request register is set to <code>_RQ</code> .
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Single_Step Row

The following table lists the contents of the Single_Step Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Single Step register in the PLI. By default, the Single Step register is set to <code>_SS</code> .

Item	Description
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Status Row

The following table lists the contents of the Status Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Status tag suffix. By default, the Status tag is set to _ST for standard phases. For Batch Direct phases, the Status tag is set to _RS for Running, _OS for Holding, _HS for Held, _AS for Aborting, _PS for Stopping, and _TS for Restarting.
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Step Index Row

The following table lists the contents of the Step Index Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.

Item	Description
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Step Index register in the PLI. By default, the Step Index register is set to _SI.
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Unit Row

The following table lists the contents of the Unit Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Unit register in the PLI. By default, the Unit register is set to _UN.
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Parameter Row

The following table lists the contents of the Parameter Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Parameter Value register in the PLI. By default, the Parameter Value register is set to P.
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Report Row

The following table lists the contents of the Report Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Report Value register in the PLI. By default, the Report Value register is set to R.

Item	Description
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Request Tag Row

The following table lists the contents of the Request Tag Row:

Item	Description
Server Alias	The SCADA server node name. This field is automatically populated with the name you enter in the Node field for the Command tag.
Phase	Placeholder for the actual phase name. You cannot edit this field. When you add or modify equipment phases in the Equipment Editor, the Name field in the Edit Equipment Phase dialog box replaces this generic PHASE placeholder.
Suffix	The Request Data register in the PLI. By default, the Request Data register is set to Q.
Extension	The field type. By default, the field type is set to the current value, displayed as a number (F_CV).

Use Server Alias

Click this button to populate all of the Server name fields with the "#ALIAS#" text. The #ALIAS# syntax allows you to use the Alias configured in the Create OPC Server dialog box.

NOTE: To access the Create OPC Server dialog box, on the Edit menu, select Server. Select a server and click Edit, or click Add to add a new one. The dialog that displays after you click Edit or Add will display the Alias field.

Tag Template Dialog Box

The Tag Template dialog box displays the following items:

Server Alias

Displays the alias for the server node name. You cannot edit this field.

Phase

Displays the phase name. You cannot edit this field.

Suffix

The Command register in the PLI.

Extension

The field type.

Unit Properties Dialog Box

The Unit Properties dialog box displays the following items:

General Tab

The following table lists the contents of the General tab:

Item	Description
Name	Enter the unit name. Unit names must be unique within an area model. Valid Entries: A - Z, 0 - 9, and the underscore character. Examples: FLAVORING, WATER
Class	Displays the name of the unit class from which this unit was created.
Icon	Icon representing the unit to be edited.

Item	Description
HMI Unit Picture	<p>Enter the file name of the iFIX picture associated with this equipment entity. You can associate pictures with process cells and units.</p> <p>iFIX Examples: PLANT.GRF, MIX1.GRF</p>
Browse	Click to browse directories for the HMI picture.
Master Process Cell	Specifies the process cell that the unit will report against in the Event Journal.

Equipment Capacity Tab

The following table lists the contents of the Equipment Capacity tab:

Item	Description
Name	<p>Enter the unit name. Unit names must be unique within an area model.</p> <p>Valid Entries: A - Z, 0 - 9, and the underscore character.</p> <p>Examples: FLAVORING, WATER</p>
Class	Displays the name of the unit class from which this unit was created.
Amount	<p>Enter the maximum amount that the unit can contain, transfer, or process. During Active Binding, Proficy Batch Execution uses this criteria to select units that meet the unit procedure's minimum capacity requirement defined in the recipe.</p> <p>Example: If a unit procedure requires a unit capacity of 1000 Liters, the selected unit must have a capacity amount that is greater than or equal to 1000 Liters.</p>

Item	Description
UOM	<p>Enter or select the Unit's Unit of Measure (UOM). If you enter a UOM that does not exist, Proficy Batch Execution prompts you to add it to the UNIT_OF_MEASURE enumeration set.</p> <p><i>NOTE: If you want Proficy Batch Execution to consider a unit's capacity as part of its unit selection criteria, assign the same UOM to (1) all units within the same unit class, and (2) the unit procedure's capacity requirement. If a unit has a different UOM than the UOM specified in the unit procedure's capacity requirement, Proficy Batch Execution ignores the unit's capacity amount as part of the selection criteria.</i></p>

Unit Tags Tab

The following table lists the contents of the Reports tab:

Item	Description
Name	<p>Enter the unit name. Unit names must be unique within an area model.</p> <p>Valid Entries: A - Z, 0 - 9, and the underscore character.</p> <p>Examples: FLAVORING, WATER</p>
Class	Displays the name of the unit class from which this unit was created.
Use Unit Ready Tag	<p>Select this option if your process uses a Unit Ready tag value to determine if the unit is ready for use. Proficy Batch Execution checks the value of this tag to determine if this unit can be allocated to a batch.</p> <p>Example: If the Unit Ready tag value is set to zero (0), this indicates the unit is online and Proficy Batch Execution can allocate the unit to a batch. If the tag is set to a non-zero value, Proficy Batch Execution cannot allocate this unit to a batch.</p>
Unit Always Ready	<p>Select this option to define the unit as always ready for use (online). With this option selected, Proficy Batch Execution can allocate this unit to a batch.</p>
Unit Always Not Ready	<p>Select this option to define the unit as always not ready for use (offline). With this option selected, Proficy Batch Execution cannot allocate this unit to a batch.</p>
Edit Tag	Lets you define the Unit Ready tag name and data server.

Item	Description
Use Unit Priority Tag	Select this option if your process uses a Unit Priority tag to determine the unit's priority. With this option selected, Proficy Batch Execution checks the priority tag's value and selects the unit with the highest priority value.
Use Default Priority	Select this option to define a priority value for the unit. Enter a value in the edit box to indicate the unit's relative importance, compared to other units within the same unit class. With this option selected, Proficy Batch Execution selects the unit with the highest priority value. Valid Entries: 0 through 2,147,483,647
Edit Tag	Lets you define the Unit Priority tag name and data server.
User Defined Tags	Lists the unit tags configured for this unit.
Add	Lets you add a unit tag for this unit.
Edit	Lets you edit the currently selected unit tag.
Remove	Deletes the currently selected unit tag.

Arbitration Tab

The following table lists the contents of the Arbitration tab:

Item	Description
Name	Enter the unit name. Unit names must be unique within an area model. Valid Entries: A - Z, 0 - 9, and the underscore character. Examples: FLAVORING, WATER
Class	Displays the name of the unit class from which this unit was created.
Equipment ID	Enter the unique equipment ID to identify this unit.

Item	Description
Max Owners	Enter the maximum number of owners that may simultaneously own this unit.
Equipment Needed	Lists the equipment that this equipment needs to own exclusively in order to begin operation.
Add	Lets you add equipment to the Equipment Needed list box.
Remove	Deletes the selected equipment from the Equipment Needed list box.

Zoom Dialog Box

The Zoom dialog box displays the following items:

Scale

The following table lists the contents of the Scale area:

Item	Description
50%	Use this command to reduce the work area display by 50%.
100%	Use this command to return to the normal display size of 100%.
150%	Use this command to magnify the work area by 150%.
200%	Use this command to magnify the work area by 200%.
250%	Use this command to magnify the work area by 250%.

Item	Description
300%	Use this command to magnify the work area by 300%.
Custom	Enter the zoom percentage. Valid values include 50 through 300 percent.

Default

Returns the picture to the default view (100%).

How Do I...

The following sections explain how to work with the Equipment Editor:

- Configuring an Area Model
- Defining Data Servers
- Configuring Areas
- Configuring Process Cells
- Configuring Units
- Configuring Unit Connections
- Configuring Equipment Phases
- Configuring Control Modules
- Configuring Enumerations
- Configuring Arbitration
- Configuring Shared Resources

Configuring an Area Model

For information on configuring an area model, refer to the following sections:

- Overview: Configuring an Area Model
- Importing a .TXT Version of the Area Model
- Importing an .XML Version of the Area Model
- Exporting the Area Model
- Viewing Audit Versioning Information

Overview: Configuring an Area Model

►To configure an area model:

1. In the Batch Equipment Editor or WorkSpace, configure an area.
2. Configure process cell classes.
3. Configure process cell instances.
4. Configure unit classes.
5. Configure unit instances.
6. Configure the equipment paths between physically connected units.
7. Configure a server.
8. Configure equipment phase classes.
9. Configure equipment phase instances.

Importing a .TXT Version of the Area Model

►To import a .TXT version of the area model:

1. In the Batch Equipment Editor, on the File menu, point to Import, and then click Text. A message appears explaining that the existing .CFG file will be overwritten.
2. Select OK to continue. The File Import dialog box appears.
3. From the File Import dialog box, enter the name of the text file to import in the File name field and click Open.

NOTE: The imported .TXT file must be in ASCII format.

4. Enter any required electronic signatures:
 - If a Performed By electronic signature is required for the import command, a dialog appears requesting the appropriate signature.
 - If a Verified By electronic signature appears, a second dialog appears requesting the appropriate signature.

Importing an .XML Version of the Area Model

►To import an .XML version of the area model:

1. In the Batch Equipment Editor, on the File menu, point to Import, and then click XML. A message appears indicating that Proficy Batch Execution will modify the existing .CFG file.
2. Click OK to continue. The Import Equipment Model XML File dialog box appears.
3. From the Import Equipment Model XML File dialog box, select the file that you want to import.
4. Click Open.
5. Enter any required electronic signatures:

- If a Performed By electronic signature is required for the import command, a dialog appears requesting the appropriate signature.
- If a Verified By electronic signature appears, a second dialog appears requesting the appropriate signature.

The file then opens in the Proficiency Batch Execution Equipment Editor.

Exporting the Area Model

►To export the current area model:

1. On the File menu (Equipment Editor) or Area menu (WorkSpace), click Export. The sub-menu opens with the export formats.
2. Select either Text or XML as the export format. The File Export As dialog box appears unless Proficiency Batch Execution requires that you enter electronic signatures first.
3. From the File Export As dialog box, in the File name field, enter a name for the file.
4. Select a location to save the file.
5. Click Save.
6. Enter any required electronic signatures:
 - If a Performed By electronic signature is required for the export command, a dialog appears requesting the appropriate signature.
 - If a Verified By electronic signature appears, a second dialog appears requesting the appropriate signature.

Viewing Audit Versioning Information

►To view the audit versioning information for the current file:

1. In the Batch Equipment Editor or WorkSpace, on the File menu, click Audit Information. The Audit Information dialog box appears.
2. Examine each of the fields.

The fields displayed in the Audit Information dialog box include the audit version number and electronic signature information for the user(s) who authorized the Proficiency Batch Execution Equipment Editor to save the current version of the area model.

NOTE: Information only appears in these fields if you enabled auditing and configured Save or Save As signature requirements in the Batch Execution Configuration dialog box in the WorkSpace, and then saved the area model with the required electronic signatures.

Defining Data Servers

For information on defining data servers, refer to the following sections:

- Defining an OPC Data Server
- Defining the VBSIM Server
- Selecting a Default Data Server
- Selecting the Equipment Phase Data Server

Defining an OPC Data Server

►To define an OPC data server:

1. In the Batch Equipment Editor or WorkSpace, on Edit menu, click Servers. The Edit Servers dialog box appears.
2. Click the New Server button. The Edit Server Name dialog box appears.
3. In the Server Name field, enter the name of the OPC server and click the OPC Server button. The Create OPC Server dialog box appears.
4. In the Select a Server list box, select the OPC I/O driver you want to associate with the OPC server name.

To communicate with iFIX SCADA Server, select the I/O driver `Intellution.OPCEDA`. For the GES OPC Server for Proficy Process Systems, select the `GE.GES.OPCServer` server name.

5. In the Alias field, enter an alternate name that you would like to associate with the active server for Proficy Process Systems. The format of this name is: `Channel.Device`.

The name that you enter here will later be substituted into the Tag Template, after it is configured. For example, for a channel named `PAC1` and a device named `D1`, enter `PAC1.D1` in this field.

6. In the Watchdog field, enter a tag to act as a watchdog register. For Proficy Process Systems, the format of this name is: `Channel.Device.WatchDog.WD`.

For example, for Proficy Process Systems, for channel named `PAC1`, a device named `D1`, and a Watchdog function block named `WD5`, enter `PAC1.D1.WD5.WD` in this field.

7. Click OK. The new OPC server appears in the list in the Edit Servers dialog box.

Selecting a Default Data Server

►To select a default data server:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Servers. The Edit Servers dialog box appears.
2. Highlight the server that by default you want to assign to all equipment phase tags.
3. Select the Default Server check box.

Selecting the Equipment Phase Data Server

►To select an equipment phase's data server:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click the phase instance. The Edit Equipment Phase dialog box appears.
2. Click the Server button. The Set Tag Server dialog box appears.
3. Click the down arrow next to the Name field and select the appropriate data server.
4. Confirm that the Change All Tags check box is selected to assign this server to all tags. This check box is unavailable for editing; it should be automatically selected for you.
5. Click OK.

Configuring Areas

►To configure an area:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Areas. The Edit Area dialog box appears.
2. Enter a unique area name.
3. Enter a version number for the area.
4. Click OK.

NOTE: Starting the Equipment Editor automatically creates a default area called AREA1.

Configuring Process Cells

For information on configuring process cells, refer to the following sections:

- Overview: Configuring Process Cells
- Configuring Process Cell Classes
- Configuring Process Cell Instances
- Configuring Process Cell Instances to Toggle to an iFIX Picture
- Maintaining Process Cells

Overview: Configuring Process Cells

►To configure process cells:

1. Define a process cell class.
2. Define a process cell instance.

Configuring Process Cell Classes

►To configure a process cell class:

1. In the Batch Equipment Editor or WorkSpace at the process cell level, on the Class menu, click New. The Create Process Cell Class dialog box appears.
2. In the Name field, enter the process cell name.
3. Select an appropriate icon for the process cell.
4. Click OK.

Configuring Process Cell Instances

►To configure a process cell instance:

1. In the Batch Equipment Editor or WorkSpace at the process cell level, in the Cell Classes area, select a cell class.
2. Move the pointer into the work area and click once. An instance of the process cell class appears.
3. Right-click the mouse button and select Cell Properties from the pop-up menu. The Edit Process Cell dialog box appears.
4. In the Name field, enter the process cell name.
5. In the HMI Process Cell Picture field, enter the corresponding iFIX picture.
6. Enter any equipment arbitration information.
7. Specify any needed equipment.
8. Click OK.

Configuring Process Cell Instances to Toggle to an iFIX Picture

►To configure a process cell or unit instance to toggle to an iFIX picture:

1. In the Batch Equipment Editor or WorkSpace, in the work area, right-click the process cell or unit instance, and select Cell Properties or Unit Properties. The Edit Process Cell or Edit Unit Properties dialog box appears.
2. In the HMI Process Cell or Unit Picture field, enter the corresponding iFIX picture name, including the file path.
3. Click OK.

Maintaining Process Cells

For information on maintaining process cells, refer to the following sections:

- Modifying Process Cells
- Deleting Process Cells

Modifying Process Cells

►To modify a process cell:

1. In the Batch Equipment Editor or WorkSpace, in the work area, select the process cell you want to modify.
2. Right-click the process cell and select Class Properties. The Edit Process Cell Class dialog box appears.
3. Enter your changes and click OK.
4. Right-click the process cell and select Cell Properties. The Edit Process Cell dialog box appears.
5. Enter your changes and click OK.

Deleting Process Cells

►To delete a process cell:

1. In the Batch Equipment Editor or WorkSpace, in the work area, click the process cell you want to delete.
2. Press the Delete key on the keyboard.

***NOTE:** Before you can delete a process cell, you must first delete all units and equipment phases within the process cell.*

Configuring Units

For information on configuring units, refer to the following sections:

- Overview: Configuring Units
- Configuring a Unit Class
- Configuring Unit Instances
- Configuring Unit Capacity
- Connecting Units
- Configuring Unit Tags
- Maintaining Units

Overview: Configuring Units

►To configure units:

1. In the Batch Equipment Editor or WorkSpace, configure a unit class.
2. Configure a unit instance.
3. Configure the unit's equipment capacity.

4. If appropriate, define unit tags.
5. Configure the unit's equipment paths.
6. If the unit is shared by another process cell, share the unit.

Configuring a Unit Class

►To configure a unit class:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click the process cell containing the units you are configuring.
2. On the toolbar, click the Add New Object button. The Create Unit Class dialog box appears.
3. In the Name field, enter a class name.
4. Click an appropriate icon.
5. Click OK. The unit class appears in the Configured Classes window.

NOTE: Tag classes are automatically created when you define more than one unit tag of the same class on multiple units.

Configuring Unit Instances

►To configure a unit instance:

1. In the Batch Equipment Editor or WorkSpace, in the Phase Classes area, click a class. The cursor changes to a right angle.
2. Move the cursor into the work area and click the mouse button. An instance of the unit appears.
3. Right-click the mouse button and select the Unit Properties command from the pop-up menu. The Unit Properties dialog box appears.
4. In the Name field, enter a unit name.
5. In the HMI Unit Picture field, enter the corresponding iFIX picture.
6. Define the unit's equipment capacity.
7. Configure user-defined unit tags, Unit Ready, and Unit Priority tags.
8. Enter any equipment arbitration information.
9. Specify any needed equipment.
10. Click OK.

Configuring Unit Capacity

►To configure a unit's equipment capacity:

1. In the Batch Equipment Editor or WorkSpace, in the Phase Classes area, left-click the mouse on a phase class. The cursor changes to a right angle when you move it into the work area.
2. Click inside the work area. An instance of the unit appears.

3. Right-click the mouse button and select the Properties command from the pop-up menu. The Unit Properties dialog box appears.
4. Select the Equipment Capacity tab.
5. In the Amount field, enter the maximum amount the unit can contain, transfer, or process.
6. In the UOM field, enter the unit's unit of measure. Choose from a list of predefined UOMs or enter a new unit of measure and add it to the UNIT_OF_MEASURE enumeration set.

***NOTE:** If you want Proficy Batch Execution to consider a unit's capacity as part of its unit selection criteria, assign the same UOM to (1) all units within the same unit class, and (2) the unit procedure's capacity requirement. If a unit has a different UOM than the UOM specified in the unit procedure's capacity requirement, Proficy Batch Execution ignores the unit's capacity amount as part of the selection criteria.*

Connecting Units

►To link physically connected units together:

1. If you are linking multiple units together, in the Batch Equipment Editor or WorkSpace, click the Manifold button to drop in a manifold object.
2. On the toolbar, click the Link Units button. The cursor changes to indicate that you are in connection mode.
3. Position the cursor over a handle on the origin unit. This highlights the handle.
4. Press and hold the left mouse button down while dragging the pointer from the origin unit to a handle on either the destination unit or manifold object.
5. Release the left mouse button. A connector line appears with the arrow pointing to the destination unit or manifold object.
6. Optionally, configure connection properties.
7. Optionally, configure manifold properties.

Configuring Unit Tags

For information on configuring unit tags, refer to the following sections:

- Configuring Unit Tags
- Configuring Unit Ready and Unit Priority Tags
- Configuring User-Defined Unit Tags
- Adding Unit Tags to the iFIX Database

Configuring Unit Tags

►To configure unit tags:

1. In the Batch Equipment Editor or WorkSpace, in the work area, select the unit instance containing the unit tags you want to define.
2. Right-click the unit and select the Unit Properties. The Unit Properties dialog box appears.

3. Select the Unit Tags tab.
4. Configure Unit Ready and Unit Priority tags.
5. Configure user-defined unit tags.

Configuring Unit Ready and Unit Priority Tags

►To configure Unit Ready and Unit Priority tags:

1. In the Batch Equipment Editor or WorkSpace, in the work area, select the unit instance containing the unit tags you want to define.
2. Right-click the unit and select the Unit Properties. The Unit Properties dialog box appears.
3. Select the Unit Tags tab.
4. In the Unit Ready area, select the appropriate option.
5. In the Unit Priority area, select the appropriate option.
6. If you selected either the Use Unit Ready Tag or Use Unit Priority Tag options, click the Edit Tag button. The Edit Unit Tag dialog box appears.
7. Select the Server for the tag in the Server field.

NOTE: The correct server type must be configured before configuring tags.

8. Enter the OPC tag name or click the browse button next to the Item field to display the Browse OPC Items dialog box. If you are using the iFIX OPC server and the tag you require does not exist, you can add the tag to the database. For more information, refer to the Adding a Unit Tag to the iFIX Database section.

NOTES: (a) The browse functionality is available only if your OPC server supports the browse function as defined in the OPC Specification. GE's OPC server supports the browse function. (b) The correct server type must be configured before configuring tags.

9. Click the plus (+) sign to expand the selected server's tags.
10. Double-click a tag from the list. The tag name appears in the Item field.
11. Click OK to return to the Edit Equipment Phase Tag dialog box.

Configuring User Defined Unit Tags

►To configure user defined unit tags:

1. In the Batch Equipment Editor or WorkSpace, in the work area, select the unit instance containing the unit tags you want to define.
2. Right-click the unit and select the Unit Properties. The Unit Properties dialog box appears.
3. Select the Unit Tags tab.
4. In the User Defined Tags area, click the Add button. The Create Unit Tag dialog box appears.
5. Enter a unique unit tag name in the Name field.

IMPORTANT: Do not use UNITNAME_STATUS or UNITNAME_PRIORITY (where UNITNAME is the actual name of the unit) for the unit tag names because Proficy Batch Execution uses these names internally to represent the Ready and Priority tags, respectively.

These names are reserved.

6. Enter a new tag class in the Tag field or select an existing class using the down-arrow.

Assigning multiple unit tags to the same class across units automatically creates a unit tag class.

7. Click the down-arrow next to the Type field to select the data type.
8. If the tag uses an enumeration data type, select the enumeration set in the Enum field.
9. Enter the tag name or click the browse button next to the Item field to display the Browse OPC Items dialog box. If you are using the iFIX OPC server and the tag you require does not exist, you can add the tag to the database. For more information, refer to the Adding a Unit Tag to the iFIX Database section.

NOTES: (a) *The browse functionality is available only if your OPC server supports the browse function as defined in the OPC Specification. GE's OPC server supports the browse function.* (b) *The correct server type must be configured before configuring tags.*

10. Click the plus sign to expand the selected server's tags.
11. Double-click a tag from the list.
12. The tag name appears in the Item field.
13. Click OK to return to the Edit Equipment Phase Tag dialog box.

Adding a Unit Tag to the iFIX Database

►To add a unit tag to the iFIX database:

1. In the Batch Equipment Editor or WorkSpace, in the work area, select a unit.
2. Right click the unit select Unit Properties. The Edit Unit dialog box appears.
3. Select the Unit Tags tab.
4. For Unit Ready and Unit Priority tags, click the Edit Tag button. For user-defined tags, click the Add button. The Create or Edit Unit Tag dialog box appears.
5. In the Server area, enter the Intellution OPC server in the Name field. Click the down-arrow to select from a list of configured servers.
6. In the Item field, enter the node.tag.field for the tag that you want to add to the database. A message appears indicating that the tag does not exist and asks if you want to add it to the database.
7. Click Yes to add the tag to the new database. The iFIX Add Block dialog box appears.
8. Select the block type you want to add to the database. The selected block's dialog box appears.
9. Configure the block and click OK. The new block is added to the iFIX database and is assigned to the unit tag.

NOTE: *When saving and exiting the WorkSpace, you are prompted to save your changes in the database if a tag was added through the Equipment Editor.*

Maintaining Units

For information on maintaining units, refer to the following sections:

- Deleting Units
- Modifying Units

Modifying Units

►To modify a unit:

1. In the Batch Equipment Editor or WorkSpace, in the work area, click the unit you want to modify.
2. Right-click the unit and select Class Properties. The Edit Equipment Class Properties dialog box appears.
3. Enter you changes and click OK.

Deleting Units

►To delete a unit:

***IMPORTANT:** If this unit is shared, refer to the Deleting a Shared Unit Instance or Deleting a Master Shared Unit section for steps on how to delete. The keyboard Delete button cannot be used to delete a shared instance.*

1. In the Batch Equipment Editor or WorkSpace, in the work area, click the unit you want to delete.
2. Press the Delete key on the keyboard.

***NOTE:** Before you can delete a unit, you must first delete all equipment phases within the unit.*

Configuring Unit Connections

For information on configuring unit connections, refer to the following sections:

- Connecting Units
- Configuring Connection Properties
- Configuring Manifold Properties

Connecting Units

►To link physically connected units together:

1. If you are linking multiple units together, in the Batch Equipment Editor or WorkSpace, click the Manifold button to drop in a manifold object.

2. On the toolbar, click the Link Units button. The cursor changes to indicate that you are in connection mode.
3. Position the cursor over a handle on the origin unit. This highlights the handle.
4. Press and hold the left mouse button down while dragging the pointer from the origin unit to a handle on either the destination unit or manifold object.
5. Release the left mouse button. A connector line appears with the arrow pointing to the destination unit or manifold object.
6. Optionally, configure connection properties.
7. Optionally, configure manifold properties.

Configuring Connection Properties

►To configure properties for connections:

1. In the Batch Equipment Editor or WorkSpace, create the connection.
2. Double-click the connection line. The Connection Properties dialog box appears.
3. In the Name field, enter a name for the connection.
4. Optionally, in the Label field, provide a descriptive label for the connection.
5. Enter any equipment arbitration information.
6. Specify any needed equipment.

Configuring Manifold Properties

►To configure properties for manifolds:

1. In the Batch Equipment Editor or WorkSpace, create a manifold object.
2. Double-click the manifold object. The Manifold Properties dialog box appears.
3. In the Name field, enter a name for the manifold.
4. Select either Vertical or Horizontal orientation.
5. Enter any equipment arbitration information.
6. Specify any needed equipment.

Configuring Equipment Phases

For information on configuring equipment phases, refer to the following sections:

- Configuring the Standard Phase Template
- Configuring the Direct Phase Template
- Overview: Configuring Equipment Phases
- Configuring Equipment Phase Classes

- Configuring Equipment Phase Parameters
- Configuring Equipment Phase Reports
- Configuring Operator Messages
- Configuring Equipment Phase Instances
- Updating the Edit Equipment Phase Dialog Box
- Tying Equipment to the Data
- Adding an Equipment Phase Tag to an iFIX Database
- Assigning OPC Data Items to Standard Equipment Phase Tags
- Editing Enter, Exit, and Status Tags for a State Block in a Direct Phase
- Modifying the Standard Tags for a Direct Phase
- Modifying the Direct Phase tag
- Maintaining Equipment Phases

Configuring the Standard Tag Template

►To configure the Standard Tag Template:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Tag Template. The Standard Phase Template dialog box appears.
2. If you want to change the SCADA node name, enter a new value in the Node field for the Command tag, including the separator – for example, a period (.). This value automatically populates the other Node name fields. Otherwise, click the Use Server Alias button to populate all of the Server name fields with the "#ALIAS#" text. The #ALIAS# syntax allows you to use the Alias configured in the Create OPC Server dialog box.

***NOTE:** To access the Create OPC Server dialog box, on the Edit menu, select Server. Select a server and click Edit, or click Add to add a new one. The dialog that displays after you click Edit or Add will display the Alias field for you to edit. You will want to use the Alias feature when using Proficy Process Systems with Batch Execution.*

3. In the Suffix field, the third column, enter the separator and PLI variable for the standard tags. For example, for the RX7i, you would enter a period (.) before each suffix name, instead of the underscore (_) that appears by default for iFIX.
4. If you want to change the field type for any of the standard tags, in the Extension fields, enter each of your changes in the fourth column. For example, for iFIX the extension for the current value is .F_CV.
5. After you finish making updates, click OK.

Configuring the Direct Phase Template

►To configure the Direct Phase Template:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Direct Tag Template. The Direct Tag Template dialog box appears.
2. From the Direct Tag Template dialog box, select the check box for each state that you want to

enable, by default.

3. To modify the Enter, Exit, and Status tags for the direct phase state blocks, in the Direct Tags group box, click the browse button (...) next to the state block you want to edit. The Direct Phase Tag Template dialog box appears.
4. Enter your changes to the Enter, Exit, and/or Status tags, and click OK.
5. To modify the tag for a standard phase, in the Standard Tags group box, click the browse button (...) next to the standard tag you want to edit. The Tag Template dialog box appears.
6. Enter your changes to the tag or field, and click OK to return to the Direct Phase Template dialog box.
7. To modify the node name for all phases, enter it in the Node field. Otherwise, click the Use Server Alias button to populate all of the Server name fields with the "#ALIAS#" text. The #ALIAS# syntax allows you to use the Alias configured in the Create OPC Server dialog box.

***NOTE:** To access the Create OPC Server dialog box, on the Edit menu, select Server. Select a server and click Edit, or click Add to add a new one. The dialog that displays after you click Edit or Add will display the Alias field for you to edit.*

8. Click OK.

Overview: Configuring Equipment Phases

►To configure equipment phases:

1. In the Batch Equipment Editor or WorkSpace, configure an equipment phase class for every equipment phase required in your process.
2. Configure an instance of each equipment phase class on each unit where the equipment phase executes.
3. Tie each equipment phase instance to the equipment.
4. If the equipment phase is shared by multiple units, share the equipment phase between units.

Configuring Equipment Phase Classes

►To configure an equipment phase class:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click any unit in your process cell. The Create Equipment Phase Class dialog box appears.
2. From the General tab, enter a unique name for the equipment phase class in the Name field. If you are creating a Batch Direct class, consider using a prefix such as BD_ at the beginning of the name.
3. Enter the equipment phase type in the Type field, or leave this field blank.
4. Select an appropriate icon for the equipment phase class.
5. For standard phases only, enter the number of:
 - Request tags required by this equipment phase class.
 - Phase partners required by this equipment phase class.

***NOTE:** Both of these fields are unavailable for direct phases. Direct phases do not support message partners.*

6. Select the Parameters tab and configure any phase parameters required by the equipment phase class.
7. Select the Reports tab and configure any phase reports required by the equipment phase class.
8. For standard phases only, select the Operator Messages tab and configure any operator messages required by the equipment phase class.
9. For direct phases only, select the Enable Tags tab and enable any tags required by the direct phase class.

NOTE: The Enable Tags tab is only available for direct phases. Similarly, the Operator Messages tab only appears in the dialog box for standard phases.

Configuring Equipment Phase Parameters

►To configure equipment phase parameters:

1. In the Batch Equipment Editor or WorkSpace, in the Create or Edit Equipment Phase Class dialog box, or Direct Phase Class dialog box, select the Parameters tab.
2. Click the Add button. The Edit Phase Parameter dialog box appears.
3. In the Name field, enter a unique, meaningful name.
4. In the ID field, enter a unique ID. This ID must match the ID used by the phase logic.
5. Click the down-arrow and select the phase parameter's data type.
6. For integer and real parameters: enter the engineering units in the Eng Units field, enter the high, low, and default values, and, if appropriate, check the Scale check box to enable scaling.
7. For string parameters: in the Eng Units field enter the engineering units, and in the Default field enter a default value.
8. For enumeration parameters: click the down-arrow next to the Enum field and select the parameter's enumeration set. Then, click the down-arrow next to the Default field and select the default enumeration value.
9. Click OK.

Configuring Equipment Phase Reports

►To configure phase reports:

1. In the Batch Equipment Editor or WorkSpace, in the Create or Edit Equipment Phase Class dialog box, or Direct Phase Class dialog box, select the Reports tab.
2. Click the Add button. The Edit Phase Report dialog box appears.
3. In the Name field, enter a unique, meaningful name.
4. In the ID field, enter a unique ID. This ID must match the ID used by the phase logic.
5. Click the down-arrow and select the phase report's data type.
6. For real, integer, and string reports: enter the engineering units in the Eng Units field.
7. For enumeration reports: click the down-arrow next to the Enum field and select the report's enumeration set.
8. Click OK.

Configuring Operator Messages

►To configure phase operator messages for standard phases:

1. In the Batch Equipment Editor or WorkSpace, in the Create or Edit Equipment Phase Class dialog box, select the Operators Messages tab.
2. Click the Add button. The Edit Operator Message dialog box appears.
3. In the Name field, enter the text of the operator message.
4. In the ID field, enter a unique ID. This ID must match the ID used by the phase logic.
5. Click OK.
6. For each operator message you configure, increment the Request field by one.

Configuring Equipment Phase Instances

►To configure an equipment phase instance:

1. In the Batch Equipment Editor or WorkSpace, make sure that a server is configured.
2. In the Equipment folder, double-click the unit to which you want to add the equipment phase.
3. Select the appropriate equipment phase class from the Phase Classes area.
4. Move the cursor to the work area. The cursor changes to a right angle.
5. Click the left-mouse button. An instance of the equipment phase appears.
6. Double-click the equipment phase instance. The Edit Equipment Phase dialog box appears.
7. In the Name field, enter a unique name. If you are creating a Batch Direct class, consider using a prefix such as BD_ at the beginning of the name.
8. Click the Server button to select a data server for the equipment phase tags.
9. Double-click an item in the list box to modify the associated tag (standard phase) or tags (direct phase).
10. Enter any equipment arbitration information.
11. Specify any needed equipment.
12. Click OK.

Updating the Edit Equipment Phase Dialog Box

►To update the Edit Equipment Phase dialog box:

1. In the Batch Equipment Editor or WorkSpace, right-click the phase and select Equipment Phase Properties. The Edit Equipment Phase dialog box appears.
2. In the Name field, enter a unique name. If you are creating a Batch Direct class, consider using a prefix such as BD_ at the beginning of the name.
3. Click the Server button to select a data server for the equipment phase tags.
4. Double-click an item in the list box to modify the associated tag (standard phase) or tags (direct phase).

5. Enter any equipment arbitration information.
6. Specify any needed equipment.
7. Click OK.

Tying Equipment to the Data

►To tie equipment to the data:

1. In the Batch Equipment Editor or WorkSpace, define the OPC data server.
2. Assign the OPC data server to equipment phase tags.
3. Assign the OPC items to the standard equipment phase tags.
4. Additionally, if you are configuring a direct phase, assign the Enter, Exit, and Status tags for the direct phase state blocks (Running, Holding, Held, Restarting, Stopping, or Aborting).

Adding an equipment phase tag to an iFIX Database

►To add an equipment phase tag to an iFIX database:

1. In the Batch Equipment Editor or WorkSpace, double-click the equipment phase. The Edit Equipment Phase dialog box appears.
2. Assign the Intellution OPC server to the equipment phase tags.
3. In the Equipment Phase Tags list box, double-click the equipment phase tag. The Edit Equipment Phase Tag dialog box appears.
4. In the Item field, enter the node.tag.field for the tag that you want to add to the database. A message appears indicating that the tag does not exist and asks if you want to add it to the database.
5. Click Yes to add the new tag to the database. The iFIX Add Block dialog box appears.
6. Select the block type you want to add to the database. The selected block's dialog box appears.
7. Configure the block and click OK. The new block is added to the iFIX database and is assigned to the selected equipment phase tag.

***NOTE:** When saving and exiting the WorkSpace, you are prompted to save your changes in the iFIX database if a tag was added through the Equipment Editor.*

Assigning OPC Data Items to Equipment Phase Tags

►To assign an OPC item to a standard equipment phase tag:

1. In the Batch Equipment Editor or WorkSpace, double-click the equipment phase. The Edit Equipment Phase dialog box appears.
2. In the list box, double-click the equipment phase tag. The Edit Equipment Phase Tag dialog box appears.
3. Enter the OPC tag name or click the ? button next to the Item field to display the Browse OPC Items dialog box. If you are using the iFIX OPC server and the tag you require does not exist,

you can add the tag to the database. For more information, refer to the Adding an equipment phase tag to an iFIX Database section.

NOTE: *The browse functionality is available only if your OPC server supports the browse function as defined in the OPC Specification. GE's OPC server supports the browse function.*

4. Click the plus sign (+) to expand the database.
5. Double-click a tag from the list. The tag name appears in the Item field.
6. Click OK to return to the Edit Equipment Phase Tag dialog box.
7. Click OK.

Editing the Enter, Exit, and Status tags for a State Block in a Direct Phase

►To edit the Enter, Exit, and Status tags for a state block in a direct phase:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Direct Tag Template. The Direct Tag Template dialog box appears.
2. In the Direct Tags group box, click the browse button (...) next to the state block you want to edit. The Direct Phase Tag Template dialog box appears.
3. For each tag, enter any changes to the tag suffix, field, or value:

If you want the Status tag to have the same address as the Enter tag, select the Same as Enter tag check box. Be aware that for the Status tag you can also change the operator from = to another logical operator from the drop-down list.

If you want the Exit tag to use the same address as the Enter tag, but invert the active level, select the Inverse of the Enter tag check box. For instance, if the Enter tag is equal to 1, the Exit tag would be set to 0.

4. Click OK.

NOTE: *You cannot edit the Node or Phase fields from the Direct Phase Tag Template dialog box. To change the node name, change the Node field from the Direct Phase Template dialog box. Be aware that the Phase name field is just a placeholder for information that gets added when you actually add the phase; the Phase name field gets modified when you add or modify equipment phases in the Equipment Editor.*

Modifying the Standard Tags for a Direct Phase

►To edit a standard phase tag for a direct phase:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Direct Tag Template. The Direct Tag Template dialog box appears.
2. Select the browse (...) next to the standard tag that you want to edit. The Tag Template dialog box appears.
3. If you want to change the tag name, enter the change in the third field.
4. If you want to change the tag type, enter the change in the fourth field.
5. Click OK.

NOTE: *You cannot edit the Node or Phase fields from this dialog box. To change the node*

name, change the Node field from the Direct Phase Template dialog box. Be aware that the Phase name field is just a placeholder for information that gets added when you actually add the phase; the Phase name field gets modified when you add or modify equipment phases in the Equipment Editor.

Modifying the Direct Phase Tags in the Template

►To edit the direct phase tags in the template:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Direct Tag Template. The Direct Tag Template dialog box appears.
2. In the Direct Tags group box, click the browse button (...) next to the state block you want to edit. The Direct Phase Tag Template dialog box appears.
3. Enter the tags and values for the Enter, Exit, and Status tags. Click the browse button (...) to browse tags from your OPC server software, if it's available.

If you want the Status tag to have the same address as the Enter tag, select the Same as Enter tag check box. Be aware that for the Status tag you can also change the operator from = to another logical operator from the drop-down list.

If you want the Exit tag to use the same address as the Enter tag, but invert the active level, select the Inverse of the Enter tag check box. For instance, if the Enter tag is equal to 1, the Exit tag would be set to 0.

4. Click OK.

Maintaining Equipment Phases

For information on maintaining equipment phases, refer to the following sections:

- Editing Equipment Phase Tags
- Resetting Equipment Phase Tag Items to the Proficy Batch Execution Defaults
- Enabling Tags
- Modifying Equipment Phase Classes
- Deleting Equipment Phase Classes

Editing Equipment Phase Tags

►To edit all equipment phase tags:

1. In the Batch Equipment Editor or WorkSpace, on Edit menu, click Tags. The Edit Tags dialog box appears.
2. Select the tag class type for the equipment phase tags you want to edit. All equipment phase tags for the selected tag class appear in the Tags list box.
3. In the Tags list box, select the tag you want to edit.
4. Click the Edit Tag button to edit the tag.

Resetting Equipment Phase Tag Items to the Proficy Batch Execution Defaults

►To reset tag items to the Proficy Batch Execution default names:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click the equipment phase instance. The Edit Equipment Phases dialog box appears.
2. Click the Default button. All tags are renamed to the Proficy Batch Execution defaults.

Enabling Tags for Direct Phases

►To enable tags for direct phases:

1. In the Batch Equipment Editor or WorkSpace, click the Add Batch Direct Phase icon, or double-click the batch direct phase class in the Phase Classes area. The Create or Edit Direct Equipment Phase dialog box appears.
2. Select the Enable Tags tab.
3. Select the check box next to each state block that you want to enable tags for.

***NOTE:** Only the Running state block is required. As such, the check box is not available; you cannot clear the check box next to the Running state block.*

4. Click OK.

Modifying Equipment Phase Classes

►To modify an equipment phase class:

1. In the Batch Equipment Editor, in the Phase Classes area, double-click the equipment phase class that you want to modify. The Edit Equipment Phase Class dialog box appears.
2. If necessary, modify the name for the equipment phase class in the Name field.
3. If necessary, modify the equipment phase type in the Type field, or leave this field blank.
4. If necessary, select an appropriate icon for the equipment phase class.
5. If necessary, for standard phases only, modify the number of:
 - Request tags required by this equipment phase class.
 - Phase partners required by this equipment phase class.

***NOTE:** Both of these fields are unavailable for direct phases. Direct phases do not support message partners.*

6. If necessary, configure any phase parameters required by the equipment phase class. For more information, refer to the Configuring Equipment Phase Parameters section.
7. If necessary, configure any phase reports required by the equipment phase class. For more information, refer to the Configuring Equipment Phase Reports section.
8. If necessary, for standard phases only, configure any operator messages required by the equipment phase class. For more information, refer to the Configuring Operator Messages section.

9. If necessary, for direct phases only, enable any tags required by the direct phase class. For more information, refer to the Enabling Tags for Direct Phases section.

NOTE: The Enable Tags tab is only available for direct phases. Similarly, the Operator Messages tab only appears in the dialog box

Deleting Equipment Phase Classes

►To delete an equipment phase class:

1. In the Batch Equipment Editor, in the Phase Classes area, select the equipment phase class that you want to delete.
2. Press the Delete key.

NOTE: Before you can delete a phase class, you must first delete all its associated equipment phases.

Configuring Control Modules

For information on configuring control modules, refer to the following sections:

- Configuring Control Modules
- Deleting Control Modules
- Modifying Control Modules

Configuring Control Modules

►To configure control modules:

1. In the Batch Equipment Editor or WorkSpace, on Edit menu, click Control Modules. The Edit Control Modules dialog box appears.
2. In the Classes area, click the Add button. The Add Control Module Class dialog box appears.
3. Enter a unique name for the control module class and click OK.
4. Select the control module class to which you want to add a control.
5. In the Control Modules area, click the Add button. The Add Control Module dialog box appears.
6. Enter a unique name for the control module in the Name field.
7. Enter any equipment arbitration information.
8. Specify any needed equipment.

Deleting Control Modules

►To delete control modules:

1. In the Batch Equipment Editor or WorkSpace, on Edit menu, click Control Modules. The Edit Control Modules dialog box appears.
2. In the Control Module Class list box, select the class containing the control module you want to delete.
3. In the Control Modules list box, select the control module you want to delete.
4. Click Delete. The resource is removed from the Control Modules list box.

Modifying Control Modules

►To modify control modules:

1. In the Batch Equipment Editor or WorkSpace, on Edit menu, click Control Modules. The Edit Control Modules dialog box appears.
2. In the Control Module Class list box, select the class containing the control module you want to modify.
3. In the Control Modules list box, double-click the control module you want to modify.
4. Modify the name or arbitration information as appropriate.

Configuring Enumerations

For information on configuring enumerations, refer to the following sections:

- Overview: Configuring Enumerations
- Defining Enumeration Sets
- Defining Enumerations
- Modifying Enumeration Set Names
- Configuring the UNIT_OF_MEASURE Enumeration Set
- Deleting Enumeration Sets

Overview: Defining Enumerations

►To define enumerations:

1. Define enumeration sets:
 - a. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Enumeration Sets. The Create Enumerations Sets and Enumerations dialog appears.
 - b. In the Sets area, click the New button. The Create Enumeration Set dialog appears.
 - c. Enter a unique name for the enumeration set in the Enumeration Set field.

- d. Click OK.
2. Define enumeration strings and their corresponding ordinal values:
 - a. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Edit Enumerations. The Create Enumerations Sets and Enumerations dialog box appears.
 - b. Click the appropriate enumeration set.
 - c. In the Enumerations area, click the New button. The Create Enumeration dialog box appears.
 - d. In the Enumeration field, enter a unique, meaningful name.
 - e. In the Ordinal field, enter the corresponding numeric value. This value must match the value defined in phase logic.
 - f. Click OK.

***NOTE:** Proficy Batch Execution supplies two predefined enumeration sets: PHASE_FAILURES and UNIT_OF_MEASURE. These sets are required by Proficy Batch Execution and cannot be deleted.*

Defining Enumeration Sets

►To define enumeration sets:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Enumeration Sets. The Create Enumerations Sets and Enumerations dialog appears.
2. In the Sets area, click the New button. The Create Enumeration Set dialog appears.
3. Enter a unique name for the enumeration set in the Enumeration Set field.
4. Click OK.

Defining Enumerations

►To define enumerations:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Enumeration Sets. The Create Enumerations Sets and Enumerations dialog box appears.
2. Click the appropriate enumeration set.
3. In the Enumerations area, click the New button. The Create Enumeration dialog box appears.
4. In the Enumeration field, enter a unique, meaningful name.
5. In the Ordinal field, enter the corresponding numeric value. This value must match the value defined in phase logic.
6. Click OK.

Modifying Enumeration Set Names

►To modify an enumeration set name:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Enumeration Sets. The Create Enumeration Sets and Enumerations dialog box appears.
2. Click the appropriate enumeration set.
3. Enter the new name for the enumeration set.
4. Click OK.

NOTE: You cannot modify the names of the UNIT_OF_MEASURE or PHASE_FAILURES

Configuring the UNIT_OF_MEASURE Enumeration Set

►To configure the UNIT_OF_MEASURE enumeration set:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Enumeration Sets. The Create Enumerations Sets and Enumerations dialog box appears.
2. In the Enumeration Sets list box, select the UNIT_OF_MEASURE enumeration set. A list of the existing units of measure appear in the Enumerations list box.
3. To add a new unit of measure, in the Enumerations area, click New.
4. To edit an existing unit of measure, in the Enumerations list box, select the unit of measure and click Edit.
5. To delete a unit of measure, in the Enumerations list box, select the unit of measure and click Delete.

NOTE: You cannot delete a unit of measure that is currently assigned to a unit. First, assign a different unit of measure to the unit and then you can delete the unused unit of measure.

Deleting Enumeration Sets

►To delete an enumeration set:

1. In the Batch Equipment Editor or WorkSpace, on the Edit menu, click Enumeration Sets. The Create Enumeration Sets and Enumerations dialog box appears.
2. Click the appropriate enumeration set.
3. In the Sets area, click the Delete button.

NOTE: You must delete all enumerations within an enumeration set before you can delete the enumeration set.

4. Click Yes when prompted for confirmation.
5. Click OK.

NOTE: You cannot delete the UNIT_OF_MEASURE or PHASE_FAILURES enumeration sets.

Configuring Arbitration

For information on configuring arbitration, refer to the following sections:

- Configuring Equipment Arbitration
- Configuring Needed Equipment

Configuring Arbitration

►To configure arbitration:

1. In the Batch Equipment Editor or WorkSpace, in the work area, select the piece of equipment for which you need to define arbitration settings.
2. Right-click the equipment, select Properties. The Edit or Properties dialog box for the equipment instance appears.

NOTE: For control modules, select the Edit Control Modules button on the toolbar and double click the control module.

3. In the Equipment ID field, enter a unique ID. Proficiency Batch Execution assigns a default unique ID.

NOTE: If your phase logic performs requests to acquire and release this equipment, it must match the ID in the phase logic.

4. In the Max Owners field, enter the maximum number of owners that can simultaneously use this piece of equipment.

NOTE: If the equipment phase is shared, you need to set the Max Owners field to 1 in the Edit Equipment Phase dialog box.

Configuring Needed Equipment

►To assign needed equipment:

1. In the Batch Equipment Editor or WorkSpace, in the work area, select the equipment entity you want to assign needed equipment.
2. Right-click the equipment and select Properties. The Edit dialog box for the equipment instance appears.

NOTE: For control modules, select the Edit Control Modules button on the toolbar and double-click the control module.

3. In the arbitration area, click the Add button. The Select Equipment dialog appears.
4. Click the plus sign (+) next to the folder containing the required equipment. The folder expands listing all the configured equipment.
5. Double-click the required equipment. The selected equipment appears in the Needed list.
6. Click OK.

Configuring Shared Resources

For information on configuring shared resources, refer to the following sections:

- Sharing Resources
- Sharing Units Between Process Cells
- Sharing Equipment Phases Between Units
- Defining a Master Process Cell for Shared Units
- Deleting a Master Shared Unit
- Deleting a Shared Unit Instance

Sharing Resources

►To share a unit between process cells:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click the process cell to which you want to add the shared unit.
2. Click the Share button on the Equipment Editor toolbar, or from the Edit menu, click Share Unit. The Share Unit dialog box appears.
3. Click the plus sign (+) next to the process cell containing the unit that you want to share. The folder expands listing all of the configured units.
4. Select the unit you want to share, and click OK.
The unit appears in the work area. A share icon displays beneath the unit to indicate it is shared.
5. Define a master process cell for the shared units:
 - a. Right-click the shared unit and select Unit Properties. The Unit Properties dialog box appears.
 - b. On the General tab, in the Master Process Cell drop-down list, select a process cell to designate as the master (primary) process cell for the shared units.

After you select a master for this shared unit, all shared instances of this unit are updated with the master process cell name.

►To share an equipment phase between units:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click the unit to which you want to add the shared equipment phase.
2. Click the Share button on the Equipment Editor toolbar, or from the Edit menu, click Share Equipment Phase. The Share Equipment Phase dialog box appears.
3. Click the plus sign (+) next to the unit containing the equipment phase you want to share. The folder expands listing all of the configured equipment phases.
4. Select the equipment phase you want to share, and click OK.
5. The equipment phase appears in the work area. A share icon displays beneath the equipment phase to indicate it is shared.

Sharing Units Between Process Cells

►To share a unit between process cells:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click the process cell to which you want to add the shared unit.
2. Click the Share button on the Equipment Editor toolbar, or from the Edit menu, click Share Unit. The Share Unit dialog box appears.
3. Click the plus sign (+) next to the process cell containing the unit that you want to share. The folder expands listing all of the configured units.
4. Select the unit you want to share, and click OK.

The unit appears in the work area. A share icon displays beneath the unit to indicate it is shared.

5. Define a master process cell for the shared units:
 - a. Right-click the shared unit and select Unit Properties. The Unit Properties dialog box appears.
 - b. On the General tab, in the Master Process Cell drop-down list, select a process cell to designate as the master (primary) process cell for the shared units.

After you select a master for this shared unit, all shared instances of this unit are updated with the master process cell name.

Sharing Equipment Phases Between Units

►To share an equipment phase between units:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click the unit to which you want to add the shared equipment phase.
2. Click the Share button on the Equipment Editor toolbar, or from the Edit menu, click Share Equipment Phase. The Share Equipment Phase dialog box appears.
3. Click the plus sign (+) next to the unit containing the equipment phase you want to share. The folder expands listing all of the configured equipment phases.
4. Select the equipment phase you want to share, and click OK.

The equipment phase appears in the work area. A share icon displays beneath the equipment phase to indicate it is shared.

Defining a Master Process Cell for Shared Units

►To define a master process cell for your shared units:

1. In the Batch Equipment Editor or WorkSpace, in the work area, double-click the process cell that contains the unit that you want to become the master.
2. Right-click the unit and select Unit Properties. The Unit Properties dialog box appears.
3. On the General tab, in the Master Process Cell drop-down list, select the process cell to designate as the master (primary) process cell for the shared units.

After you select a master for this shared unit, all shared instances of this unit are updated with the master process cell name.

Deleting a Master Shared Unit

►To delete a master unit:

***NOTE:** When you remove a master unit that is shared amongst process cells, all instances of that unit are removed. If you do not delete all the equipment phases before attempting to remove the master unit, then the removal fails and the system displays an error message.*

1. In the Batch Equipment Editor or WorkSpace, delete all equipment phases within the unit.
2. In the work area, click the master shared unit you want to delete.
3. On the Edit menu, select Delete Unit. A confirmation message box appears.
4. Click Yes to continue. The master and all instances of that unit are deleted from your project.

Deleting a Shared Unit Instance

►To delete an instance of a shared unit:

1. In the Batch Equipment Editor or WorkSpace, in the work area, click the unit you want to delete.
2. On the Edit menu, select Remove Shared Unit.

Index

A

Active Binding	
and equipment capacity	10
and equipment pathing	10
and unit status tags.....	10
implementing.....	10
overview	2
Active Binding	2
Add Control Module dialog box.....	86
Add Control Modules Class dialog box.....	87
adding	
iFIX database tags	50
adding.....	50
advanced topics	77
arbitration	78
area models	
configuration tasks.....	25
defining.....	33
example	33
exporting.....	14
importing	14
merging.....	14
understanding	14
area models.....	14
areas.....	33

arrow buttons	15
---------------------	----

Audit Information dialog box	87
------------------------------------	----

B

Batch Direct equipment phases	
class properties	73
configuration prerequisites	53
configuring	70
differences between direct and standard phases	56
Enter, Ext, and Status tags	66
FAQ	76
how they work	63
naming convention	71
OPC data server.....	69
PLI structure	54
state blocks	64
template	71
understanding.....	63
user interface locations	59
Batch Direct equipment phases	52
Batch Direct PLI structure	54
Batch Execution.....	3
batch size	
unit of measure	29
batch size	29

Browse OPC Items dialog box	89	operator messages	46
C		process cells (overview)	34
capacity		scalable parameters	83
unit	11	shared equipment	78
capacity	11	units (overview)	35
CFG file	14	configuring	35
class properties, Batch Direct	73	connecting units	36
class-based equipment design	9	Connection Properties dialog box	90
class-based recipes		control modules	
configuring equipment for	9	as common resources	7
class-based recipes	9	configuring	77
class-based unit strategy	34	control modules	77
classes window	15	Create Direct Equipment Phase Class dialog box	91
Client changes for Batch Direct	61	Create Enumeration dialog box	93
combinations of tags	66	Create Enumeration Set dialog box	94
common resource		Create Enumeration Sets and Enumerations dialog box	94
control module	7	Create Equipment Phase Class dialog box	95
equipment phase	7	Create OPC Server dialog box	98
example	7	Create Process Cell Class dialog box	99
identifying	7	Create Unit Class dialog box	99
common resource	7	Create Unit Tag dialog box	100
configured classes window	15	customizing the Equipment Editor	15
configuring		D	
arbitration	78	data servers	
area models	25	supported types	50
control modules	77	data servers	50
enumerations	26	DDE data server	50
equipment phases (overview)	42		

defining	
area models.....	33
areas.....	33
enumeration strings	29
equipment guidelines.....	5
process cells.....	33
units	34
defining.....	34
destination unit	36
device failures.....	29
differences between standard and direct phases	56
Direct Phase Tag Template dialog box.....	101
Direct Tag Template dialog box.....	104
E	
Edit Area dialog box.....	106
Edit Control Modules dialog box	106
Edit Direct Phase Tags dialog box	110
Edit Enumeration In dialog box.....	113
Edit Enumeration Set Name dialog box	113
Edit Equipment Phase Class dialog box .	107, 113
Edit Equipment Phase dialog box.....	116
Edit Equipment Phase Tag dialog box.....	118
Edit Operator Message dialog box	119
Edit Phase Parameter dialog box	119
Edit Phase Report dialog box	120
Edit Process Cell Class dialog box.....	121
Edit Process Cell dialog box.....	121
Edit Servers dialog box.....	122
Edit Tags dialog box.....	124
Edit Unit Class dialog box	124
Edit Unit Tag dialog box	124
EGU ranges	50
Enable Tags tab	73
Enter, Exit, and Status tags	66
Enumeration Set Modification dialog box.....	126
enumeration sets	
UNIT_OF_MEASURE.....	29
enumeration sets	29
enumerations	
example.....	27
implementation tasks	26
maintaining	31
prerequisites.....	30
understanding.....	26
enumerations.....	26
equipment	
arbitration	78
binding.....	2
common	7
configuration pre-requisites	16
IDs	79
maintaining	9
needed.....	79
partitioning	4
shared.....	7

equipment	7	equipment status	11
equipment capacity		equipment status tags	10
configuration guidelines	38	examples	
configuring units	34	Active Binding	11
example	38	area model	33
implementing	11	class-based units	9
overview	10	common resources	7
unit of measure	29	configuring units	35
equipment capacity	29	defining the MIXER unit	6
equipment definition guidelines	5	enumerations	27
Equipment Editor		equipment arbitration	79
benefits	1	equipment capacity	38
overview	1	equipment pathing	21
window	15	equipment phase reports	46
Equipment Editor	15	equipment phases	18
Equipment editor changes for Batch Direct	60	multi-product process cell	21
equipment pathing		network-path process cell	21
configuring units	34	operator messages	46
example	21	P&ID drawing	17
guidelines	10	PHASE_FAILURES enumeration set	29
implementing	10	process cells	34
overview	10	sample application equipment	
equipment pathing	10	configuration	17
equipment phase configuration (overview)	42	sample application equipment hierarchy	18
equipment phases	41	unit tag classes	80
equipment status		UOMs	38
example	11	examples	38
implementing	11	exclusive-use resources	7

execution paths	21	L	
exporting area models.....	14	linking units	36
F		location bar	15
FAQ, Batch Direct.....	76	M	
File Export As dialog box.....	126	Manifold Properties dialog box	129
File Import dialog box	127	manifolds	36
G		maximum number of owners	79
guidelines for defining equipment	5	merging area models.....	14
I		multi-product process cell.....	5
I/O, equipment phases	48	N	
iFIX		navigation tools	15
viewing data in	2	needed equipment	3
iFIX	2	NetDDE data	
iFIX database tags	50	server	50
implementing		NetDDE data	50
class-based designs.....	9	O	
class-based units	9	object linking and embedding.....	2
implementing.....	9	OLE for process control	2
importing		OPC data	
area models.....	14	server	50
importing	14	OPC data.....	50
ingredient type, specifying	26	OPC data server.....	2
ISA S88.01		open architecture.....	2
Batch Control Models and Terminology	2	operator messages.....	46
Physical Model	3	origin unit	36
ISA S88.01	3	overview, direct phases.....	70
J		owners, maximum number	79
Jacobson Links	10		

P

P&ID drawing	17
parameters (standard phase)	
data types	44
equipment phases.....	44
re-configuring	32
parameters (standard phase)	32
partitioning	
plant equipment	4
process cells.....	5
units	6
partitioning	6
partners, equipment phases.....	48
PHASE_FAILURES enumeration set	29
prerequisites, Batch Direct	53
Print Setup dialog box	130
priority status for units.....	81
process cells	
configuring (overview)	34
defining.....	33
multiple path structure	5
network structure	5
partitioning	5
single path structure.....	5
structure	5
process cells.....	5
process controller	16
Proficy Batch Execution WorkSpace	15

R

ready status for units.....	81
recipe development.....	3
Recipe Editor, changes for Batch Direct	61
recipes	
class-based	9
equipment capacity UOM.....	29
recipes.....	29
reports	
standard phases	46
reports	46
request functions.....	48
resizing the Equipment Editor window	15
resources	
common	7
resources	7
S	
S88.01	2
scalable parameters.....	83
scaling equipment phase parameters.....	44
Select Directories dialog box	131
Select Equipment dialog box	131
Select HMI Picture dialog box	128, 132
Set Tag Server dialog box.....	133
Share Equipment Phase dialog box	133
Share Unit dialog box	133
shared equipment	7
shared-use resources	7

single-product process cell	5	T	
specifying an ingredient type.....	26	Tag Template dialog box	142
standard equipment phases		tags	
class properties	44	equipment phases.....	48
classes	41	tags.....	48
common resources	7	template	
configuration prerequisites	41	direct phase	52
configuring	40	standard phase.....	43
example	18	toolbar.....	15
I/O.....	48	tying equipment phases to equipment.....	48, 74
iFIX database tags	50	U	
instances	41	unit capacity.....	11
operator messages.....	46	unit design	6
parameters	44	unit of measure	
partners	48	default batch size	29
reports.....	46	equipment capacity	29
requests	48	recipe's capacity requirement.....	29
tags	48	unit of measure	29
template	43	Unit Priority	
understanding	41	setting a static value for	81
standard equipment phases	41	tag	10
Standard Phase Template dialog box.....	134	Unit Priority.....	34
state blocks, Batch Direct phase	64, 66	Unit Properties dialog box	142
status		unit ready	
equipment	11	setting a static value for	81
status.....	11	tag	10
status bar.....	15	tags.....	34
synchronization	48	using a tag.....	11

unit ready	11	partitioning	6
unit tags		status	10
UNIT_PRIORITY	40	Unit Priority	34
UNIT_READY	40	Unit Ready	34
unit tags	40	UNIT_PRIORITY tag	81
UNIT_OF_MEASURE		UNIT_READY tag	81
enumeration set	29	using manifolds	36
UNIT_OF_MEASURE	29	units	36
UNIT_PRIORITY tag	40	UOM	
UNIT_READY tag	40	equipment capacity	38
units		UOM	38
configuring (task overview)	35	using the graphical interface	15
connecting	36	using the toolbar	15
defining	34	W	
design strategies	34	work area	15
destination	36	WorkSpace	
equipment capacity	34	system tree	15
equipment pathing	34	WorkSpace	15
linking	36	Z	
origin	36	Zoom dialog box	146