



Thickness Monitoring



Contents

Chapter 1: Overview	1
Overview of the Thickness Monitoring (TM) Module	2
Access the Thickness Monitoring Overview Page for a Selected Hierarchy Level	2
Access the Thickness Monitoring Overview Page for all Hierarchy Levels	3
Thickness Monitoring (TM) Workflow	4
Chapter 2: Workflows	5
Thickness Monitoring Planning Workflow	6
Thickness Monitoring: Thickness Assessment Workflow	10
Thickness Monitoring Piping Rotation Workflow	13
Chapter 3: Corrosion Analyses in Thickness Monitoring	17
About Corrosion Analyses in Thickness Monitoring	18
About the Types of Corrosion Analyses	18
About Corrosion Analysis Settings	19
About Thickness Monitoring Tasks	20
About Archived Asset Corrosion Analyses	21
About Bulk Analysis	21
About the Remaining Life Graph	22
Create Corrosion Analysis Settings	22
Access the Analysis Overview Workspace	23
Access the Remaining Life Graph	24
Modify Corrosion Analysis Settings	24
Calculate a Corrosion Analysis	25
Perform a Bulk Analysis	26
Archive an Asset Corrosion Analysis	27
Delete an Asset Corrosion Analysis	27
Review Archived Analyses	28
Reset Maximum Historical Corrosion Rate (MHCR)	28

Chapter 4: TMLs	29
About Thickness Measurement Locations (TMLs)	31
About Renewing Thickness Measurement Locations (TMLs)	31
About Moving Thickness Measurement Locations (TMLs)	31
Access a Thickness Measurement Location (TML)	32
Filter Thickness Measurement Locations (TMLs)	33
Create a Thickness Measurement Location (TML)	34
Configure the Thickness Monitoring Location (TML) Section	34
Copy Thickness Measurement Locations (TMLs)	35
Relocate a Thickness Measurement Location (TML)	35
Renew Thickness Measurement Locations (TMLs)	36
Organize Thickness Measurement Locations (TMLs)	36
Exclude a Thickness Monitoring Location (TML)	37
Access the TM Quick View Page	38
Modify TMLs in Bulk	39
Access the TML Trends Graph	39
Define Allowable Stress	40
Calculate Allowable Stress	40
Make a Thickness Measurement Location (TML) Inactive	41
Delete a Thickness Measurement Location (TML)	41
Chapter 5: TML Groups	43
About TML Groups	44
About Equipment and TML Groups	45
About Corrosion Analyses that Include TML Groups	46
About Corrosion Analyses that Exclude TML Groups	48
About TML Groups and RBI Components	50
Create a TML Group	50
Link a TML Group to RBI Components	51
Delete a Thickness Monitoring Location (TML) Group	51
Chapter 6: Thickness Measurements	53
About Thickness Measurements	54

About Nominal and Actual Measurements	54
About Skipped Measurements	55
How Measurement Values Are Determined	58
About Measurement and Corrosion Rate Variance	59
About Measurement and Corrosion Rate Variance Validation	59
About Measurement Correction Based on Growth	59
Access Thickness Measurements	61
Add a Thickness Measurement	63
Add a Nominal Measurement	63
Create Measurement Not Taken (MNT) Records	64
Modify a Thickness Measurement	65
Use the Measurement Data Entry (MDE) Workspace	65
Delete a Thickness Measurement	66
Chapter 7: T-Min Calculations	67
About T-Min Calculations	68
About the Calculated T-Min Value using Policy	68
About the Calculated T-Min Value using Formula	68
About Nominal Allowance	68
About Default T-Min	68
About User-Defined T-Min	68
About the Results of a T-Min Calculation	69
About the Calculation Details	69
About TML Calculation Details	69
Calculate Minimum Thickness (T-Min)	69
View T-Min Calculation History	70
T-Min Calculations	71
Chapter 8: Schematic View	74
About Schematic View	75
About Schematic Image Adapting to Updated Source Reference Document	75
Access the Thickness Monitoring Schematic View	75
Plot a TML in the Schematic View	76
Unplot a TML in the Schematic View	76
Replot a TML in the Schematic View	77

Search a TML in the Schematic Sidebar	77
Open a TML Pop-Up in the Schematic View	77
Delete Plotted TMLs on a Schematic Image	78
Swap a Schematic Image	78
Download a Schematic Image	79
Turn TML Label Visibility On or Off	79

Chapter 9: Piping Rotation and Flip **80**

About Piping Rotation and Flip	82
About Piping Asset Hierarchy	82
Types of Piping Components	82
Types of Bands	83
About Positions	85
About Rotation of Straight Spools	85
About Flipping of Straight Spools	86
About Flipping of Elbows	88
About Undo Movement	91
About Calculation of Nominal Measurement	91
About Corrosion Rate Methods	91
About Heat Maps	92
About Alert Levels	92
Create Corrosion Analysis Settings for a Piping Asset	94
Create a Component	94
Create a Band	95
Copy a Component	96
Copy a Band	97
Access Trends Graphs for a Piping Band	98
Rotate a Straight Spool	98
Flip a Piping Component	99
Rotate or Flip Multiple Spools	100
Access the Piping Rotation or Flip History	101
Undo Last Rotation or Flip	102
Create a What-If Scenario	102
Access What-If Scenarios	104
Perform Rotation or Flip from a What-If Scenario	104

Chapter 10: Thickness Monitoring Export	105
About Thickness Monitoring Export	106
Access the Thickness Monitoring Export Workspace for a Single Asset	108
Access the Thickness Monitoring Export Workspace for Multiple Assets	108
Export TMLs	109
Chapter 11: Dataloggers in Thickness Monitoring	111
About Dataloggers in Thickness Monitoring (TM)	112
Access the TM Dataloggers Page for an Asset or TML Group	112
Access the TM Dataloggers Page for Multiple Assets	113
Modify Datalogger Settings	113
Send Data to a Datalogger	114
Receive Data from a Datalogger	116
Chapter 12: Data Loaders	118
TM Data Loaders	119
Thickness Measurement - Assets Data Loader	160
TM Piping Data Loaders	165
Chapter 13: Admin	215
Global Preferences	216
Family Preferences	227
Datalogger Mappings	228
Chapter 14: Deployment and Upgrade	235
Deployment	236
Upgrade	236
Chapter 15: Reference	237
General Reference	238
Family Field Descriptions	260
Corrosion Rates in Thickness Monitoring	312

Calculations	312
Family Search Configuration	314
Chapter 16: Troubleshooting	315
Troubleshooting Scenarios	316

Copyright Digital, part of GE Vernova

© 2024 GE Vernova and/or its affiliates. All rights reserved.

GE, the GE Monogram, and Predix are trademarks of General Electric Company used under trademark license.

This document may contain Confidential/Proprietary information of GE Vernova and/or its affiliates. Distribution or reproduction is prohibited without permission.

THIS DOCUMENT AND ITS CONTENTS ARE PROVIDED "AS IS," WITH NO REPRESENTATION OR WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF DESIGN, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE. ALL OTHER LIABILITY ARISING FROM RELIANCE UPON ANY INFORMATION CONTAINED HEREIN IS EXPRESSLY DISCLAIMED.

Access to and use of the software described in this document is conditioned on acceptance of the End User License Agreement and compliance with its terms.

Chapter 1

Overview

Topics:

- [Overview of the Thickness Monitoring \(TM\) Module](#)
- [Access the Thickness Monitoring Overview Page for a Selected Hierarchy Level](#)
- [Access the Thickness Monitoring Overview Page for all Hierarchy Levels](#)
- [Thickness Monitoring \(TM\) Workflow](#)

Overview of the Thickness Monitoring (TM) Module

Thickness Monitoring (TM) is a module in APM that allows you to document, manage, and analyze corrosion data used to predict the remaining usable life for an asset. It provides the tools that you need to monitor the corrosion of the asset in your plant and to take preventative actions that will help you avoid the economic, environmental, and human costs of corrosion-related failures.


Access the Thickness Monitoring Overview Page for a Selected Hierarchy Level

Before You Begin

- You can access the **Thickness Monitoring Overview** page only if you are a member of one of the following Security Groups:
 - MI Thickness Monitoring Administrator
 - MI Thickness Monitoring Inspector
 - MI Thickness Monitoring User

You can perform the various tasks in this page based on the privileges granted to these Security Groups.

Procedure

1. In the main navigation bar, select .
The Asset Hierarchy appears.
2. Navigate to the hierarchy level for which you want to access the **Thickness Monitoring Overview** page.
A list of types of analyses performed on assets in the selected hierarchy level appears in the workspace, in the **Health** section.
3. In the workspace, select the **Integrity** tab.
The **Integrity** section appears, displaying a list of the functions performed on the selected hierarchy level.


Note: In the **Thickness Monitoring** row, the counts listed for TML Groups and TMLs only lists records that are directly linked to the parent asset.

4. Select the link in the **Thickness Monitoring** row.
The **Thickness Monitoring Overview** page appears, displaying the following information that corresponds only to the selected hierarchy level.

Note: If you have selected an asset instead of a hierarchy level (that is, functional location), instead of the **Thickness Monitoring Overview** page, the **TM** page appears, displaying the **Corrosion Analysis Settings** workspace.

- **The Corrosion Rate Distribution graph:** Plots the corrosion rate values of assets.
- **The Remaining Life graph:** Plots the remaining life values of assets.
- **The TM Tasks section:** Displays a list of Thickness Monitoring tasks, sorted by the value in the Next Date field.
- **The Degradation Distribution section:** Displays a list of Degradation Mechanisms and RBI Analyses linked to each asset.

- **The Assets section:** Displays a list of Equipment and Functional Locations in the selected hierarchy level that are linked to Corrosion Analysis Settings. If you want to include an asset in this list, you will first need to [create Corrosion Analysis Settings](#) for that asset. If you have loaded data using the Thickness Monitoring (TM) Data Loaders, then this list is updated to display the assets that have been added or updated via the data loader workbook.
- **The Assets Requiring a Calculation section:** Displays a list of assets that have not been calculated. If you have loaded data using the Thickness Monitoring (TM) Data Loaders, then this list is updated to display the assets that have been added or updated via the data loader workbook.
- **The Thickness Inspections section:** Displays the asset controlling next inspection date specified in a Thickness Inspection linked to each asset.
- **The Excessive Corrosion section:** Displays the controlling corrosion rate values of assets with high rates of corrosion.
- **The Assets Near or Past Retirement section:** Displays a list of assets that are near or past retirement.

Optionally, if you have configured Thickness Monitoring to link Functional Locations directly with TMLs and TML Groups, in the workspace, you can select  to access the Functional Location in the **Analysis Overview** workspace.

Access the Thickness Monitoring Overview Page for all Hierarchy Levels

Before You Begin

- You can access the **Thickness Monitoring Overview** page only if you are a member of one of the following Security Groups:
 - MI Thickness Monitoring Administrator
 - MI Thickness Monitoring Inspector
 - MI Thickness Monitoring User

You can perform the various tasks on this page based on the privileges granted to these Security Groups.


Procedure

In the **Applications** menu, navigate to the **INTEGRITY** section, and then select **Thickness Monitoring**. The **Thickness Monitoring Overview** page appears, displaying the following information for all hierarchy levels.

- The **Corrosion Rate Distribution** graph: Plots the corrosion rate values of assets greater than 10 Mills/year.
- The **Remaining Life** graph: Plots the remaining life values of assets, up to 60 months.
- The **TM Tasks** section: Displays a list of Thickness Monitoring tasks, sorted by the value in the Next Date field.
- **The Degradation Distribution section:** Displays a list of Degradation Mechanisms and RBI Analyses linked to each asset.
- **The Assets section:** Displays a list of Equipment and Functional Locations. If you have loaded data using the Thickness Monitoring (TM) Data Loaders, then this list is updated to display the assets that have been added or updated via the data loader workbook.
- **The Assets Requiring a Calculation section:** Displays a list of assets that have not been calculated. If you have loaded data using the Thickness Monitoring (TM) Data Loaders, then this list is updated to

display the assets and functional locations that have been added or updated via the data loader workbook.

- **The Thickness Inspections section:** Displays the asset controlling next inspection date specified in a Thickness Inspection linked to each asset.
- **The Excessive Corrosion section:** Displays the controlling corrosion rate values of assets with high rates of corrosion.
- **The Assets Near or Past Retirement section:** Displays a list of assets that are near or past retirement.

Note: The **Thickness Monitoring Overview** page is not updated automatically when you return to the previously opened tab. You can select  to update the page.

Next Steps

[Create Corrosion Analysis Settings](#)

Thickness Monitoring (TM) Workflow

The following workflow provides the basic, high-level steps for using TM. The steps and links in this workflow do not reference every possible procedure.

1. Determine the assets in your plant that need to be monitored for corrosion.
2. [Create corrosion analysis settings](#) for each asset.
3. For each asset that will be monitored, identify one or more [Thickness Measurement Locations \(TMLs\)](#) that will be contained in a TML Group.
4. After you have identified the TMLs, record [Thickness Measurement](#) readings for each TML. These readings can be recorded via data entry or datalogger.
5. After you record measurements for the TMLs, [calculations are made based on those measurements](#). TM allows you to select different inspection types for your analyses, as well as use multiple types of analyses at once. Using the measurement data, TM can calculate the corrosion rate, the Next Inspection Date, and the Remaining Life for equipment. The calculations can help determine when to repair or replace the asset.

In addition to facilitating the basic analysis workflow described above, TM also provides other tools and features that help you manage your corrosion data and monitor your asset, including:

- The [Minimum Thickness \(T-Min\) Calculator](#), which is designed to calculate the minimum thickness for certain types of components. The T-Min value is used to determine the corrosion rate, remaining life, and next inspection date for the component. The T-Min Calculator is available for piping, pressure vessels, and tanks, and is compliant with ANSI B31 (for piping), API 653 (for tanks), and ASME Section VIII DIV 1 and NBIC NB23, API 510 (for pressure vessels).
- An [interface for handheld data recorders](#) (dataloggers) manufactured by [Olympus and GE](#). This allows measurement readings that have been recorded in the field to be uploaded automatically to TM. Additionally, data stored in the application can be downloaded to handheld devices.

TM Best Practice

TM Best Practice specifies that you will create analyses for an asset and its components only. You should not create analyses for locations. If you are following Enterprise APM Best Practice, your asset information will be stored in Equipment records, which serve as the root records for your corrosion analyses.

Additionally, TM Best Practice specifies that you can organize your equipment by defining components of the asset. [TML Groups](#) should be used to represent the components of the asset at this level.

Chapter 2

Workflows

Topics:

- [Thickness Monitoring Planning Workflow](#)
- [Thickness Monitoring: Thickness Assessment Workflow](#)
- [Thickness Monitoring Piping Rotation Workflow](#)

Thickness Monitoring Planning Workflow


Thickness Monitoring Planning Workflow

The TM Planning process requires defining all of the elements required to implement and execute a comprehensive TM inspection plan. This includes identifying the relevant assets for TM and how they are subject to different corrosion environments.

For example, a heat exchanger is typically subject to two different process streams. One stream may be a fluid or gas with minimal corrosive properties, while the other may be a fluid or gas with highly corrosive properties. In this case, the Corrosion Analyst may define two corrosion groups with different analysis properties to assess wall thickness. Once the corrosion groups have been established, the Corrosion Analyst will identify the measurement locations needed to properly assess the current wall thickness and project future remaining life.

In the following workflow diagram, the blue text in a shape indicates that the corresponding description has been provided in the sections that follow the diagram. For more information, refer to the [Interpreting the Workflow Diagrams](#) topic in the [APM Product Workflows](#) documentation.

Note: For information on the personas associated with a APM module, refer to the [APM Product Workflows](#) documentation.



Create or Update Inspection Task from Asset Strategy

Persona: Analyst

The need for TM is defined as part of a well-developed Asset Strategy that mitigates risk of failure. TM typically mitigates the risk of loss of containment for stationary assets.

Asset Set-up for TM?

Persona: Analyst

The Analyst will be notified to set up the asset for TM.

If the asset is already set up for TM inspections, then validate the strategy recommended scope and schedule for TM inspection.

If the asset is not set up for TM inspections, then the additional information relative to the corrosive environments of the asset needs to be collected in order to determine TM inspection scope and schedule.

Identify Asset for Thickness Monitoring

Persona: Analyst

Starting at the asset level, defines all TM information.

Examples of assets in this context include stationary equipment such as piping, vessels, exchangers, tanks, and boilers.

Set Up Analysis Settings

Persona: Analyst

Define Corrosion Analysis preferences for each corrosion group.

These preferences establish how the corrosion rate will be calculated using standard Short Term, Long Term, and/or Least Squares methods. It also defines how that data is used to determine the Controlling Rate for the Corrosion Group and overall Asset.

In addition, a minimum task interval should be defined that is typically based on a risk-based strategy analysis or compliance to a regulatory code.

All of this information is used to determine the next inspection date from measurement readings taken in the field.

Determine Corrosion Groupings

Persona: Analyst

Define corrosion groups associated with the asset. Examples of this are:

- A heat exchanger subject to two different process streams on the shell and tube sides.
- A column that produces multiple distillate streams that may be subject to different corrosion environments.

In either case, the Corrosion Analyst may define corrosion groups with different analysis properties to assess the wall thicknesses of the affected asset components.

Create Thickness Measurement Locations (TMLs)

Persona: Analyst

Create TMLs, which are locations where TM data will be acquired in the field, trended, and analyzed.

TMLs are typically defined for each Corrosion Group.

TMLs are defined to adequately assess the wall thickness of the asset based on the asset configuration, corrosion group, and fluid stream properties.

All TMLs Created?

Persona: Analyst

Determine if all TMLs have been defined. After all TMLs are defined, initial readings and corrosion analysis will be conducted to determine the proper TM inspection task.

Validate TML Analysis Settings

Persona: Analyst

Assign each TML to a Corrosion Group, which will cause the TML to inherit that group's preferences. These preferences will be validated at the TML level, and will be adjusted as needed for the specific location.

Document Initial Measurements

Persona: Analyst

For new TMLs, document initial measurements to determine next inspection date and provide a baseline for future readings.

Calculate Corrosion Analysis

Persona: Analyst

Based on the initial readings, conduct a full corrosion analysis to determine the controlling corrosion rate, remaining life, and next inspection date.

Corrosion Analysis

Persona: Analyst

The result is a corrosion analysis summary by asset, a corrosion group, and an individual TML.

Validate Task Scope and Schedule

Persona: Analyst

The analysis will produce a Task scope and schedule for the next inspection date.

Validate that the scope defined by the analysis fully supports any existing asset strategy defined by risk analysis or code compliance.

Also, review the analysis results to ensure that it is based on good measurements and correct preference settings.

Acceptable?

Persona: Analyst

Based on the review of the analysis results in the previous step, determine if the analysis is acceptable.

Modify Preferences and Update Measurements

Persona: Analyst

If the results are not acceptable, then the Corrosion Analyst may elect to take some action to update the analysis to be more accurate.

This may include updating the preferences. For example, if the next inspection date does not support an existing risk-based asset strategy, the minimum interval preference may need to be updated.

This may also include updating measurements. For example, the accuracy of one measurement may be suspect. In this case, the Corrosion Analyst will acquire a new measurement reading to ensure that the analysis results are accurate.

TM Assessment

Persona: Analyst

If the analysis results are acceptable, then the Task is scheduled and will be executed as part of the Thickness Monitoring: Thickness Assessment workflow.

Go to the [Thickness Assessment workflow](#).

Recommendation Management

Persona: Analyst

As a result of the TM Assessment, the Corrosion Analyst may recommend an asset or component replacement when it is determined that end of life is imminent or near term.

Go to the [Manage Performance Recommendations workflow](#).

Implement Recommendation for Replacement

Persona: Analyst

Implement a recommendation for replacement of the asset or component. This recommendation will be managed through the Manage Performance Recommendations workflow and tracked through implementation.

Renew Associated TMLs

Persona: Analyst

Renew the TMLs associated with the replacement asset or component and initiate them for future TM inspections.

Archive History

Persona: Analyst

The prior TM measurement data is archived for historical purposes.

Preference Change Required?

Persona: Analyst

Determine if any preference change is required due to the new asset or component properties.

If a change is required, the TMLs will be updated with the change, and then the TM task validation process will be repeated.

If a change is not required, the TM task validation process will be repeated with the existing preferences defined for the previous TMLs.


Thickness Monitoring: Thickness Assessment Workflow

Thickness Monitoring: Thickness Assessment Workflow

The Thickness Assessment process includes complying with the execution of TM Tasks to acquire thickness measurements to evaluate asset integrity. A Technician will perform the inspections specified by the TM Tasks at the scheduled intervals. The Technician will typically use a data logger device to facilitate the field data collection.

In the following workflow diagram, the blue text in a shape indicates that the corresponding description has been provided in the sections that follow the diagram. For more information, refer to the [Interpreting the Workflow Diagrams](#) topic in the [APM Product Workflows](#) documentation.

Note: For information on the personas associated with a APM module, refer to the [APM Product Workflows](#) documentation.



TM Planning

Persona: Analyst

TM Planning includes defining all of the elements required to implement and execute a comprehensive TM inspection plan. This includes identifying the relevant assets for TM and if they are subject to different corrosion environments.

For example, a heat exchanger is typically subject to two different process streams. One stream may be a fluid or gas with minimal corrosive properties, while the other may be a fluid or gas with highly corrosive properties. In this case, the Corrosion Analyst may define two corrosion groups with different analysis properties to assess wall thickness. Once the corrosion groups have been established, the Corrosion

Analyst will identify the measurement locations needed to properly assess the current wall thickness and project remaining life.

Go to the [TM Planning workflow](#).

Review Scope of Task(s)

Persona: Technician

For upcoming TM inspections, review the task scope to ensure that the proper thickness measurement method is used for the inspection.

Data Logger?

Persona: Technician

Information can be collected in the field either manually or using a data logger device. Determine if a data logger will be used for collection, and then proceed down the appropriate workflow path.

Download TMLs to Data Logger

Persona: Technician

If a data logger is used, download TMLs scheduled for inspection from the asset definition.

Perform TM Inspection with Data Logger

Persona: Technician

Using the data logger device, perform the TM inspection.

Upload TMLs from Data Logger

Persona: Technician

When all TMLs have been inspected, upload the measurements from the data logger device for review and analysis.

List TMLs for Manual Data Collection

Persona: Technician

If a data logger is not used, manually list the TMLs scheduled for inspection from the asset definition.

Perform TM Inspection

Persona: Technician

If a data logger is not used, use a measurement device and manually record measurements in the field at predefined locations.

Enter TMLs from Inspection

Persona: Technician

When all TMLs have been inspected, if a data logger has not been used, manually enter measurements for review and analysis.

Thickness Measurements Created

Persona: Technician

The result of executing TM inspections is new measurements for each TML for review and analysis.

Thickness Measurement

Persona: Technician

The result of executing a TM inspection is new measurements for each TML for review and analysis.

Calculate Corrosion Analysis

Persona: Analyst

Use the new measurements to perform a full corrosion analysis to determine the controlling corrosion rate, remaining life, and next inspection date.

Updated Corrosion Analysis

Persona: Analyst

The resultant corrosion analysis is created, and the associated TM task is updated with the next inspection date.

Review Corrosion Analysis Results

Persona: Analyst

Review the results to determine if any follow-up action is necessary to ensure the integrity of the asset or improve asset performance.

Compliance Management Reports

Persona: Analyst

TM Inspection program compliance is an important part of the overall workflow.

Compliance Management Reports based on the defined TM Tasks provide a means to identify upcoming inspections so that they are scheduled and executed appropriately.

Take Action?

Persona: Analyst

Determine if a follow-up action is necessary. If it is, a proposal will be made by the analyst to business management. This could be a proposed change to an asset strategy, procedure, process, or policy.

Recommendation Needed?

Persona: Analyst

Determine if a recommendation is needed.

If a recommendation is not needed, the proposal requires immediate attention, and action is taken immediately.

If a recommendation is needed, the proposed change requires formal review and approval, as well as traceability through implementation. In this case, a recommendation will be created and managed forward.

Manage Performance Recommendations

Persona: Analyst

The new recommendation is managed for approval and implementation through the Manage Performance Recommendation workflow.

Go to the [Manage Performance Recommendations workflow](#).

Corrosion History

Persona: Analyst

The overall result of TM inspections is to provide Corrosion History, which is used primarily for long-term strategy evaluation and development.

This corrosion history can be evaluated through Core Analysis workflows or advanced strategy development methods, such as Risk Based Inspection (RBI).

Other APM Workflows

Persona: Analyst

For follow-up analysis, use Core Analysis.

Go to the Core Analysis: Asset Event Analysis workflow.

Go to the Core Analysis: Graph Analysis workflow.

Go to the Core Analysis: Query Analysis workflow.

Go to the Core Analysis: Report Analysis workflow.


Thickness Monitoring Piping Rotation Workflow

Thickness Monitoring Piping Rotation Workflow

This workflow describes the process of performing a rotation or flip on piping components. The TM Planning workflow and the TM Assessment workflow are applicable for all piping assets. However, for piping assets that are part of a pipe rotation strategy, the Piping Rotation workflow follows specific TM Planning and Assessment workflows. The Corrosion Analyst will review the corrosion analysis results and determine if a movement (rotation or flip) is necessary.

In the following workflow diagram, the blue text in a shape indicates that the corresponding description has been provided in the sections that follow the diagram. For more information, refer to the [Interpreting the Workflow Diagrams](#) topic in the [APM Product Workflows](#) documentation.

Note: For information on the personas associated with a APM module, refer to the [APM Product Workflows](#) documentation.



TM Planning

Persona: Analyst

TM Planning includes defining all of the elements required to execute rotation or flip of a piping asset. This includes defining a piping asset, setting up components, bands, and thickness monitoring locations based on the corrosion mechanisms affecting the circuit.

Piping Asset Setup

Persona: Analyst

Enable the piping rotation workflow and define values for the wall ratio preferences. In addition, you must [set up analysis settings](#) for the asset.

Create Components

Persona: Analyst

Create components for the piping asset. Components are basically TML groups that contain bands at defined locations. Components can be straight spools or elbows.

Create Bands

Persona: Analyst

Create bands for the piping component. Based on the location on the component, bands can be classified into center band, mirrored band, and odd bands. Elbows can also contain an additional type of band called the extrados band.

Create Nominal Measurements for TMLs

Persona: Analyst

Enter Nominal measurement values and the date when the measurement was taken for each TML. For new TMLs, [document initial measurements](#).

Calculate Corrosion Analysis

Persona: Analyst

Use the new measurements to perform a full corrosion analysis to determine the controlling corrosion rate, remaining life, and next inspection date.

TM Assessment

Persona: Analyst

Over a period of time, as a piping asset erodes, an evaluation is carried out to determine if certain components need to be rotated or flipped to extend the life of the asset. This section includes the steps involved in analysis of corrosion data, creating and using what-if scenarios, and performing a rotation or flip on the components.

Rotate or Flip Component?

Persona: Analyst

Determine whether a rotation or flip is required for piping components based on the corrosion analysis for the piping asset.

Select Parameters for Movement

Persona: Analyst

Select the action that you want to perform (that is, rotate or flip), and then enter the parameters for the movement, such as Rate Method, Movement Date, and so on.

Create What-If Scenario?

Persona: Analyst

Determine if you want to create a What-If Scenario for evaluation.

What-If Scenario

Persona: Analyst

Create a What-If scenario for rotating or flipping the component.

Review What-If Scenarios

Persona: Analyst

Evaluate the scenarios and select the most optimal scenario for movement based on the analysis outputs.

Perform Movement from a Scenario?

Persona: Analyst

Determine if you want to perform a rotation or flip from the selected scenario.

Rotate or Flip the Component

Persona: Analyst

Perform a rotation or flip on the piping component.

Rotation Event

Persona: Analyst

An inspection is created for the asset for the Pipe Rotation Event.

Review Corrosion Analysis Results

Persona: Analyst

Review the results to determine if any follow-up action is necessary to ensure the integrity of the asset or improve asset performance.

Corrosion History

Persona: Analyst

The overall result of TM inspections is to provide Corrosion History, which is used primarily for long-term strategy evaluation and development.

This corrosion history can be evaluated through Core Analysis workflows or advanced strategy development methods, such as Risk Based Inspection (RBI).

Other APM Workflows

Persona: Analyst

For follow-up analysis, use Core Analysis.

Go to the Core Analysis: Asset Event Analysis workflow.

Go to the Core Analysis: Graph Analysis workflow.

Go to the Core Analysis: Query Analysis workflow.

Go to the Core Analysis: Report Analysis workflow.

Updated Corrosion Analysis

Persona: Analyst

The resultant corrosion analysis is created, and the associated TM task is updated with the next inspection date.

Chapter 3

Corrosion Analyses in Thickness Monitoring

Topics:

- [About Corrosion Analyses in Thickness Monitoring](#)
- [About the Types of Corrosion Analyses](#)
- [About Corrosion Analysis Settings](#)
- [About Thickness Monitoring Tasks](#)
- [About Archived Asset Corrosion Analyses](#)
- [About Bulk Analysis](#)
- [About the Remaining Life Graph](#)
- [Create Corrosion Analysis Settings](#)
- [Access the Analysis Overview Workspace](#)
- [Access the Remaining Life Graph](#)
- [Modify Corrosion Analysis Settings](#)
- [Calculate a Corrosion Analysis](#)
- [Perform a Bulk Analysis](#)
- [Archive an Asset Corrosion Analysis](#)
- [Delete an Asset Corrosion Analysis](#)
- [Review Archived Analyses](#)
- [Reset Maximum Historical Corrosion Rate \(MHCR\)](#)

About Corrosion Analyses in Thickness Monitoring

A Thickness Monitoring Corrosion Analysis is a top-level summary of corrosion data for an asset, determined by calculations made using the values in Thickness Measurements linked to TMLs. Often, TMLs are linked in batches to TML Groups, which represent component parts of an asset.

Details

To conduct a Corrosion Analysis for an asset, you must:

- Identify an asset to analyze.
- Optionally, identify components of the asset you want to include as [TML Groups](#).
- Organize equipment into [TMLs](#).
- Collect [measurement data](#) for those TMLs.

You will complete these tasks by [creating records](#), populating them with the appropriate information, and linking them together to establish relationships. As you complete these tasks, other records will be created to store calculations based upon the records that you created. Throughout this documentation, we refer to all these records and links collectively as a Corrosion Analysis.

About the Types of Corrosion Analyses

There are two kinds of Corrosion Analysis records:

- An Asset Corrosion Analysis, which is created and linked automatically to an asset when you first define [Corrosion Analysis Settings](#) for that asset.
- A TML Corrosion Analysis, which is created and linked automatically to a TML when the TML is first created.

The Asset Corrosion Analysis linked to an asset can be considered the top-level Corrosion Analysis, as it aggregates all data from the other Corrosion Analyses linked directly or indirectly to the asset.

Asset Corrosion Analyses

In addition to assets, Asset Corrosion Analyses are also created and linked automatically to any TML Group that is included in the Corrosion Analysis for an asset.

An Asset Corrosion Analysis represents a summary of the calculations that are stored in the TML Corrosion Analysis for each TML linked to a single asset or TML Group. Using an Asset Corrosion Analysis, you can determine the overall corrosion of an asset and make decisions about the actions that should be taken based upon the analysis results.

An Asset Corrosion Analysis represents:

- An Equipment record or TML Group.
- All the TMLs of a given TML Analysis Type (UT, RT, or TML) that are linked to the Equipment record or TML Group.
- All the Thickness Measurements that are linked to the TMLs.
- All the calculations that are performed based upon the values in the TMLs and Thickness Measurements.

Because baseline Thickness Monitoring supports the use of three TML Analysis Types (UT, RT, and TML), each Equipment record or TML Group can have up to three Asset Corrosion Analyses linked to it.

The TML Analysis Types UT and RT are provided for customers who want to classify TMLs according to measurement-collection method (ultrasonic thickness or radiographic thickness), and then perform calculations on each set of TMLs.

The TML Analysis Type TML is provided for customers who do not want to classify TMLs according to measurement-collection method, and instead prefer to analyze all TMLs together. Typically, you will use either both UT and RT, or only TML. Most customers will not use all three. Therefore, Equipment records and TML Groups will usually have either one or two Asset Corrosion Analyses linked to them.

TML Corrosion Analyses

Each TML Corrosion Analysis stores summary information and calculation results that are determined using the [Thickness Measurements](#) linked to TMLs.

When TMLs are linked to an asset or TML Group, the TML Corrosion Analyses linked to the TMLs will provide the information to the Asset Corrosion Analysis, which serves as an overview of the corrosion information gathered for each TML.

While the Asset Corrosion Analysis provides a useful summary of the corrosion status of a given asset, if you want to get a more detailed perspective of the corrosion of the equipment, you will need to examine the individual TML Corrosion Analyses. Because values in the Asset Corrosion Analysis are determined using values stored in individual TML Corrosion Analyses, you may need to review the TML Corrosion Analyses in order to interpret the data in a Corrosion Analysis Summary.

Equipment-Level Analysis Information

In most cases, the values stored in the Asset Corrosion Analysis represent calculations that are performed for TMLs using values in the TML Corrosion Analyses, which have been summarized based on [settings defined for the analysis](#). For example, in the [Corrosion Analysis Settings](#), you can specify whether you want the Asset Controlling Corrosion Rate to be the maximum corrosion rate for all TMLs, or an average of the corrosion rates that have been calculated for the TMLs. In other words, Asset Corrosion Analysis values are typically not unique to the Asset Corrosion Analysis itself.

In Corrosion Analyses that include both assets and TML Groups, the Asset Corrosion Analysis will contain information that is derived from the information stored in the Asset Corrosion Analyses for the assets and the TML Group.

For example, consider a piping circuit that contains three piping lines where the information for the piping circuit is stored in four records:

- Equipment A - Piping Circuit
- TML Group 1 - Piping Line 1
- TML Group 2 - Piping Line 2
- TML Group 3 - Piping Line 3

Additionally, assume that TMLs exist for each TML Group, and each of those TMLs has its own TML Corrosion Analysis. In this situation, each TML Group will have its own Asset Corrosion Analysis that stores summary information about the calculations stored in the corresponding TML Corrosion Analyses. The asset will also be linked to its own Asset Corrosion Analysis that stores summary information that is derived from the information in the analyses that are linked to each TML Group.

About Corrosion Analysis Settings

Corrosion Analysis Settings let you specify certain options that control how various values will be calculated in [Asset and TML Corrosion Analyses](#). While Corrosion Analysis Settings exist as records, the settings should only be [accessed](#) and [modified](#) via Thickness Monitoring. Corrosion Analysis Settings are

used to calculate fields in Asset Corrosion Analyses. They are also used to populate fields in TMLs, and to determine values in the linked TML Corrosion Analyses. Some values can be defined at the asset or TML Group level, and then customized at the TML level. You will need to [configure the Corrosion Analysis Settings](#) based on the requirements of your organization. This will ensure that the analyses yield results that are useful and are meaningful to you and your organization. You can also select any [custom corrosion rates](#) that you defined via the TM Admin Preferences page.

For Assets and TML Groups

In a Corrosion Analysis that [includes both an asset and TML Groups](#), Corrosion Analysis Settings must be defined for the asset and each TML Group. If you access an asset or TML Group in Thickness Monitoring that does not have Corrosion Analysis Settings defined, the Corrosion Analysis Settings workspace will be displayed automatically.

Different settings can be defined for each Inspection Type (UT, RT, and TML). When you create the Corrosion Analysis Settings for an asset or TML Group, you will need to choose the Inspection Type for which you want to configure settings. The Corrosion Analysis Settings that you create at the asset level can then be spread to the TML Group level (i.e., Corrosion Analysis Setting can be created and linked automatically to the TML Group) in the following scenarios:

- When you create a new TML Group for asset.
- When you define Corrosion Analysis Settings of a new Inspection Type for an asset. You can specify which existing TML Groups receive the new settings [through the Select Spreading window](#).

The Corrosion Analysis Settings for a TML Group can also be accessed and modified individually.

Important: Analysis settings must be defined for asset and TML Group before you begin creating TMLs of a given TML Analysis Type and linking them to TML Groups.

For TMLs

On the TML level, the Corrosion Analysis Settings control how various values will be calculated in the TML Corrosion Analysis that is linked to a TML.

When you create a TML, Corrosion Analysis Settings are created and linked to it automatically. The Corrosion Analysis Settings for a TML are created using the settings defined for the asset or TML Group to which the TML is linked.

Most Corrosion Analysis Settings are [defined at the asset or TML Group level](#). The following settings can be defined at the TML level:

- Allowable Measurement Variance
- Corrosion Rate Variance
- Default Inspection Interval
- Minimum Corrosion Rate
- Std Deviation Factor

After Corrosion Analysis Setting exist for a TML, you can modify the TML-specific settings via the [Corrosion Analysis Settings](#) workspace.

About Thickness Monitoring Tasks

Thickness Monitoring Tasks can be used to manage the inspection schedules for assets that you analyze in TM. Thickness Monitoring Task records will be created automatically when you create Corrosion Analysis Settings for an asset or TML Group. If you select the **Auto Manage Tasks** check box on the **TM Admin Preferences** page, when you update a TML, the corresponding Thickness Monitoring Task will be updated automatically.

The **Auto Manage Tasks** setting is disabled by default. If the Risk Based Inspection license is active, you should accept the default setting because you will use the Tasks generated from RBI, rather than TM, to determine your inspection intervals. If the Risk Based Inspection license is not active, you should enable the **Auto Manage Tasks** setting.

Note: Thickness Monitoring will create and update Thickness Monitoring Tasks automatically only if the Component ID setting is defined for the Equipment or TML Group family.

About Archived Asset Corrosion Analyses

When you [archive an Asset Corrosion Analysis](#), you create a copy of the current, active Asset Corrosion Analysis and stores the data in a new, inactive Asset Corrosion Analysis.

Details

The value in the Analysis State field for the inactive Asset Corrosion Analysis is set to Archived. Additionally, Asset Corrosion Analyses:

- Are linked to the asset or TML Group through the Has Archived Corrosion Analyses relationship.
- Are linked to Corrosion Analysis Settings through the Has Archived Corrosion Analysis Settings relationship. When the Asset Corrosion Analysis is archived, a copy of the Corrosion Analysis Settings is also created and stored.

Tip: When you [review an archived Asset Corrosion Analysis](#), the archived Corrosion Analysis Settings are visible in the **Archived Corrosion Analyses** workspace.

- Are not linked to TMLs. TMLs and Thickness Measurements linked to those TMLs remain linked only to the active Asset Corrosion Analysis.

Archived Asset Corrosion Analyses are meant to serve as a historical record of the conditions that existed at the time the Asset Corrosion Analysis was archived. Archiving an Asset Corrosion Analysis can be useful if you want to:

- Create a snapshot of the Asset Corrosion Analysis based on certain Corrosion Analysis Settings, and then modify the settings to see how they affect the calculations.
- Create a copy of the existing Asset Corrosion Analysis before making changes to the related TMLs or Thickness Measurements, such as adding or excluding TMLs.

Each asset and TML Group can have multiple archived analyses. You can archive the current, active Asset Corrosion Analysis as many times as needed.

Note: When you archive an Asset Corrosion Analysis, the Asset Corrosion Analyses for TML Groups linked to the asset will also be archived.

About Bulk Analysis

Bulk Analysis allows you to use a single action to update calculations for all or selected assets, as well as all TMLs and TML Groups linked to those assets.

When you [calculate a bulk analysis](#), you:

- Calculate an analysis for each selected asset, as well as TML Groups and TMLs linked to the selected asset.
- Print or save a log of all the calculated analyses.

About the Remaining Life Graph

The data on the Remaining Life graph represents how long after the current day an asset or TML Group can be in service, based on the T-Min value and the current rate of corrosion.

Details

When you [access the Remaining Life graph](#), the results of the analysis performed on a specific asset or component are displayed in sections. By default, the sections are ranges of years:

- 0 - 5
- 6 - 10
- 11 - 25
- > 25

The size of a section is determined by the number of TMLs that have a Remaining Life that fall in the range of the section.

On the Remaining Life graph, you can:


- View a list of TMLs or TML Groups for a range, along with their remaining life values and the IDs of the associated assets, by selecting the section on the graph.
- Clear the filter by selecting **Clear Filter**.
- Filter the data based on the analysis type by selecting the appropriate value in the **Analysis Type** box.

Create Corrosion Analysis Settings

About This Task

Before an asset can be accessed via the **Thickness Monitoring Overview** page, you must create [Corrosion Analysis Settings](#) for that asset.

Procedure

1. On the top navigation bar, select  .
The **Asset Hierarchy** page appears.
2. On the **Asset Hierarchy** page, select the asset for which you want to create corrosion analysis settings.
3. In the workspace, select the **Integrity** tab, and then, in the **Thickness Monitoring** row, select **TML Groups**.

Note: **TML Groups** will only appear if you have selected an asset. If you have selected a functional location, **Assets** replaces **TML Groups**.

The **TM** page appears, displaying the **Corrosion Analysis Settings** workspace. By default, values in the following boxes are populated automatically as follows:

- The **Inspection Type** box is set to UT.
- The **Controlling Corrosion Rate** box is set to Maximum.
- The **Std Deviation Factor**, **Remaining Life Critical Number of TMLs**, **Minimum Corrosion Rate**, and **Remaining Life Factor** boxes are populated with values.

Note: The value in the Remaining Life Critical Number of TMLs box has no significance in the calculation of remaining life.

- The **Short Term**, **Long Term**, **Factor Remaining Life**, and **Inspection Interval** check boxes are selected.

Tip: If needed, you can modify values in the [available fields](#).

4. **Optional:** For piping assets, select the **Piping Asset** check box.

Note: The **Piping Asset** check box appears only if you [enable the piping rotation workflow](#) in the **Pipe Rotation Preferences** section of the **Global Preferences** workspace found in the **TM Admin Preferences** page.

5. Select **Create Settings**.
The Corrosion Analysis Settings record is created.

Next Steps

[Access a TML](#).

Access the Analysis Overview Workspace

Before You Begin

[Create Corrosion Analysis Settings](#).

Procedure

1. [Access the Thickness Monitoring Overview page](#) for the Functional Location that contains the asset, TML Group, or TML whose **Analysis Overview** workspace you want to access.
2. In the workspace, select the **Assets** tab.
The **Assets** section appears, displaying a list of assets with Corrosion Analysis Settings that are contained in the Functional Location.
3. In the row containing the asset whose **Analysis Overview** workspace you want to access, select the link.
The **Analysis Overview** workspace for the asset appears.

Tip: To access or modify the datasheet for the selected asset or TML Group, in the workspace, select the **Details** tab.

If you want to access the Analysis Overview for a:

- TML Group, proceed to the next step.
 - TML, proceed to step 5.
4. In the left pane, select a TML Group.
The **Analysis Overview** workspace for the TML Group appears.
 5. To access the **Analysis Overview** workspace for a TML, complete the following steps:
 - a) In the left pane, select a TML.
The **Measurements** section for the TML appears.
 - b) Select the **Analysis Output** tab.
The **Analysis Overview** workspace for the TML appears.

Tip:

- To access or modify the datasheet of the selected TML, in the workspace, select the **TM Details** tab.
- To access or modify the datasheet of the selected asset or TML Group, in the workspace, select the **Details** tab.

- To access the Asset Corrosion Analysis or the TML Analysis datasheet for the selected asset, TML Group, or TML, select the **Details** tab within the **Analysis Output** section.

Results

From the **Analysis Overview** workspace for an asset or TML Group, you can also:

- [Access the Remaining Life graph.](#)
- [Access linked TMLs.](#)
- Access the datasheet for the selected asset or TML Group, or the Asset Corrosion Analysis.

From the **Analysis Overview** workspace for a TML, you can also:

- [Access the Trends graph.](#)
- [Access linked measurements.](#)
- Access the datasheet for the selected TML, or the TML Corrosion Analysis.

From the **Analysis Overview** workspace, in the **Analysis Output** section, you can also access a summary of the Asset Corrosion Analysis or the TML Corrosion Analysis for the selected asset, TML Group, or TML.

Access the Remaining Life Graph

Procedure

1. [Access the Analysis Overview workspace](#) for the Asset or TML Group that contains the **Remaining Life graph** that you want to access.
2. In the workspace, expand the **REMAINING LIFE** section.
The **REMAINING LIFE** section is expanded, and displays the following information:
 - **The Remaining Life graph:** Displays a pie chart of the remaining life (in years) of the TMLs linked to the selected Asset or TML Group.
 - **The Remaining Life table:** Displays a list of TMLs along with their remaining life values, the IDs of the associated assets, and their analysis types. This list is filtered based on your selection on the graph. If you want to view a list of all the TMLs in the TML Group or Asset, select **Clear Filter**.

Note: If you have selected an Asset, and the Asset contains only TML Groups, but no TMLs directly linked to it, a list of TML Groups appears in the table.

For piping assets, a list of components appears at the Asset level, and a list of bands appears at the component level. In addition, a list of TMLs sorted by their positions in the band appears at the band level.

Tip: By default, the graph is plotted for TMLs associated with all analysis types. You can, however, filter the graph by selecting an analysis type in the **Analysis Type** box.

Modify Corrosion Analysis Settings

Before You Begin


[Create Corrosion Analysis Settings.](#)

About This Task

If you modify the settings for an asset, you can apply the modified settings to the associated TML Groups and TMLs as well.

After modifying the corrosion analysis settings, the analysis will be recalculated.

Procedure

1. Access the [Analysis Overview workspace](#) for the asset, TML Group, or TML whose corrosion analysis settings you want to modify.
2. In the upper-right corner of the workspace, select .
The **Corrosion Analysis Settings** workspace appears.
3. Modify the settings as needed.
4. Select **Update Settings** or **Create Settings**.

Note: The **Create Settings** button appears only if you have selected an Inspection Type for the analysis that does not yet exist for the selected record.

A message appears, indicating that the settings have been updated successfully. In addition:

- If you selected a TML, the analysis is recalculated using the new settings. If so, skip to step 10.
 - If you selected an asset that is not linked to TML Groups or TMLs, the analysis is recalculated using the new settings. If so, skip to step 10.
 - If you selected an asset or TML Group that is linked to TMLs that have settings, the **Select Dependencies to Update** window appears, displaying a list of those TMLs. If so, skip to step 8.
 - If you selected an asset that is linked to TML Groups with settings of the same Inspection Type as the asset, the **Select Dependencies to Update** window appears. If so, skip to step 6.
 - If the selected asset is linked to TML Groups that do not have settings of the same Inspection Type as the asset, the **Select Spreading** window appears. By default, all rows in the list are selected. If so, proceed to the next step.
5. In the **Select Spreading** window, in the list, clear the rows that correspond to the TML Groups for which you do not want to create settings of the same Inspection Type.
 6. Select **Done**.
The settings for the selected TMLs are saved. In addition:
 - If there are no additional TMLs linked to the selected asset that share the same Inspection Type as the asset, the procedure is complete. If so, skip to step 10.
 - If there are additional TML Groups that are linked to the asset that share the same Inspection Type as the asset, the **Select Dependencies to Update** window appears. If so, proceed to the next step.
 7. In the **Select Dependencies to Update** window, in the list, select the check boxes that correspond to the TML Groups whose settings you want to update.
 8. Select **Next**.
A new window appears, displaying a list of TMLs. By default, the check boxes for all TMLs are selected.
 9. In the list, clear the check boxes corresponding to each TML whose settings you do not want to update.
Note: Only the settings that were changed in step 2 will be updated.
 10. Select **Finish**.
A message appears, indicating that the settings for the selected asset or TML Group and all selected dependent settings have been updated successfully. Then, the analysis is recalculated.
 11. To return to the **Analysis Overview** workspace, select **Cancel**.


Calculate a Corrosion Analysis


Before You Begin

- [Create Corrosion Analysis Settings](#).
- [Create a Thickness Measurement Location \(TML\)](#).

- [Add a Thickness Measurement](#).

Procedure

1. Access the [Analysis Overview workspace](#) for the asset, TML Group, or TML whose analysis you want to calculate.
2. In the upper-right corner of the workspace, select .

Note: If the button is an orange , data has changed since the last calculation, and the analysis needs to be recalculated.

The analysis is calculated.

Results

- The Calculated Date field on the Asset Corrosion Analysis or the TML Corrosion Analysis datasheet is updated with the current date. Any other analysis data that changes will also be updated on the datasheet.

Perform a Bulk Analysis

About This Task

When you perform a bulk analysis, the following analyses will be updated:

- Asset Corrosion Analyses for all or selected assets.
- Asset Corrosion Analyses for TML Groups that are linked to all or selected assets.
- TML Corrosion Analyses for TMLs that are linked to the assets and TML Groups.

Procedure

1. Access the [Thickness Monitoring Overview page](#).
2. Select the **Assets** tab or the **Assets Requiring a Calculation** tab.
The corresponding section appears.
3. If you want to analyze all the assets in the list, select **Bulk Analyze** in the upper-right corner of the section.
-or-

If you want to analyze a subset of the available assets, then select the check box for each asset that you want to analyze, and then select **Bulk Analyze** in the upper-right corner of the section.

A message appears, asking you to confirm that you want to validate and analyze those assets that require calculation.

4. Select **Done**.

Note: The assets that required calculation are calculated while those that have been previously calculated are skipped. If, however, you select the **Calculate 100 assets** check box, all the selected assets are calculated regardless of their previous calculation status.

The **Bulk Analyze** window appears, displaying the calculation progress and a log detailing any errors. If the calculation fails, a list of the required fields appears in an error report at the bottom of the **Bulk Analyze** window.

5. After the calculation is complete:
 - To view the log details for all calculated analyses, select **View Complete Log**.

- To view the log details for a single analysis, in the list, select that analysis.
- To close the window, select **Close**.

Note: If the calculation is still in progress, a message appears, stating that the calculation continues even after you close the **Bulk Analyze** window. If the calculation is complete, then the window closes, and the lists of assets in the **Assets** and **Assets Requiring a Calculation** sections on the **Thickness Monitoring Overview** page are updated.

Archive an Asset Corrosion Analysis


Before You Begin

When you archive an Asset Corrosion Analysis, the Asset Corrosion Analyses for TML Groups linked to the asset will also be archived.

Procedure

1. Access the [Analysis Overview workspace](#) for the asset that contains the Asset Corrosion Analysis that you want to archive.

Note: Asset Corrosion Analyses can only be archived on the asset level.

2. In the upper right corner of the workspace, select , and then select **Archive Analyses**.

A message appears, asking you to confirm that you want to archive the selected Asset Corrosion Analysis.

Results

- You can now [review the archived analyses](#).

Delete an Asset Corrosion Analysis


About This Task

When you delete an Asset Corrosion Analysis:

- It deletes the Asset Corrosion Analysis and the Corrosion Analysis Settings.
- After deletion, you are redirected to the Corrosion Analysis Settings page.

Procedure

1. Access the [Analysis Overview workspace](#) for the asset for which you want to delete the Asset Corrosion Analysis.


2. In the upper right corner of the workspace, select , and then select **Delete**. The **Confirm Delete** dialog box appears, asking you to confirm that you want to delete the Asset Corrosion Analysis and the Corrosion Analysis Settings.

Note: Delete will only be enabled if the Asset has no related Thickness Measurement Locations or TML Groups. Similarly, for Piping assets, there can be no related TML Groups designated as Piping Components.

3. Select **Yes**.
A success message appears, and then you are redirected to **Corrosion Analysis Settings Page**.

Review Archived Analyses

Procedure

1. Access the [Analysis Overview workspace](#) for the asset or TML Group that contains the archived Asset Corrosion Analysis that you want to review.
2. In the upper-right corner of the workspace, select , and then select **Review Archived Analyses**. The **Archived Corrosion Analyses** workspace appears.

Tip: Archived Asset Corrosion Analyses can only be reviewed at the selected level. For example, if you select an asset, you cannot review the archived Asset Corrosion Analysis for a linked TML Group.


Reset Maximum Historical Corrosion Rate (MHCR)

About This Task

When you reset the [Maximum Historical Corrosion Rate](#) (MHCR) for:

- An [Asset Corrosion Analysis](#), the Maximum Historical Corrosion Rate in the analysis is replaced with the Controlling Corrosion Rate.
- A [TML Corrosion Analysis](#), the Maximum Historical Corrosion Rate in the analysis is populated with the value in the Corrosion Rate field.

Procedure

1. Access the [Analysis Overview workspace](#) for the asset, TML Group, or TML for which you want to reset MHCR.
2. In the workspace heading, select , and then select **Reset MCHR**.

The **Confirm MHCR Reset** dialog box appears, asking you to confirm that you want to reset the MHCR.

Note: If the TML Group for which you want to reset the MHCR has analyses of different inspection types, the **Reset MHCR** window appears. Next to the Inspection Types that you want to reset, select the check boxes.

3. Select **Yes**.

The MHCR is reset.

Results

- The corrosion analysis for which you reset MHCR needs to be recalculated.

Chapter

4

TMLs

Topics:

- [About Thickness Measurement Locations \(TMLs\)](#)
- [About Renewing Thickness Measurement Locations \(TMLs\)](#)
- [About Moving Thickness Measurement Locations \(TMLs\)](#)
- [Access a Thickness Measurement Location \(TML\)](#)
- [Filter Thickness Measurement Locations \(TMLs\)](#)
- [Create a Thickness Measurement Location \(TML\)](#)
- [Configure the Thickness Monitoring Location \(TML\) Section](#)
- [Copy Thickness Measurement Locations \(TMLs\)](#)
- [Relocate a Thickness Measurement Location \(TML\)](#)
- [Renew Thickness Measurement Locations \(TMLs\)](#)
- [Organize Thickness Measurement Locations \(TMLs\)](#)
- [Exclude a Thickness Monitoring Location \(TML\)](#)
- [Access the TM Quick View Page](#)
- [Modify TMLs in Bulk](#)
- [Access the TML Trends Graph](#)
- [Define Allowable Stress](#)
- [Calculate Allowable Stress](#)
- [Make a Thickness Measurement Location \(TML\) Inactive](#)

- Delete a Thickness Measurement Location (TML) |

About Thickness Measurement Locations (TMLs)

A TML is a specific location on an asset where Thickness Measurement readings are taken and for which various values, including minimum thickness, are calculated. Each asset or TML Group can have multiple [TMLs](#) associated with it, which stores identifying information. [Thickness Measurements](#) are linked to TMLs, which store readings taken at that location.

About Renewing Thickness Measurement Locations (TMLs)

Renewing TMLs provides a mechanism for optionally recording a new base measurement for a TML and setting all existing Thickness Measurements to Inactive. Additionally, the value that was the Controlling Corrosion Rate for the TML prior to the renewal replaces the Minimum Corrosion Rate value in the associated Corrosion Analysis Settings after the renewal. You can [renew Thickness Measurement Locations without adding new measurements](#).

Details

Generally, you will want to renew TMLs when you replace an asset. For example, if an asset representing a tank is linked to one or more TMLs that have Thickness Measurements, when you replace the tank, you can renew the TMLs to retain the measurement data recorded for the old tank while creating a new base measurement for the new tank. When you do this, you can begin calculating Corrosion Analyses for the new tank.

When you renew a TML:

- In linked Thickness Measurements, if the Measurement Status Indicator field was set to Active prior to the renewal, it will be set to Inactive. In addition, the value in the Measurement Status Indicator Basis will be populated.
- The value in the Historical Sequence Number field in linked Thickness Measurements that were used during that life cycle will be incremented. For example, if the Historical Sequence Number field previously contained no value, indicating that the associated TML had never been renewed, it will now be 1, indicating that the associated Thickness Measurement Location record has been renewed one time.
- The value in the Renew Historical Sequence Number field of the TML will be populated with the largest Historical Sequence Number in the associated Thickness Measurements that were used during that life cycle. For example, assume there are two associated Thickness Measurements that were used during the life cycle. If the Historical Sequence Number of the first measurement is 1 and that of the second measurement is 2, the Renew Historical Sequence Number field in the TML is populated with the value 2. This will keep track of the life cycle for that TML.
- The value in the Minimum Corrosion Rate field in the [Corrosion Analysis Settings](#) for the TML is replaced with the current value in the Controlling Corrosion Rate field in the TML.
- The value in the Status Changed By field in the TML will update to reflect the User ID of the Security User who renewed the TML.
- The value in the Status Changed Date field in the TML will change to the current date.

About Moving Thickness Measurement Locations (TMLs)

Under some circumstances, it may be necessary to move TMLs from one asset or TML Group to another. There are two scenarios in which you might perform this task.

Moving TMLs from one Corrosion Analysis to another

You may determine that a TML that was originally linked to one asset or TML Group actually belongs to a different asset or TML Group that is included in a different Corrosion Analysis. In this case, rather than creating a new TML for the correct asset or TML Group, you can relocate the TML.

In this case, you will use [Relocate TMLs](#) to select the TML that you want to move and the asset or TML Group to which it will be linked.

Moving TMLs from one TML Group to another in the same Corrosion Analysis

You may determine that a particular subset of existing TMLs actually belong in their own TML Group. If so, you would create a TML Group for the asset, and then move the TMLs to the new TML Group.

In this case, you will use [Organize TMLs](#) to move the TMLs from one TML Group to another.

Details

When you move a TML from one asset or TML Group to another:

- The TML ID of the TML you want to relocate cannot be the same as that of a TML that is already linked to the target asset or TML Group.
- The TML that you relocate will now be linked only to the target asset or TML Group that you select via the Has Datapoints relationship.
- The value in the TML Asset ID field of any relocated TML will be updated to reflect the target asset or TML Group.
- Any Thickness Measurements, TML Corrosion Analyses, and Corrosion Analysis Settings that are linked to a TML will remain linked after the TML is relocated.
- The Corrosion Analysis Settings for the relocated TML will inherit the values in the Corrosion Analysis Settings that are linked to the target asset or TML Group, with the exception of the following fields:
 - Allowable Measured Variance
 - Corrosion Rate Variance
 - Default Inspection Interval
 - Minimum CR
- You can select TMLs from multiple source assets or TML Groups for a single relocate operation, but you can select only a single target. If you want to relocate TMLs to more than one target asset or TML Group, you will need to perform the relocate procedure multiple times.
- After the TMLs are relocated, all calculations will be updated for the Corrosion Analysis that is associated with the source and target asset or TML Groups.

Access a Thickness Measurement Location (TML)

About This Task


This topic describes how to access a TML via the **Analysis Overview** workspace for an asset or TML Group. You can also [access the Analysis Overview workspace](#) directly for a TML.

Procedure

1. [Access the Analysis Overview workspace](#) for the asset or TML Group that contains the TML that you want to access.
2. In the workspace, select the **TMLs** tab.
The **TMLs** section appears, displaying the following information:

- If you selected an asset, a list of TMLs linked to the asset appears. This list includes TMLs linked to TML Groups or subcomponents linked to the selected asset.
- If you selected a TML Group, a list of TMLs linked to the TML Group appears.
- The [color-coding categories](#) appear at the top of the section. The number in parentheses next to each category indicates the number of TMLs in each category.
- The visual cue that appears in each row indicates the color-coding category that is applicable to the TML.

Tip: In the **TMLs** section, you can:

- Choose to view all TMLs or only the TMLs whose status is Active. To view all TMLs, clear the **Active** check box.
 - Select a color-coding category to filter the list of TMLs in that category. For example, if you select **Below T-Min**, the TMLs that meet the criterion for Below T-Min appear. You can remove the filter by selecting the same category again.
 - Delete a TML by selecting . This button is only available for security users associated with the MI Thickness Monitoring Administrator Security Group.
3. In the row containing the TML that you want to access, select the link.
The **Measurements** section appears.
 4. Select the **Analysis Output** tab.
The **Analysis Output** section appears, displaying a summary of the associated TML Corrosion Analysis.
 5. If you want to access the TML datasheet, select the **TML Details** tab.
The **TML Details** section appears, displaying the TML datasheet.


Tip: If needed, modify values in the [available fields](#), and then select  to save your changes.


Filter Thickness Measurement Locations (TMLs)

About This Task

This topic describes how to filter TMLs based on set criteria.

Procedure

1. [Access the Analysis Overview workspace](#) for the asset or TML Group that contains the TML that you want to access.
2. In the workspace, select the **TMLs** tab.
The **TMLs** section appears.
3. Select .
The **Filter Columns** window appears.
4. Specify filter criteria in the **Filter Columns** window, and then select **Apply**.
The TMLs are filtered based on the criteria you entered.


Note: You can also filter TMLs using the  button in the following windows:

- Relocate TMLs
- Organize TMLs
- Renew TMLs
- Exclude TMLs

Tip: To clear a filter, next to the filter that you want to clear, select .

Create a Thickness Measurement Location (TML)

Procedure

1. Access the [Analysis Overview](#) workspace for the asset or TML Group for which you want to create a new TML.
2. In the left pane, select , and then select **TML**.
The **Create TML** window appears.
3. In the **TML ID** box, enter a unique TML ID.
4. In the **Analysis Type** box, select the type of analysis that you want to create.
If you have defined additional required fields for TMLs, proceed to the next step. Otherwise, skip to step 7.
5. Select **Next**.
The TML datasheet appears.
6. As needed, enter values in the [available fields](#).
7. Select **Done**.
The new TML is created, and the **TML Overview** workspace appears.

Results

- The new TML is linked to the record selected in step 1.
- [TML Corrosion Analysis Settings](#) are created automatically for the new TML. The values in the TML Analysis Settings are inherited from the analysis settings for the asset or TML Group selected in step 1.
- You can modify the TML by accessing the datasheet.



Configure the Thickness Monitoring Location (TML) Section


About This Task


You can configure the table in the **TMLs** section by adding or removing fields using the **Choose Columns** window.

Note: The **Choose Columns** window displays all the fields from the [TML Corrosion Analysis](#) and [Thickness Monitoring Location](#) families except for the TML ID field. The table in the **TMLs** section displays the default column configuration for first-time users. You can access the **Choose Columns** window to add or remove columns from the table. You can also arrange the columns in the table. Any changes made to the columns in the table in the **TMLs** section of the **Analysis Overview** page are saved to the APM database for APM users.

Procedure

1. Access the [Analysis Overview](#) workspace containing the **TMLs** section that you want to configure.
2. In the **Analysis Overview** workspace, select the **TMLs** tab.
The **TMLs** section appears.
3. In the **TMLs** section, select .
The **Choose Columns** window appears.
4. In the **Choose Columns** window, in the **Available Fields** section, select the fields you want to appear in the table, and then select .

Tip: To remove a field from the table, in the **Choose Columns** window, in the **Display Fields** section, select the field you want to remove from the table, and then select .


5. Optionally, to reorder the fields in the **Display Fields** section, select .
6. Select **OK**.
The selected fields appear in the **TMLs** section.

Results

- The TML table configuration is saved as a user preference in the APM database.
- The fields added via the **Choose Columns** window also appear in the following areas:
 - The [Renew TMLs](#) window
 - The [Exclude TMLs](#) window
 - The [Organize TMLs](#) window
 - The [Relocate TMLs](#) workspace

Copy Thickness Measurement Locations (TMLs)

Procedure


1. [Access the TML](#) that you want to copy.
2. In the upper-right corner of the page, select , and then select **Copy TML**.
The **Copy TML** window appears.
3. Complete the required fields:
 - In the **Number of Copies** box, use the arrows to indicate how many copies of the selected TML you want to create.
 - In the **TML ID** field, enter a unique name for the copied TML
 - **Important:** You cannot update the **TML ID** field if are copying more than one TML. If you copy multiple TMLs, this field will be populated automatically.
4. Select **OK**.
The **Analysis Overview** workspace appears, and the newly copied TMLs appear in the left pane.

Relocate a Thickness Measurement Location (TML)

About This Task

You can relocate TMLs to move TMLs from a source asset or TML Group to a different target asset, or to a TML Group or subcomponent linked to that target asset. If you need to move TMLs to or between subcomponents linked to the same asset, use the [Organize TMLs](#) method.

Procedure

1. [Access the Analysis Overview workspace](#) for the asset the TMLs you want to relocate.
2. Select , and then select **Relocate TMLs**.
The **Relocate TMLs** workspace appears.
3. In the list, select the check boxes corresponding to the TMLs that you want to relocate.

Note: If you do not see the TMLs that you expect, or want to limit the list, in the upper-left corner of the workspace, confirm the setting in the **Analysis Type** list, and whether the **Active TMLs Only** check box is selected.

4. Select **Select an Asset**.
The **Select Target** window appears.
5. In the Asset Hierarchy, navigate to the asset to which you want to relocate the TMLs.
In the **Selected Item** box, the Asset ID for the asset appears. In the **Available Subcomponents** box, a list of linked subcomponents appears.
6. If you want to relocate the TMLs to a subcomponent, such as a TML Group, in the **Available Subcomponents** box, select the subcomponent to which you want to relocate the TMLs.
7. Select **Done**.
The TMLs are relocated to the selected asset or subcomponent.


Results

The analyses of the affected assets and subcomponents are recalculated.

Important: You cannot relocate TMLs from a non-piping asset to a piping asset. In addition, the **Relocate TMLs** option is not available for piping assets.

Renew Thickness Measurement Locations (TMLs)

Procedure

1. Access the [Analysis Overview workspace](#) for the asset or TML Group that contains the TMLs that you want to renew.
2. Select , and then select **Renew TMLs**.

Note: For piping assets, the **Renew TMLs** option is only available at the component and band levels.

The **Renew TMLs** window appears, displaying a list of the TMLs linked to the asset or TML group.

Tip: For piping components and bands, you can view the position of each TML in the band from the **POSITION** column.

3. Select the check boxes corresponding to the TMLs that you want to renew.

Note: If you do not see the TMLs that you expect, or want to filter the list, verify the filter settings. You can configure to view only the active TMLs and filter the list based on the analysis type.

4. Select **Renew TMLs**.
The renewal of TMLs starts and the renewal progress appears in the upper-right corner of the **Renew TMLs** window.


Tip: The renewal process continues even if you close the **Renew TMLs** window. You can view the progress of the job from the Schedule Logs. In case any TML fails to renew, the job is placed in the **Failed** section of the **Schedule Logs** page.

Organize Thickness Measurement Locations (TMLs)

About This Task

You can organize TMLs to move TMLs to or between TML Groups and subcomponents associated with the same asset. If you want to move TMLs to another asset, or to a subcomponent of that asset, you should [relocate those TMLs](#).

Procedure

1. Access the [Analysis Overview workspace](#) for the TML Group or subcomponent to which you want to move TMLs.
2. In the upper-right corner of the workspace, select , and then select **Organize TMLs**.
The **Organize TMLs** workspace appears, displaying a list of TMLs linked to the asset to which the TML Group or subcomponent you selected in step 1 is linked. This list includes TMLs linked to all TML Groups and subcomponents that the asset contains, including the one that you selected in step 1.
Note: If you do not see the TMLs that you expect, or want to limit the list, in the upper-left corner of the workspace, confirm the setting in the **Analysis Type** list, and whether the **Active TMLs Only** check box is selected.
3. Select the check boxes corresponding to the TMLs that you want to move to the TML Group or subcomponent.
4. Select **Move**.
The selected TMLs are moved to the TML Group or subcomponent, and the corrosion analysis is recalculated.

Results


Important: The **Organize TMLs** option is not available for piping assets.

Exclude a Thickness Monitoring Location (TML)

Before You Begin

- Only MI Thickness Monitoring Administrator and members of the MI Thickness Monitoring Inspector Security Group can exclude TMLs from an analysis.

Procedure

1. Access the [Analysis Overview workspace](#) for the asset or TML Group that contains the TMLs that you want to exclude.
2. In the workspace, select the **TMLs** tab.
A list of TMLs contained in the analysis appears in the workspace.
3. In the upper-right corner of the workspace, select , and then select **Exclude TMLs**.
Note: For piping assets, the **Exclude TMLs** option is only available at the component and band levels.
The **Exclude TMLs** window appears, providing a list of TMLs in the analysis. If a TML has already been excluded, the corresponding check box is selected.
Tip: For piping components and bands, you can view the position of each TML in the band from the **POSITION** column.
4. In the list, select the check boxes corresponding to the TMLs that you want to exclude.
Note: If you do not see the TMLs that you expect, or want to limit the list, in the upper-left corner of the window, confirm the setting in the **Analysis Type** box, and whether the **Active TMLs Only** check box is selected.
5. Select **Done**.
The selected TMLs are excluded from the analysis.


Tip: At this time, you can [calculate the Analysis](#) with the newly excluded TMLs by selecting .

Access the TM Quick View Page

About This Task

The **TM Quick View** page displays a list of TMLs in an asset or TML Group, along with details on the corrosion rate, next inspection date, measurements taken in each month, and so on.

Procedure

1. Access the **Analysis Overview** workspace for the asset or TML Group whose TMLs you want to view.
2. Select , and then select **Quick View**.

Note: For piping assets, the **Quick View** option is only available at the component and band levels.

The **TM Quick View** page appears.


Tip: For piping components and bands, you can view the position of each TML in the band from the **POSITION** column.

Note: The unit of measure displayed on the grid is based on your selections on the **Units of Measure and Conversion Set** page.





The **TM Quick View** page displays the following information:

- From the **Thickness Measurement Location** family:
 - Minimum Thickness
 - TML Analysis Type
 - TML Asset ID
 - TML ID

Tip: You can select the link in the **TML ID** column to access the **Analysis Overview** page corresponding to a TML.
- From the **TML Corrosion Analysis** family:
 - Corrosion Rate
 - Projected T-Min Date
 - Scheduled Next Inspection Date
- From the **Thickness Measurement** family:
 - <Month><Year>: Contains a list of measurements for the month and year displayed in the column heading, separated by a semicolon.

Note: By default, the **TM Quick View** page displays measurements taken in the past ten years. If you want to modify the data range, in the upper-left corner of the page, select .

Note:

- To export specific rows from TM Quick View Data in PDF format, select the checkbox of each row that you want to download, and then select . If you do not select any checkbox and select , all row data is downloaded in PDF format.
- To export TM Quick View Data in Excel format, select the checkbox of each row that you want to download, and then select . If you do not select any checkbox and select , all row data is downloaded in Excel format.

Modify TMLs in Bulk

Procedure

1. Access the [Analysis Overview workspace](#) for the asset or TML Group that you want to modify.
2. In the workspace, select the **TMLs** tab.
The **TMLs** section appears.
3. Next to each TML that you want to modify, select the check box, and then, in the upper-right corner of the section, select **Edit in Bulk**.
The **Bulk Edit TMLs** window appears, displaying the selected TMLs.

Tip: The Bulk Edit TMLs window displays 50 TMLs per page.

4. As needed, on the **Bulk Edit TMLs** window, modify the fields.
5. Select **Save**, and then select **Close**.
The selected TMLs are modified.

Tip: The TMLs you selected appear in the TML Bulk Edit datasheet.

Access the TML Trends Graph

About This Task

Note: If you are a member of the MI TM Viewer Security Group, or if you are assigned the MI Mechanical Integrity Viewer Security Role, then you cannot access the Trends graph.

Procedure

1. Access the [TML](#) whose Trends graph you want to access.
2. In the workspace, select the **Analysis Output** tab.
3. Expand the **TRENDS** section.
The **TRENDS** section appears, displaying the Trends graph.

Note: By default, the Trends graph displays data based on the thickness measurements and Controlling Corrosion Rate for the TML.

Note: Alert levels 1 and 2 are calculated by multiplying the Minimum Thickness value with the values defined in the **Wall Ratio Preferences** section of the **TM Admin Preferences** page. To view or hide a line representing an alert level, select the corresponding alert level from the **Plot Lines** field. To view or hide the line representing the Nominal Thickness, select the **Nominal Thickness** option from the **Plot Lines** field.

4. At the bottom of the section, select:
 - **Thickness Measurements** to view or hide plotted points based on the values of linked Thickness Measurements.
 - **Controlling CR** to view or hide trend lines based on the Controlling Corrosion Rate.
 - **LSCR, STCR, or LTCR** to view or hide trend lines based on the Least Squares, Short Term, or Long Term Corrosion Rates.

Note: At most, two of the three options, **LSCR, STCR, or LTCR**, will be available at any given time. The third one is represented by **Controlling CR**. The options are visible if the corresponding corrosion rates exist.


Define Allowable Stress

About This Task

This topic describes how to define the Allowable Stress value for a TML manually. You can also [have APM populate the value](#) based on values in a few fields in the TML record. This procedure can be performed before or after you have automatically calculated Allowable Stress for a TML.

Note: Refer to the [Allowable Stress reference tables](#) and the [method of interpolation](#) used in Thickness Monitoring.

Procedure

1. [Access the TML](#) for which you want to define Allowable Stress.
2. In the workspace, select the **TML Details** tab.
The **TML Details** section appears, displaying the **General Information** subsection.
3. Select the **Design General** tab.
The **Design General** subsection appears.
4. Select the **Override Allowable Stress** check box.
The **Allowable Stress** box is enabled.
5. Enter a value in the **Allowable Stress** box.
6. Select .
The Allowable Stress value is saved.

Calculate Allowable Stress

About This Task

This topic describes how to have APM calculate the value in the Allowable Stress field automatically. You can also [define a value manually](#).

Note: Refer to the [Allowable Stress reference tables](#) and the [method of interpolation](#) used in Thickness Monitoring.

Procedure

1. [Access the TML](#) for which you want to define Allowable Stress.
2. In the workspace, select the **TML Details** tab.
The **TML Details** section appears, displaying the **General Information** subsection.
3. Depending on the type of equipment the TML represents (i.e., the component type), enter values in the required fields.
For Piping and Pressure Vessels, enter values in the following fields:
 - **Code Year (Allowable Stress Lookup)**
 - **Design Code**
 - **Material Grade**
 - **Material Specification**
 - **Design Temperature**


For Tanks of the type Welded Shell, enter values in the following fields:

- **Code Year** (Allowable Stress Lookup)
- **Course Number**
- **Design Code**
- **Tank Type**
- **Material Grade**
- **Material Specification**

For Tanks of the type Annular Ring, enter values in the following fields:

- **Maximum Operating Fill Height**
- **Tank Diameter**
- **Specific Gravity**
- **Plate Thickness**

The Allowable Stress field is [populated with a value based on the component type](#).

4. In the upper-right corner of the section, select .
The Allowable Stress value is saved.

Make a Thickness Measurement Location (TML) Inactive

Before You Begin

- When you make a Thickness Measurement Location (TML) inactive, it will be excluded from any future corrosion analysis calculations.

Procedure


1. [Access the TML](#) that you want to make Inactive.
2. In the workspace, select the **TML Details** tab.
The **TML Details** section appears, displaying the **General Information** subsection.
3. In the **Status Indicator** box, select **Inactive**, and then select **Save**.
The TML is now inactive.

Delete a Thickness Measurement Location (TML)

Before You Begin

- When you delete a TML, any linked measurements, Corrosion Analysis Settings, and TM Corrosion Analyses are also deleted.

Procedure

1. [Access the TML](#) that you want to delete.
2. Select , and then select **Delete**.

Note: The **Delete** option is only available for security users associated with one of the following security groups:

- MI Thickness Monitoring Administrator
- MI Thickness Monitoring Inspector
- MI Thickness Monitoring User

- MI Thickness Monitoring Viewer

If a security user is not associated with the MI Thickness Monitoring Administrator security group and does not have additional delete privileges, when the user attempts to delete the TML, an error message will appear.

A message appears, asking you to confirm that you want to delete the TML and any linked Thickness Measurements.

3. Select **Yes**.

The TML is deleted.

Chapter 5

TML Groups

Topics:


- [About TML Groups](#)
- [About Equipment and TML Groups](#)
- [About Corrosion Analyses that Include TML Groups](#)
- [About Corrosion Analyses that Exclude TML Groups](#)
- [About TML Groups and RBI Components](#)
- [Create a TML Group](#)
- [Link a TML Group to RBI Components](#)
- [Delete a Thickness Monitoring Location \(TML\) Group](#)

About TML Groups

A TML Group is a group of TMLs that represent a component of an asset.

Details

Suppose you have an asset, Piping Circuit 101, which contains three components, Line A, Line B, and Line C. On those components, there are multiple TMLs. The following image illustrates this example, where the components are represented by shaded regions, and the TMLs are represented by stars.




For a given asset, a TML Group can represent:

- **All TMLs that exist on that asset.** You would create a TML Group to represent all TMLs that exist on an entire asset if the asset is a standalone asset. You would create one TML Group to represent all of the stars.




- **A subset of TMLs that exist on one or more components that belong to the asset.** Using this option, you could create:
 - One TML Group per component, where the TML Group represents all TMLs that exist on that component. You would create three TML Groups, one to represent each set of stars.



-or-

- **One TML Group for multiple components, where the TML Group represents all TMLs that exist on those components.** Using the previous Piping Circuit 101 example, you could create two TML Groups, where one represents the blue and green stars and one represents the orange stars.



Additionally, throughout the life of the asset, you might identify one or more TMLs within a TML Group that you want to analyze separately from other TMLs. In this case, you can create additional TML Groups to represent any subdivision of an existing group of TMLs.

For example, suppose that an asset that you are analyzing in Thickness Monitoring represents a shell and tube heat exchanger. The shell and tube heat exchanger has two components, the shell side and the tube side, each with its own process flow. Since the corrosion environments of these components will differ, you might create the following TML Groups:

- TML Group - Shell Side
- TML Group - Tube Side

When you first begin analysis on the shell and tube heat exchanger, you are not sure what the TM corrosion data will show, (i.e., whether TML Group - Shell Side or TML Group - Tube Side will have more aggressive corrosion). After you have completed some analysis on the shell and tube heat exchanger, you notice that a subset of TMLs on the shell side near the nozzle have very high corrosion rates. At this point, you create a third TML Group, TML Group - Shell Nozzle to represent this component, and you move the TMLs associated with this component from TML Group - Shell Side to TML Group - Shell Nozzle.

Regardless of what they represent, all TML Groups in a Corrosion Analysis will be linked directly to a single asset. If you decide to use TML Groups, all TMLs in your Corrosion Analysis should be linked directly to TML Groups (rather than the asset to which the TML Groups are linked).

About Equipment and TML Groups

Each [Corrosion Analysis](#) begins with an asset for which you want to monitor corrosion. The asset you want to monitor may consist of a number of components you want to monitor independently. If so, you can create a TML Group for each component to contain the TMLs that are for that specific component.

Details

Before you can conduct a Corrosion Analysis on an asset, an Equipment record must exist in the APM database to represent the asset on which you want to perform the corrosion analysis. The types of records that you create in your Corrosion Analyses will depend upon what your Equipment records represent.

Before you can create TML Groups, an Asset Corrosion Analysis and Corrosion Analysis Settings must be created for an asset, represented by an Equipment record. Equipment records can be created manually via Record Manager, or they may be loaded into your database from another data source (e.g., SAP). After assets exist, you can [create TML Groups](#).

Example: Using Piping Circuits to define TML Groups

Consider, for example, a piping circuit that contains three piping lines. You might want:

- [One Equipment record to store all of the information](#) for the piping circuit and the three piping lines.

-or-

- One Equipment record to store information for the piping circuit and three TML Groups to store information for the individual piping lines (one TML Group for each piping line). These TML Groups would be linked directly to the Equipment record that stores information for the piping circuit.

About Corrosion Analyses that Include TML Groups


You should include TML Groups in your Corrosion Analyses if any of the assets that you will analyze in TM consist of components that you want to analyze individually, or you want to analyze corrosion data for certain groups of TMLs on an asset or component. What the TML Groups that you create represent will depend upon whether the associated Equipment record represents a standalone asset or an asset that contains components.

If you use this method:

- You must configure preferences for the Equipment family.
- Each TML Group that you create will be linked to an Equipment record representing the asset through the Has TML Group relationship.
- An Asset Corrosion Analysis and Corrosion Analysis Settings will be created and linked to the Equipment record representing the asset, as well as each TML Group that is linked to that asset.
- All TMLs that you create will be linked directly to a TML Group. In this case, TMLs should not be linked directly to the asset.

Details

The following diagram illustrates the structure of Corrosion Analyses that include TML Groups. Specifically, this diagram illustrates the records and links that would exist if a Corrosion Analysis included one Equipment record (representing an asset), which is linked to three TML Groups. The boxes in the diagram are labeled according to the records that they represent, and the lines connecting the boxes represent the links between these records in a Corrosion Analysis.



The following table provides information on how the records that are illustrated in the diagram are created manually or automatically.

Record	Notes
Corrosion Analysis Settings	Manually for Equipment records -and- Automatically for TML Groups that you create and link to those equipment records.
Asset Corrosion Analysis	Automatically for Equipment records and TML Groups, but at different points in the workflow .
Equipment	Manually.

Record	Notes
Thickness Measurement	Manually.
Thickness Measurement Location	Manually.
Thickness Monitoring Task	Automatically (when a Corrosion Analysis Setting are created).
TML Corrosion Analysis	Automatically (when a Thickness Measurement Location record is saved).

About Corrosion Analyses that Exclude TML Groups


You can exclude TML Groups from your TM analyses if none of the equipment that you will analyze in TM contain components, or if you want to analyze an asset without considering the components individually.

If you use this method:

- Asset Corrosion Analyses and Corrosion Analysis Settings will be created and linked to each Equipment record.
- All TMLs that you create will be linked directly to Equipment records representing assets.

Details

The following diagram illustrates the structure of Corrosion Analyses that do not include TML Group records. The boxes in the diagram are labeled according to the records that they represent, and the lines connecting the boxes represent links between these records in a Corrosion Analysis.



The following table provides information on how the records illustrated in the diagram are created manually or automatically.

Record	Notes
Corrosion Analysis Settings	Automatically.
Asset Corrosion Analysis	Automatically (when a Corrosion Analysis Setting are created for an Equipment record).
Equipment	Manually.
Thickness Measurement	Manually.
Thickness Measurement Location	Manually.

Record	Notes
Thickness Monitoring Task	Automatically (when a Corrosion Analysis Setting are created).
TML Corrosion Analysis	Automatically (when a Thickness Measurement Location record is saved).

About TML Groups and RBI Components

You can use TML Corrosion Analyses to determine corrosion rates in Risk Based Inspection (RBI). To complete the analysis, you must perform key steps in this workflow within the RBI module. If you want to specify that TML Group values should be used to calculate RBI corrosion rate values, you can perform this step using TM rather than RBI. Before you can link an RBI Component to a TML Group, you must first create an RBI Component for the asset, and then set the Source of Calculated Corrosion Rate field for the component to Component.

Note: For more information on RBI Components, see the Risk Based Inspection section of the documentation.

Details

To complete this task, you will need to link a TML Group to a Criticality Calculator RBI Component. When you link a Criticality Calculator RBI Component to a TML Group, RBI corrosion rate values for the RBI Analysis that you create are based on the average of the following values in the TML Corrosion Analysis:

- Long Term Corrosion Rate
- Short Term Corrosion Rate


In other words, the values in the preceding list will determine the following values in the Criticality Int. Corr. Deg. Mech. Eval record associated with the RBI Analysis that is created from the linked TML Group record:

- Short Term Avg. Corr. Rate
- Long Term Avg. Corr. Rate

Note: When you use TM to select a TML Group to link to a Criticality Calculator RBI Component, you will do so for only one TML Group at a time. Alternatively, via RBI, you can select more than one TML Group at a time to link to a Criticality Calculator RBI Component.

Create a TML Group

Procedure

1. Access the [Analysis Overview workspace](#) for the asset for which you want to create a TML Group.
2. In the left pane, select , and then select **TML Group**.
The Select Analysis Type window appears.
3. On the **Select Analysis Type** window, select either **UT** or **RT** for the analysis type, and then select **Done**.
The new TML Group is created as a subcomponent of the asset.

Results

- The TML Group ID is automatically generated.

- The TML Group inherits the [Corrosion Analysis Settings](#) from the asset.
- You can make changes to the TML Group by accessing the datasheet.

Link a TML Group to RBI Components

Before You Begin


Create an RBI Component for the asset, and then set the Source of Calculated Corrosion Rate field for the component to Component.

Note: For more information on creating RBI Components, refer to the Risk Based Inspection section of the documentation.

About This Task

You can link multiple RBI Components to a TML Group.

Procedure

1. Access the [Analysis Overview workspace](#) for the TML Group to which you want to link an RBI Component.
2. In the workspace, select  , and then select **Manage RBI Components**. The **Manage RBI Components** window appears.
3. Next to each RBI Component that you want to link to the TML Group, select the check box.

Note: To unlink the TML Group, you can repeat this procedure and clear the check box.

4. Select **OK**.
The TML Group is now linked to the RBI Components.

Results


- RBI Components linked to TML Groups inherit the corrosion rate values from the TML Groups. The resulting RBI Analysis is based on the average of the following values in the TML Corrosion Analyses linked to the TML Group:
 - [Short Term Corrosion Rate](#)
 - [Long Term Corrosion Rate](#)
 - [Controlling Corrosion Rate](#)

Delete a Thickness Monitoring Location (TML) Group

Before You Begin

- When you delete a TML Group, the following linked records are also deleted:
 - TMLs
 - Thickness Measurements
 - Corrosion Analysis Settings
 - TML Corrosion Analyses
 - Asset Corrosion Analyses

Procedure

1. Access the [Analysis Overview workspace](#) for the TML Group that you want to delete.
2. Select , and then select **Delete**.

Note: The **Delete** option is only available for security users associated with one of the following security groups:

- MI Thickness Monitoring Administrator
- MI Thickness Monitoring Inspector
- MI Thickness Monitoring User
- MI Thickness Monitoring Viewer

If a security user is not associated with the MI Thickness Monitoring Administrator security group and does not have additional delete privileges, when the user attempts to delete the TML Group, an error message will appear.

A message appears, asking you to confirm that you want to delete the TML Group.

3. Select **Yes**.

The TML Group is deleted.

Note:

To allow the deletion of TML groups that has larger number of TMLs associated with an asset, the delete operation is provided as a scheduled action. You can download the corresponding logs from the [Download Job Logs](#) page.

Chapter 6

Thickness Measurements

Topics:

- [About Thickness Measurements](#)
- [About Nominal and Actual Measurements](#)
- [About Skipped Measurements](#)
- [How Measurement Values Are Determined](#)
- [About Measurement and Corrosion Rate Variance](#)
- [About Measurement and Corrosion Rate Variance Validation](#)
- [About Measurement Correction Based on Growth](#)
- [Access Thickness Measurements](#)
- [Add a Thickness Measurement](#)
- [Add a Nominal Measurement](#)
- [Create Measurement Not Taken \(MNT\) Records](#)
- [Modify a Thickness Measurement](#)
- [Use the Measurement Data Entry \(MDE\) Workspace](#)
- [Delete a Thickness Measurement](#)

About Thickness Measurements

Thickness Measurements represent readings that are recorded at locations on an asset or one of its components. They are created and linked to TMLs.

Details

A Thickness Measurement is a value that quantifies the thickness of a given TML at a specific point in time. Each TML will have various types of Thickness Measurements, including:

- **Base Measurement** : The first measurement taken for the TML.
- **Near Measurement** : The second-most-recently-recorded measurement for the TML.
- **Last Measurement** : The most-recently-recorded measurement for the TML.

Base, Near and Last Measurements are not recorded in the Thickness Measurements themselves. Instead, they are determined for the TML Corrosion Analysis by evaluating how many Thickness Measurements exist, and when the Thickness Measurements were created. After you create a new TML, you will want to record the base measurement, which represents the first recorded reading for that TML. Additional Thickness Measurements will be created later, as measurement readings are taken throughout the life of the asset.

Important: To ensure data integrity, existing Thickness Measurements should be managed using Thickness Monitoring instead of the Record Manager.

About Nominal and Actual Measurements

Each Thickness Measurement can be classified as either a nominal measurement or an actual measurement.

- A nominal measurement represents a reading that is not taken physically but is recorded from some other source, such as a design specification.
- An actual measurement represents a reading that is taken manually at the physical thickness measurement location on the equipment.

Details

Actual measurements are typically more accurate and result in calculations that are more representative of the actual asset. Nominal measurements may not be as accurate, but provide an efficient mechanism for recording initial measurement data.

Any nominal measurement value can be used in the creation of a nominal measurement. Nominal measurements are used only for the base measurement (i.e., the first measurement).

- Measurement data will be populated automatically for the initial Thickness Measurement linked to TMLs configured for nominal base measurements.
- Measurement data must be entered manually for Thickness Measurements that are linked to TMLs that are not configured for nominal base measurements.

Thickness Monitoring will use all active thickness measurements for performing TML Corrosion Analysis calculations. Nominal measurements will become inactive measurement automatically after two subsequent actual measurements have been recorded. In other words, if the Measurement Taken Date of any two actual measurements is after the Measurement Taken Date of a nominal measurement, the nominal measurement will become an inactive measurement.

About Skipped Measurements

APM Thickness Monitoring provides the option to skip measurements. This applies when you want to satisfy inspection requirements, but do not want to take an actual measurement at the TML. When you skip a measurement, instead of creating a Thickness Measurement for a TML, you will create a Measurement Not Taken (MNT) record to store the inspection data.

Important: The APM Thickness Monitoring Best Practice is to record actual readings for all inspections and not skip measurements. This section of the documentation provides information on using this functionality. All TM documentation outside of this section assumes that the Skip Measurements feature is disabled.

Details

Some reasons that you may want to skip measurements include:

- The physical location of certain TMLs may be difficult to reach or may require a shutdown in order to take a measurement.
- Your organization may have a strategy that calculates based on a certain percentage of TML measurements for an asset.
- Resource limitations may make it difficult or impossible to take measurements at all TMLs on an asset or its components.

In order to skip measurements in Thickness Monitoring, the [Allow Measurements to be Skipped check box](#) must be selected on the **TM Admin Preferences** page. Then you will need to [create MNT records](#) to represent any measurement that was skipped. After you have enabled this option and created MNT records, Corrosion Analyses containing skipped measurements will be updated to take those MNT records into account.

Skipping Measurements Consecutively

If you enable the option to skip measurements in TM, you will also have the option to enable a feature that allows you to skip measurements consecutively. When you do this, you will be able to create successive MNT records.

Example: Skipping Measurements Consecutively

Suppose that the TML TML01 is difficult to reach. As a result, your organizational policy dictates that while readings for all other TMLs on the associated piece of equipment must be taken every six months, a reading for TML01 must be taken only once per year, as illustrated in the following table.

TML	Scheduled Readings
TML01	June 1, 2014 June 1, 2015
TML02	June 1, 2014 December 1, 2014 June 1, 2015 December 1, 2015
TML03	June 1, 2014 December 1, 2014 June 1, 2015 December 1, 2015

Suppose that you create an MNT record when a reading is skipped for TML01 on December 1, 2014. Next, suppose that, due to budget constraints at your facility, the scaffolding necessary to gain access to TML01 is unable to be built on June 1, 2015 (the date on which an actual thickness measurement reading is scheduled to be taken for this TML). In this case, you may want to create another MNT record for TML01, assuming that an actual measurement will be taken when possible.

Interpreting Calculations in Corrosion Analyses that Include Skipped Measurements

When active Thickness Measurements and MNT records exist in a Corrosion Analysis, all calculations, with the exception of Interval Next Inspection Date, are calculated as if MNT records are not included in your Corrosion Analysis.

Consider the calculation for Short Term Corrosion Rate. Short Term Corrosion Rate is calculated using the Short Term Loss and Short Term Interval, where:

$$\text{Short Term Corrosion Rate} = \text{Short Term Loss} / \text{Short Term Interval}$$

...where:

$$\text{Short Term Loss} = \text{Near Measurement Value} - \text{Last Measurement Value}$$

...and:

$$\text{Short Term Interval} = \text{Last Measurement Date} - \text{Near Measurement Date}$$

Example: Corrosion Analyses that Include Skipped Measurements

Consider the following measurements.

ReadingDateMeasurement (inches)

Reading	Date	Measurement (Inches)
Base	1/1/1985	.2
N/A	1/1/1987	<Measurement Not Taken>
Near	1/1/1990	.195
N/A	1/1/1993	<Measurement Not Taken>

Reading	Date	Measurement (Inches)
Last	1/1/1995	.19
N/A	1/1/2000	<Measurement Not Taken>

Short Term Loss = .195 - .19

Short Term Loss = .005

Short Term Interval = 1/1/1995 - 1/1/1990

Short Term Interval = 5 years

Short Term Corrosion Rate = .005 / 5

Short Term Corrosion Rate = .001

The Short Term Loss was not calculated using a Last Measurement Value of 1/1/2000, the date in the MNT record that is associated with the most recent inspection of this TML. There is no value associated with this date (or the date in ANY MNT record) and therefore, these records are ignored in all calculations with the exception of Interval Next Inspection Date.

Interval Next Inspection Date

When MNT records are included in a Corrosion Analysis, Interval Next Inspection Date is calculated using the following equation:

Interval Next Inspection Date = Last Measurement Date + Default Inspection Interval

Where **Last Measurement Date** is the most recent value in the Measurement Taken Date field of both the active Thickness Measurement and active MNT records linked to a given TM

Example: Interval Next Inspection Date

Consider a Default Inspection Interval of 60 months (i.e., 5 years) and a TML that is linked to records with the following Measurement Taken Dates:

Record	Measurement Taken Date
Thickness Measurement	1/1/2004
Measurement Not Taken	1/1/2005
Thickness Measurement	1/1/2006
Measurement Not Taken	1/1/2007

In this case, the Interval Next Inspection Date would be calculated as:

Interval Next Inspection Date = 1/1/2007 + 60 months

Interval Next Inspection Date = 1/1/2012

Skipped Measurements and TML Corrosion Analysis Fields

When the most recent date is from an MNT record, and when the Corrosion Rate of a TML is less than the Controlling Corrosion Rate of the asset, the following fields in the TML Corrosion Analysis are populated with data based on the Controlling Corrosion Rate:

- Asset Average Corrosion Rate
- Asset Average Corrosion Rate Remaining Life

- Asset Average Corrosion Rate Retirement Date
- Asset Average Corrosion Rate Next Inspection Date

This differs from when the fields are populated in a Corrosion Analysis that does not include skipped measurements.

Example: Skipped Measurements in TML Corrosion Analysis Fields

Consider an asset with:

- An Asset Corrosion Analysis with a Controlling Corrosion Rate of 2.9 Mils/year.
- A TML Corrosion Analysis for a TML linked to the asset, with a Corrosion Rate of 2.2 Mils/year. The most recent measurement date is from an MNT record.

In this case, the Asset Average Corrosion Rate would be set to 2.9 Mils/year.

This Asset Average Corrosion Rate value could be the result of any method that is specified to determine the asset controlling corrosion rate (Maximum, Average, or Formula). This differs from a Corrosion Analysis that does not include skipped measurements. When a Corrosion Analysis does not include skipped measurements, the Asset Average Corrosion Rate field is populated only when certain settings are specified, and this value can be the result only of an Average or Formula method.

Asset Average Corrosion Rate is an input to some of the calculations that are used to populate the Asset Average Corrosion Rate Remaining Life, Retirement Date, and Next Inspection Date fields. These calculations are performed using the same formulas that are used when a Corrosion Analysis does not include skipped measurements. The results of the same calculations in a Corrosion Analysis that includes skipped measurements versus a Corrosion Analysis that does not include skipped measurements, however, may differ because of the values that will be used to populate the Asset Average Corrosion Rate field in each of these Corrosion Analyses.

In every case, the value selected will be the most conservative (i.e., highest) corrosion rate, whether from the TML Corrosion Analysis Corrosion Rate field, or the Asset Corrosion Analysis Controlling Corrosion Rate field.

How Measurement Values Are Determined

The final value associated with a Thickness Measurement is stored in the [Measurement Value field](#). Values are not, however, entered directly into the Measurement Value field itself. Instead, values are entered into the Readings field.

To determine the Measurement Value for a Thickness Measurement, one or more readings will be collected at a given TML. To account for the margin of error associated with user error, equipment malfunction, or environmental conditions, you may wish to collect multiple readings for each Thickness Measurement. The number of readings that you may take for a measurement will depend upon various factors, including your company's policies, the characteristics of the TML, and the method that you are using to collect the readings. The number of readings that you must take for each measurement is determined by the value specified in the Number of Readings field in the TML to which the Thickness Measurement is linked.

After you have determined how many readings you must take for a specific measurement and have collected those readings, you will [add a Thickness Measurement](#) and log the reading values in the Readings box. [A calculation will be performed against the values in the Readings box](#), based on the [settings that you have defined for measurement readings](#). Then, the Uncorrected Measurement field will be populated with the result of that calculation. Finally, the Measurement Value field will be populated with the value in the Uncorrected Measurement field. The Measurement Value field will then contain a value representing the final, corrected thickness measurement value.

Note: The Uncorrected Measurement field is meant to serve as an intermediate storage location between the Readings and Measurement Value fields. In Thickness Monitoring, the Measurement Value field is simply populated with the value in the Uncorrected Measurement field. You can create custom rules for the Measurement Value field so that the Uncorrected Measurement value is adjusted based upon additional factors and the result of that calculation becomes the value in the Measurement Value field.

About Measurement and Corrosion Rate Variance

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About Measurement and Corrosion Rate Variance Validation

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About Measurement Correction Based on Growth

Thickness Measurements can be automatically corrected if they contain a value that is greater than a previous measurement.

About This Task

A Thickness Measurement is a growth if the value in the Uncorrected Value field is greater than the value in the Measurement Value field of the preceding measurement. APM can automatically detect this growth scenario and update the measurement to correct it. To enable this functionality, you must select the **Correct Measurements Based on Growth** check box in the TM **Admin Preferences** page on the **Global Preferences** workspace.

When a measurement is corrected based on growth, the following actions happen:

- The Measurement Value field of the measurement is updated with the value from the Measurement Value field of the preceding measurement. The value in the Uncorrected Measurement field is left as it is to be used later for future updates or comparisons.
- The Basis for Measurement Correction field is set to Growth to indicate that the value was changed and the reason for change.

Measurement correction occurs during the following scenarios:

- When a measurement is created against a Thickness Measurement Location. During this scenario, the measurement being created is evaluated and updated accordingly. Also, if the measurement was inserted between any existing measurements, the measurements following the newly created measurement are evaluated for growth and updated accordingly.
- When a measurement is updated, if the **Check for Growth** field is set to true prior to saving the record, the measurement is evaluated for growth and updated accordingly. Also, other measurements on the same related Thickness Measurement Location are evaluated and updated accordingly.

Note:

- A Thickness Measurement that is preceded by a Nominal Thickness Measurement will not have its value corrected for growth as it is considered the first actual measurement to be taken for that TML.
- When a Thickness Measurement is deleted, the set of remaining measurements are not corrected automatically for growth. If a correction for growth is required, it is recommended to set the Status

Indicator field of the Thickness Measurement to Inactive and set the Check for Growth field to true to force a correction for growth.

Examples

Scenario 1: Inserting a measurement with growth at the end of a collection

Assume the following collection of measurements exists where the highlighted row is being added as a new measurement.

Measurement Taken Date	Uncorrected Value (Inches)	Measurement Value	Basis for Measurement Correction
January 1, 2010	.75	.75	
January 1, 2015	.73	.73	
January 1, 2020	.735	.73	Growth

In this scenario because the value being entered on January 1, 2020, contains a growth over the value on January 1, 2015, its Measurement Value field gets updated with the previous measurement value and the Basis for Measurement Correction is updated to Growth.

Scenario 2: Inserting a measurement in the middle of a collection which creates a growth scenario

Assume the following collection of measurement exist where the highlighted row is being inserted in between the existing measurements.

Measurement Taken Date	Uncorrected Value (Inches)	Measurement Value	Basis for Measurement Correction
January 1, 2005	.75	.75	
January 1, 2010	.73	.73	
January 1, 2015	.72	.72	

Now assume a measurement with a value of .724 is created on January 1, 2008. The measurements will now look like:

Measurement Taken Date	Uncorrected Value (Inches)	Measurement Value	Basis for Measurement Correction
January 1, 2005	.75	.75	
January 1, 2008	.724	.724	
January 1, 2010	.73	.724	Growth
January 1, 2015	.72	.72	

Because the measurement was inserted between existing measurements, it now created a growth between it and the measurement that now follows it on January 1, 2010. That measurement then has its Measurement Value field updated with .724 and the Basis for Measurement Correction field set to "Growth".

Note: The measurement taken on January 1, 2015, is still a decrease from the value .724 that it will not be updated.

Scenario 3 – Updating a measurement

Assume the following collection of measurements exist where the measurements have already been corrected for growth

Measurement Taken Date	Status Indicator	Uncorrected Value (Inches)	Measurement Value	Basis for Measurement Correction
January 1, 2005	Active	.75	.75	
January 1, 2008	Active	.724	.724	
January 1, 2010	Active	.73	.724	Growth
January 1, 2015	Active	.72	.72	

Now, assume that the measurement on January 1, 2008, was determined to be inaccurate and has its Status Indicator field set to Inactive, the Check for Growth field is to true, and saved. The set of measurements would look like the following:

Measurement Taken Date	Status Indicator	Uncorrected Value (Inches)	Measurement Value	Basis for Measurement Correction
January 1, 2005	Active	.75	.75	
January 1, 2008	Inactive	.724	.724	
January 1, 2010	Active	.73	.73	
January 1, 2015	Active	.72	.72	

Because the measurement on January 1, 2008, was made inactive, the value from the measurement on January 1, 2010, of .73 is now being compared with the value from the measurement on January 1, 2005, which is no longer a growth. As a result, the Measurement Value field of the measurement on January 1, 2010, is reset to its Uncorrected Value and the value Growth is removed from the Basis for Measurement Correction field.

Access Thickness Measurements

About This Task

You can access Thickness Measurements in any one of the following sections:

- **TMLs**
- **Measurements**

Procedure


1. To access Thickness Measurements in the **TMLs** section, perform the following steps:
 - a) [Access the Analysis Overview workspace](#) for the asset or TML Group that contains the TML that you want to access.
 - b) Select the **TMLs** tab.

The **TMLs** section appears, displaying the following information:

- If you selected an asset, a table of TMLs linked to the asset appears. This table includes TMLs linked to TML Groups or subcomponents linked to the selected asset.


- If you selected a TML Group, a table of TMLs linked to the TML Group appears.

Note: If the TML Group that you want to access does not contain any TMLs, the **Details** section appears when you access the **Analysis Overview** workspace.

- c) In the row containing the TML for which you want to access the Thickness Measurement, select .

The row is expanded, and the Thickness Measurements appear below the row. The visual cue that appears in each row indicates the **color-coding category** that is applicable to the Thickness Measurement.

Note: By default, only active Thickness Measurements are displayed. If you want to access all measurements, clear the **Active Measurements Only** check box.

Tip: You can select the **Column Chooser** () button to add or remove columns from the table. The **Measurement Taken Date** field is pinned to the first column and is always displayed. In addition, the **MEASUREMENT TAKEN DATE** column is locked when using the scroll box to move through the columns.

The fields that appear in the **Choose Columns** window are taken from the Thickness Measurement family. By default, the following columns are displayed:

- MEASUREMENT TAKEN DATE
- MEASUREMENT VALUE
- READINGS
- READINGS PASS/FAIL
- VERIFY MEASUREMENT
- MEASUREMENT VERIFIED
- MEASUREMENT TAKEN BY
- MEASUREMENT STATUS INDICATOR
- NOMINAL


This preference is saved for each Security User.

2. To access Thickness Measurements in the **Measurements** section, perform the following steps:

- a) **Access the TML** that contains the thickness measurement that you want to access.
- b) In the workspace, select the **Measurements** tab.

The **Measurements** section appears, displaying a table of measurements linked to the TML. The visual cue that appears in each row indicates the **color-coding category** that is applicable to the Thickness Measurement. The column after the visual cue is locked when using the scroll box to move through the columns.

Note: By default, only active Thickness Measurements are displayed. If you want to access all measurements, clear the **Active Measurements Only** check box.

Tip: You can select the **Column Chooser** () button to add or remove columns from the table. The **Measurement Taken Date** field is pinned to the first column and is always displayed. In addition, the **MEASUREMENT TAKEN DATE** column is locked when using the scroll box to move through the columns.


The fields that appear in the **Choose Columns** window are taken from the Thickness Measurement family. By default, the following columns are displayed:

- MEASUREMENT TAKEN DATE
- MEASUREMENT VALUE
- READINGS
- READINGS PASS/FAIL

- VERIFY MEASUREMENT
- MEASUREMENT VERIFIED
- MEASUREMENT TAKEN BY
- MEASUREMENT STATUS INDICATOR
- NOMINAL

This preference is saved for each Security User.

- c) If you want to access the Thickness Measurements datasheet, in the row containing the Thickness Measurement, select the link in the **MEASUREMENT TAKEN DATE** column. The Thickness Measurements datasheet appears.


Tip: If needed, you can modify values in the [available fields](#), and then select  to save your changes.


Add a Thickness Measurement

Before You Begin

- If you are recording readings for multiple Thickness Measurements, you can use the [Measurement Data Entry workspace](#). Additionally, you can [use a datalogger](#) to record Thickness Measurement readings.

Procedure

1. [Access Thickness Measurements](#) for the TML to which you want to add a Thickness Measurement.
2. In the **Measurements** section, select .

Note: If [skipping measurements has been enabled](#), select , and then select **Add Measurement**.

The **Add Measurement** window appears.

3. In the **Readings** box, enter the measurement value.

Note: The number of readings you will enter is determined by the value in the Number of Readings field in the TML datasheet.

4. In the **Measurement Date** box, enter the date when the measurement was taken.
5. Select **Done**.
The new Thickness Measurement is added to the TML.

Next Steps

[Calculate a Corrosion Analysis](#)

Add a Nominal Measurement

Procedure



1. [Access the TML](#) for which you want to create a nominal measurement.
2. In the workspace, select the **TML Details** tab.
The TML datasheet appears, displaying the **General Information** section.
3. In the datasheet, select the **Design General** tab, and then, in the **Nominal Thickness** box, enter a value.

-or-

In the datasheet heading, select the **Piping** tab, and then select the appropriate values in the following boxes:

- **Piping Nominal Diameter - NPS**
- **Piping Nominal Diameter - DN**
- **Schedule**

The **Nominal Thickness** box is automatically populated with a value based on the values you selected.

4. Select .
The nominal measurement values are saved.
5. Access the **Analysis Overview** page of the TML.
6. Select , and then select **Nominal Measurements**.

Note: For piping assets, the **Nominal Measurements** option is only available at the component and band levels.


The **Nominal Measurements** window appears, displaying a list of possible Nominal Measurements.

Tip: For piping components and bands, you can view the position of each TML in the band from the **Position** column.

Note: You can create nominal measurements only for TMLs that have a valid value in the Nominal Thickness field and do not have any active measurements.

7. **Optional:** If all the measurements are taken on the same date, specify the date in the **Common Measurement Taken Date** box.
8. Select the check boxes next to the TMLs for which you want to create measurements.
9. Specify the measurement taken dates for the TMLs.
10. Select **OK**.

The nominal measurement creation process starts, and the progress appears on the upper-right corner of the **Nominal Measurements** window.

Tip: The nominal measurement creation process continues even if you close the **Nominal Measurements** window. You can select the  button in the **Thickness Monitoring Overview** page to view the progress of the job in the scheduler. In case the nominal measurement creation fails for any TML, the job appears in the **Failed** section of the **Schedule Logs** page.

Results

For each check box you selected, a Thickness Measurement is created and linked to the corresponding TML. The value of the Thickness Measurement is marked as the Nominal Thickness value in the TML datasheet.

Note: When two or more active measurements are created, the nominal measurement becomes inactive. In such cases, the system ignores the nominal measurements and calculates the corrosion rate using actual measurements.


Create Measurement Not Taken (MNT) Records

Before You Begin

To **Skip Measurements** by creating MNT records, the **Allow Measurements to be Skipped** check box must be selected on the **TM Admin Preferences** page.


Optionally, you can also select the **Allow Consecutive Measurements to be Skipped** check box to allow the recording of multiple consecutive MNTs for a single TML without the recording of an [actual measurement](#).

Procedure

1. [Access Thickness Measurements](#) for the TML to which you want to create an MNT record.
2. Select , and then select **Add Skipped Measurement**.
The **Add Skipped Measurement** window appears.
3. In the **Readings** box, the default value <Not Taken> will populate and cannot be adjusted by the user.
4. In the **Measurement Date** box, enter the date for the measurement that you want to skip.
5. Select **Done**.
The new MNT record is added to the TML.


Modify a Thickness Measurement

Procedure

1. [Access Thickness Measurements](#) for the TML that contains the Thickness Measurement that you want to modify.
2. In the **Measurements** section, in the row containing the Thickness Measurement that you want to modify, select the link in the **MEASUREMENT TAKEN DATE** column.
The Thickness Measurement datasheet appears.
Tip: If you want to modify only the value in the **Readings** column, in the row containing the Thickness Measurement, select the link in the **MEASUREMENT VALUE** column, and then enter a value.
3. Modify values in the [available fields](#), and then select .
The Thickness Measurement is saved.



Use the Measurement Data Entry (MDE) Workspace

Procedure


1. [Access the Analysis Overview workspace](#) for the Asset or TML Group for which you want to record Thickness Measurements.
2. Select .
The **Measurement Data Entry** workspace appears, displaying a list of TMLs.
Note: For Piping Assets, the **Measurement Data Entry** workspace does not contain the **TML Asset ID** column, but it contains the **Component ID**, **Piping Band ID**, and **Position** columns.
3. In the **Common Measurement Data** section, enter values in the **Measurement Taken Date**, **Measurement Taken By**, and **Temperature** boxes.
Note: If you have customized the common measurement data section, there may be additional boxes available.
4. In the data entry grid, enter values in the **Readings** box for each TML.
Each time you enter a value into a **Readings** box, the other boxes in the row are populated with the values that you entered in step 3.
5. If you want to enter multiple readings for a TML, then perform one of the following steps:

- a. In the **Readings** box, enter the readings separated by semi-colon.
The **Readings** box is populated with the values that you entered, separated by semi-colon.

-or-

- a. In the **Readings** box, select .
The **Readings** window appears.
 - b. In each box, enter a value, and then select **OK**.
The **Measurement Data Entry** workspace appears. The **Readings** box is populated with the values that you entered, separated by semi-colon.
6. Do one of the following:
 - a) Select .
The readings are saved.

-or-

- b) Select .
The readings are saved and the calculation starts for the asset.


Note: If you do not enter a value in the **Readings** box for all the TMLs displayed in the grid, a confirmation message appears, indicating that one or more measurement values were not entered. The message asks you to confirm that you want to continue.


Results

- For each reading that is saved, a Thickness Measurement is created and linked to the corresponding TML.
- You can now [recalculate the corrosion analysis](#).

Delete a Thickness Measurement

Procedure


1. [Access Thickness Measurements](#) for a TML.
2. Next to the Thickness Measurement you want to delete, select .

Note: The Delete button () is only available for security users associated with the MI Thickness Monitoring Administrator Security Group.

A message appears, asking you to confirm that you want to delete the measurement.

3. Select **Yes**.

The Thickness Measurement is deleted.

The  button will change color to indicate that the analysis needs to be recalculated.

Chapter 7

T-Min Calculations

Topics:

- [About T-Min Calculations](#)
- [About the Calculated T-Min Value using Policy](#)
- [About the Calculated T-Min Value using Formula](#)
- [About Nominal Allowance](#)
- [About Default T-Min](#)
- [About User-Defined T-Min](#)
- [About the Results of a T-Min Calculation](#)
- [About the Calculation Details](#)
- [About TML Calculation Details](#)
- [Calculate Minimum Thickness \(T-Min\)](#)
- [View T-Min Calculation History](#)
- [T-Min Calculations](#)

About T-Min Calculations

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About the Calculated T-Min Value using Policy

The Calculated T-Min value is determined by performing calculations using T-Min formulas and [values from the Thickness Measurement Location \(TML\)](#). This calculation will be performed using a policy that is provided in the [TM Rules Lookup](#).

Policy execution is defined in a way that it takes the TML entity as an input, after the execution it should return a numeric value for T-Min Value, and optionally a valid System Code ID for the Minimum Thickness Type. The policy can also return a string if any validation failures occur during execution.

Note:

- If the T-Min Formula Policy field is set in the TM Rules Lookup record, the T-min calculator will execute the specified policy. Else, the calculator will check the Formula Rule field and execute it.
- The node returning T-Min value should be named T-Min Value, while the node returning Minimum Thickness Type should be named Minimum Thickness Type.
- If the Minimum Thickness Type is returned from policy, then the baseline values are overridden with values returned from the policy.
- If you select the checkbox Override Minimum Thickness Type and modify the value for Minimum Thickness Type, then Minimum Thickness Type value returned from policy will not be retained. You will have to recalculate the TML value in T-Min calculator page.

About the Calculated T-Min Value using Formula

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About Nominal Allowance

The Nominal Allowance T-Min is the minimum thickness value that is derived by deducting Corrosion Allowance from Nominal Thickness.

About Default T-Min

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About User-Defined T-Min

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About the Results of a T-Min Calculation

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About the Calculation Details

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About TML Calculation Details

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Calculate Minimum Thickness (T-Min)


Before You Begin

Ensure there are values in the [fields required to calculate T-Min](#) for each TML.

Procedure

1. Access the [Analysis Overview workspace](#) for the asset or TML Group that contains the TMLs whose T-Min you want to calculate.

Tip: When you select an asset, T-Min will be calculated for TMLs linked to the asset, as well as TMLs linked to TML Groups the asset contains. When you select a TML Group, T-Min is calculated only for the TMLs it contains.

2. Select  , and then select **T-Min Calculator**.

Note: For piping assets, the **T-Min Calculator** option is only available at the component and band levels.

The **T-Min Calculator Disclaimer** appears.



3. Read the disclaimer completely, and then, if you agree, select **OK**.
The **T-Min Calculator** workspace appears, displaying a list of TMLs.


Tip: For piping components and bands, you can view the position of each TML in the band from the **Position** column.

4. In the list, select the check boxes corresponding to the TMLs whose T-Min you want to calculate.

Note: If you want to specify a [user defined T-Min value](#) for a TML, enter a value in the corresponding **User Defined** box.

5. Select **Calculate T-Min**.
The **T-Min Calculation Output** dialog box appears. After the operation is complete, it displays the calculation log.
6. Select **OK**.

In the **T-Min Calculator** workspace,  and  images appear next to the TML IDs to indicate whether the TMLs have been calculated successfully. The **Calculated** column is updated to reflect the new calculated values.

Note: If you want to investigate why a TML was not calculated, select the  image next to the TML ID.

The **T-Min Calculation Output** dialog box appears, displaying the calculation log.

7. For each TML, in the last column, select a value in the **Selected T-Min Source** box.

Note: The default selection in the **Selected T-Min Source** list is the field containing the most conservative (i.e., the largest) value, based on the Calculated, Default, Nominal, and User Defined T-Min values. For example, if the User Defined T-Min value was 0.81, and the Calculated T-Min value was 0.76, the Final T-Min Source would default to User Defined.

The selection in the **Selected T-Min Source** list determines what value is saved as the TML's current T-Min Value. For example, if you specified a User Defined T-Min value of 0.18, and the Calculated T-Min value was 0.281, you could choose to save the value in the Calculated field by selecting Calculated in the **Selected T-Min Source** list, instead of User Defined.

8. If you want to review the output of the most recent calculations before saving, in the upper-right corner of the workspace, select **View Calculation Output**.

The **T-Min Calculation Output** dialog box appears, displaying the log of the most recent T-Min calculations.

9. Select **Save T-Min Values**.

The new T-Min Values, as determined by the selected T-Min source for each TML, are saved, and the analysis is recalculated.


Tip: To return to the **Analysis Overview** workspace, select .

View T-Min Calculation History


Procedure

1. Access the **Analysis Overview workspace** for the asset or TML Group that contains the TMLs whose T-Min you want to calculate.

Note: When you select an asset, T-Min will be calculated for TMLs linked to the asset, as well as TMLs linked to TML Groups the asset contains. When you select a TML Group, T-Min is calculated only for the TMLs it contains.

2. Select , and then select **T-Min Calculator**.
The **T-Min Calculator Disclaimer** appears.
3. Read the disclaimer completely, and then, if you agree, select **OK**.
The **T-Min Calculator** workspace appears, displaying a list of TMLs.

Tip: For piping assets, you can view the position of each TML from the **Position** column.

4. At the end of the row corresponding to the TML whose history you want to view, select .
The **T-Min Calculation Output** dialog box appears, displaying a historical log of all calculations that were saved for that TML.

T-Min Calculations

About T-Min Calculations

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About the Calculated T-Min Value using Policy

The Calculated T-Min value is determined by performing calculations using T-Min formulas and [values from the Thickness Measurement Location \(TML\)](#). This calculation will be performed using a policy that is provided in the [TM Rules Lookup](#).

Policy execution is defined in a way that it takes the TML entity as an input, after the execution it should return a numeric value for T-Min Value, and optionally a valid System Code ID for the Minimum Thickness Type. The policy can also return a string if any validation failures occur during execution.

Note:

- If the T-Min Formula Policy field is set in the TM Rules Lookup record, the T-min calculator will execute the specified policy. Else, the calculator will check the Formula Rule field and execute it.
- The node returning T-Min value should be named T-Min Value, while the node returning Minimum Thickness Type should be named Minimum Thickness Type.
- If the Minimum Thickness Type is returned from policy, then the baseline values are overridden with values returned from the policy.
- If you select the checkbox Override Minimum Thickness Type and modify the value for Minimum Thickness Type, then Minimum Thickness Type value returned from policy will not be retained. You will have to recalculate the TML value in T-Min calculator page.

About the Calculated T-Min Value using Formula

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About Nominal Allowance

The Nominal Allowance T-Min is the minimum thickness value that is derived by deducting Corrosion Allowance from Nominal Thickness.

About Default T-Min

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About User-Defined T-Min

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About the Results of a T-Min Calculation

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About the Calculation Details

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About TML Calculation Details

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Calculate Minimum Thickness (T-Min)


Before You Begin

Ensure there are values in the [fields required to calculate T-Min](#) for each TML.

Procedure

1. Access the [Analysis Overview workspace](#) for the asset or TML Group that contains the TMLs whose T-Min you want to calculate.

Tip: When you select an asset, T-Min will be calculated for TMLs linked to the asset, as well as TMLs linked to TML Groups the asset contains. When you select a TML Group, T-Min is calculated only for the TMLs it contains.

2. Select , and then select **T-Min Calculator**.

Note: For piping assets, the **T-Min Calculator** option is only available at the component and band levels.

The **T-Min Calculator Disclaimer** appears.

3. Read the disclaimer completely, and then, if you agree, select **OK**.
The **T-Min Calculator** workspace appears, displaying a list of TMLs.

Tip: For piping components and bands, you can view the position of each TML in the band from the **Position** column.



4. In the list, select the check boxes corresponding to the TMLs whose T-Min you want to calculate.


Note: If you want to specify a [user defined T-Min value](#) for a TML, enter a value in the corresponding **User Defined** box.

5. Select **Calculate T-Min**.

The **T-Min Calculation Output** dialog box appears. After the operation is complete, it displays the calculation log.

6. Select **OK**.

In the **T-Min Calculator** workspace,  and  images appear next to the TML IDs to indicate whether the TMLs have been calculated successfully. The **Calculated** column is updated to reflect the new calculated values.

Note: If you want to investigate why a TML was not calculated, select the  image next to the TML ID.

The **T-Min Calculation Output** dialog box appears, displaying the calculation log.

7. For each TML, in the last column, select a value in the **Selected T-Min Source** box.

Note: The default selection in the **Selected T-Min Source** list is the field containing the most conservative (i.e., the largest) value, based on the Calculated, Default, Nominal, and User Defined T-Min values. For example, if the User Defined T-Min value was 0.81, and the Calculated T-Min value was 0.76, the Final T-Min Source would default to User Defined.

The selection in the **Selected T-Min Source** list determines what value is saved as the TML's current T-Min Value. For example, if you specified a User Defined T-Min value of 0.18, and the Calculated T-Min value was 0.281, you could choose to save the value in the Calculated field by selecting Calculated in the **Selected T-Min Source** list, instead of User Defined.

8. If you want to review the output of the most recent calculations before saving, in the upper-right corner of the workspace, select **View Calculation Output**.

The **T-Min Calculation Output** dialog box appears, displaying the log of the most recent T-Min calculations.

9. Select **Save T-Min Values**.

The new T-Min Values, as determined by the selected T-Min source for each TML, are saved, and the analysis is recalculated.


Tip: To return to the **Analysis Overview** workspace, select .

View T-Min Calculation History


Procedure

1. Access the **Analysis Overview workspace** for the asset or TML Group that contains the TMLs whose T-Min you want to calculate.

Note: When you select an asset, T-Min will be calculated for TMLs linked to the asset, as well as TMLs linked to TML Groups the asset contains. When you select a TML Group, T-Min is calculated only for the TMLs it contains.

2. Select , and then select **T-Min Calculator**.
The **T-Min Calculator Disclaimer** appears.
3. Read the disclaimer completely, and then, if you agree, select **OK**.
The **T-Min Calculator** workspace appears, displaying a list of TMLs.

Tip: For piping assets, you can view the position of each TML from the **Position** column.

4. At the end of the row corresponding to the TML whose history you want to view, select .
The **T-Min Calculation Output** dialog box appears, displaying a historical log of all calculations that were saved for that TML.

Chapter

8

Schematic View

Topics:

- [About Schematic View](#)
- [About Schematic Image](#)
[Adapting to Updated Source](#)
[Reference Document](#)
- [Access the Thickness](#)
[Monitoring Schematic View](#)
- [Plot a TML in the Schematic](#)
[View](#)
- [Unplot a TML in the Schematic](#)
[View](#)
- [Replot a TML in the Schematic](#)
[View](#)
- [Search a TML in the Schematic](#)
[Sidebar](#)
- [Open a TML Pop-Up in the](#)
[Schematic View](#)
- [Delete Plotted TMLs on a](#)
[Schematic Image](#)
- [Swap a Schematic Image](#)
- [Download a Schematic Image](#)
- [Turn TML Label Visibility On or](#)
[Off](#)

About Schematic View

Schematic View is a feature of the Thickness Monitoring (TM) module in APM that allows you to plot Thickness Measurement Locations (TML) over a Schematic Image. It provides additional physicality of TMLs within APM in relation to their location in a physical space and adds visual and contextual awareness of your asset's health.

Supported File Types

Schematic View allows you to use the following Reference Document formats as the Schematic Image:

- PNG Image (.png)
- JPG/JPEG Image (.jpg, .jpeg)
- PDF Document (.pdf)

Note: Only the first six pages of a provided PDF will be used in the resulting Schematic Image.

- DWG Drawing (.dwg)
- SVG Image (.svg)

About Schematic Image Adapting to Updated Source Reference Document

When you select a Source Reference Document for a Schematic View, a mirror copy is created and stored within APM (referred to as the Schematic Image in subsequent documentation). Each time you navigate to the Schematic View, APM identifies whether the Source Reference Document is modified, if so, a new Schematic Image is generated from the Source Reference Document and displayed within the Schematic View.

If the Source Reference Document is moved or deleted, a new Schematic Image cannot be generated. However, the existing Schematic Image displays within the Schematic View with a warning that the Source Reference Document is not available.

Note: If the Source Reference Document is not accessible, APM attempts to retrieve it for up to 30 seconds before it loads the Schematic View with the existing Schematic Image. If the Source Reference Documents are moved or are missing, the Schematic View may take longer to load. For more information on how to replace the Source Reference Document, refer to the [Swap a Schematic Image](#) on page 78 section of the documentation.

Access the Thickness Monitoring Schematic View

Before You Begin

Ensure that you have the Mechanical Integrity 2D Visualization License enabled, Mechanical Integrity 2D Visualization User role applied to your user account, and have linked one or more Reference Documents to the target asset or TML Group.

Tip: For more information, refer to the [Manage Reference Documents](#) section of the Record Manager module for additional options when working with reference documents.

Note: The **Schematic View** section displays only if you have the Mechanical Integrity 2D Visualization License enabled and the Mechanical Integrity 2D Visualization User role applied to your user account.

Procedure

1. [Access the Analysis Overview Workspace](#) on page 23 for the asset or TML Group that you want to use in the Schematic View.
2. Select the **Schematic View** tab.
3. Select **Select Reference Document**.
The **Select Reference Document** window appears with the list of available/compatible reference documents.
4. Select the reference document that you want to use as the Schematic Source Reference Document.
5. Select **Done**.
The Schematic View is displayed.


Note: After selecting the Source Reference Document, the Reference Document is saved for subsequent navigations to the **Schematic View** section.

Plot a TML in the Schematic View

About This Task

This topic describes how to plot a Thickness Measurement Location (TML) onto the Schematic Image within the Schematic View. You can plot more than one TMLs on a Schematic Image to represent the TML in physical space.

Procedure

1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select  in the Schematic View workspace.
The Schematic View sidebar appears.
3. Select the desired TML from the tree.
4. Select the location within the Schematic Image for the TML you want to plot.
The selected TML is plotted on the Schematic Image (represented by the TML's corresponding Health Indicator icon).



Note: The Health Indicator icons are the color-coding categories for the Thickness Measurement Location (TML) or Thickness Measurement. For more information on Health Indicator icons, refer to the [About Color-Coding](#) section of the documentation.

Unplot a TML in the Schematic View

About This Task

This topic describes how to remove a previously plotted Thickness Measurement Location (TML) from the Schematic Image within the Schematic View.

Procedure

1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select  in the Schematic View workspace.
The Schematic View sidebar appears.
3. Locate the desired TML in the tree, which you want to unplot from the Schematic Image.
4. Select  from the desired TML row.


The plotted TML will no longer be visible on the Schematic Image.

Replot a TML in the Schematic View

About This Task

This topic describes how to replot a previously plotted Thickness Measurement Location (TML) from the Schematic Image within the Schematic View.

Procedure


1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select  in the Schematic View workspace.
The Schematic View sidebar appears.
3. Locate and select the desired TML in the tree that you want to replot within the Schematic View.
4. Select a new location within the Schematic Image where you want to replot the selected TML.
The selected TML is plotted on the Schematic Image in a new location.

Search a TML in the Schematic Sidebar

About This Task

This topic describes how to search for a specific TML within the tree located in the Schematic sidebar.

Procedure

1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select  in the Schematic View workspace.
The Schematic View sidebar appears.
3. Select the **Search** box within the Schematic View sidebar.
4. Enter the needed characters in the **Search** box to search for a specific TML.
The Schematic View sidebar filters to Asset, TML Groups, and TMLs, and displays the searched term.

Note: TMLs can be plotted or unplotted from the filtered Schematic View sidebar.

Open a TML Pop-Up in the Schematic View

About This Task

This topic describes how to open a TML pop-up for a previously plotted Thickness Measurement Location (TML) from the Schematic Image within the Schematic View.

The TML pop-up contains the following TML attributes:

- Asset ID
- Minimum Thickness
- Last Thickness Measurement Date
- Last Thickness Measurement
- Corrosion Rate

Procedure

1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select the desired TML Health Indicator icon on the Schematic Image for which you want to open the TML pop-up.
The TML pop-up is displayed on the Schematic Image.

Note: To close the pop-up, perform one of the following actions:

- Select outside of the pop-up on the Schematic Image.
- Select the same TML Health Indicator icon.
- Select another TML Health Indicator icon.
- Plot another TML onto the Schematic Image.
- Unplot the corresponding TML.
- Navigate away from the Schematic View.

Delete Plotted TMLs on a Schematic Image

About This Task

This topic describes how to delete all previously plotted TMLs from a Schematic Image within the Schematic View.

Procedure

1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select **Delete Mapping**.
The **Confirm Delete** window appears, asking you to confirm if you want to delete the plotted TMLs.
3. Select **Yes**.
The plotted TMLs are deleted from the Schematic Image.

Swap a Schematic Image

About This Task

This topic describes how to change the Source Reference Document for a Schematic View, after you have already selected a Source Reference Document.

Procedure

1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select **Swap Image**.
The list of available/compatible reference documents are displayed in the **Select Reference Document** window.
3. Select the reference document that you want to use as the Schematic Source Reference Document.
4. Select **Done**.
The Schematic Image representing the newly selected Source Reference Document is displayed.


Note: The Swap Image functionality deletes all existing plotted TMLs on the Schematic Image.

Download a Schematic Image

About This Task

This topic describes how to download a copy of the Schematic Image (as it fits in the browser window), including all plotted TMLs, labels, and open TML pop-ups.

Procedure

1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select 
The Schematic Image is downloaded in PNG format to the local computer.

Turn TML Label Visibility On or Off

About This Task

Each TML plotted on the Schematic Image has a label below the TML Health Indicator icon, containing the TML ID template of the plotted TML. You can turn the TML labels ON or Off using the **Show Labels** check box.

Procedure

1. [Access the Thickness Monitoring Schematic View](#) on page 75.
2. Select the **Show Labels** check box.
The TML labels are visible on the Schematic Image.

Note: You can turn the TML labels off by clearing the **Show Labels** check box.

Chapter 9

Piping Rotation and Flip

Topics:

- [About Piping Rotation and Flip](#)
- [About Piping Asset Hierarchy](#)
- [Types of Piping Components](#)
- [Types of Bands](#)
- [About Positions](#)
- [About Rotation of Straight Spools](#)
- [About Flipping of Straight Spools](#)
- [About Flipping of Elbows](#)
- [About Undo Movement](#)
- [About Calculation of Nominal Measurement](#)
- [About Corrosion Rate Methods](#)
- [About Heat Maps](#)
- [About Alert Levels](#)
- [Create Corrosion Analysis Settings for a Piping Asset](#)
- [Create a Component](#)
- [Create a Band](#)
- [Copy a Component](#)
- [Copy a Band](#)
- [Access Trends Graphs for a Piping Band](#)
- [Rotate a Straight Spool](#)
- [Flip a Piping Component](#)
- [Rotate or Flip Multiple Spools](#)
- [Access the Piping Rotation or Flip History](#)
- [Undo Last Rotation or Flip](#)
- [Create a What-If Scenario](#)
- [Access What-If Scenarios](#)

- Perform Rotation or Flip from a What-If Scenario

About Piping Rotation and Flip


Piping Rotation and Flip is a feature of the Thickness Monitoring (TM) module in APM that allows you to record actions related to rotation or flip of piping components. It enables you to make accurate assessments of the remaining life after rotating or flipping components.

The internal surfaces of piping components in a piping circuit are prone to severe erosion due to the abrasive nature of the fluid flowing through them at high velocities. These damage mechanisms cause localized erosion within the component. Therefore, the erosion rate at certain regions are higher than the others. Typically, erosion rates are higher at the bottom surfaces in the interior of straight spools and the internal surfaces in the outside of elbows.

Rotations or flips are an essential part of the maintenance activity carried out on piping assets. This allows you to take advantage of the positions with higher thickness, where erosion has occurred to a lesser extent, thereby prolonging the life of the component.

About Piping Asset Hierarchy

Piping assets can be organized into a hierarchy. The hierarchy and an example of a piping asset in the hierarchy is illustrated in the diagram below.



A piping asset can be a piping circuit, and a piping component can be a straight spool or an elbow. A piping component can consist of several bands positioned at various locations on its surface. A band is a path along the circumference or length of a piping component that contains equally spaced TMLs. These TMLs are located at specific positions on the band.

Types of Piping Components

Piping assets are made up of a number of interconnected components. These components can be classified into straight spools and elbows.

Straight spools are segments that form a part of straight sections of a piping circuit. Straight spools can be rotated or flipped.

Elbows are curved sections of a piping circuit that are used to change the direction of fluid flow. Elbows can only be flipped. When flipped, the erosion pattern at the bands changes and is dependent on the position of the bands relative to the flow. Both bent and mitered elbows are supported by APM.

Types of Bands

The bands on a piping component can be classified into the following types:


Center band: A center band is a band that is located at the center of a piping component. Center bands can exist on elbows and straight spools.

Mirrored band: A mirrored band is a band on a piping component that has another symmetrically opposite band relative to the center point. Mirrored bands can exist on elbows and straight spools.


Odd band: An odd band is a band that is located on a piping component at specific critical positions such as near the inlet or weld. Odd bands can exist on elbows and straight spools.

Extrados band: An extrados band is a band where the TMLs are distributed along the long radius or outer curve of an elbow. Such bands exist only on elbows.


The following diagram illustrates the bands that can exist on a straight spool.



The following diagram illustrates the bands that can exist on a bent elbow.




The following diagram illustrates the bands that can exist on a mitered elbow.



About Positions

Positions are fixed points occupied by TMLs on a band, that can be considered as references for rotation of a piping component. The number of positions on a band correspond to the number of TMLs on the band. There can be multiple configurations for the number of positions. The number of positions supported by APM are 4, 12, 24, 36, and 48. The following widgets are available for representing bands containing 4, 12, and 24 TMLs.



For example, in a piping component, if each band contains 4 TMLs, you can select a configuration of 4 positions. In this configuration, 4 equally spaced reference points (that is 3, 6, 9, and 12) are available along which the component can be rotated. The reference point for rotation is the Top Center. In this example, position 12 is the Top Center.


When a piping component is flipped, the positions of TMLs change based on a fixed pattern. For more information, refer to the [Flipping of Straight Spool](#) section of the documentation.

Note: The ability to rotate or flip is not supported for components containing bands with 36 or 48 positions.

About Rotation of Straight Spools

Rotations are necessary to extend the life of a straight spool. When the spool is rotated, the TMLs located on the band will move from one position to another. However, the location of the bands on the spool does not change.

The following example shows the change in positions of TMLs on a band containing 12 TMLs, when the spool is rotated by 90 degrees clockwise. Hence, the TML colored orange that was at clock position 6 is now moved to clock position 9. We can say that the Top Center is moved to position 3.




After a spool is rotated, the corrosion analysis for each TML within the bands is re-calculated based on the corrosion rate at the new position. This results in an updated remaining life for the component.

About Flipping of Straight Spools

When a straight spool is flipped, the location of bands do not change. The behavior of each type of band after a flip is detailed below:

- For a center band, the TMLs do not move to a new location along the length of the spool, but the positions of the TMLs on the band change according to a fixed pattern.
- For mirrored bands, the TMLs move to a new location along the length of the spool. The TMLs in each mirrored band move to the band that is located symmetrically opposite to it relative to the center. The positions of the TMLs on mirrored bands change according to a fixed pattern.
- For an odd band, the TMLs move to a location where no bands exist, and the material from that location moves to this band. Because existing thickness measurements for this band are not available, the band is renewed. The previous measurements are inactivated, and new measurements should be taken.

The flip for a horizontal straight spool is done in a vertical plane, and the band positions are viewed from the inlet of the straight spool. The following example shows the change in positions of TMLs on a band containing 12 TMLs, when the spool is flipped. The TMLs at positions 3 and 9 remain at the same positions, whereas the TMLs at positions 12 and 6 exchange positions. Similarly, other TMLs exchange positions based on a definite pattern.



The following tables contain the band positions for center and mirrored bands before and after a flip.

Table 1: Component with 4 band positions

Band position before flip	12	3	6	9
Band position after flip	6	3	12	9

Table 2: Component with 12 band positions

Band position before flip	12	1	2	3	4	5	6	7	8	9	10	11
Band position after flip	6	5	4	3	2	1	12	11	10	9	8	7

Table 3: Component with 24 band positions


Band position before flip	24	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Band position after flip	12	11	10	9	8	7	6	5	4	3	2	1	24	23	22	21	20	19	18	17	16	15	14	13

After a spool is flipped, the corrosion analysis for each TML within the bands is re-calculated based on the corrosion rate at the new position. This results in an updated remaining life for the component.

About Flipping of Elbows

When an elbow is flipped, the location of bands do not change. The behavior of each type of band after a flip is similar to that of straight spools. For an extrados band, the TMLs on the band will move to a mirrored location within the band along the length of the elbow.


The top view of a horizontal bent elbow containing a center band, four mirrored bands, and an odd band is illustrated in the following image.



The bands colored yellow are mirrored bands, and the band colored blue is the center band. The band colored red is an odd band. When the elbow is flipped, the TMLs on the odd band move to a different location on the elbow, where a band did not previously exist.

The change in positions of TMLs within center and mirrored bands when an elbow is flipped follows a similar pattern as that of a straight spool.


The following example shows the change in positions of TMLs on a band containing 12 TMLs, when the elbow is flipped.




The following table illustrates the band positions for center and mirrored bands before and after a flip for an elbow with 12 band positions.

Band position before flip	12	1	2	3	4	5	6	7	8	9	10	11
Band position after flip	6	5	4	3	2	1	12	11	10	9	8	7

The top view of a horizontal bent elbow showing an extrados band is illustrated in the image below.



The arrows show the movement of TMLs on the band after a flip. Each TML exchanges position with its mirrored TML within the band. The following image illustrates the positions of TMLs in an extrados band before and after flipping the elbow.



After an elbow is flipped, the corrosion analysis for each TML within the bands is re-calculated based on the corrosion rate at the new position. This results in an updated remaining life for the component.

About Undo Movement

The APM system allows you to revert the last performed rotation or flip on a piping component. After an undo movement operation is performed, the nominal measurements that were calculated for each TML as a result of the movement are deleted, and the previous measurements are activated. If measurements were added after performing the movement, you must delete those measurements before you perform an undo movement. In addition, after performing the undo movement, in the Pipe Rotation Event inspection datasheet for the Asset, the Reverted flag is set to true.

About Calculation of Nominal Measurement

When a component is rotated or flipped, APM will calculate the estimated nominal thickness values for each TML for the specified movement date. This is to account for the corrosion that has occurred from the date when the last measurement was taken till the date when the rotation or flip is carried out.

Note: When a component is flipped, the nominal measurements for TMLs in odd bands are not calculated because the bands are renewed. The existing measurements are inactivated, and new measurements should be taken for such bands.

The calculated nominal thickness value for a given TML is based on the following criteria:

- The last measurement value for the TML.
- The corrosion rate at the current position of the TML within the band prior to the rotation or flip.
- The time that has passed between the last measurement date and the selected movement date.

The estimated nominal thickness value for a TML on the day of movement is calculated using the following formula.

$$\text{Nominal Measurement} = (\text{Last Measurement Value}) - (\text{Corrosion Rate} \times (\text{No of Days}) / 365.25)$$

Calculation of estimated thickness for a TML on a specified day of movement

Suppose, the last recorded thickness value for a TML is 0.793 inch for a measurement taken on May 1st, 2015, and the corrosion rate at the current position of the TML is 0.0134018 inch per year. If the component is rotated on May 1st, 2020, the estimated thickness for the TML on this day is calculated as follows:

The number of days elapsed since the last measurement for this case is 1827 days.

$$\text{Estimated Thickness on May 1}^{\text{st}}, 2020 = 0.793 - (0.0134018 \times 1827 / 365.25) = 0.72596 \text{ inch}$$

About Corrosion Rate Methods

The corrosion rate that will be considered when calculating the corrosion analysis for the TMLs is based on the Rate Method that you specify. The Rates Methods are classified into the following types:

Least Squares: The Least Squares Corrosion Rate is the rate of corrosion as determined using the least squares linear regression method, which is a mathematical method of finding the best-fit line for a set of data points by minimizing the squares of the offsets. For more information, refer to the section [Least Squares Corrosion Rate \(LSCR\)](#) on page 312 of the documentation.

Long Term: The Long Term Corrosion Rate is a calculation that indicates the rate of corrosion over the full length of time for which measurements have been recorded. The LTCR will be calculated for a given TML if the analysis settings for the related Asset, Component, or band specify that LTCR should be used. For more information, refer to the section [Long Term Corrosion Rate \(LTCR\)](#) on page 312 of the documentation.

Short Term: The Short Term Corrosion Rate is the rate of corrosion as determined by the most recently recorded values. The STCR will be calculated for a given Thickness Measurement Location record only if the Analysis Settings for the related asset specify that STCR should be used and there are two more Thickness Measurements for the Thickness Measurement Location record. For more information, refer to the section [Short Term Corrosion Rate \(STCR\)](#) on page 312 of the documentation.





Minimum Corrosion Rate: The Minimum Corrosion Rate is the value specified in the **Minimum Corrosion Rate** box in the **TML Corrosion Rate** section of the **Corrosion Analysis Settings** workspace.

Most Conservative: The Most Conservative Corrosion Rate is the maximum value among the values obtained from all the corrosion rate methods configured in the Corrosion Analysis Settings for the component including the Minimum Corrosion Rate value.

About Heat Maps

A heat map is a graphical representation of the alert levels of TMLs on a band using color codes. For more information on how alert levels are calculated, refer to the section [about alert levels](#). You can customize the alert levels 0, 1, and 2 by [modifying the values of Alert Level 1 Max and Alert Level 2 Max](#) in the **Define Wall Ratio Preferences** section of the **TM Admin Preferences** page.

There are four color codes that represent different alert levels as shown in the following table.

Alert Level Name	Color Code
Alert Level 0	 Green
Alert Level 1	 Yellow
Alert Level 2	 Orange
Alert Level 3	 Red

You can access heat maps at the component level from the **Component Details** section, and at the band level from the **TML Band Details** section. The widgets that appear in the window used to rotate or flip a component also contain heat maps.

Tip: You can hover over a position on a widget to view the TML ID of the TML at that position and its last measurement value.

The usage of heat maps is best understood from the following example.

The **Band Heatmap** section contains the heat maps for each band on the Pipe Spool-01 component. Since the Mirror Band-02 band is selected, the heat map for that band appears in the widgets that display the positions of each TML before and after the rotation or flip.

About Alert Levels

Alert levels are used to monitor the wall thickness of a TML and are an indicator of TML health. TM makes use of two parameters called Alert Level 1 Max and Alert Level 2 Max for calculating alert levels. These

values are used to determine the Alert Levels for Band Trends graphs and for Heat Maps and Pipe Rotation widgets.

Note: You can [define these values](#) in the **Wall Ratio Preferences** section of the **Global Preferences** workspace found in the **TM Admin Preferences** page. The value of these parameters cannot be less than 1.

Alert Levels for Band Trends Graphs

The T-Min value is used to calculate the Alert Level Ranges in [Band Trends graphs](#) for piping bands.

Alert Level 1 is calculated as follows:

$$A1 = (T\text{-Min}) \times (\text{Alert Level 1 Max}).$$

Alert Level 2 is calculated as follows:

$$A2 = (T\text{-Min}) \times (\text{Alert Level 2 Max}).$$

The Alert Levels in Band Trends graphs, and the corresponding color codes are defined as shown in the following table.





Alert Level Name	Value	Color Code
Alert Level 1	A1	Yellow
Alert Level 2	A2	Orange
Default T-Min	T-Min	Red

Alert Levels for Heat Maps and Piping Rotation Widgets

The Alert Levels for Heat Maps and Piping Rotation widgets are based on the wall ratio. Wall ratio (WR) is defined as the ratio of the last measurement value of a TML and the minimum thickness (T-Min) value. It is calculated as follows:

$$WR = (\text{Last Measurement Value}) / T\text{-Min}$$

The Alert Levels in Heat Maps and Pipe Rotation Widgets, and the corresponding color codes are defined as shown in the following table.

Alert Level Name	Range	Color Code
Alert Level 0	$WR > (\text{Alert Level 1 Max})$	 Green
Alert Level 1	$(\text{Alert Level 1 Max}) \geq WR > (\text{Alert Level 2 Max})$	 Yellow
Alert Level 2	$(\text{Alert Level 2 Max}) \geq WR > 1$	 Orange
Alert Level 3	$WR \leq 1$	 Red

Simple Example of an Alert Level Calculation for Heat Maps and Piping Rotation Widgets

Let us assume that the value for Alert Level 2 Max is set to 2.5 and the value for Alert Level 1 Max is set to 3.5

Suppose, the last measurement value for a TML is 0.326 inch and the minimum thickness value is 0.1 inch. The wall ratio (WR) is calculated as $0.326 / 0.1 = 3.26$

Since the calculated wall ratio falls between the Alert Level 2 Max and the Alert Level 1 Max values, the TML is assigned Alert Level 1 and the color code for the TML in the heat map is Yellow.


Create Corrosion Analysis Settings for a Piping Asset

Before an asset can be accessed via the **Thickness Monitoring Overview** page, you must create [Corrosion Analysis Settings](#) for that asset.

Before You Begin

Make sure you have [enabled pipe rotation](#) in the **Pipe Rotation Preferences** section of the **Global Preferences** workspace found in the **TM Admin Preferences** page.

Procedure

1. On the top navigation bar, select  .
The **Asset Hierarchy** page appears.
2. On the **Asset Hierarchy** page, select the asset for which you want to create corrosion analysis settings.
3. In the workspace, select the **Integrity** tab, and then, in the **Thickness Monitoring** row, select the **TML Groups, TMLs** link.

Note: The **TML Groups, TMLs** link will appear only if you have selected an equipment. If you have selected a functional location, the **TM Assets** link appears instead of **TML Groups, TMLs**.

The **<Asset Name>** page appears, displaying the Corrosion Analysis Settings. By default, values in the following boxes are populated automatically as follows:

- The **Inspection Type** box is set to UT.
- The **Controlling Corrosion Rate** box is set to Maximum.
- The **Std Deviation Factor, Remaining Life Critical Number of TMLs, Minimum Corrosion Rate,** and **Remaining Life Factor** boxes are populated with values.

Note: The value in the Remaining Life Critical Number of TMLs box has no significance in the calculation of remaining life.

- The **Short Term, Long Term, Factor Remaining Life,** and **Inspection Interval** check boxes are selected.

Note: If needed, you can modify values in the [available fields](#), and then select **Update Settings** to save the settings.

4. Select the **Piping Asset** check box.

Note: The **Piping Asset** check box appears only if you have [enabled the piping rotation workflow](#).

5. Select **Yes**.
The Corrosion Analysis Settings record is created for the piping asset.

Create a Component

Before You Begin

Make sure you have [created Corrosion Analysis Settings for the piping asset](#).

About This Task

This topic describes how to create a component for a piping asset. When a component is created, the Corrosion Analysis Settings and the values that appear in the Analysis Output section are inherited from the selected asset.

Procedure

1. Access the [Analysis Overview workspace](#) for the piping asset.
2. In the left pane, select **Add (+)**, and then select **Create Component**. The **Create Component** window appears.
3. In the **Component ID** box, enter a unique component ID.
4. In the **Piping Component Type** drop-down list box, select the type of the piping component.
5. Select **Create**. The component is created, and the **Bands** section appears.

Results

- The created component is linked to the piping asset.
- If an Asset has more than one TML Analysis Type or Inspection Type, all analysis types are copied to the created component.

Next Steps

[Create bands for the piping component.](#)

Create a Band

Before You Begin

Make sure you have [created a component for the piping asset](#).

About This Task

This topic describes how to create bands for a piping component. When a band is created, new TMLs are created and linked to individual positions within the band. The number of TMLs on each band corresponds to the number of positions that you specify. The Corrosion Analysis Settings and the values that appear in the Analysis Output section are inherited from the component.

Procedure

1. Access the [Analysis Overview workspace](#) for the piping asset.
2. Select the component for which, you want to create a band.
3. In the left pane, select **Add (+)**, and then select **Create Band**. The **Create Piping Band** window appears.

By default, values in the following boxes are populated automatically:

- The **Corrosion Analysis Setting** box is set based on the Corrosion Analysis Settings for the component. If multiple analysis types exist for a component, the box is set to the first available analysis type from the component.
 - The **Number of Positions** box is set to 12.
4. In the **Create Piping Band** window, perform the following actions:

- a) In the **Piping Band ID** box, enter a unique ID for the band.
- b) The **Corrosion Analysis Setting** box is set based on the Corrosion Analysis Settings for the component. If multiple settings exist for a component, select an inspection type to inherit.
- c) In the **Number of Positions** drop-down list box, select the number of TMLs on each band.
- d) In the **Piping Band Type** drop-down list box, select the type of band.

Note: To create a relationship between two mirrored bands, select the mirrored band from the **Mirrored Band** drop-down list box. This box is only available when the specified piping band type is Mirrored.

- e) In the **Distance from Inlet <UOM>** and **Nominal Thickness <UOM>** boxes, enter appropriate values.

Note: A band cannot be created until all selections for required fields marked by an asterisk are made. You can change the values in the Piping Band ID, Piping Band Type, and the Distance from Inlet fields after the band is created from the **TML Band Details** section.

5. Select **Create**.

The band is created, and the **TMLs** section displaying the TMLs for that band appears.

Note: In the left pane, TMLs and bands are sequenced as follows:

- The TMLs are sorted based on their position numbers.
- The bands are sorted based on their distance from the inlet of the pipe. The bands that do not contain a value in the Distance from Inlet field are sorted alphanumerically.

Results

- The created band is linked to the component.
- The Corrosion Analysis Settings for each TML in the created band are inherited from the band.

Next Steps

Add measurements to individual TMLs or [modify TMLs in Bulk](#).

Copy a Component


Before You Begin

Make sure you have [created a component for the piping asset](#).

About This Task

This topic describes how to create copies of a piping component within an asset. When a component is copied, the Corrosion Analysis Settings and the values that appear in the Analysis Output section are inherited from the parent asset.

Procedure

1. Access the [Analysis Overview workspace](#) for the piping asset.
2. Select the component that you want to copy.
3. In the left pane, select **Copy Component** .
The **Copy Component: <Component ID>** window appears.
4. Enter a value in the **Number of Copies** box.

5. **Optional:** To create Nominal measurements for TMLs within the copied components, select the **Create Nominal Measurements** check box, and then select a date in the **Nominal Measurements Date** box.

Note: When the component is copied, all bands that contain a Nominal Thickness value for its TMLs will have measurements created for each TML in the copied bands. The Measurement Value field will be populated with the Nominal Thickness value for the TML, and the Measurement Taken Date field will be populated with the date that you have selected in the **Copy Component: <Component ID>** window.

6. Select **Copy**.

The job status appears in the page heading, displaying the progress of the job. If the job is successful, copies of the component are created and can be identified by the Component ID of the component that is copied.

Note: To view and download the log file for the copy operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Copy Component.

Copy a Band


Before You Begin

Make sure you have [created a band for the piping component](#).

About This Task

This topic describes how to create copies of a band within a piping component. When a band is copied, the Corrosion Analysis Settings are also copied from the selected band.

Procedure

1. Access the [Analysis Overview workspace](#) for the piping asset.
2. Select the component whose band you want to copy.
3. Select the band that you want to copy.
4. In the left pane, select **Copy Band** .
The **Copy Band: <Band ID>** window appears.
5. Enter a value in the **Number of Copies** box.
6. **Optional:** To create Nominal measurements for each TML in the copied bands, select the **Create Nominal Measurements** check box, and then select a date in the **Nominal Measurements Date** box.

Note: If the band that you want to copy contains a Nominal Thickness value for its TMLs, measurements are added for each TML in the copied bands. The Measurement Value field will be populated with the Nominal Thickness value for the TML, and the Measurement Taken Date field will be populated with the date that you have selected.

In the following example, for the band that was copied, a Nominal Thickness value of 0.4 inch was specified, and 2/1/2020 was selected as the measurement date. Therefore, a measurement is added for each TML in every band that is created.

7. Select **Copy**.

The job status appears in the page heading, displaying the progress of the job. If the job is successful, copies of the band are created and can be identified by the Band ID of the band that is copied.

Important: When you copy a band, the Piping Band Type is not copied. You can specify the Piping Band Type for the bands that are created from the **TML Band Details** section.

Note: To view and download the log file for the copy operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Copy Band.

Access Trends Graphs for a Piping Band

About This Task

The Trends graphs for a piping band display historical measurement data for each position on the band, and for each TML in the band plotted against the [alert levels](#).

Note: If you are a member of the MI TM Viewer Security Group, or if you are assigned the MI Mechanical Integrity Viewer Security Role, then you cannot access the Trends graphs.

Procedure

1. Access the band whose Trends graphs you want to access.
2. In the workspace, select the **Trends** tab.
The **Trends** section appears, displaying the **BAND TREND BY CLOCK POSITION** and the **BAND TREND BY TML** graphs.

Note:

- To view or hide the plotted points and trend line for a position from the **BAND TREND BY CLOCK POSITION** graph, on the right side of the graph, select the position from the list.
- To view or hide the plotted points and trend line for a TML from the **BAND TREND BY TML** graph, on the right side of the graph, select the TML from the list.
- To view or hide a line representing an alert level, select the alert level from the **Plot Lines** field.

Rotate a Straight Spool

Before You Begin

- [Create corrosion analysis settings](#).
- [Create a component](#).
- [Create bands](#).
- Add thickness measurements.

About This Task

This topic describes how to rotate a straight spool.

Procedure

1. [Access the Analysis Overview workspace](#) for a piping asset.
2. Select the straight spool that you want to rotate.
3. If an analysis has not been performed or the data has changed since the last calculation, [calculate the Analysis](#).
4. In the left pane, select **Rotate/Flip Selection**.
The **Rotate Pipe: <Component ID>** window appears, containing widgets that display the current positions of the TMLs on the selected band and a preview of the changed positions after you rotate the spool.
5. Select a corrosion rate method from the **Rate Method** drop-down list box.

Note: The Least Squares rate method is only available when the **Least Squares** check box is selected in the **TML Corrosion Rate** section of the **Corrosion Analysis Settings** workspace for the component.

6. In the **Move Top Center To** drop-down list box, select the position to which you want to rotate the Top Center of the component.
The Change Preview widget is updated to show the positions after you rotate the spool.

7. Select a rotation date in the **Movement Date** box.

Note: You cannot select a date prior to the date when the last measurement was taken. Also, you cannot select a future date for rotation or flip. Future dates can only be selected when creating What-If scenarios.

8. Select **Rotate**.

The job status appears in the page heading, displaying the progress of the job. To view and download the log file for the rotate operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Pipe Rotation.

Results

- If the job is successful, the component is rotated.
- For the asset, an inspection is created for the Pipe Rotation Event and appears under the **Inspections** section of the [Inspection Management Overview](#) page.

Flip a Piping Component

Before You Begin

- [Create corrosion analysis settings](#).
- [Create a component](#).
- [Create bands](#).
- Add thickness measurements.

About This Task

This topic describes how to flip a piping component.

Procedure

1. [Access the Analysis Overview workspace](#) for a piping asset.
2. Select the piping component that you want to flip.
3. If an analysis has not been performed or the data has changed since the last calculation, [calculate the Analysis](#).
4. In the left pane, select **Rotate/Flip Selection**.
5. In the window that appears, in the **Action** drop-down list box, select Flip.
The **Flip Pipe: <Component ID>** window appears, containing widgets that display the current positions of the TMLs on the selected band and a preview of the changed positions of the TMLs on that band after you flip the component.

Note: The **Change Preview** widget displays the changed positions of the TMLs in the selected band, based on the band type as given below. For extrados bands, the **Change Preview** widget is hidden.

- For a mirrored band, the TMLs in each position correspond with the updated positions of the TMLs from the band located symmetrically opposite to it.

- For a center band, the TMLs that appear in each position will be based on the updated positions after the flip.
 - For odd bands, because such bands are renewed, the **Change Preview** widget displays Alert Level 0 (Green).
6. Select a corrosion rate method from the **Rate Method** drop-down list box.

Note: The Least Squares rate method is only available when the **Least Squares** check box is selected in the **TML Corrosion Rate** section of the **Corrosion Analysis Settings** workspace for the component.
 7. Select a flip date in the **Movement Date** box.

Note: You cannot select a date prior to the date when the last measurement was taken. Also, you cannot select a future date for rotation or flip. Future dates can only be selected when creating What-If scenarios.
 8. Select **Flip**.

The job status appears in the page heading, displaying the progress of the job. To view and download the log file for the flip operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Pipe Flip.

Note: To flip a piping component, all bands must have a band type specified.

Results

- If the job is successful, the component is flipped.
- For the asset, an inspection is created for the Pipe Rotation Event and appears under the **Inspections** section of the [Inspection Management Overview](#) page.

Rotate or Flip Multiple Spools

Before You Begin

- [Create corrosion analysis settings.](#)
- [Create a component.](#)
- [Create bands.](#)
- Add thickness measurements.

About This Task

This topic describes how to rotate or flip multiple spools.

Procedure

1. Access the [Analysis Overview](#) workspace for a piping asset.
2. If an analysis has not been performed or the data has changed since the last calculation, [calculate the Analysis.](#)
3. In the left pane, select **Rotate/Flip Selection**.

Note: If the asset contains only elbows, an error message appears when you select **Rotate/Flip Selection**.

The **Select Components** window appears containing a list of spools within the asset.
4. Select the check boxes that correspond to the spools that you want to rotate or flip, and then select **Done**.

Note: The **Done** button is disabled if you select more than 10 spools or select components with varied number of positions.

The **Rotate Components** window appears.

Tip: You can select the spool whose data you want to view in the band heatmap and the widgets from the **View Component Heatmap** drop-down list box.

5. To rotate the selected spools, perform the following steps:
 - a) Select a corrosion rate method from the **Rate Method** drop-down list box.
 - b) In the **Move Top Center To** drop-down list box, select the position to which you want to rotate the Top Center of the spools.
The Change Preview widget is updated to show a preview of the positions after the rotation.
 - c) Select a rotation date in the **Movement Date** box.

Note: You cannot select a date prior to the date when the last measurement was taken.

- d) Select **Rotate**.
The job status appears in the page heading, displaying the progress of the job. To view and download the log file for the operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Pipe Rotation.
6. To flip the selected components, perform the following steps:
 - a) In the **Action** drop-down list box, select Flip.
The **Flip Components** window appears. The Change Preview widget shows a preview of the updated positions after the flip.
 - b) Select a corrosion rate method from the **Rate Method** drop-down list box.
 - c) Select a flip date in the **Movement Date** box.

Note: You cannot select a date prior to the date when the last measurement was taken.

- d) Select **Flip**.
The job status appears in the page heading, displaying the progress of the job. To view and download the log file for the operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Pipe Rotation.

Results

- If the job is successful, the selected components are rotated or flipped.
- For the asset, an inspection is created for the Pipe Rotation Event and appears under the **Inspections** section of the [Inspection Management Overview page](#).

Access the Piping Rotation or Flip History

Before You Begin

Perform a rotation or flip on a piping component.

About This Task

This topic describes how to access the rotation or flip history for a piping component.

Procedure

1. Access the [Analysis Overview workspace](#) for the piping asset.
2. Select the piping component for which, you want to access the rotation or flip history.
The **Bands** section appears.

3. Select the **Component Details** tab.
The rotation or flip history for the piping component appears in the **PIPE ROTATION: HISTORY** section.

Undo Last Rotation or Flip

About This Task

This topic describes how to perform an undo operation on the last performed rotation or flip for a piping component.

Procedure

1. [Access the rotation or flip history for the piping component](#) for which you want to perform an undo operation.
2. Select **Undo Last Pipe Movement**.
The **Undo Last Pipe Movement** window appears, asking you to confirm if you want to proceed.

Note: The following fields must be present in the Rotation History for Component query:

- MI_PIPE_ROT_EVNT_DATE_D
- MI_PIPE_ROT_EVNT_MOV_TYPE_C

If you modify the query and remove this field, you cannot perform an undo operation.

3. Select **Yes**.
The job status appears in the page heading, displaying the progress of the job. To view and download the log file for the operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Undo Pipe Movement.

Results

- The last performed rotation or flip on the selected piping component is reverted.

Create a What-If Scenario

Before scheduling a rotation or flip event for a piping component, you can create different scenarios for analysis. You can evaluate these scenarios and select the most optimal scenario based on the analysis outputs such as remaining life and retirement date. You can then perform an actual rotation or flip from the selected scenario. For creating a What-If scenario, a virtual rotation or flip is performed, and the analysis results are stored in a Pipe Rotation Event for comparison and future use. However, the change in TML positions are not stored. After you perform a rotation or flip from a scenario, all existing What-If scenarios for the component are deleted.

Before You Begin

- [Create corrosion analysis settings](#).
- [Create component](#).
- [Create band](#).
- Add thickness measurements.

About This Task

This topic describes how to create a What-If scenario for rotating or flipping a piping component.

Procedure

1. Access the [Analysis Overview workspace](#) for a piping asset.
2. If an analysis has not been performed or the data has changed since the last calculation, [calculate the Analysis](#).
3. Select the piping component for which you want to create a What-If scenario, and then select **Rotate/Flip Selection** from the left pane.
4. If you want to create a What-If scenario for multiple spools, perform the following steps from the asset level:

- a) Select **Rotate/Flip Selection** from the left pane.

Note: If the asset contains only elbows, an error message appears when you select **Rotate/Flip Selection**.

The **Select Components** window appears containing a list of spools within the asset.

- b) Select the check boxes that correspond to the components for which you want to create a What-If scenario.
 - c) Select **Done**.
5. In the window that appears, in the **Action** drop-down list box, select the action that you want to perform for creating the scenario.
 6. Select a corrosion rate method from the **Rate Method** drop-down list box.

Note: The Least Squares rate method is only available when the **Least Squares** check box is selected in the **TML Corrosion Rate** section of the **Corrosion Analysis Settings** workspace for the component.

7. If you have selected Rotation in the **Action** drop-down list box, select the position to which you want to rotate the Top Center of the component from the **Move Top Center To** drop-down list box. The current positions of the TMLs and a preview of the changed positions appears in the widgets.
8. Select a date for the event from the **Movement Date** box.

Note: You can select a future date for the event when creating the scenario. When you select a future date, the **Rotate** or **Flip** button is disabled.

9. **Optional:** Enter an ID in the **Scenario ID** box.

Note: The Scenario ID is retained when you perform an actual rotation or flip from the scenario.

10. Select **Add as What-If**.

The job status appears in the page heading, displaying the progress of the job. To view and download the log file for the operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Pipe Rotation or Pipe Flip.

Results

- If the job is successful, a What-If Pipe Rotation Event containing the analysis results of the rotation or flip is created for the component. The created scenario is available under the **PIPE ROTATION: WHAT-IFS** section.

Next Steps

[Access What-If scenarios.](#)

Access What-If Scenarios

Before You Begin

[Create What-If scenarios.](#)

About This Task

This topic describes how to access What-If scenarios for rotation or flip.

Procedure

1. Access the **Analysis Overview** workspace for the piping asset.
2. Select the piping component for which, you want to access the What-If scenario. The **Bands** section appears.
3. Select the **Component Details** tab. The What-If scenarios that you have created for the piping component appear in the **PIPE ROTATION: WHAT-IFS** section.

Next Steps

[Perform a rotation or flip from a What-If scenario.](#)

Perform Rotation or Flip from a What-If Scenario

Before You Begin

[Create What-If scenarios.](#)

About This Task

This topic describes how to perform an actual rotation or flip from a What-If scenario. After you perform these tasks, all existing What-If scenarios for the component are deleted, and the event appears in the pipe rotation or flip history.

Procedure

1. [Access What-If scenarios.](#)
2. Select the row containing the scenario that you want to use for the rotation or flip.
3. Select **Rotate/Flip Selection**. The window for rotation or flip appears. The values in the drop-down list boxes are populated from the scenario that you have selected. You can modify these values as required.

Note: The ENTY_KEY field must be present in the Rotation What-Ifs for Component query for the **Rotate/Flip Selection** button to be enabled. If you modify the query and remove this field, the button will remain disabled when you select a row.

4. Based on the action that you want to perform, select **Rotate** or **Flip**. The job status appears in the page heading, displaying the progress of the job. To view and download the log file for the flip operation, select **View Log** to access the **Schedule Logs** page, and find the entries for Type Mechanical Integrity and Description Pipe Rotation or Pipe Flip.

Chapter 10

Thickness Monitoring Export

Topics:

- [About Thickness Monitoring Export](#)
- [Access the Thickness Monitoring Export Workspace for a Single Asset](#)
- [Access the Thickness Monitoring Export Workspace for Multiple Assets](#)
- [Export TMLs](#)

About Thickness Monitoring Export

The **Thickness Monitoring Export** workspace allows you to review Thickness Measurement Locations (TMLs) that you can select for the export with the related Thickness Monitoring data. You can also export the Thickness Monitoring data in the Thickness Monitoring (TM) Data Loader template format for easy data modification and re-importing.

Note: When exporting the existing TM Asset and TML data in the **Thickness Monitoring Export** workspace, the (Picklist) sheet in the Thickness Monitoring (TM) Data Loader template is excluded. To reference the valid values for picklist fields, you can download the Thickness Monitoring (TM) Data Loader template.

When to Export

You can export TM data in the following scenarios:

- You want to re-assess existing TM data based on triggers such as time, process variations, inspection, or thickness updates.
- You want to quickly modify existing TM data in bulk. After exporting the records into an Excel spreadsheet, make the changes as needed, and re-import the records using the Thickness Monitoring (TM) Data Loader.

What to Export

The list of assets that appears in the **Thickness Monitoring Export** workspace is based on the following catalog query: `Public\Meridium\Modules\Thickness Monitoring\Queries\Export Select Asset Query`. By default, this query returns the assets whose Asset Controlling Next Inspection Date field contains a value and fall within the selected level of Asset Hierarchy.

The Export Select Asset Query has the Asset parameter; the query returns the underlying assets of the selected value in the Asset Hierarchy. By default, the Asset parameter is set to the current asset context provided in the **Thickness Monitoring Overview** page.

The export tool takes the TML Entity Keys and Asset Entity Key from the selected query results to determine which data to export. The following families are considered on each exported worksheet:

Table 4: For Non-Piping Assets

Worksheet	Family
Assets	Equipment and Functional Location
Asset_CAS	Corrosion Analysis Settings
TML_Group	TML Group
TML_Group_CAS	Corrosion Analysis Settings
TML	Thickness Measurement Location
TML_CAS	Corrosion Analysis Settings
Measurements	Thickness Measurement

Table 5: For Piping Assets

Worksheet	Family
Assets	Equipment and Functional Location
Asset_CAS	Corrosion Analysis Settings
Piping_Component	TML Group
Piping_Component_CAS	Corrosion Analysis Settings
Piping_Band	TML Group
Piping_Band_CAS	Corrosion Analysis Settings
TML	Thickness Measurement Location
TML_CAS	Corrosion Analysis Settings
Measurements	Thickness Measurement

Thickness Monitoring Export Data

The Thickness Monitoring Export allows you to review the TML and related data in bulk, and then import it to APM. The data is exported in the same format used by the Thickness Monitoring (TM) Data Loader to enable importing and updating data.

To match the Thickness Monitoring (TM) Data Loader format, the following lookup fields are included in each worksheet:

Table 6: For Non-Piping Assets

Worksheet	Lookup Fields
Asset	Equipment ID, CMMS System, and Equipment Technical Number
Asset_CAS	Component and Inspection Type in addition to the Asset lookup fields
TML_Group	TML Group ID in addition to the Asset lookup fields
TML_Group_CAS	Inspection Type in addition to the TML_Group lookup fields
TML	TML ID in addition to the TML_Group lookup fields
TML_CAS	Inspection Type in addition to the TML lookup fields
Measurements	Same as the TML lookup fields

Table 7: For Non-Piping Assets

Worksheet	Lookup Fields
Asset	Equipment ID, CMMS System, and Equipment Technical Number
Asset_CAS	Component and Inspection Type in addition to the Asset lookup fields
Piping_Component	Component ID in addition to the Asset lookup fields
Piping_Component_CAS	Inspection Type in addition to the Piping_Component lookup fields
Piping_Band	Piping Band ID in addition to Piping_Component lookup fields
Piping_Band_CAS	Inspection Type in addition to Piping_Band lookup fields
TML	Position in addition to the Piping_Band lookup fields

Worksheet	Lookup Fields
TML_CAS	Same as the TML lookup fields
Measurements	Same as the TML lookup fields

After the lookup fields, datasheet fields for each family associated with the template worksheet are exported with the following exceptions:

- **System Fields:** You cannot edit these fields. These fields are maintained by APM.
- **Output Fields:** These fields are calculated. You cannot set these fields.

The default datasheet set in Family Management determines the fields to be exported for each family. If there is no datasheet marked as default for a family, the fields from the first available datasheet are used.

- For Piping_Component, the MI_PIP_COMP datasheet is used to retrieve the fields.
- For Piping_Band, the MI_PIP_BAND datasheet is used to retrieve the fields.

Note: Data will be exported using your login and culture settings.


Important: Only users with the same unit of measure and culture settings can re-import through the Thickness Monitoring (TM) Data Loader.

Access the Thickness Monitoring Export Workspace for a Single Asset

About This Task

This topic describes how to access the **Thickness Monitoring Export** workspace for a single asset. You can also [access the workspace for multiple assets](#).

Procedure

1. Access the **Analysis Overview** workspace for the asset for which you want to access the **Thickness Monitoring Export** workspace.
2. Select , and then select **Export**.
The **Thickness Monitoring Export** workspace appears, displaying the **Select TMLs** section, which contains a hierarchical list of TMLs linked to the selected asset. This list also includes TMLs linked to any TML Groups in the asset.

Access the Thickness Monitoring Export Workspace for Multiple Assets

About This Task

This topic describes how to access the **Thickness Monitoring Export** workspace for multiple assets. You can also [access the workspace for a single asset](#).

Procedure

1. Access the **Analysis Overview** workspace for the functional location that contains the assets for which you want to access the **Thickness Monitoring Export** workspace.
2. Select **Actions > Export TM Data**.

The **Select Assets to Load for Export** window appears, displaying a list of assets in the functional location.

3. In the rows containing the assets for which you want to access the Thickness Monitoring Export workspace, select the check boxes.

Important: The assets that you select must be all non-piping or all piping assets.

Note: We recommend that you select the same type of assets (that is, either Equipment or Functional Locations).

4. Select **Done**.

The **Thickness Monitoring Export** workspace appears, displaying the **Select TMLs** section. The **Select TMLs** pane contains a hierarchical list of TMLs linked to the selected assets. This list also includes TMLs linked to any TML Groups in the assets.

Export TMLs

Procedure

1. Access the **Thickness Monitoring Export** workspace.

2. In the **Select TMLs** pane, perform one of the following steps:

- Select **Select Assets** to navigate through the Asset Hierarchy, and select the check boxes corresponding to the TMLs whose records you want to export. To select all TMLs from an Asset, TML Group, Component, or Band, select the check box next to each item.
- Search for a TML using the **Search** box. Enter the TML ID of the TML that you want to search for in the **Search** field. From the search results, select the check boxes corresponding to the TMLs whose records you want to export.

Tip: You can also search for Assets, TML Groups, Components, or Bands using their IDs. If you want to select items at a different level, you must select **Apply** before entering the next search item.

Note:

- For an asset, if there are more than 1000 linked TMLs, a message appears, and the TMLs do not appear in the pane. However, you can select the check box next to the Asset or TML Group to select all the linked TMLs.
- Selecting assets using the **Select Assets** option adds the assets to the existing list of items; it will not replace the existing selection. If you want to add assets afresh, refresh the page, or revisit the **Thickness Monitoring Export** workspace.

3. Select **Apply**.

The selected TMLs appear in the **Selected TMLs** section.

Note:

- For non-piping assets, TMLs are sorted in the ascending order of Asset ID, TML Asset ID, and TML ID. For assets that have Piping Rotation enabled, TMLs are sorted in the ascending order of Asset ID, Component ID, Distance From Inlet, Piping Band ID, and Position.
- If the total number of TMLs across all the selected assets is more than 5,000, the TMLs do not appear in the **Selected TMLs** section. However, the **Confirm Send** window appears, asking you to confirm that you want to send all the selected items to the device. For Oracle databases, the aforementioned limit is 1,000 TMLs.

Note: Select  to access the **Table Settings** window, where you can set the column preferences.

4. Select **Export**.

The **Export to a File** message box appears, asking for a file name.

5. Select **Include Measurements** checkbox to include existing Thickness Measurement records in the exported content. By default, the checkbox is selected, which indicates that all measurements will be exported. If the checkbox is not selected, the Measurements workbook will include all the lookup fields populated without the Measurement data.

Note: If you do not select the **Include Measurements** checkbox, and export the excel, you need to add Measurement details and then upload the exported excel through Data Loader.

6. Enter the file name, and then select **Export**.
An Excel spreadsheet is downloaded, containing the data that you want to export.

Chapter 11

Dataloggers in Thickness Monitoring

Topics:

- [About Dataloggers in Thickness Monitoring \(TM\)](#)
- [Access the TM Dataloggers Page for an Asset or TML Group](#)
- [Access the TM Dataloggers Page for Multiple Assets](#)
- [Modify Datalogger Settings](#)
- [Send Data to a Datalogger](#)
- [Receive Data from a Datalogger](#)

About Dataloggers in Thickness Monitoring (TM)

Dataloggers are data collection devices, which are used to measure and record the thickness of a component. Using the Thickness Monitoring (TM) module, you can:

- [Send data](#) related to a TML to the datalogger.
- [Receive data](#) from the datalogger (after you collect measurement data in the field and record it in the datalogger).

Important: If you are using the GE DMS Go/Go+ device and your company restricts the use of removable storage devices in USB ports, the device may not function as expected. You must request an exemption to the company policy from your IT administrator, such that you are allowed Write permissions to the USB drive. Although the Olympus 38DL Plus device supports USB, it does not store its data in the same way and is therefore not likely subject to the same restriction. If your company restricts the use of removable storage devices in USB ports, the datalogger device may not function as expected. You must request an exemption to the company policy from your IT administrator.

The following dataloggers are supported in TM:

- GE DMS Go
- GE DMS Go+
- GE DMS2
- Olympus 37DL Plus Ultrasonic Thickness Gage
- Olympus 38DL Plus Ultrasonic Thickness Gage
- Olympus Epoch 650

For each datalogger, APM provides:

- [Baseline Datalogger Mapping records](#), which are used to send or receive data from the datalogger.
- [Default datalogger settings](#), which you must review and [modify](#) if needed before you use the datalogger.

To use dataloggers, you must install the latest version of the Meridium Devices Service as well as any necessary device drivers.

If you have modified the `Public\Meridium\Modules\Thickness Monitoring\Queries\TM Assets` query, you must revert the query to baseline or add the following SQL code for piping Asset to the query.


```
[MI Corrosion Analysis Settings].[MI_CA_SET_PIPING_F] "Piping Asset"
```

Access the TM Dataloggers Page for an Asset or TML Group

About This Task

This topic describes how to access the **TM Dataloggers** page for an asset or TML Group. You can also [access the TM Dataloggers page for multiple assets](#).

Procedure

1. Access the [Analysis Overview workspace](#) for the asset or TML Group for which you want to access the **TM Dataloggers** page.
2. Select  , and then select **Dataloggers**.

The **TM Dataloggers** page appears, displaying the **Send To** section. In the **Select TMLs** pane, a hierarchical list of TMLs linked to the selected Asset or TML Group appears. The list also includes TMLs linked to any TML Groups in the asset.

Next Steps

[Modify the datalogger settings.](#)

Access the TM Dataloggers Page for Multiple Assets

About This Task

This topic describes how to access the **TM Dataloggers** page for multiple assets. You can also [access the TM Dataloggers page for a single asset or TML Group](#).

Procedure

1. [Access the Thickness Monitoring Overview page](#) for the functional location that contains the assets for which you want to access the **TM Dataloggers** page.

2. Select **Actions > Dataloggers**.

The **Select Assets to Load for Dataloggers** window appears, displaying a list of assets that the functional location contains.

Note: If you have modified the TM Assets query, revert the query to the baseline query found in the `Baseline/Meridium/Modules/Thickness Monitoring/Queries/` folder.

3. In the rows containing the assets for which you want to access the **TM Dataloggers** page, select the check boxes.

Note: We recommend that you select the same type of assets (that is, either Equipment or Functional Locations).

Important: The selected assets must be all non-piping assets or all piping assets.

4. Select **Done**.

The **TM Dataloggers** page appears, displaying the **Send To** section. In the **Select TMLs** pane, a hierarchical list containing the selected Assets appears. The list includes the TMLs linked to the Assets. In addition, it also includes TMLs linked to any TML Groups in the Assets.

Next Steps

[Modify the datalogger settings.](#)

Modify Datalogger Settings

Before You Begin


- [Default datalogger settings](#) are provided by APM. Review these settings prior to making any modifications.
- Datalogger settings are specific to the user, data source, and browser. If you log in as a different user, switch browsers, or use a different data source, you will need to reconfigure your datalogger settings.
- When you send data to a GE DMS Go or GE DMS Go+ datalogger, APM creates a folder in the USB drive. Therefore, you must have the Write permission to the USB drive on the machine that you will use to send data.

- When using the Olympus Epoch 650 device, you must specify the COM port used by the device.

Tip: To determine the COM port of the device in Windows:

1. Access Device Manager.
2. Under Ports (COM & LTP), verify the COM port next to the USB Serial device.

Procedure

1. Access the **TM Dataloggers** page.
2. Select .
A page containing the datalogger settings appears.
3. In the drop-down list box at the top of the workspace, select the datalogger whose settings you want to configure. By default, the datalogger that you used previously is selected.
4. If you want to use the GE DMS Go or GE DMS Go+ datalogger, specify a directory in the **File Directory** box. Files will be sent to and received from the **Meridium** folder that is created in the specified directory.
5. If you want to use the Olympus 38DL Plus Ultrasonic Thickness Gage datalogger device, select the desired File Mode option to send to and receive from the device.

Note: For sending and receiving measurements taken on the device when the thru coat mode is enabled, this option must be set to Thru-Coat.

6. As needed, enter values in the [remaining fields](#), and then select **Save**.
The datalogger settings are modified.

Results

If you have already selected the assets that you want to send to the datalogger, then the **Send To** section appears. Otherwise, the **Select Assets to Load for Dataloggers** window appears, allowing you to select the assets for which you want to send data to the datalogger.

Next Steps


[Send data to the datalogger.](#)

Send Data to a Datalogger

Before You Begin

- Install the Meridium Device Service on the machine that you will use with dataloggers. If you do not install it, when you attempt to send or receive data, you will be prompted to install it.
- Refer to the [limitations when using a datalogger](#).
- If needed, [modify the datalogger settings](#).

Procedure

1. Access the **TM Dataloggers** page.
2. At the top of the page, in the drop-down list box, select the datalogger to which you want to send data. By default, the datalogger that you previously used is selected.
3. In the **Send To** section, in the **Select TMLs** pane, perform one of the following steps:
 - a) Select  to navigate through the hierarchy, and select the check boxes corresponding to the TMLs whose records you want to send to the device. To select all TMLs from an Asset, TML Group, Component, or Band, select the check box next to the item.

- b) Search for a TML using the **Search** box. Enter the TML ID of the TML that you want to search in the search field, and press Enter. From the list that appears, select the check boxes corresponding to the TMLs whose records you want to send to the device.

You can also search for Assets, TML Groups, Components, or Bands using their IDs to get a list of corresponding Assets, TML Groups, Components, or Bands containing the search term. If you want to select items at a different level, you must select **Apply** before entering the next search term.

Note:

- For an Asset or TML Group, if there are more than 1000 linked TML records, a message appears, and the TMLs are not displayed in the pane. You can select the check box next to the Asset or TML Group to select all the linked TMLs.
- Sending TML measurement data for piping Assets, piping components, or piping bands is only supported by the Olympus 38DL Plus Ultrasonic Thickness Gage datalogger device.

4. Select **Apply**.

The selected TMLs appear in the **Selected TMLs** workspace. For non-piping assets, TMLs are sorted in ascending order of Asset ID, TML Asset ID, and TML ID. For assets that have Piping Rotation enabled, TMLs are sorted in ascending order of Asset ID, Component ID, Distance From Inlet, Piping Band ID, and Position.

Note: If the total number of TMLs across all the selected assets is more than 5,000, the TMLs do not appear in the **Selected TMLs** workspace. However, the **Confirm Send** window appears, asking you to confirm that you want to send all the selected items to the device. For Oracle databases, the above-mentioned limit is 1,000 TMLs.

Tip: Select  to access the **Table Settings** window, where you can set the column preferences.

5. Select **Send To Device**.

The job status appears in the page heading, displaying the progress of the job.

- If you are using the Olympus 38DL Plus Ultrasonic Thickness Gage or the Olympus Epoch 650 datalogger device, the **Send To Device** window appears, displaying the file name, Inspector, and the TML count for each asset whose TMLs will be sent to the device. You can modify the file names if required. In addition, you can select the name of the Inspector taking readings on the device. This value will be used later to populate the Measurement Taken By field of measurements upon receiving readings back into APM. Once all necessary changes are made select **Send** to send the TML records to the device.
- When sending data to the Olympus 38DL Plus Ultrasonic Thickness Gage or the Olympus Epoch 650 datalogger device, for each file that is sent to the device, a Datalogger History record is created. Datalogger History records are used to uniquely identify TML records by entity keys rather than by Asset IDs and TML IDs.

Note: When sending data to the Olympus Epoch 650 device, the device has a limitation that prevents you from sending duplicate TML IDs within the same file (for example, TML Groups with repeated TML IDs). In that case, you must send the TML Groups separately.

Results

If the job is successful, the selected TML records are sent to the device.

If an error occurs, the **Datalogger Errors** window containing the error messages appears.

If the data related to an asset was already sent to the datalogger previously, a message appears, asking you to confirm whether you want to overwrite the existing data on the datalogger. If you choose to overwrite, the data related to the asset is replaced with the data that you send. If you choose not to overwrite, the data will not be sent to the datalogger.

Receive Data from a Datalogger

Before You Begin

- Install the Meridium Device Service on the machine that you will use with dataloggers. If you do not install it, when you attempt to send or receive data, you will be prompted to install it.

Procedure

1. Access the [TM Dataloggers](#) page.
2. At the top of the page, in the drop-down list box, select the datalogger from which you want to receive data. By default, the datalogger that you previously used is selected.
3. Ensure that the [datalogger settings](#) are correct.
4. Select the **Receive From** tab.
The **Receive From** section appears.
5. Select **Receive**.
The **Select Files to Receive** window appears, displaying a list of files that store the measurement data. By default, the check boxes corresponding to all the files are selected. If you do not want to receive the data stored in a file, clear the corresponding check box.
6. Next to each file name representing the file whose data you want to receive, select the check box.
7. Select **Done**.
The job status appears in the page heading, displaying the progress of the job. If the job is successful, data is received from the datalogger, and the Thickness Measurement Location records appear in the workspace.

Note: The check boxes corresponding to the Thickness Measurement Location records that contain measurement readings are automatically selected. The TML records that do not contain readings are not selected. However, if you have selected the **Allow Measurements to be Skipped** check box in [Measurement Preferences](#), all records are automatically selected.

Note: If you are using the Olympus 38DL Plus Ultrasonic Thickness Gage datalogger, the file name corresponding to each TML record received from the device appears in the **FILENAME** column. In addition, the Datalogger History records that were created when sending data to the device are updated.

8. Select the check boxes corresponding to the required Thickness Measurement Location records, and then select **Save**.
The **Confirm Save** window appears, asking you to confirm if you want to save the TML records. To change the measurement taken date for the selected measurements, select the **Override Measurement Taken Date from device** check box, and then select a date in the **Measurement Taken Date** box.
9. Select **Yes**.
The job status appears in the page heading, displaying the progress of the job. If the job is successful, the selected Thickness Measurement Location records that contain Thickness Measurements are saved.

Note: If you are using the Olympus 38DL Plus Ultrasonic Thickness Gage datalogger, and you had selected an Inspector when sending data to the device, that user will be populated in the Measurement Taken By field of any new measurements created against the asset. A Datalogger Mapping for the device's Inspector field is not required to save the data in APM but is required to be displayed in the column in the Receive From grid in APM. The Measurement Taken By will be populated even if the mapping does not exist.

Results

If you have selected the **Allow Measurements to be Skipped** check box in [Measurement Preferences](#), the selected records that do not contain measurement readings appear in the **Create Skipped Measurements** window, and allows you to create Measurement Not Taken records.

The following analyses are re-calculated:

- TML Corrosion Analysis linked to each TML whose measurement data you have received.
- Asset Corrosion Analysis linked to each asset whose measurement data you have received.

Chapter 12

Data Loaders

Topics:

- [TM Data Loaders](#)
- [Thickness Measurement - Assets Data Loader](#)
- [TM Piping Data Loaders](#)

TM Data Loaders

About the Thickness Monitoring (TM) Data Loaders

The following Data Loaders are available in Thickness Monitoring:

- Thickness Monitoring (TM) Equipment Data Loader
- Thickness Monitoring (TM) Functional Location Data Loader

Throughout the documentation, these Data Loaders are collectively called the Thickness Monitoring (TM) Data Loaders. You can use them to implement Thickness Monitoring when you have thickness measurement data in a legacy system. To import data using these Data Loaders, APM provides the following Excel templates:

- Thickness Monitoring (TM) Equipment.xlsx
- Thickness Monitoring (TM) Functional Location.xlsx

These templates support baseline Thickness Monitoring in APM. You must export measurement data from your legacy system so that the data can be used to populate the templates. The data from the templates will then be imported into APM using the corresponding Data Loaders.

Note: The Excel templates are referred to throughout this documentation as the data loader workbooks.

The data loader workbooks allow you to:

- Create or update Corrosion Analysis Settings (CAS) records for an Asset (i.e., Equipment or Functional Location), TML Group, or TML.
- Create or update TML Group records, and link each of them to an Asset.
- Create or update TML records, and link each of them to an Asset or TML Group.
- Create or update Thickness Measurement records, and link them to a TML.

About the Thickness Monitoring (TM) Data Loaders Requirements

Before you use the data loader workbooks, you must complete the following steps:

- Ensure that the Thickness Monitoring module is deployed.
- Ensure that the following licenses are active:
 - APM Connect Plus
 - Thickness Monitoring
- Ensure that the following data is present:
 - Site Reference
 - Equipment Taxonomy
 - Equipment and Functional Location Families
 - Units of Measure Conversion Sets
 - Stress Tables (APM provides Stress Tables for Piping, Pressure Vessels, and Tanks. If you want to use values from these Stress Tables with the data loader workbook, you must ensure that the records are imported into your database prior to performing the data load).
- Ensure that you have set up appropriate relationships and key fields. To do so, you must login as a member of the MI Thickness Monitoring Administrator Security Group.
- Create a relationship between TML Groups and Assets. To do so, [configure family preferences](#), specifying the following values:
 - Asset-to-Subcomponent Relationship: Has TML Group


- Subcomponent-to-Asset Relationship: Has TML Group
- Component ID Field: TML Group ID

Note: By default, the relationship is created between Equipment and TML Groups. If you want to use the Thickness Monitoring (TM) Functional Location Data Loader, in the drop-down list box at the top of the workspace, select **Functional Location**.

- The Security User loading the data must be associated with either the MI Data Loader User or MI Data Loader Admin Security Role, and must also be associated with the MI Thickness Monitoring Administrator or the MI Thickness Monitoring Inspector Security Group or a Security Role that is associated with at least one of these Security Groups.
- The data loader workbooks contain sample data in each column. It is only for your reference. You must remove this data before using the data loader workbooks.

About the Thickness Monitoring (TM) Data Loaders Data Model

The Thickness Monitoring (TM) Data Loaders do not load the entire data model illustrated in the normal help documentation. The following data model illustrates which records the Data Loaders support. Assets (Equipment or Functional Location records), illustrated in green, must exist prior to importing data.



About the Thickness Monitoring (TM) Data Loaders General Loading Strategy

This topic describes the best practices to loading the data and the order in which the data will be loaded.

Best Practices

- For Oracle databases, valid cell values are case-sensitive.
- The imported data must load in a specific sequence in order to successfully populate fields, to create records, and to link them to the predecessor and successor records.

- If a data loader worksheet contains any blank cells:
 - When you create new records, the fields corresponding to the blank cells are updated with the default values, if any.
 - When you update existing records, the fields corresponding to the blank cells are not updated.
- The Thickness Monitoring (TM) Data Loaders map the datasheet columns in the data loader workbooks to fields in APM families by their position. Therefore, you must not change the column positions and IDs. You can, however, change the captions if needed.
- ID fields must not include special characters or spaces.
- Columns (including columns representing custom fields) in the worksheets should be formatted as Text.
- You must consider the rules described in the [Workbook Layout and Use](#) section of this document while using the data loader workbooks.
- Details related to an Equipment that is linked to a TML Group or a TML must always be entered on the assets and Asset_CAS worksheets of the Thickness Monitoring (TM) Equipment Data Loader even if the asset has already been loaded earlier. Similarly, details related to a Functional Location that is linked to a TML Group or a TML must always be entered on the Functional_Location and Functional_Location_CAS worksheets of the Thickness Monitoring (TM) Functional Location Data Loader even if the Functional Location has already been loaded earlier.
- When you override the values for Minimum Thickness and Minimum Thickness Type fields, the values from the data loader will be considered.
- In addition to the fields included in the data loader workbooks, if you want to add values for more fields for a record, you can add columns for those fields on the appropriate worksheet.

Note: The fields that you want to add to the data loader workbooks must already exist in the corresponding family. If not, you must add the fields to the family via Configuration Manager.
- Do not delete a worksheet in the data loader workbooks.

Load Sequence

The data must be loaded in the following sequence to successfully populate fields, create records, and link them to the predecessor and successor records:

1. The Assets or the Functional_Location worksheet is processed.

If you are using the Thickness Monitoring (TM) Equipment Data Loader, it searches for the Equipment that corresponds to the Equipment ID, CMMS System, and Equipment Technical Number information that you provide on the Assets worksheet. If you are using the Thickness Monitoring (TM) Functional Location Data Loader, it searches for the Functional Location that corresponds to the Functional Location ID and CMMS System information that you provide on the Functional_Location worksheet. If an asset specified on the worksheet does not exist, it will not be loaded. In addition, the TML Groups and TMLs linked to the asset are not loaded.
2. The Asset_CAS or the Functional_Location_CAS worksheet is processed.

If you have entered values in all the mandatory cells and if the details of an asset on this worksheet match the details on the Assets or the Functional_Location worksheet:

 - A Corrosion Analysis Settings record is created and linked to the asset using the Has Corrosion Analysis Settings relationship.
 - An Asset Corrosion Analysis record is created and linked to the asset using the Has Corrosion Analyses relationship.

If you do not enter values (in cells other than the mandatory ones) on this worksheet, the default values are used.
3. The TML_Group worksheet is processed. For each TML Group, if the details of the asset on the TML_Group worksheet match the details on the assets or the Functional_Location worksheet, a TML Group record is created and linked to the asset using the Has TML Group relationship.

4. The TML_Group_CAS worksheet is processed. For each TML Group:
 - A Corrosion Analysis Settings record is created, and linked to the TML Group using the Has Corrosion Analysis Settings relationship. The fields in the Corrosion Analysis Settings record are populated with the corresponding values on the Asset_CAS or the Functional_Location_CAS worksheet.
 - If you have entered values on the TML_Group_CAS worksheet, the values in the fields in the Corrosion Analysis Settings record linked to the TML Group are replaced with the values on the TML_Group_CAS worksheet.
 - An Asset Corrosion Analysis record is created, and linked to the TML Group using the Has Corrosion Analyses relationship.
5. The TML worksheet is processed.
 - If you have entered a value in the TML Group ID column on this worksheet, a Thickness Measurement Location is created and linked to the TML Group using the Has DataPoints relationship. Otherwise, the TML is linked to the asset that you have specified on this worksheet.
6. The TML_CAS worksheet is processed. For each TML:
 - A Corrosion Analysis Settings record is created, and linked to the TML using the Has Corrosion Analysis Settings relationship. The fields in the Corrosion Analysis Settings record are populated with the corresponding values on the TML_Group_CAS, Asset_CAS, or Functional_Location_CAS worksheet, depending on whether the TML is linked to a TML Group, Equipment, or Functional Location respectively.
 - A TML Corrosion Analysis record is created, and linked to the TML using the Has Corrosion Analyses relationship.
 - If you have entered values on this worksheet, the values in the fields in the Corrosion Analysis Settings record linked to the TML are replaced with the values on the TML_CAS worksheet.
7. The Measurements worksheet is processed. For each row on this worksheet, a Thickness Measurement record is created (or updated), and linked to the TML using the Has Measurements relationship.

Note: For a given TML, if two or more rows contain the same value in the Measurement Date field, then only one Measurement record is created. The fields in that record are populated with values in the last row among them.

After you load the data, the updated assets appear in the **Assets** and **Assets Requiring a Calculation** sections on the **Thickness Monitoring Overview** page. You must calculate all the analyses that you have loaded because they are not calculated automatically after you load the data.

Note: The data loaders used in TM split large amount of data into the following transaction scopes:

- Asset Level Data
- TML Groups in 100-count batches
- Thickness Measurement Locations in 100-count batches
- Measurements in 250-count batches

If an error occurs while loading data, you can reduce the transaction scopes as per your requirement. For information on modifying the transaction scopes, refer to the [Configure Data Loader Transaction Scopes](#) topic.

About the Thickness Monitoring (TM) Data Loaders Workbook Layout and Use

Color Coding

Certain columns on the worksheets have different functions and requirements. To illustrate this, certain columns are color-coded. The following table lists the colors and what they represent.

Color	Description	Comments
Grey	Lookup Fields	Indicates columns that contain values that are used by the Thickness Monitoring Data Loader to look up and create records. If these columns are removed from the worksheets, the data load will fail. While the worksheets require that these columns be present, values are not necessarily required in these columns.
Red	Fields Required for Calculation	Indicates columns that contain values that are required to perform calculations in Risk Based Inspection. Some cells only require values in certain cases. Such cases are found in parentheses in the first row of each worksheet.
Blue	Recommended Fields	Indicates columns that, according to APM Best Practice for Risk Based Inspection, should contain values.
Green	Custom Fields	Indicates columns where you can specify custom fields.

Limitations

The Thickness Monitoring (TM) Data Loaders have the following limitations:

- If you modify the format of the values in columns on any of the worksheets, you will not be able to import data.
- You cannot create or update nominal measurements using the data loader workbooks. You can only create or update actual measurements.
- The values that you enter in the data loader workbooks are case-sensitive.
- You cannot link an RBI Component to a TML Group using the data loader workbooks.
- You cannot relocate, renew, or organize TMLs using the data loader workbooks.
- You cannot skip measurements using the data loader workbooks.
- If you reimport data, the records that have been created by the Thickness Monitoring (TM) Data Loaders will be updated. Therefore, while reimporting data related to a record, if you remove the data for a field in the data loader workbooks, the value for the corresponding field in APM will be either a default value or blank.

Tip: If you do not want to update a field value, you can remove the corresponding column from the data loader workbooks. You cannot, however, remove columns that correspond to required fields.

Assets Worksheet

On the Assets worksheet, you will specify Equipment to which you want to link Thickness Measurement Locations (TMLs) and TML Groups. This worksheet is included only in the Thickness Monitoring (TM) Equipment Data Loader. The columns that appear on this worksheet also appear on every subsequent worksheet in the Thickness Monitoring (TM) Equipment Data Loader. They are used to identify the records that will be linked, directly or indirectly, to the Equipment. The combination of values in the three columns on this worksheet must be unique.

Note: The Assets worksheet can also be used to load Functional Location data.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	If the Equipment record for an asset has a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	If you are required to enter a value for the CMMS System cell for a piece of equipment, and the Equipment record has a value in the Equipment Technical Number field, enter that value in this column. If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.
Asset Family ID	ASSET_FAMILY_ID	Character (255)	If you are uploading Functional Location data in the Assets worksheet, specify the MI_FNCLOC00 value in this column. If the column is not present or data is null in this field, APM will consider it as Equipment data.

Functional_Location Worksheet

On the Functional_Location worksheet, you will specify Functional Locations to which you want to link Thickness Measurement Locations (TMLs) and TML Groups. This worksheet is included only in the Thickness Monitoring (TM) Functional Location Data Loader. The columns that appear on this worksheet also appear on every subsequent worksheet in the Thickness Monitoring (TM) Functional Location Data Loader. They are used to identify the records that will be linked, directly or indirectly, to the Functional Locations. The combination of values in the two columns on this worksheet must be unique.

Field Caption	Field ID	Data Type (Length)	Comments
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value.
CMMS System	MI_FNCLOC00_SAP_SYSTEM_C	Character (255)	If the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.

Asset_CAS Worksheet

On the Asset_CAS worksheet, you will specify Corrosion Analysis Settings records for an Equipment. If you do not enter values on this worksheet, the default values are used. This worksheet is included only in the Thickness Monitoring (TM) Equipment Data Loader.

In addition, the values that you enter on this worksheet are used to specify Corrosion Analysis Settings for associated TML Groups and TMLs. You can, however, overwrite these values by specifying different values on the TML_Group_CAS and TML_CAS worksheets respectively.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	If the Equipment record for an asset has a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.

Field Caption	Field ID	Data Type (Length)	Comments								
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>								
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	<p>If you do not enter a value in this cell, then data in this row is not loaded.</p> <p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <table border="1"> <thead> <tr> <th>System Code ID</th> <th>Inspection Type</th> </tr> </thead> <tbody> <tr> <td>UT</td> <td>Ultrasonic Thickness</td> </tr> <tr> <td>RT</td> <td>Radiographic Thickness</td> </tr> <tr> <td>TML</td> <td>Thickness Measurement Location</td> </tr> </tbody> </table> <p>The list in this field is populated by the CITP System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	System Code ID	Inspection Type	UT	Ultrasonic Thickness	RT	Radiographic Thickness	TML	Thickness Measurement Location
System Code ID	Inspection Type										
UT	Ultrasonic Thickness										
RT	Radiographic Thickness										
TML	Thickness Measurement Location										

Field Caption	Field ID	Data Type (Length)	Comments
Controlling Corrosion Rate	MI_CA_SET_CR_ROLL_OPT_CHR	Character (50)	This cell may only contain one of the following values: <ul style="list-style-type: none"> Average Formula Maximum The default value is Maximum.
Comments	MI_CA_SET_COM_CON_COR_RAT_CHR	Character (2500)	None
Apply CCR to TML Rem Life Next Insp Date Calc	MI_CA_SET_APPLY_CR_FLG	Boolean	Enter True or False. The default value is False.
Safety Factor	MI_CA_SET_AVG_CR_SFTY_FCTR_NBR	Numeric	The default value is 1.
Minimum Number of TMLs	MI_CA_SET_AVG_CR_MN_TML_NBR	Numeric	The default value is 1.
Percentile	MI_CA_SET_AVG_CR_PERC_NBR	Numeric	The default value is 100.
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NBR	Numeric	The default value is 2.
Remaining Life Critical Number of TMLs	MI_CA_SET_RM_LIF_CRIT_TMLS_NBR	Numeric	The default value is 1. Enter a value between 0 and 1.
Corrosion Rate Options - Least Squares	MI_CA_SET_CR_OPT_LS_FLG	Boolean	Enter True or False. The default value is False.
Corrosion Rate Options - Short Term	MI_CA_SET_CR_OPT_ST_FLG	Boolean	Enter True or False. The default value is True.
Corrosion Rate Options - Long Term	MI_CA_SET_CR_OPT_LT_FLG	Boolean	Enter True or False. The default value is True.
Corrosion Rate Options - Custom A	MI_CA_SET_CR_OPT_A_F	Boolean	Enter True or False. The default value is False.
Corrosion Rate Options - Custom B	MI_CA_SET_CR_OPT_B_F	Boolean	Enter True or False. The default value is False.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	The default value is 0.
Inspection Interval Options - Factor Remaining Life	MI_CA_SET_INSP_INT_OPT_FRL_FLG	Boolean	Enter True or False. The default value is True.
Inspection Interval Options - Inspection Interval	MI_CA_SET_INSP_INT_OPT_II_FLG	Boolean	Enter True or False. The default value is True.
Default T-Min (Inches)	MI_CA_SET_REF_TMIN_NBR	Numeric	The default value is 0.
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	The default value is 5.

Field Caption	Field ID	Data Type (Length)	Comments
Use Minimum Corrosion Rate	MI_CA_SET_USE_MN_CR_FLG	Boolean	Enter True or False. The default value is False.
Remaining Life Factor	MI_CA_SET_REM_LIFE_FCTR_NBR	Numeric	The default value is 0.5. Enter a number between 0 and 1.
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	The default value is 0.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	The default value is 0.

Functional_Location_CAS Worksheet

On the Functional_Location_CAS worksheet, you will specify Corrosion Analysis Settings records for a Functional Location. If you do not enter values on this worksheet, the default values are used. This worksheet is included only in the Thickness Monitoring (TM) Functional Location Data Loader.

In addition, the values that you enter on this worksheet are used to specify Corrosion Analysis Settings for associated TML Groups and TMLs. You can, however, overwrite these values by specifying different values on the TML_Group_CAS and TML_CAS worksheets respectively.

Field Caption	Field ID	Data Type (Length)	Comments
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value.
CMMS System	MI_FNCLOC00_SAP_SYSTEM_C	Character (255)	If the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.

Field Caption	Field ID	Data Type (Length)	Comments								
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	<p>If you do not enter a value in this cell, then data in this row is not loaded.</p> <p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <table border="1"> <thead> <tr> <th>System Code ID</th> <th>Inspection Type</th> </tr> </thead> <tbody> <tr> <td>UT</td> <td>Ultrasonic Thickness</td> </tr> <tr> <td>RT</td> <td>Radiographic Thickness</td> </tr> <tr> <td>TML</td> <td>Thickness Measurement Location</td> </tr> </tbody> </table> <p>The list in this field is populated by the CITP System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	System Code ID	Inspection Type	UT	Ultrasonic Thickness	RT	Radiographic Thickness	TML	Thickness Measurement Location
System Code ID	Inspection Type										
UT	Ultrasonic Thickness										
RT	Radiographic Thickness										
TML	Thickness Measurement Location										
Controlling Corrosion Rate	MI_CA_SET_CR_ROLL_OPT_CHR	Character (50)	<p>This cell may only contain one of the following values:</p> <ul style="list-style-type: none"> • Average • Formula • Maximum <p>The default value is Maximum.</p>								
Comments	MI_CA_SET_COM_CON_COR_RAT_CHR	Character (2500)	None								
Apply CCR to TML Rem Life Next Insp Date Calc	MI_CA_SET_APPLY_CR_FLG	Boolean	Enter True or False. The default value is False.								
Safety Factor	MI_CA_SET_AVG_CR_SFTY_FCTR_NBR	Numeric	The default value is 1.								
Minimum Number of TMLs	MI_CA_SET_AVG_CR_MN_TML_NBR	Numeric	The default value is 1.								
Percentile	MI_CA_SET_AVG_CR_PERC_NBR	Numeric	The default value is 100.								

Field Caption	Field ID	Data Type (Length)	Comments
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NBR	Numeric	The default value is 2.
Remaining Life Critical Number of TMLs	MI_CA_SET_RM_LIF_CRIT_TMLS_NBR	Numeric	The default value is 1.
Corrosion Rate Options - Least Squares	MI_CA_SET_CR_OPT_LS_FLG	Boolean	Enter True or False. The default value is False.
Corrosion Rate Options - Short Term	MI_CA_SET_CR_OPT_ST_FLG	Boolean	Enter True or False. The default value is True.
Corrosion Rate Options - Long Term	MI_CA_SET_CR_OPT_LT_FLG	Boolean	Enter True or False. The default value is True.
Corrosion Rate Options - Custom A	MI_CA_SET_CR_OPT_A_F	Boolean	Enter True or False. The default value is False.
Corrosion Rate Options - Custom B	MI_CA_SET_CR_OPT_B_F	Boolean	Enter True or False. The default value is False.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	The default value is 0.
Inspection Interval Options - Factor Remaining Life	MI_CA_SET_INSP_INT_OPT_FRL_FLG	Boolean	Enter True or False. The default value is True.
Inspection Interval Options - Inspection Interval	MI_CA_SET_INSP_INT_OPT_II_FLG	Boolean	Enter True or False. The default value is True.
Default T-Min (Inches)	MI_CA_SET_REF_TMIN_NBR	Numeric	The default value is 0.
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	The default value is 5.
Use Minimum Corrosion Rate	MI_CA_SET_USE_MN_CR_FLG	Boolean	Enter True or False. The default value is False.
Remaining Life Factor	MI_CA_SET_REM_LIFE_FCTR_NBR	Numeric	The default value is 0.5. Enter a number between 0 and 1.
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	The default value is 0.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	The default value is 0.

TML_Group Worksheet

On the TML_Group worksheet, you will specify the TML groups (which are or will be represented by TML Group records) that you want to create or update.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader.</p> <p>To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.</p>
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.</p>
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>

Field Caption	Field ID	Data Type (Length)	Comments
TML Group ID	MI_TMLGROUP_ID_C	Character (50)	A value is required and must be unique among all the TML Groups linked to an Asset. Note: Although the TML Group ID field is disabled and populated automatically in APM, you can override the value using the data loader workbook.
Description	MI_TMLGROUP_DESCR_C	Character (255)	None
Corrosion Group	MI_TMLGROUP_CORRO_GROU P_C	Character (255)	None
Comments	MI_TMLGROUP_COMME_T	Character (2500)	None

TML_Group_CAS

On the TML_Group_CAS worksheet, you will specify Corrosion Analysis Settings records for a TML Group. If you do not enter values on this worksheet, the values on the Asset_CAS or Functional_Location_CAS worksheet for the associated asset are used. Otherwise, the values that you enter on the TML_Group_CAS are used for the TML Group.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.

Field Caption	Field ID	Data Type (Length)	Comments
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	<p>If you do not enter a value in this cell, then data in this row is not loaded. This cell may only contain a value that you entered in the Inspection Type cell for the associated asset on the Asset_CAS or Functional_Location_CAS worksheet.</p>
TML Group ID	MI_TMLGROUP_ID_C	Character (50)	<p>A value is required and must match one of the value in the corresponding cell on the TML Group worksheet.</p>
Controlling Corrosion Rate	MI_CA_SET_CR_ROLL_OPT_CHR	Character (50)	<p>This cell may only contain one of the following values:</p> <ul style="list-style-type: none"> • Average • Formula • Maximum
Comments	MI_CA_SET_COM_CON_COR_R AT_CHR	Character (2000)	None

Field Caption	Field ID	Data Type (Length)	Comments
Apply CCR to TML Rem Life Next Insp Date Calc	MI_CA_SET_APPLY_CR_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Safety Factor	MI_CA_SET_AVG_CR_SFTY_FCT R_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Minimum Number of TMLs	MI_CA_SET_AVG_CR_MN_TML_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Percentile	MI_CA_SET_AVG_CR_PERC_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Remaining Life Critical Number of TMLs	MI_CA_SET_RM_LIF_CRIT_TMLS_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Options - Least Squares	MI_CA_SET_CR_OPT_LS_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Corrosion Rate Options - Short Term	MI_CA_SET_CR_OPT_ST_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Options - Long Term	MI_CA_SET_CR_OPT_LT_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Options - Custom A	MI_CA_SET_CR_OPT_A_F	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Options - Custom B	MI_CA_SET_CR_OPT_B_F	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Inspection Interval Options - Factor Remaining Life	MI_CA_SET_INSP_INT_OPT_FRL_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Inspection Interval Options - Inspection Interval	MI_CA_SET_INSP_INT_OPT_IL_F LG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Default T-Min (Inches)	MI_CA_SET_REF_TMIN_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Use Minimum Corrosion Rate	MI_CA_SET_USE_MN_CR_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Remaining Life Factor	MI_CA_SET_REM_LIFE_FCTR_N BR	Numeric	Enter a number between 0 and 1. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.

TML Worksheet

On the TML worksheet, you will specify the TMLs (that are or will be represented by Thickness Measurement Location records) that you want to create. For some of the cells, if you do not enter a value on this worksheet, after you load data, the corresponding fields are populated automatically in APM.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column. If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.
TML Group ID	MI_TMLGROUP_ID_C	Character (50)	If you do not enter a value in this cell, the TML is directly linked to the Asset.
TML ID	MI_DP_ID_CHR	Character (50)	A value is required, and must be unique among all the TMLs linked to a TML Group or an Asset.
TML Analysis Type	MI_TML_TYPE_CHR	Character (50)	A value is required. This cell may only contain one of the values that you entered in the Inspection Type cell in the Asset_CAS, Functional_Location_CAS, or TML_Group_CAS worksheet, whichever is linked to the TML.
Component Type	MI_TML_COMP_TYPE_CHR	Character (10)	In the baseline APM system, this cell may only contain one of the following System Code IDs: <ul style="list-style-type: none"> • Piping • Pressure Vessel • Tank
Location	MI_DP_LOCTN_CHR	Character (50)	None
ISO Drawing Number	MI_DP_ISO_DRAW_CHR	Character (50)	None

Field Caption	Field ID	Data Type (Length)	Comments
Access	MI_DP_ACCESS_CHR	Character (50)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <ul style="list-style-type: none"> • LADDER • MANLIFT • SCAFFOLD <p>The list in this field is populated by the DPAC System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>
Inspection Sequence Number	MI_DP_INSP_SEQ_NBR	Numeric	None
Insulated Flag	MI_TML_INSLTED_FLG	Boolean	Enter True or False. The default value is False.
TML Comment	MI_DP_COMMNT_CHR	Character (255)	None
Minimum Thickness	MI_TML_MIN_THICK_NBR	Numeric	If you do not enter a value in this cell, the value in the Default T-Min (Inches) cell on the TML_CAS worksheet is used.
Additional Thickness	MI_THICK_MEASU_LOCAT_ADDIT_THI	Numeric	None
Excluded From Analysis	MI_DP_EXCL_FROM_ANALYSIS_FLG	Logical	Enter True or False. The default value is False.
Number of Readings	MI_TML_READ_NUM_N	Numeric	Enter a number between 1 and 26. The default value is 1.

Field Caption	Field ID	Data Type (Length)	Comments									
Design Code	MI_TML_DSGN_CODE_CHR	Character (50)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs based on the value in the Component Type cell:</p> <table border="1"> <thead> <tr> <th>Component Type</th> <th>Design Code</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Piping</td> <td>B31.1</td> </tr> <tr> <td>B31.3</td> </tr> <tr> <td>Pressure Vessel</td> <td>ASME VIII DIV 1</td> </tr> <tr> <td>Tank</td> <td>API 653</td> </tr> </tbody> </table> <p>The list in this field is populated by the DSCD System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	Component Type	Design Code	Piping	B31.1	B31.3	Pressure Vessel	ASME VIII DIV 1	Tank	API 653
Component Type	Design Code											
Piping	B31.1											
	B31.3											
Pressure Vessel	ASME VIII DIV 1											
Tank	API 653											
Code Year (T-Min Formula)	MI_TML_CODE_YEAR_C	Character (4)	<p>A value is required if the value in the Design Code cell is not N/A. This cell may only contains one of the following values:</p> <ul style="list-style-type: none"> N/A 1995 									

Field Caption	Field ID	Data Type (Length)	Comments										
Code Year (Allowable Stress Lookup)	MI_TML_CODE_YEAR_STRESS_C	Character (4)	<p>A value is required if the value in the Design Code cell is not N/A. The following table provides the valid values that you can enter in this cell based on the value in the Design Code cell.</p> <table border="1"> <thead> <tr> <th>Design Code</th> <th>Code Year (Allowable Stress Lookup)</th> </tr> </thead> <tbody> <tr> <td>API 653</td> <td>2008</td> </tr> <tr> <td>ASME VIII DIV 1</td> <td>1998 2010</td> </tr> <tr> <td>B31.1</td> <td>2014</td> </tr> <tr> <td>B31.3</td> <td>2014</td> </tr> </tbody> </table>	Design Code	Code Year (Allowable Stress Lookup)	API 653	2008	ASME VIII DIV 1	1998 2010	B31.1	2014	B31.3	2014
Design Code	Code Year (Allowable Stress Lookup)												
API 653	2008												
ASME VIII DIV 1	1998 2010												
B31.1	2014												
B31.3	2014												
Material Specification	MI_TML_MAT_SPEC_CHR	Character	A value is required if the value in the Override Allowable Stress cell is False, and if you want APM to calculate T-min values. Refer to the (Picklist) worksheet in the data loader workbook for valid values that you can enter in this cell based on the values in the Design Code and Code Year (Allowable Stress Lookup) cells.										
Material Grade	MI_TML_MAT_GRADE_CHR	Character (50)	A value is required if the value in the Override Allowable Stress cell is False, and if you want APM to calculate T-min values. Refer to the (Picklist) worksheet in the data loader workbook for valid values that you can enter in this cell based on the values in the Design Code, Code Year (Allowable Stress Lookup), and Material Specification cells.										
Material Type	MI_TML_MATER_TYPE_CHR	Character	None										
Design Pressure	MI_TML_DSGN_PRESS_NBR	Numeric	A value is required if you want APM to calculate T-min values.										

Field Caption	Field ID	Data Type (Length)	Comments
Design Temperature	MI_TML_DSGN_TEMP_NBR	Numeric	A value is required if you want APM to calculate T-min values.
Nominal Thickness	MI_TML_NOM_THICK_NBR	Numeric	None
Override Allowable Stress	MI_TML_OVRD_ALLOW_STRESS_F	Boolean	Enter True or False.
Allowable Stress	MI_TML_ALLOWABLE_STRESS_N	Numeric	A value is required if the value in the Override Allowable Stress cell is True, and you want APM to calculate T-min values.
Outside Diameter	MI_TML_OUTSD_DIAM_NBR	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Vessel Type cell is CON_HEAD (Conical Head), ELLIP_HEAD (Ellipsoidal Head), PIPENOZZ (Pipe nozzle), TORCC_HEAD (Toriconical Head), or TORCK_HEAD (Toriconical Head, Knuckle Portion). The value in the PV Formula cell is Outside. You want APM to calculate T-min values.
Inside Diameter	MI_TML_INSD_DIAM_NBR	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Vessel Type cell is CON_HEAD (Conical Head), ELLIP_HEAD (Ellipsoidal Head), TORCC_HEAD (Toriconical Head), or TORCK_HEAD (Toriconical Head, Knuckle Portion). The value in the PV Formula cell is Inside. You want APM to calculate T-min values.

Field Caption	Field ID	Data Type (Length)	Comments
Joint Factor	MI_TML_JOINT_EFF_NBR	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is RIVSHELL (Rivited Shell) or WELDSHELL (Welded Shell). You want APM to calculate T-min values. <p>The default value is 1.</p>
Corrosion Allowance	MI_TML_CORR_ALLOW_NBR	Numeric	None
Piping Nominal Diameter - NPS	MI_TML_NOM_DIAM_NBR	Numeric	<p>Refer to the (Picklist) worksheet in the data loader workbook for a list of values that you can enter in this cell.</p> <p>The values in the Piping Nominal Diameter - NPS and Piping Nominal Diameter - DN cells are mapped using the Piping Properties reference table. Therefore, if you enter a value in one of these cells, the other field is populated with the mapped value after you load data.</p> <p>If you enter a value that is not mapped to the value in the Piping Nominal Diameter - DN cell, then the value in this cell is ignored, and the corresponding field is populated with the value mapped to the value in the Piping Nominal Diameter - DN cell. For example, if the value in the Piping Nominal Diameter - DN cell is 6, then the value in this cell must be 0.125. If you enter a different value in this cell or leave it blank, then the value 0.125 is used to populate the corresponding field in APM.</p>

Field Caption	Field ID	Data Type (Length)	Comments
Piping Nominal Diameter - DN	MI_TML_PIPING_NOM_DIAM_D N_N	Numeric	<p>Refer to the (Picklist) worksheet in the data loader workbook for a list of values that you can enter in this cell.</p> <p>The values in the Piping Nominal Diameter - NPS and Piping Nominal Diameter - DN cells are mapped using the Piping Properties reference table. Therefore, if you enter a value in one of these cells, the other field is populated with the mapped value after you load data.</p>
Schedule	MI_TML_SCHED_CHR	Character (50)	<p>A value is required if you have entered a value in the Piping Nominal Diameter - NPS cell. Refer to the (Picklist) worksheet in the data loader workbook for a list of values that you can enter in this cell based on the value in the Piping Nominal Diameter - NPS cell.</p>

Field Caption	Field ID	Data Type (Length)	Comments								
Piping Formula	MI_TML_PIPING_FORMULA_C	Character (4)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs based on the values in the Design Code cell:</p> <table border="1"> <thead> <tr> <th>Design Code</th> <th>Piping Formula</th> </tr> </thead> <tbody> <tr> <td>No value</td> <td>A B C D</td> </tr> <tr> <td>B31.3</td> <td>A B C D</td> </tr> <tr> <td>Any value other than B31.3</td> <td>N/A</td> </tr> </tbody> </table> <p>The list in this field is populated by the PIPFMU System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	Design Code	Piping Formula	No value	A B C D	B31.3	A B C D	Any value other than B31.3	N/A
Design Code	Piping Formula										
No value	A B C D										
B31.3	A B C D										
Any value other than B31.3	N/A										
Mechanical Allowance	MI_TML_MECH_ALLOWANCE_N	Numeric	The default value is 0.								
Design Factor	MI_TML_DESIGN_FACTOR_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Component Type cell is Piping. The value in the Design Code cell is B31.8. You want APM to calculate T-min values. <p>The default value is 1.</p>								

Field Caption	Field ID	Data Type (Length)	Comments												
Temperature Factor	MI_TML_TEMP_FACTOR_N	Numeric	A value is required if the value in the Component Type cell is Piping, and if you want APM to calculate T-min values. The default value is 1.												
Tank Type	MI_TML_TANK_TYPE_C	Character (50)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <table border="1"> <thead> <tr> <th>System Code ID</th> <th>Tank Type</th> </tr> </thead> <tbody> <tr> <td>ANNRING</td> <td>Annular Ring</td> </tr> <tr> <td>FLRPLATE</td> <td>Floor Plate</td> </tr> <tr> <td>RIVSHELL</td> <td>Rivited Shell</td> </tr> <tr> <td>ROOFPLATE</td> <td>Roof Plate</td> </tr> <tr> <td>WELDSHELL</td> <td>Welded Shell</td> </tr> </tbody> </table> <p>The list in this field is populated by the TNKT System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	System Code ID	Tank Type	ANNRING	Annular Ring	FLRPLATE	Floor Plate	RIVSHELL	Rivited Shell	ROOFPLATE	Roof Plate	WELDSHELL	Welded Shell
System Code ID	Tank Type														
ANNRING	Annular Ring														
FLRPLATE	Floor Plate														
RIVSHELL	Rivited Shell														
ROOFPLATE	Roof Plate														
WELDSHELL	Welded Shell														
Shell Type	MI_TML_SHELL_TYPE_C	Character (50)	None												
API Method	MI_TML_API_METHOD_C	Character (50)	None												
Plate Thickness	MI_TML_PLATE_THICKNESS_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is ANNRING (Annular Ring). You want APM to calculate T-min values. 												

Field Caption	Field ID	Data Type (Length)	Comments
Minimum Yield Strength	MI_TML_MIN_YIELD_STR_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is WELDSHELL (Welded Shell). You want APM to calculate T-min values.
Minimum Tensile Strength	MI_TML_MIN_TENSILE_STR_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is WELDSHELL (Welded Shell). You want APM to calculate T-min values.
Course Height	MI_TML_COURSE_HEIGHT_N	Numeric	None
Course Number	MI_TML_COURSE_NUMBER_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is WELDSHELL (Welded Shell). You want APM to calculate T-min values.
Fill Height	MI_TML_FILL_HEIGHT_N	Numeric	None
Specific Gravity	MI_TML_SPECIFIC_GRAVITY_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is ANNRING (Annular Ring), RIVSHELL (Riveted Shell), or WELDSHELL (Welded Shell). You want APM to calculate T-min values.

Field Caption	Field ID	Data Type (Length)	Comments
Floor Plate has Detection?	MI_TML_FLR_PLATE_DETECTIO N_L	Boolean	Enter True or False. The default value is False.
Floor Plate has Reinforced Lining?	MI_TML_FLR_PLATE_REINFORC ED_LINING_L	Boolean	Enter True or False. The default value is False.
Maximum Operating Fill Height	MI_TML_MAX_OP_FILL_HEIGH T_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is ANNRING (Annular Ring), RIVSHELL (Rivited Shell), or WELDSHELL (Welded Shell). You want APM to calculate T-min values.
Distance From the Bottom	MI_TML_DIST_FROM_BOTT_NB R	Numeric	None
Tank Diameter	MI_TML_TANK_DIAMETER_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is ANNRING (Annular Ring), RIVSHELL (Rivited Shell), or WELDSHELL (Welded Shell). You want APM to calculate T-min values.

Field Caption	Field ID	Data Type (Length)	Comments																				
Vessel Type	MI_TML_VESSEL_TYPE_C	Character (50)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <table border="1"> <thead> <tr> <th>System Code ID</th> <th>Tank Type</th> </tr> </thead> <tbody> <tr> <td>CON_HEAD</td> <td>Conical Head</td> </tr> <tr> <td>CYL_SHELL</td> <td>Cylindrical Shell</td> </tr> <tr> <td>ELLIP_HEAD</td> <td>Ellipsoidal Head</td> </tr> <tr> <td>HEM_HEAD</td> <td>Hemispherical Head</td> </tr> <tr> <td>PIPENOZZ</td> <td>Pipe Nozzle</td> </tr> <tr> <td>SPH_SHELL</td> <td>Spherical Shell</td> </tr> <tr> <td>TORCC_HEAD</td> <td>Toriconical Head</td> </tr> <tr> <td>TORCK_HEAD</td> <td>Toriconical Head, Knuckle Portion</td> </tr> <tr> <td>TORSP_HEAD</td> <td>Torispherical Head</td> </tr> </tbody> </table> <p>The list in this field is populated by the VSTP System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	System Code ID	Tank Type	CON_HEAD	Conical Head	CYL_SHELL	Cylindrical Shell	ELLIP_HEAD	Ellipsoidal Head	HEM_HEAD	Hemispherical Head	PIPENOZZ	Pipe Nozzle	SPH_SHELL	Spherical Shell	TORCC_HEAD	Toriconical Head	TORCK_HEAD	Toriconical Head, Knuckle Portion	TORSP_HEAD	Torispherical Head
System Code ID	Tank Type																						
CON_HEAD	Conical Head																						
CYL_SHELL	Cylindrical Shell																						
ELLIP_HEAD	Ellipsoidal Head																						
HEM_HEAD	Hemispherical Head																						
PIPENOZZ	Pipe Nozzle																						
SPH_SHELL	Spherical Shell																						
TORCC_HEAD	Toriconical Head																						
TORCK_HEAD	Toriconical Head, Knuckle Portion																						
TORSP_HEAD	Torispherical Head																						

Field Caption	Field ID	Data Type (Length)	Comments
PV Formula	MI_TML_PV_FORMULA_C	Character (10)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <ul style="list-style-type: none"> • Inside • Outside <p>The list in this field is populated by the PVFMU System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>
Dish Radius	MI_TML_DISH_RADIUS_N	Numeric	<p>A value is required if:</p> <ul style="list-style-type: none"> • The value in the Vessel Type cell is TORSP_HEAD (Torispherical Head). <p>-and-</p> <ul style="list-style-type: none"> • You want APM to calculate T-min values.
Knuckle Radius	MI_TML_KNUCKLE_RADIUS_N	Numeric	<p>A value is required if:</p> <ul style="list-style-type: none"> • The value in the Vessel Type cell is TORCK_HEAD (Toriconical Head, Knuckle Portion) or TORSP_HEAD (Torispherical Head). <p>-and-</p> <ul style="list-style-type: none"> • You want APM to calculate T-min values.
apex_angle	MI_TML_APEX_ANGLE_N	Numeric	<p>A value is required if:</p> <ul style="list-style-type: none"> • The value in the Vessel Type cell is CON_HEAD (Conical Head), TORCC_HEAD Toriconical Head), or TORCK_HEAD (Toriconical Head, Knuckle Portion). <p>-and-</p> <ul style="list-style-type: none"> • You want APM to calculate T-min values.

Field Caption	Field ID	Data Type (Length)	Comments
Inside Radius	MI_TML_INSIDE_RADIUS_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Vessel Type cell is CYL_SHELL (Cylindrical Shell), HEM_HEAD Hemispherical Head, or SPH_SHELL (Spherical Shell). The value in the PV Formula cell is Inside. You want APM to calculate T-min values.
Outside Radius	MI_TML_OUTSIDE_RADIUS_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Vessel Type cell is CYL_SHELL (Cylindrical Shell), HEM_HEAD Hemispherical Head, or SPH_SHELL (Spherical Shell). The value in the PV Formula cell is Outside. You want APM to calculate T-min values.
Head Diameter	MI_TML_HEAD_DIAMETER_N	Numeric	None

TML_CAS Worksheet

On the TML_CAS worksheet, you will specify Corrosion Analysis Settings records for a TML.

- If you do not enter values on this worksheet, and:
 - If the TML is linked to a TML Group, then the values on the TML_Group_CAS worksheet for the associated TML Group are used.
 - If the TML is not linked to a TML Group, the values that you enter on the Asset_CAS or Functional_Location_CAS worksheet are used.
- Otherwise, the values on the TML_CAS worksheet are used.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader.</p> <p>To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.</p>
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.</p>
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>

Field Caption	Field ID	Data Type (Length)	Comments
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	If you do not enter a value in this cell, then data in this row is not loaded. If the TML is linked to a TML Group, then this cell may only contain a value that you have entered in the Inspection Type cell for the associated TML Group on the TML_Group_CAS worksheet. Otherwise, this cell may only contain a value that you have entered in the Inspection Type cell for the associated asset on the Asset_CAS worksheet.
TML Group ID	MI_TMLGROUP_ID_C	Character (50)	A value is required if the TML is linked to a TML Group. The value should match the value in the TML Group ID cell for the corresponding TML on the TML worksheet. If you do not enter a value in this cell, the TML is directly linked to the Asset.
TML ID	MI_DP_ID_CHR	Character (50)	A value is required and must be unique.
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NBR	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.

Measurements Worksheet

On the Measurements worksheet, you will specify the TMs (that are or will be represented by Thickness Measurement records) that you want to create or update.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader.</p> <p>To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.</p>
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.</p>
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>

Field Caption	Field ID	Data Type (Length)	Comments
TML Group ID	MI_TMLGROUP_ID_C	Character (50)	A value is required if the corresponding TML is linked to a TML Group. The value that you enter must match the value in the TML Group ID cell for the corresponding TML on the TML worksheet.
TML ID	MI_DP_ID_CHR	Character (50)	A value is required and should match the value in the TML ID cell for the corresponding TML on the TML worksheet. Otherwise, data in this row is not loaded.
Readings	MI_THICK_MEASU_READI_C	Character (2000)	A value is required. Enter a number greater than 0. If you have multiple readings, separate them with semicolons. If you do not enter a value in this cell, the data in this row is not loaded.
Measurement Date	MI_DP_MEAS_TAKEN_DT	Date	Enter a value in the following format: YYYY-MM-DD hh:mm:ss If you do not enter a value, the current date is used.

Field Caption	Field ID	Data Type (Length)	Comments
Measurement Taken By	MI_DP_MEAS_TAKEN_BY_CHR	Character	<p>Enter a value in the following format: <Last Name>, <First Name> ~ <User ID></p> <p>When you want to create a Thickness Monitoring record using the data loader workbook, and if your user ID appears in the Measurement Taken By field on a Thickness Measurement datasheet, then you need not enter a value in this cell. The appropriate value is automatically populated in the Measurement Taken By field after you load data. If not, enter a value that matches the user ID of a Security User in APM. Otherwise, the data in this row is not loaded.</p> <p>If, however, you do not want the Measurement Taken by field to be populated automatically, using the data loader workbook, update the Thickness Monitoring record by leaving the Measurement Taken By cell blank.</p>
Measurement Comment	MI_DP_MEAS_COMMENT_CHR	Character (255)	None
Temperature	MI_THICK_MEAS_TEMP_TAKEN_AT_N	Numeric	None

About the Thickness Monitoring (TM) Data Loaders Load Verification

About This Task

After you load data, perform the following steps in APM to confirm the integrity and accuracy of the data that you have loaded:

Procedure

- Access the details of the import job. These details indicate if any errors were encountered during the data load. The log may help account for any records that are not loaded.
- In Thickness Monitoring or Record Manager, access the assets specified in the data loader workbook, and then verify that the expected TML Groups and TMLs are present or updated, and that any associated records that you expected to be created are also present in the database.
- To view a list of TML Groups created after a specific date, run the following query:

- For an **SQL** database:

```
SELECT [MI_TMLGROUP].[MI_TMLGROUP_ID_C] "TML Group ID",
[MI_TMLGROUP].[MI_TMLGROUP_DESCR_C]
"Description", [MI_TMLGROUP].LAST_UPDT_DT "LAST_UPDT_DT" FROM
[MI_TMLGROUP] WHERE
[MI_TMLGROUP].LAST_UPDT_DT >= CONVERT(VARCHAR(255),
(? :d :caption='Enter a Date'), 110)
```

- For an **Oracle** or **Postgres** database:

```
SELECT [MI_TMLGROUP].[MI_TMLGROUP_ID_C] "TML Group ID",
[MI_TMLGROUP].[MI_TMLGROUP_DESCR_C]
"Description", [MI_TMLGROUP].LAST_UPDT_DT "LAST_UPDT_DT",
[MI_TMLGROUP].ENTY_ID "ENTY_ID"
FROM [MI_TMLGROUP] WHERE [MI_TMLGROUP].LAST_UPDT_DT >=
to_date(to_char((? :d :caption='Enter
a Date'), 'mm/dd/yyyy'), 'mm/dd/yyyy')
```

- To view a list of TMLs created after a specific date, run the following query:

- For an **SQL** database:

```
SELECT [MI Thickness Measurement Location].[MI_DP_ID_CHR] "TML
ID", [MI Thickness Measurement Location].
[MI_DP_ASSET_ID_CHR] "TML Asset ID", [MI Thickness Measurement
Location].LAST_UPDT_DT "LAST_UPDT_DT"
FROM [MI Thickness Measurement Location] WHERE [MI Thickness
Measurement Location].LAST_UPDT_DT >=
CONVERT(VARCHAR(255), (? :d :caption='Enter a Date'), 110)
```

- For an **Oracle** or **Postgres** database:

```
SELECT [MI Thickness Measurement Location].[MI_DP_ID_CHR] "TML
ID", [MI Thickness Measurement Location].
[MI_DP_ASSET_ID_CHR] "TML Asset ID", [MI Thickness Measurement
Location].LAST_UPDT_DT "LAST_UPDT_DT",
[MI Thickness Measurement Location].ENTY_KEY "ENTY_KEY" FROM [MI
Thickness Measurement Location] WHERE
[MI Thickness Measurement Location].LAST_UPDT_DT >=
to_date(to_char((? :d :caption='Enter a Date'),
'mm/dd/yyyy'), 'mm/dd/yyyy')
```

- To view a list of Thickness Measurements created after a specific date, run the following query:

- For an **SQL** database:

```
SELECT [MI Thickness Measurement].[MI_THICK_MEASU_ID_CHR]
"Measurement ID", [MI Thickness Measurement].
[MI_DP_MEAS_TAKEN_BY_CHR] "Measurement Taken By", [MI Thickness
Measurement].[MI_THICK_MEAS_TML_KEY_C]
"TML Key", [MI Thickness Measurement].LAST_UPDT_DT "LAST_UPDT_DT"
FROM [MI Thickness Measurement] WHERE
[MI Thickness Measurement].LAST_UPDT_DT >= CONVERT(VARCHAR(255),
(? :d :caption='Enter a Date'), 110)
```

- For an **Oracle** or **Postgres** database:

```
SELECT [MI Thickness Measurement].[MI_THICK_MEASU_ID_CHR]
"Measurement ID", [MI Thickness Measurement].
[MI_DP_MEAS_TAKEN_BY_CHR] "Measurement Taken By", [MI Thickness
Measurement].[MI_THICK_MEASU_READ_PF_C]
```

```
"Readings Pass/Fail", [MI Thickness Measurement].
[MI_THICK_MEAS_TML_KEY_C] "TML Key",
[MI Thickness Measurement].LAST_UPDT_DT "LAST_UPDT_DT", [MI
Thickness Measurement].ENTY_KEY "ENTY_KEY"
FROM [MI Thickness Measurement] WHERE [MI Thickness
Measurement].LAST_UPDT_DT >=
to_date(to_char(?? :d :caption='Enter a Date'), 'mm/dd/yyyy'),
'mm/dd/yyyy')
```

Configure Data Loader Transaction Scopes

Before You Begin

You must be an administrator user of the server machine where APM is installed.

About This Task

By default, the data loaders used in TM split large amounts of data into the following transaction scopes:

- Asset Level Data
- TML Groups in 100-count batches
- Thickness Measurement Locations in 100-count batches
- Measurements in 250-count batches

However, based on the speed of your network connection, configuration of the APM Server, or other such factors, you may notice transaction scope errors while uploading large batches of data. To resolve this issue, you can configure the transaction scopes to reduce the number of TML Groups, TMLs, and Measurements per batch.

Procedure

1. Access the server where APM is installed.
2. Navigate to the following folder:
C:\ProgramData\Meridium\
3. Access the appsettings.Global.json file.
4. As required, modify the following parameters:

Parameter	Description
tmlGroupDataLoaderBatchSize	Defines the batch size of TML Groups.
tmlDataLoaderBatchSize	Defines the batch size of TMLs.
thicknessMeasurementDataLoaderBatchSize	Defines the batch size of thickness measurements.

5. Save the file.
6. Restart the following services:
 - Redis
 - IIS

The transaction scopes are updated.

Thickness Measurement - Assets Data Loader

About the Thickness Measurement - Assets Data Loader

The Thickness Measurement - Assets Data Loader allows you to create or update Thickness Measurements for TMLs as part of completing an Inspection Task. To import data using the Thickness Measurement - Assets Data Loader, APM provides an Excel template named `Thickness Measurement - Assets.xlsx`. Throughout the document, the Excel template is referred to as the data loader workbook.

About the Thickness Measurement - Assets Data Loader Requirements

Before using the Thickness Measurement - Assets Data Loader, you must complete the following steps:

- Ensure that the Inspection Management and Thickness Monitoring modules are deployed.
- Ensure that the TMLs for which you want to create or update thickness measurement values are linked to Inspection Tasks.

Security Settings

The Security User performing the data load operation must be associated with the following Security Groups/Roles:

- The MI Data Loader User or the MI Data Loader Admin Security Role
- The MI Inspection or the MI Thickness Monitoring Inspector Security Group (or a Security Role that is associated with this Security Group)

About the Thickness Measurement - Assets Data Loader General Loading Strategy

Load Sequence

The data is processed in the following sequence to successfully populate fields, create records, and link them to the predecessor and successor records:

1. The Assets worksheet is processed.
The data loader uses the value defined in the Asset Family column to determine which columns to use for asset lookup. If loading for the Equipment family, the fields corresponding to the Equipment will be used. Otherwise, if loading for the Functional Location family, the fields defined in parentheses in the first row will be used to look up the Functional Location record.
If an asset specified on the worksheet does not exist, it will not be loaded. In this case, the Thickness Measurements will not be loaded either.
2. The Measurements worksheet is processed. For each row on this worksheet, a Thickness Measurement record is created (or updated), and linked to the TML using the Has Measurements relationship. If you entered values in the Task ID and Task Related Entity ID columns, the created or updated measurements will be linked to a newly created General Inspection, which defines the given Task in the Tasks Addressed field.

Note: For a given TML, if two or more rows contain the same value in the Measurement Date field, only one measurement record is created. The fields in that record are populated with values in the last row among them.

After you load the data, the updates assets appear in the **Assets** and **Assets Requiring a Calculation** sections in the **Thickness Monitoring Overview** page. You must calculate all the analyses that you have loaded because they are not calculated automatically after you load the data.

Best Practices

- For Oracle databases, valid cell values are case-sensitive.
- If a data loader worksheet contains any blank cells:
 - When you create new records, the fields corresponding to the blank cells are updated with the default values, if any.
 - When you update existing records, the fields corresponding to the blank cells are not updated.
- The Data Loader maps the datasheet columns in the data loader workbook to fields in APM families by their position. Therefore, do not change the column positions and IDs. You can, however, change the captions if needed.
- ID fields must not include special characters or spaces.
- Columns (including columns representing custom fields) in the worksheets should be formatted as Text.
- You must consider the rules described in the [Workbook Layout and Use](#) section of this document while using the data loader workbook.
- When you override the values for Minimum Thickness and Minimum Thickness Type fields, the values from the data loader will be considered.
- In addition to the fields included in the data loader workbook, if you want to add values for more fields for a record, you can add columns for those fields on the appropriate worksheet.

Note: The fields that you want to add to the data loader workbook must already exist in the corresponding family. If not, you must add the fields to the family via Configuration Manager.

About the Thickness Measurement - Assets Data Loader Workbook Layout and Use

The following table provides a list of the worksheets that are included in the data loader workbook.

Worksheet	Description	Family
Assets	On the Assets worksheet, you will specify Equipment or Function Location linked to Thickness Measurement Locations (TMLs) and TML Groups. The columns that appear on this worksheet also appear on Measurements worksheet. They are used to identify the records that will be linked, directly or indirectly, to the Equipment. The combination of values in the three columns on this worksheet must be unique.	Equipment and Functional Location
Measurements	This worksheet is used to create or update Thickness Measurements for TMLs as part of completing an Inspection Task.	Thickness Measurement

Color Coding

Certain columns on the worksheets have different functions and requirements. To illustrate this, certain columns are color-coded. The following table lists the colors and what they represent.

Color	Description	Comments
Grey	Lookup Fields	Indicates columns that contain values that are used by the Thickness Measurement - Assets Data Loader to look up and create records. If these columns are removed from the worksheets, the data load will fail. While the worksheets require that these columns be present, values are not necessarily required in these columns.
Red	Fields Required for Calculation	Indicates columns that contain values that are required to perform calculations in Risk Based Inspection. Some cells only require values in certain cases. Such cases are found in parentheses in the first row of each worksheet.
Blue	Recommended Fields	Indicates columns that, according to APM Best Practice for Risk Based Inspection, should contain values.
Green	Custom Fields	Indicates columns where you can specify custom fields.

Limitations

The Thickness Measurement - Assets Data Loader has the following limitations:

- If you modify the format of the values in columns on any of the worksheets, you will not be able to import data.
- You cannot create or update nominal measurements using the data loader workbook. You can only create or update actual measurements.
- The values that you enter in the data loader workbook are case-sensitive.
- You cannot skip measurements using the data loader workbook.
- If you reimport data, the records that have been created by the data loader workbook will be updated. Therefore, while reimporting data related to a record, if you remove the data for a field in the data loader workbook, the value for the corresponding field in APM will be either a default value or blank.

Tip: If you do not want to update a field value, you can remove the corresponding column from the data loader workbooks. You cannot, however, remove columns that correspond to required fields.

- If values are provided in the Task ID and Task Related Entity ID fields but do not uniquely match a task in APM, the measurements and the corresponding event will not be created.
- If the Thickness Measurement that you want to create or update is already linked to an Inspection Event, it will not be linked to a new Inspection Event.
- The data loader workbook is not supported for Piping Assets.

Assets Worksheet

On the Assets worksheet, you will specify Equipment or Functional Locations to which you want to link Thickness Measurements. The columns that appear on this worksheet also appear in every subsequent worksheet in the data loader workbook. They are used to identify records that will be linked, directly or indirectly, to Equipment or Functional Location. The combination of values in the three columns on this worksheet must be unique.

Note: You can use the Assets worksheet to load Functional Location data by entering MI_FNCLOC00 in the Asset Family column.

Field Caption	Field ID	Data Type (Length)	Comments
Asset ID (FL:MI_FNCLOC00_FNC_ LOC_C)	MI_EQUIP000_EQUIP_ID _C	Character (255)	A value is required in at least one cell in this column. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
Asset CMMS System (FL:MI_FNCLOC00_SAP_ SYSTEM_C)	MI_EQUIP000_SAP_SYS TEM_C	Character (255)	If the Equipment record for an asset contains a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.
Equipment Technical Number	MI_EQUIP000_EQUIP_TE CH_NBR_C	Character (255)	If you are required to enter a value for the CMMS System cell for a piece of equipment, and the Equipment record contains a value in the Equipment Technical Number field, enter that value in this column. If there is no value in the CMMS System field, you can leave this column blank (even if the Equipment record contains a value for the Equipment Technical Number field).
Asset Family ID	ASSET_FAMILY_ID	Character (255)	If you want to upload Functional Location data in the Assets worksheet, enter MI_FNCLOC00 in this column. If the column is not available or data is null in this field, the asset data will be considered as Equipment data.

Measurements Worksheet

On the Measurements worksheet, you will specify the Thickness Measurements that you want to create or update. In addition, you can provide values in the Task ID and Task Related Entity ID columns if the corresponding TML has been scoped to a task to also create an inspection event corresponding to the task where the measurements will be linked.

Field Caption	Field ID	Data Type (Length)	Comments
Asset ID (FL:MI_FNCLOC00_FNC_ LOC_C)	MI_EQUIP000_EQUIP_ID _C	Character (255)	A value is required in at least one cell in this column. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
Asset CMMS System (FL:MI_FNCLOC00_SAP_ SYSTEM_C)	MI_EQUIP000_SAP_SYS TEM_C	Character (255)	If the Equipment or the Functional Location record for an asset contains a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.
Equipment Technical Number	MI_EQUIP000_EQUIP_TE CH_NBR_C	Character (255)	If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset contains a value in the Equipment Technical Number field, enter that value in this column. If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.
TML Group ID	MI_TMLGROUP_ID_C	Character (50)	A value is required if the corresponding TML is linked to a TML Group. The value that you enter must match the value of the TML Group ID related to the corresponding TML.
TML ID	MI_DP_ID_CHR	Character (50)	A value is required and must match the value of the TML ID for the corresponding TML. Otherwise, data in this row is not loaded.
Task ID	MI_TASK_ID	Character(255)	A value is required if the corresponding TML is scoped to an Inspection Task and you want to create an Inspection Event addressing that task during the creation of the Thickness Measurement.
Task Related Entity ID	MI_TASK_RELAT_ENTIT_I D_CHR	Character(255)	A value is required if the corresponding TML is scoped to an Inspection Task and you want to create an Inspection Event addressing that task during the creation of the Thickness Measurement.
Readings	MI_THICK_MEASU_REA DI_C	Character (2000)	A value is required. Enter a number greater than 0. If you have multiple readings, separate them with semicolons. If you do not enter a value in this cell, the data in this row is not loaded.
Measurement Date	MI_DP_MEAS_TAKEN_D T	Date	Enter a value in the following format: YYYY-MM-DD hh:mm:ss If you do not enter a value, the current date is used.

Field Caption	Field ID	Data Type (Length)	Comments
Measurement Taken By	MI_DP_MEAS_TAKEN_BY_CHR	Character	<p>Enter a value in the following format: <Last Name>, <First Name> ~ <User ID></p> <p>If you want to create a Thickness Measurement record using the data loader workbook, and if your user ID appears in the Measurement Taken By field on a Thickness Measurement datasheet, you need not enter a value in this cell. The appropriate value is automatically populated in the Measurement Taken By field after you load data. If not, enter a value that matches the user ID of a Security User in APM. Otherwise, the data in this row is not loaded.</p> <p>If, however, you do not want the Measurement Taken by field to be populated automatically using the data loader workbook, you update the Thickness Measurement record manually by leaving the Measurement Taken By cell blank in the data loader workbook.</p>
Measurement Comment	MI_DP_MEAS_COMMENT_CHR	Character (255)	None
Temperature	MI_THICK_MEAS_TEMP_TAKEN_AT_N	Numeric	None

TM Piping Data Loaders

About the Thickness Monitoring (TM) Piping Data Loaders

The following Piping Data Loaders are available in Thickness Monitoring:

- Thickness Monitoring (TM) Piping Equipment Data Loader
- Thickness Monitoring (TM) Piping Functional Location Data Loader

These data loaders help you manage Piping Assets.

Throughout the documentation, these Piping Data Loaders are collectively called the Thickness Monitoring (TM) Piping Data Loaders or just Piping Data Loaders. You can use them to implement Thickness Monitoring when you have thickness measurement data for piping in a legacy system. To import data using these Data Loaders, APM provides the following Excel templates:

- Thickness Monitoring (TM) Piping Equipment.xlsx
- Thickness Monitoring (TM) Piping Functional Location.xlsx

These templates support baseline Thickness Monitoring in APM. You must export measurement data from your legacy system so that the data can be used to populate the templates. The data from the templates will then be imported into APM using the corresponding Piping Data Loaders.

Note: The Excel templates are referred to throughout this documentation as the piping data loader workbooks.

The piping data loader workbooks allow you to:

- Create or update Corrosion Analysis Settings (CAS) records for a piping Asset that can be Equipment or Functional Location.
- Create or update Piping Component records, and link each of them to an Asset.
- Create or update Piping Band records, and link each of them to a Piping Component. When you create Piping Bands, the Piping Data Loader will automatically create TMLs that correspond with the number of positions in the Piping Band.
- Update TML records that are linked to a Piping Band.
- Create or update Thickness Measurement records and link them to a position.

About the Thickness Monitoring (TM) Piping Data Loaders Requirements

Before you use the data loader workbooks, you must complete the following steps:

- Ensure that the Thickness Monitoring module is deployed.
- Ensure that the following licenses are active:
 - APM Connect Plus
 - Thickness Monitoring
- Ensure that the following data is present:
 - Equipment and Functional Location Families
 - Stress Tables (APM provides Stress Tables for Piping, Pressure Vessels, and Tanks. If you want to use values from these Stress Tables with the data loader workbook, you must ensure that the records are imported into your database prior to performing the data load.)
- Ensure that you have set up appropriate relationships and key fields. To do so, you must login as a member of the MI Thickness Monitoring Administrator Security Group.
- Ensure that the Enable Pipe Rotation feature is selected in the Global Preferences section available in the Thickness Monitoring Admin Preferences
- Create a relationship between TML Groups and Assets. To do so, [configure family preferences](#).

Configure the Piping Equipment Data Loader with the following values:

- Family Preferences: Equipment
 - Asset-to-Subcomponent Relationship: Has TML Group
 - Component ID Field: Equipment ID
- Family Preferences: TML Group
 - Subcomponent-to-Asset Relationship: Has TML Group
 - Component ID Field: TML Group ID

Configure the Piping Functional Location Data Loader with the following values:

- Family Preferences: Function Location
 - Asset-to-Subcomponent Relationship: Has TML Group
 - Component ID Field: Function Location
- Family Preferences: TML Group
 - Subcomponent-to-Asset Relationship: Has TML Group
 - Component ID Field: TML Group ID


Note: By default, the relationship is created between Equipment and TML Groups. If you want to use the Thickness Monitoring (TM) Functional Location Data Loader, in the drop-down list box at the top of the workspace, select **Functional Location**.

- The Security User loading the data must be associated with either the MI Data Loader User or MI Data Loader Admin Security Role, and must also be associated with the MI Thickness Monitoring Administrator or the MI Thickness Monitoring Inspector Security Group or a Security Role that is associated with at least one of these Security Groups.

- The data loader workbooks contain sample data in each column. It is only for your reference. You must remove this data before using the data loader workbooks.

About the Thickness Monitoring (TM) Piping Data Loaders Data Model

The Thickness Monitoring (TM) Piping Data Loaders do not load the entire data model illustrated in the normal help documentation. The following data model illustrates which records the Data Loaders support. Assets (Equipment or Functional Location records) must exist prior to importing data.



About the Thickness Monitoring (TM) Piping Data Loaders General Loading Strategy

This topic describes the best practices to loading the data and the order in which the data will be loaded.

Best Practices

- For Oracle databases, valid cell values are case-sensitive.
- The import data must load in a specific sequence in order to successfully populate fields, to create records, and to link them to the predecessor and successor records.
- If a data loader worksheet contains any blank cells:

- When you create new records, the fields with blank cells are updated with the default values, if any.
 - When you update existing records, the fields with the blank cells are not updated.
 - The link between Piping Bands and TMLs is by the position number of the TML. So, when the piping data loader automatically creates TMLs for a band, it assigns the first one with position 1, the second one with position 2, and so on. Therefore, you must use these matching position numbers in TMLs, the TML Analysis Settings, and measurements in order to properly link them.
 - The Thickness Monitoring (TM) Piping Data Loaders map the datasheet columns in the piping data loader workbooks to fields in APM families by their position. Therefore, you must not change the column positions and IDs. You can, however, change the captions if needed.
 - ID fields must not include special characters or spaces.
 - Columns (including columns representing custom fields) in the worksheets should be formatted as Text.
 - You must consider the rules described in the [Workbook Layout and Use](#) section of this document while using the piping data loader workbooks.
 - Details related to an Equipment that is linked to a Piping Component, Piping Band or a TML must always be entered on the assets and Asset_CAS worksheets of the Thickness Monitoring (TM) Piping Equipment Data Loader even if the asset has already been loaded earlier. Similarly, details related to a Functional Location that is linked to a Piping Component, Piping Band, or a TML must always be entered on the Functional_Location and Functional_Location_CAS worksheets of the Thickness Monitoring (TM) Piping Functional Location Data Loader even if the Functional Location has already been loaded earlier.
 - In addition to the fields included in the piping data loader workbooks, if you want to add values for more fields for a record, you can add columns for those fields on the appropriate worksheet.
- Note:** The fields that you want to add to the piping data loader workbooks must already exist in the corresponding family. If not, you must add the fields to the family via Configuration Manager.
- Do not delete any worksheet in the piping data loader workbooks.
 - It is recommended to delete the TML_ID column from the TML worksheet when loading measurement data after performing a rotation or flip.

Load Sequence

The data must be loaded in the following sequence to successfully populate fields, create records, and link them to the predecessor and successor records:

1. The Assets or the Functional_Location worksheet is processed.

If you are using the Thickness Monitoring (TM) Piping Equipment Data Loader, it searches for the Equipment that corresponds to the Equipment ID, CMMS System, and Equipment Technical Number information that you provide on the Assets worksheet. If you are using the Thickness Monitoring (TM) Functional Location Data Loader, it searches for the Functional Location that corresponds to the Functional Location ID and CMMS System information that you provide on the Functional_Location worksheet.

If an asset specified on the worksheet does not exist, it will not be loaded. In addition, the Piping Components, Piping Bands, and TMLs linked to the asset are not loaded.
2. The Asset_CAS or the Functional_Location_CAS worksheet is processed. If you entered values in all the mandatory cells, and if the details of an asset in this worksheet match the details on the Assets or Functional_Location worksheet, then
 - If the Corrosion Analysis Settings record does not exist yet, then a record is created and linked to the asset using the Has Corrosion Analysis Settings relationship. For optional values that are left blank, the default values are used.
 - If the Corrosion Analysis Settings record already exists, then the record gets updated. For optional values that are left blank, the values from the existing record are retained.

3. The Piping_Component worksheet is processed. For each Piping Component, if the details of an asset in this worksheet match the details on the Assets or Functional_Location worksheet, then
 - If a Piping Component record does not exist, then a record is created and linked to the asset using the Has TML Group relationship. For optional values that are left blank, the default values will be populated.
 - If a Piping Component record already exists, then the existing record is updated. For optional values that are left blank, the values from the existing record are retained.
4. The Piping_Component_CAS worksheet is processed. For each Piping_Component
 - If the Corrosion Analysis Settings does not exist, then a record is created and linked to the Piping Component using the Has Corrosion Analysis Settings relationship. The values in the Corrosion Analysis Settings record are pre-populated with the corresponding values on the Asset_CAS or the Functional_Location_CAS worksheet. Any values that you enter in the Piping_Component_CAS worksheet replaces the values that were pre-populated.
 - If the Corrosion Analysis Settings record already exists, then the record is updated with the values that you provide. For optional values that are left blank, the values from the existing record are retained.
5. The Piping_Band worksheet is processed. For each Piping Band, if the columns of the asset and component match the columns in the Piping_Component worksheet, then
 - If the Piping Band record does not exist, a record is created and linked to the Piping_Component using the Has Piping Band relationship. TMLs matching the number of positions for the Piping Band are automatically created. For example, 4 TMLs are created for a Piping Band with 4 positions.
 - If a Piping Band record already exists, then the record is updated. For optional values that are left blank, the values from the existing record are retained.
6. The Piping_Band_CAS worksheet is processed. For each Piping Band CAS, if the columns of the asset and component match the columns in the Piping_Component worksheet, then
 - If the Corrosion Analysis Settings record does not exist, then a record is created and linked to the Piping Band using the Has Corrosion Analysis Settings relationship. The values in the Corrosion Analysis Settings record is pre-populated with the corresponding values in the Piping_Component_CAS worksheet. If you entered any values then those will replace the pre-populated values. Any values that you enter in the Piping_Band_CAS worksheet replaces the values that were pre-populated.
 - If the Corrosion Analysis Settings record already exists, then an Asset Corrosion Analysis record is created and linked to the Piping Component using the Has Corrosion Analyses relationship.
7. The TML worksheet is processed. Each TML has a Position field. You must number the Position for each TML in a Piping Band from 1 to the number of positions for each band. The position column is the link between the rows in the TML worksheet and the TML records that were created automatically when each band was created while processing the Piping_Band worksheet.
 - If you have entered any values in the optional fields, then those values will overwrite the default values that were populated when the TML was automatically created from the Piping_Band worksheet.
 - You may also leave the TML ID column blank to use the default TML ID or replace it with your own TML IDs that must be unique within each band. The default TML IDs are TML-1, TML-2, and so on.

Important: After a rotation or flip is performed, the TMLs change positions. Because of this, the TML ID associated with each position changes. For example, suppose TML-1 is situated at Position 1 before a rotation or flip. After the movement, a different TML will occupy Position 1.

If you want to load updated measurements after a rotation or flip, it is recommended that you delete the TML_ID column from the TML worksheet or update the TML IDs for each position in the TML worksheet before loading the updated measurements.

8. The TML_CAS worksheet is processed. For each TML

- If the Corrosion Analysis Settings record does not exist, then a record is created and linked to the TML using the Has Corrosion Analysis Settings relationship. The fields in the Corrosion Analysis Settings record are populated with the corresponding values in the Piping_Band_CAS worksheet.
 - A TML Corrosion Analysis record is created and linked to the TML using the Has Corrosion Analyses relationship.
 - If you have entered values in this worksheet, the values in the Corrosion Analysis Settings record linked to the TML are replaced with the values in the TML_CAS worksheet.
9. The Measurements worksheet is processed. For each row on this worksheet, a Thickness Measurement record is created or modified and linked to the TML using the Has Measurements relationship.

After you load the data, the updated assets appear in the **Assets** and **Assets Requiring a Calculation** sections on the **Thickness Monitoring Overview** page. You must calculate all the analyses that you have loaded because they are not calculated automatically after you load the data.

Note: The data loaders used in TM split large amount of data into the following transaction scopes:

- Asset level data
- Piping Components in 50-count batches
- Piping Bands in 50-count batches
- Thickness Measurement Locations in 100-count batches
- Measurements in 250-count batches

The guardrail for piping rotation or flip is set to 1 Asset, 100 components, and 17 bands. For assets with bands of 36 or 48 positions, this guardrail is 1 Asset, 10 components, and 17 bands. If an error occurs while loading data, you can reduce the transaction scopes as per your requirement. For information on modifying the transaction scopes, refer to the [Configure Data Loader Transaction Scopes](#) topic.

After you load the data, you can view the following information in the Interface Log datasheet:

- Number of Records Processed
- Number of Records Rejected
- Number of Records Created
- Number of Records Updated

To access the Interface Log datasheet, in the **Data Loaders** page, select a link in the **JOB ID** column.

About the Thickness Monitoring (TM) Piping Data Loaders Workbook Layout and Use

Color Coding

Certain columns on the worksheets have different functions and requirements. To illustrate this, certain columns are color-coded. The following table lists the colors and what they represent.

Color	Description	Comments
Light Grey Fields and Heading	Required Key Fields	Indicates columns that contain values that are used by the Thickness Monitoring (TM) Piping Data Loader to look up and create records. If these columns are removed from the worksheets, the data load will fail. While the worksheets require that these columns be present, check each column to determine which ones require a value.
White Fields with Pink Heading	Fields Required for Calculation	Indicates columns that contain values that are required to perform calculations in Thickness Monitoring. Some cells only require values in certain cases. Such cases are found in parentheses in the first row of each worksheet.
White Fields with Blue Heading	Recommended Fields	Indicates columns that, according to APM Best Practice for Thickness Monitoring, should contain values.

Limitations

The Thickness Monitoring (TM) Data Loaders have the following limitations:

- If you modify the format of the values in columns on any of the worksheets, you will not be able to import data.
- You cannot create or update nominal measurements using the data loader workbooks. You can only create or update actual measurements.
- The values that you enter in the data loader workbooks are case-sensitive.
- You cannot link an RBI Component to a TML Group using the data loader workbooks.
- You cannot relocate, renew, or organize TMLs using the data loader workbooks.
- You cannot skip measurements using the data loader workbooks.
- If you reimport data, the records that have been created by the Thickness Monitoring (TM) Data Loaders will be updated. Therefore, while reimporting data related to a record, if you remove the data for a field in the data loader workbooks, the value for the corresponding field in APM will be either a default value or blank.

Tip: If you do not want to update a field value, you can remove the corresponding column from the data loader workbooks. You cannot, however, remove columns that correspond to required fields.

Assets Worksheet

On the Assets worksheet, you will specify Equipment to which you want to link Piping Components. The Assets worksheet only appears on the Thickness Monitoring (TM) Piping Equipment Data Loader but not on the Thickness Monitoring (TM) Piping Functional Location Data Loader. The columns that appear on this worksheet also appear on every subsequent worksheet in the Thickness Monitoring (TM) Piping Equipment Data Loader. They are used to identify the records that will be linked, directly or indirectly, to the Equipment. The combination of values in the three columns on this worksheet must be unique.

Note: The Assets worksheet can also be used to load Functional Location data.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	If the Equipment record for an asset has a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	If you are required to enter a value for the CMMS System cell for a piece of equipment, and the Equipment record has a value in the Equipment Technical Number field, enter that value in this column. If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.
Asset Family ID	ASSET_FAMILY_ID	Character (255)	If you are uploading Functional Location data in the Assets worksheet, specify the MI_FNCLOC00 value in this column. If the column is not present or data is null in this field, APM will consider it as Equipment data.

Functional_Location Worksheet

On the Functional_Location worksheet, you will specify Functional Locations to which you want to link to Piping Components. This worksheet is included only in the Thickness Monitoring (TM) Piping Functional Location Data Loader. The columns that appear on this worksheet also appear on every subsequent worksheet in the Thickness Monitoring™ Piping Functional Location Data Loader. They are used to identify the records that will be linked, directly or indirectly, to the Functional Locations. The combination of values in the two columns on this worksheet must be unique.

Field Caption	Field ID	Data Type (Length)	Comments
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value.
CMMS System	MI_FNCLOC00_SAP_SYSTEM_C	Character (255)	If the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.

Asset_CAS Worksheet

On the Asset_CAS worksheet, you will specify Corrosion Analysis Settings records for an Equipment. If you do not enter values on this worksheet, the default values are used. This worksheet is included only in the Thickness Monitoring (TM) Piping Equipment Data Loader.

In addition, the values that you enter on this worksheet are used to specify Corrosion Analysis Settings for associated Piping Components, Piping Bands, and TMLs. You can, however, overwrite these values by specifying different values on the Piping_Component_CAS, Piping_Band_CAS and TML_CAS worksheets.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	If the Equipment record for an asset has a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.

Field Caption	Field ID	Data Type (Length)	Comments								
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>								
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	<p>If you do not enter a value in this cell, then data in this row is not loaded.</p> <p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <table border="1" data-bbox="1146 1016 1414 1377"> <thead> <tr> <th data-bbox="1146 1016 1279 1098">System Code ID</th> <th data-bbox="1279 1016 1414 1098">Inspection Type</th> </tr> </thead> <tbody> <tr> <td data-bbox="1146 1098 1279 1180">UT</td> <td data-bbox="1279 1098 1414 1180">Ultrasonic Thickness</td> </tr> <tr> <td data-bbox="1146 1180 1279 1262">RT</td> <td data-bbox="1279 1180 1414 1262">Radiographic Thickness</td> </tr> <tr> <td data-bbox="1146 1262 1279 1377">TML</td> <td data-bbox="1279 1262 1414 1377">Thickness Measurement Location</td> </tr> </tbody> </table> <p>The list in this field is populated by the CITP System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	System Code ID	Inspection Type	UT	Ultrasonic Thickness	RT	Radiographic Thickness	TML	Thickness Measurement Location
System Code ID	Inspection Type										
UT	Ultrasonic Thickness										
RT	Radiographic Thickness										
TML	Thickness Measurement Location										

Field Caption	Field ID	Data Type (Length)	Comments
Controlling Corrosion Rate	MI_CA_SET_CR_ROLL_OPT_CHR	Character (50)	This cell may only contain one of the following values: <ul style="list-style-type: none"> Average Formula Maximum The default value is Maximum.
Comments	MI_CA_SET_COM_CON_COR_RAT_CHR	Character (2500)	None
Apply CCR to TML Rem Life Next Insp Date Calc	MI_CA_SET_APPLY_CR_FLG	Boolean	Enter True or False. The default value is False.
Safety Factor	MI_CA_SET_AVG_CR_SFTY_FCTR_NBR	Numeric	The default value is 1.
Minimum Number of TMLs	MI_CA_SET_AVG_CR_MN_TML_NBR	Numeric	The default value is 1.
Percentile	MI_CA_SET_AVG_CR_PERC_NBR	Numeric	The default value is 100.
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NBR	Numeric	The default value is 2.
Remaining Life Critical Number of TMLs	MI_CA_SET_RM_LIF_CRIT_TMLS_NBR	Numeric	The default value is 1. Enter a value between 0 and 1.
Corrosion Rate Options - Least Squares	MI_CA_SET_CR_OPT_LS_FLG	Boolean	Enter True or False. The default value is False.
Corrosion Rate Options - Short Term	MI_CA_SET_CR_OPT_ST_FLG	Boolean	Enter True or False. The default value is True.
Corrosion Rate Options - Long Term	MI_CA_SET_CR_OPT_LT_FLG	Boolean	Enter True or False. The default value is True.
Corrosion Rate Options - Custom A	MI_CA_SET_CR_OPT_A_F	Boolean	Enter True or False. The default value is False.
Corrosion Rate Options - Custom B	MI_CA_SET_CR_OPT_B_F	Boolean	Enter True or False. The default value is False.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	The default value is 0.
Inspection Interval Options - Factor Remaining Life	MI_CA_SET_INSP_INT_OPT_FRL_FLG	Boolean	Enter True or False. The default value is True.
Inspection Interval Options - Inspection Interval	MI_CA_SET_INSP_INT_OPT_II_FLG	Boolean	Enter True or False. The default value is True.
Default T-Min (Inches)	MI_CA_SET_REF_TMIN_NBR	Numeric	The default value is 0.
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	The default value is 5.

Field Caption	Field ID	Data Type (Length)	Comments
Use Minimum Corrosion Rate	MI_CA_SET_USE_MN_CR_FLG	Boolean	Enter True or False. The default value is False.
Remaining Life Factor	MI_CA_SET_REM_LIFE_FCTR_NBR	Numeric	The default value is 0.5. Enter a number between 0 and 1.
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	The default value is 0.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	The default value is 0.

Functional_Location_CAS Worksheet

On the Functional_Location_CAS worksheet, you will specify Corrosion Analysis Settings records for a Functional Location. If you do not enter values on this worksheet, the default values are used. This worksheet is included only in the Thickness Monitoring (TM) Functional Location Data Loader.

In addition, the values that you enter on this worksheet are used to specify Corrosion Analysis Settings for associated Piping Components, Piping Bands, and TMLs. You can, however, overwrite these values by specifying different values in the Piping_Component_CAS, Piping_Band_CAS, and TML_CAS worksheets.

Field Caption	Field ID	Data Type (Length)	Comments
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value.
CMMS System	MI_FNCLOC00_SAP_SYSTEM_C	Character (255)	If the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.

Field Caption	Field ID	Data Type (Length)	Comments								
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	<p>If you do not enter a value in this cell, then data in this row is not loaded.</p> <p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <table border="1"> <thead> <tr> <th>System Code ID</th> <th>Inspection Type</th> </tr> </thead> <tbody> <tr> <td>UT</td> <td>Ultrasonic Thickness</td> </tr> <tr> <td>RT</td> <td>Radiographic Thickness</td> </tr> <tr> <td>TML</td> <td>Thickness Measurement Location</td> </tr> </tbody> </table> <p>The list in this field is populated by the CITP System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	System Code ID	Inspection Type	UT	Ultrasonic Thickness	RT	Radiographic Thickness	TML	Thickness Measurement Location
System Code ID	Inspection Type										
UT	Ultrasonic Thickness										
RT	Radiographic Thickness										
TML	Thickness Measurement Location										
Controlling Corrosion Rate	MI_CA_SET_CR_ROLL_OPT_CHR	Character (50)	<p>This cell may only contain one of the following values:</p> <ul style="list-style-type: none"> • Average • Formula • Maximum <p>The default value is Maximum.</p>								
Comments	MI_CA_SET_COM_CON_COR_RAT_CHR	Character (2500)	None								
Apply CCR to TML Rem Life Next Insp Date Calc	MI_CA_SET_APPLY_CR_FLG	Boolean	Enter True or False. The default value is False.								
Safety Factor	MI_CA_SET_AVG_CR_SFTY_FCTR_NBR	Numeric	The default value is 1.								
Minimum Number of TMLs	MI_CA_SET_AVG_CR_MN_TML_NBR	Numeric	The default value is 1.								
Percentile	MI_CA_SET_AVG_CR_PERC_NBR	Numeric	The default value is 100.								

Field Caption	Field ID	Data Type (Length)	Comments
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NBR	Numeric	The default value is 2.
Remaining Life Critical Number of TMLs	MI_CA_SET_RM_LIF_CRIT_TMLS_NBR	Numeric	The default value is 1.
Corrosion Rate Options - Least Squares	MI_CA_SET_CR_OPT_LS_FLG	Boolean	Enter True or False. The default value is False.
Corrosion Rate Options - Short Term	MI_CA_SET_CR_OPT_ST_FLG	Boolean	Enter True or False. The default value is True.
Corrosion Rate Options - Long Term	MI_CA_SET_CR_OPT_LT_FLG	Boolean	Enter True or False. The default value is True.
Corrosion Rate Options - Custom A	MI_CA_SET_CR_OPT_A_F	Boolean	Enter True or False. The default value is False.
Corrosion Rate Options - Custom B	MI_CA_SET_CR_OPT_B_F	Boolean	Enter True or False. The default value is False.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	The default value is 0.
Inspection Interval Options - Factor Remaining Life	MI_CA_SET_INSP_INT_OPT_FRL_FLG	Boolean	Enter True or False. The default value is True.
Inspection Interval Options - Inspection Interval	MI_CA_SET_INSP_INT_OPT_II_FLG	Boolean	Enter True or False. The default value is True.
Default T-Min (Inches)	MI_CA_SET_REF_TMIN_NBR	Numeric	The default value is 0.
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	The default value is 5.
Use Minimum Corrosion Rate	MI_CA_SET_USE_MN_CR_FLG	Boolean	Enter True or False. The default value is False.
Remaining Life Factor	MI_CA_SET_REM_LIFE_FCTR_NBR	Numeric	The default value is 0.5. Enter a number between 0 and 1.
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	The default value is 0.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	The default value is 0.

Piping_Component Worksheet

On the Piping_Component worksheet, you will specify the Piping_Components (which are or will be represented by TML Group family records) that you want to create or update.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader.</p> <p>To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.</p>
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.</p>
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>

Field Caption	Field ID	Data Type (Length)	Comments
Component ID	MI_TMLGROUP_COMP_ID_C	Character (255)	A value is required and must be unique among all the Piping Components linked to an Asset. Note: Although the Component ID field is disabled and populated automatically in APM, you can override the value using the data loader workbook.
Component Type	MI_TMLGROUP_COMP_TYPE_C	Character (255)	This column can contain any of the following values: <ul style="list-style-type: none"> • STRAIGHT SPOOL • BENT ELBOW • MITERED ELBOW
Description	MI_TMLGROUP_DESCR_C	Character (255)	None
Corrosion Group	MI_TMLGROUP_CORRO_GROU P_C	Character (255)	None
Comments	MI_TMLGROUP_COMME_T	Character (2500)	None

Piping_Component_CAS

On the Piping_Component_CAS worksheet, you will specify Corrosion Analysis Settings records for a Piping_Component. If you do not enter values in this worksheet, the values on the Asset_CAS or Functional_Location_CAS worksheet for the associated asset are used. Otherwise, the values that you enter on the Piping_Component_CAS are used for the TML Group.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.

Field Caption	Field ID	Data Type (Length)	Comments
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>
Component ID	MI_TMLGROUP_COMP_ID_C	Character (255)	A value is required and must match one of the value in the corresponding cell on the Piping_Component worksheet.
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	If you do not enter a value in this cell, then data in this row is not loaded. This cell may only contain a value that you entered in the Inspection Type cell for the associated asset on the Asset_CAS or Functional_Location_CAS worksheet.
Controlling Corrosion Rate	MI_CA_SET_CR_ROLL_OPT_CHR	Character (50)	<p>This cell may only contain one of the following values:</p> <ul style="list-style-type: none"> • Average • Formula • Maximum
Comments	MI_CA_SET_COM_CON_COR_R AT_CHR	Character (2000)	None

Field Caption	Field ID	Data Type (Length)	Comments
Apply CCR to TML Rem Life Next Insp Date Calc	MI_CA_SET_APPLY_CR_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Safety Factor	MI_CA_SET_AVG_CR_SFTY_FCT R_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Minimum Number of TMLs	MI_CA_SET_AVG_CR_MN_TML_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Percentile	MI_CA_SET_AVG_CR_PERC_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Remaining Life Critical Number of TMLs	MI_CA_SET_RM_LIF_CRIT_TMLS_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Options - Least Squares	MI_CA_SET_CR_OPT_LS_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Corrosion Rate Options - Short Term	MI_CA_SET_CR_OPT_ST_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Options - Long Term	MI_CA_SET_CR_OPT_LT_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Options - Custom A	MI_CA_SET_CR_OPT_A_F	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Options - Custom B	MI_CA_SET_CR_OPT_B_F	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Inspection Interval Options - Factor Remaining Life	MI_CA_SET_INSP_INT_OPT_FRL_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Inspection Interval Options - Inspection Interval	MI_CA_SET_INSP_INT_OPT_IL_F LG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Default T-Min (Inches)	MI_CA_SET_REF_TMIN_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Use Minimum Corrosion Rate	MI_CA_SET_USE_MN_CR_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Remaining Life Factor	MI_CA_SET_REM_LIFE_FCTR_N BR	Numeric	Enter a number between 0 and 1. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS work sheet is used.

Piping_Band Worksheet

On the Piping_Band worksheet, you will specify the Piping Bands (which are or will be represented by TML Group family records) that you want to create or update.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Piping Equipment Data Loader. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Piping Functional Location Data Loader.
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Piping Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be left blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>
Component ID	MI_TMLGROUP_COMP_ID_C	Character (255)	A value is required and must match one of the value in the corresponding cell on the Piping_Component worksheet.
Piping Band ID	MI_TMLGROUP_BAND_ID_C	Character (255)	A value is required and must be unique among all the Piping Bands linked to a Piping Component.
Number of Band Positions	MI_TMLGROUP_NUM_POS_N	Numeric	A value is required and can have values of 4, 12, or 24
Band Type	MI_TMLGROUP_BAND_TYPE_C	Character (255)	<p>This column can contain any of the following values:</p> <ul style="list-style-type: none"> • MIRRORED • CENTER • EXTRADOS • ODD <p>This column can also be blank.</p>
Mirrored Band	MIRRORED_BAND	Character (255)	<p>Only valid if the Band Type is MIRRORED. This field can contain the Band ID of the band that is the mirror of this band.</p> <p>Note: This is not an actual family field. It is used to relate two mirrored bands using the Has Mirrored Band relationship family.</p>

Field Caption	Field ID	Data Type (Length)	Comments
Distance From Inlet	MI_TMLGROUP_DIST_INLET_C	Numeric	Contains a value that denotes the distance (in feet) from the inlet side of the pipe to the position of the Piping Band.
Corrosion Group	MI_TMLGROUP_CORRO_GROU P_C	Character (255)	
Description	MI_TMLGROUP_DESCR_C	Character (255)	
Comments	MI_TMLGROUP_COMMENT	Character (2000)	

Piping_Band_CAS

On the Piping_Component_CAS worksheet, you will specify the Corrosion Analysis Settings records for a Piping_Component. If you do not enter values in this worksheet, the values in the Asset_CAS or Functional_Location_CAS worksheet for the associated asset are used. Otherwise, the values that you enter in the Piping_Component_CAS are used for the TML Group.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column. To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column. If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.
Component ID	MI_TMLGROUP_COMP_ID_C	Character (255)	A value is required and must match one of the value in the corresponding cell on the Piping_Component worksheet.
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	If you do not enter a value in this cell, then data in this row is not loaded. This cell can only contain a value that you entered in the Inspection Type cell for the associated asset in the Asset_CAS or Functional_Location_CAS worksheet.
Piping Band ID	MI_TMLGROUP_BAND_ID_C	Character (255)	A value is required and must match one of the value in the corresponding cell on the Piping_Band worksheet.
Controlling Corrosion Rate	MI_CA_SET_CR_ROLL_OPT_CHR	Character (50)	This cell may only contain one of the following values: <ul style="list-style-type: none"> • Average • Formula • Maximum
Comments	MI_CA_SET_COM_CON_COR_R AT_CHR	Character (2000)	

Field Caption	Field ID	Data Type (Length)	Comments
Apply CCR to TML Rem Life Next Insp Date Calc	MI_CA_SET_APPLY_CR_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell in the Asset_CAS or the Functional_Location_CAS worksheet is used.
Safety Factor	MI_CA_SET_AVG_CR_SFTY_FCT R_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell in the Asset_CAS or the Functional_Location_CAS worksheet is used.
Minimum Number of TMLs	MI_CA_SET_AVG_CR_MN_TML_ NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Percentile	MI_CA_SET_AVG_CR_PERC_NB R	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NB R	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Remaining Life Critical Number of TMLs	MI_CA_SET_RM_LIF_CRIT_TMLS _NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Corrosion Rate Options - Least Squares	MI_CA_SET_CR_OPT_LS_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Corrosion Rate Options - Short Term	MI_CA_SET_CR_OPT_ST_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Corrosion Rate Options - Long Term	MI_CA_SET_CR_OPT_LT_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Corrosion Rate Options - Custom A	MI_CA_SET_CR_OPT_A_F	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Corrosion Rate Options - Custom B	MI_CA_SET_CR_OPT_B_F	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Inspection Interval Options - Factor Remaining Life	MI_CA_SET_INSP_INT_OPT_FRL_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Inspection Interval Options - Inspection Interval	MI_CA_SET_INSP_INT_OPT_IL_F LG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Default T-Min (Inches)	MI_CA_SET_REF_TMIN_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Use Minimum Corrosion Rate	MI_CA_SET_USE_MN_CR_FLG	Boolean	Enter True or False. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Remaining Life Factor	MI_CA_SET_REM_LIFE_FCTR_N BR	Numeric	Enter a number between 0 and 1. If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	If you do not enter a value in this cell, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.

TML Worksheet

On the TML worksheet, you will specify the TMLs (that are or will be represented by Thickness Measurement Location records) that you want to modify. For some of the cells, if you do not enter a value on this worksheet, after you load data, the corresponding fields are populated automatically in APM.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader.</p> <p>To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.</p>
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.</p>
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>

Field Caption	Field ID	Data Type (Length)	Comments
Component ID	MI_TMLGROUP_COMP_ID_C	Character (255)	A value is required and must match one of the value in the corresponding cell on the Piping_Component worksheet.
Piping Band ID	MI_TMLGROUP_BAND_ID_C	Character (255)	A value is required and must match one of the value in the corresponding cell on the Piping_Band worksheet.
Position	MI_TMLGROUP_POSITION_N	Numeric	A value is required, and must be unique among all the TMLs linked to a Piping Band. The numbers start from 1 to the number of positions per band.
TML Analysis Type	MI_TML_TYPE_CHR	Character (50)	A value is required. This cell may only contain one of the values that you entered in the Inspection Type cell in the Asset_CAS, Functional_Location_CAS, or TML_Group_CAS worksheet, whichever is linked to the TML.
Component Type	MI_TML_COMP_TYPE_CHR	Character (10)	In the baseline APM system, this cell may only contain one of the following System Code IDs: <ul style="list-style-type: none"> • Piping • Pressure Vessel • Tank
Location	MI_DP_LOCTN_CHR	Character (50)	None
ISO Drawing Number	MI_DP_ISO_DRAW_CHR	Character (50)	None

Field Caption	Field ID	Data Type (Length)	Comments
Access	MI_DP_ACCESS_CHR	Character (50)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <ul style="list-style-type: none"> • LADDER • MANLIFT • SCAFFOLD <p>The list in this field is populated by the DPAC System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>
Inspection Sequence Number	MI_DP_INSP_SEQ_NBR	Numeric	None
Insulated Flag	MI_TML_INSLTED_FLG	Boolean	Enter True or False. The default value is False.
TML Comment	MI_DP_COMMNT_CHR	Character (255)	None
Minimum Thickness	MI_TML_MIN_THICK_NBR	Numeric	If you do not enter a value in this cell, the value in the Default T-Min (Inches) cell on the TML_CAS worksheet is used.
Additional Thickness	MI_THICK_MEASU_LOCAT_ADDIT_THI	Numeric	None
Excluded From Analysis	MI_DP_EXCL_FROM_ANALYSIS_FLG	Logical	Enter True or False. The default value is False.
Number of Readings	MI_TML_READ_NUM_N	Numeric	Enter a number between 1 and 26. The default value is 1.

Field Caption	Field ID	Data Type (Length)	Comments								
Design Code	MI_TML_DSGN_CODE_CHR	Character (50)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs based on the value in the Component Type cell:</p> <table border="1"> <thead> <tr> <th>Component Type</th> <th>Design Code</th> </tr> </thead> <tbody> <tr> <td>Piping</td> <td>B31.1 B31.3</td> </tr> <tr> <td>Pressure Vessel</td> <td>ASME VIII DIV 1</td> </tr> <tr> <td>Tank</td> <td>API 653</td> </tr> </tbody> </table> <p>The list in this field is populated by the DSCD System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	Component Type	Design Code	Piping	B31.1 B31.3	Pressure Vessel	ASME VIII DIV 1	Tank	API 653
Component Type	Design Code										
Piping	B31.1 B31.3										
Pressure Vessel	ASME VIII DIV 1										
Tank	API 653										
Code Year (T-Min Formula)	MI_TML_CODE_YEAR_C	Character (4)	<p>A value is required if the value in the Design Code cell is not N/A. This cell may only contains one of the following values:</p> <ul style="list-style-type: none"> N/A 1995 								

Field Caption	Field ID	Data Type (Length)	Comments										
Code Year (Allowable Stress Lookup)	MI_TML_CODE_YEAR_STRESS_C	Character (4)	<p>A value is required if the value in the Design Code cell is not N/A. The following table provides the valid values that you can enter in this cell based on the value in the Design Code cell.</p> <table border="1"> <thead> <tr> <th>Design Code</th> <th>Code Year (Allowable Stress Lookup)</th> </tr> </thead> <tbody> <tr> <td>API 653</td> <td>2008</td> </tr> <tr> <td>ASME VIII DIV 1</td> <td>1998 2010</td> </tr> <tr> <td>B31.1</td> <td>2014</td> </tr> <tr> <td>B31.3</td> <td>2014</td> </tr> </tbody> </table>	Design Code	Code Year (Allowable Stress Lookup)	API 653	2008	ASME VIII DIV 1	1998 2010	B31.1	2014	B31.3	2014
Design Code	Code Year (Allowable Stress Lookup)												
API 653	2008												
ASME VIII DIV 1	1998 2010												
B31.1	2014												
B31.3	2014												
Material Specification	MI_TML_MAT_SPEC_CHR	Character	<p>A value is required if the value in the Override Allowable Stress cell is False, and if you want APM to calculate T-min values. Refer to the (Picklist) worksheet in the data loader workbook for valid values that you can enter in this cell based on the values in the Design Code and Code Year (Allowable Stress Lookup) cells.</p>										
Material Grade	MI_TML_MAT_GRADE_CHR	Character (50)	<p>A value is required if the value in the Override Allowable Stress cell is False, and if you want APM to calculate T-min values. Refer to the (Picklist) worksheet in the data loader workbook for valid values that you can enter in this cell based on the values in the Design Code, Code Year (Allowable Stress Lookup), and Material Specification cells.</p>										
Material Type	MI_TML_MATER_TYPE_CHR	Character	None										
Design Pressure	MI_TML_DSGN_PRESS_NBR	Numeric	A value is required if you want APM to calculate T-min values.										

Field Caption	Field ID	Data Type (Length)	Comments
Design Temperature	MI_TML_DSGN_TEMP_NBR	Numeric	A value is required if you want APM to calculate T-min values.
Nominal Thickness	MI_TML_NOM_THICK_NBR	Numeric	None
Override Allowable Stress	MI_TML_OVRD_ALLOW_STRESS_F	Boolean	Enter True or False.
Allowable Stress	MI_TML_ALLOWABLE_STRESS_N	Numeric	A value is required if the value in the Override Allowable Stress cell is True, and you want APM to calculate T-min values.
Outside Diameter	MI_TML_OUTSD_DIAM_NBR	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Vessel Type cell is CON_HEAD (Conical Head), ELLIP_HEAD (Ellipsoidal Head), PIPENOZZ (Pipe nozzle), TORCC_HEAD (Toriconical Head), or TORCK_HEAD (Toriconical Head, Knuckle Portion). The value in the PV Formula cell is Outside. You want APM to calculate T-min values.
Inside Diameter	MI_TML_INSD_DIAM_NBR	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Vessel Type cell is CON_HEAD (Conical Head), ELLIP_HEAD (Ellipsoidal Head), TORCC_HEAD (Toriconical Head), or TORCK_HEAD (Toriconical Head, Knuckle Portion). The value in the PV Formula cell is Inside. You want APM to calculate T-min values.

Field Caption	Field ID	Data Type (Length)	Comments
Joint Factor	MI_TML_JOINT_EFF_NBR	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is RIVSHELL (Rivited Shell) or WELDSHELL (Welded Shell). You want APM to calculate T-min values. <p>The default value is 1.</p>
Corrosion Allowance	MI_TML_CORR_ALLOW_NBR	Numeric	None
Piping Nominal Diameter - NPS	MI_TML_NOM_DIAM_NBR	Numeric	<p>Refer to the (Picklist) worksheet in the data loader workbook for a list of values that you can enter in this cell.</p> <p>The values in the Piping Nominal Diameter - NPS and Piping Nominal Diameter - DN cells are mapped using the Piping Properties reference table. Therefore, if you enter a value in one of these cells, the other field is populated with the mapped value after you load data.</p> <p>If you enter a value that is not mapped to the value in the Piping Nominal Diameter - DN cell, then the value in this cell is ignored, and the corresponding field is populated with the value mapped to the value in the Piping Nominal Diameter - DN cell. For example, if the value in the Piping Nominal Diameter - DN cell is 6, then the value in this cell must be 0.125. If you enter a different value in this cell or leave it blank, then the value 0.125 is used to populate the corresponding field in APM.</p>

Field Caption	Field ID	Data Type (Length)	Comments
Piping Nominal Diameter - DN	MI_TML_PIPING_NOM_DIAM_D N_N	Numeric	<p>Refer to the (Picklist) worksheet in the data loader workbook for a list of values that you can enter in this cell.</p> <p>The values in the Piping Nominal Diameter - NPS and Piping Nominal Diameter - DN cells are mapped using the Piping Properties reference table. Therefore, if you enter a value in one of these cells, the other field is populated with the mapped value after you load data.</p>
Schedule	MI_TML_SCHED_CHR	Character (50)	<p>A value is required if you have entered a value in the Piping Nominal Diameter - NPS cell. Refer to the (Picklist) worksheet in the data loader workbook for a list of values that you can enter in this cell based on the value in the Piping Nominal Diameter - NPS cell.</p>

Field Caption	Field ID	Data Type (Length)	Comments								
Piping Formula	MI_TML_PIPING_FORMULA_C	Character (4)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs based on the values in the Design Code cell:</p> <table border="1"> <thead> <tr> <th>Design Code</th> <th>Piping Formula</th> </tr> </thead> <tbody> <tr> <td>No value</td> <td>A B C D</td> </tr> <tr> <td>B31.3</td> <td>A B C D</td> </tr> <tr> <td>Any value other than B31.3</td> <td>N/A</td> </tr> </tbody> </table> <p>The list in this field is populated by the PIPFMU System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	Design Code	Piping Formula	No value	A B C D	B31.3	A B C D	Any value other than B31.3	N/A
Design Code	Piping Formula										
No value	A B C D										
B31.3	A B C D										
Any value other than B31.3	N/A										
Mechanical Allowance	MI_TML_MECH_ALLOWANCE_N	Numeric	The default value is 0.								
Design Factor	MI_TML_DESIGN_FACTOR_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Component Type cell is Piping. The value in the Design Code cell is B31.8. You want APM to calculate T-min values. <p>The default value is 1.</p>								

Field Caption	Field ID	Data Type (Length)	Comments												
Temperature Factor	MI_TML_TEMP_FACTOR_N	Numeric	A value is required if the value in the Component Type cell is Piping, and if you want APM to calculate T-min values. The default value is 1.												
Tank Type	MI_TML_TANK_TYPE_C	Character (50)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <table border="1"> <thead> <tr> <th>System Code ID</th> <th>Tank Type</th> </tr> </thead> <tbody> <tr> <td>ANNRING</td> <td>Annular Ring</td> </tr> <tr> <td>FLRPLATE</td> <td>Floor Plate</td> </tr> <tr> <td>RIVSHELL</td> <td>Rivited Shell</td> </tr> <tr> <td>ROOFPLATE</td> <td>Roof Plate</td> </tr> <tr> <td>WELDSHELL</td> <td>Welded Shell</td> </tr> </tbody> </table> <p>The list in this field is populated by the TNKT System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	System Code ID	Tank Type	ANNRING	Annular Ring	FLRPLATE	Floor Plate	RIVSHELL	Rivited Shell	ROOFPLATE	Roof Plate	WELDSHELL	Welded Shell
System Code ID	Tank Type														
ANNRING	Annular Ring														
FLRPLATE	Floor Plate														
RIVSHELL	Rivited Shell														
ROOFPLATE	Roof Plate														
WELDSHELL	Welded Shell														
Shell Type	MI_TML_SHELL_TYPE_C	Character (50)	None												
API Method	MI_TML_API_METHOD_C	Character (50)	None												
Plate Thickness	MI_TML_PLATE_THICKNESS_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is ANNRING (Annular Ring). You want APM to calculate T-min values. 												

Field Caption	Field ID	Data Type (Length)	Comments
Minimum Yield Strength	MI_TML_MIN_YIELD_STR_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is WELDSHELL (Welded Shell). You want APM to calculate T-min values.
Minimum Tensile Strength	MI_TML_MIN_TENSILE_STR_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is WELDSHELL (Welded Shell). You want APM to calculate T-min values.
Course Height	MI_TML_COURSE_HEIGHT_N	Numeric	None
Course Number	MI_TML_COURSE_NUMBER_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is WELDSHELL (Welded Shell). You want APM to calculate T-min values.
Fill Height	MI_TML_FILL_HEIGHT_N	Numeric	None
Specific Gravity	MI_TML_SPECIFIC_GRAVITY_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Design Code cell is API 653. The value in the Tank Type cell is ANNRING (Annular Ring), RIVSHELL (Riveted Shell), or WELDSHELL (Welded Shell). You want APM to calculate T-min values.

Field Caption	Field ID	Data Type (Length)	Comments
Floor Plate has Detection?	MI_TML_FLR_PLATE_DETECTIO N_L	Boolean	Enter True or False. The default value is False.
Floor Plate has Reinforced Lining?	MI_TML_FLR_PLATE_REINFORC ED_LINING_L	Boolean	Enter True or False. The default value is False.
Maximum Operating Fill Height	MI_TML_MAX_OP_FILL_HEIGH T_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> • The value in the Design Code cell is API 653. • The value in the Tank Type cell is ANNRING (Annular Ring), RIVSHELL (Rivited Shell), or WELDSHELL (Welded Shell). • You want APM to calculate T-min values.
Distance From the Bottom	MI_TML_DIST_FROM_BOTT_NB R	Numeric	None
Tank Diameter	MI_TML_TANK_DIAMETER_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> • The value in the Design Code cell is API 653. • The value in the Tank Type cell is ANNRING (Annular Ring), RIVSHELL (Rivited Shell), or WELDSHELL (Welded Shell). • You want APM to calculate T-min values.

Field Caption	Field ID	Data Type (Length)	Comments																				
Vessel Type	MI_TML_VESSEL_TYPE_C	Character (50)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <table border="1"> <thead> <tr> <th>System Code ID</th> <th>Tank Type</th> </tr> </thead> <tbody> <tr> <td>CON_HEAD</td> <td>Conical Head</td> </tr> <tr> <td>CYL_SHELL</td> <td>Cylindrical Shell</td> </tr> <tr> <td>ELLIP_HEAD</td> <td>Ellipsoidal Head</td> </tr> <tr> <td>HEM_HEAD</td> <td>Hemispherical Head</td> </tr> <tr> <td>PIPENOZZ</td> <td>Pipe Nozzle</td> </tr> <tr> <td>SPH_SHELL</td> <td>Spherical Shell</td> </tr> <tr> <td>TORCC_HEAD</td> <td>Toriconical Head</td> </tr> <tr> <td>TORCK_HEAD</td> <td>Toriconical Head, Knuckle Portion</td> </tr> <tr> <td>TORSP_HEAD</td> <td>Torispherical Head</td> </tr> </tbody> </table> <p>The list in this field is populated by the VSTP System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>	System Code ID	Tank Type	CON_HEAD	Conical Head	CYL_SHELL	Cylindrical Shell	ELLIP_HEAD	Ellipsoidal Head	HEM_HEAD	Hemispherical Head	PIPENOZZ	Pipe Nozzle	SPH_SHELL	Spherical Shell	TORCC_HEAD	Toriconical Head	TORCK_HEAD	Toriconical Head, Knuckle Portion	TORSP_HEAD	Torispherical Head
System Code ID	Tank Type																						
CON_HEAD	Conical Head																						
CYL_SHELL	Cylindrical Shell																						
ELLIP_HEAD	Ellipsoidal Head																						
HEM_HEAD	Hemispherical Head																						
PIPENOZZ	Pipe Nozzle																						
SPH_SHELL	Spherical Shell																						
TORCC_HEAD	Toriconical Head																						
TORCK_HEAD	Toriconical Head, Knuckle Portion																						
TORSP_HEAD	Torispherical Head																						

Field Caption	Field ID	Data Type (Length)	Comments
PV Formula	MI_TML_PV_FORMULA_C	Character (10)	<p>In the baseline APM system, this cell may only contain one of the following System Code IDs:</p> <ul style="list-style-type: none"> • Inside • Outside <p>The list in this field is populated by the PVFMU System Code Table. If the system code table has been customized, the valid values could be different. To verify which options are acceptable in your APM system, via Configuration Manager, refer to the appropriate table.</p>
Dish Radius	MI_TML_DISH_RADIUS_N	Numeric	<p>A value is required if:</p> <ul style="list-style-type: none"> • The value in the Vessel Type cell is TORSP_HEAD (Torispherical Head). <p>-and-</p> <ul style="list-style-type: none"> • You want APM to calculate T-min values.
Knuckle Radius	MI_TML_KNUCKLE_RADIUS_N	Numeric	<p>A value is required if:</p> <ul style="list-style-type: none"> • The value in the Vessel Type cell is TORCK_HEAD (Toriconical Head, Knuckle Portion) or TORSP_HEAD (Torispherical Head). <p>-and-</p> <ul style="list-style-type: none"> • You want APM to calculate T-min values.
apex_angle	MI_TML_APEX_ANGLE_N	Numeric	<p>A value is required if:</p> <ul style="list-style-type: none"> • The value in the Vessel Type cell is CON_HEAD (Conical Head), TORCC_HEAD Toriconical Head), or TORCK_HEAD (Toriconical Head, Knuckle Portion). <p>-and-</p> <ul style="list-style-type: none"> • You want APM to calculate T-min values.

Field Caption	Field ID	Data Type (Length)	Comments
Inside Radius	MI_TML_INSIDE_RADIUS_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Vessel Type cell is CYL_SHELL (Cylindrical Shell), HEM_HEAD Hemispherical Head, or SPH_SHELL (Spherical Shell). The value in the PV Formula cell is Inside. You want APM to calculate T-min values.
Outside Radius	MI_TML_OUTSIDE_RADIUS_N	Numeric	<p>A value is required if all of the following conditions are satisfied:</p> <ul style="list-style-type: none"> The value in the Vessel Type cell is CYL_SHELL (Cylindrical Shell), HEM_HEAD Hemispherical Head, or SPH_SHELL (Spherical Shell). The value in the PV Formula cell is Outside. You want APM to calculate T-min values.
Head Diameter	MI_TML_HEAD_DIAMETER_N	Numeric	None

TML_CAS Worksheet

On the TML_CAS worksheet, you will specify Corrosion Analysis Settings records for a TML. If you do not enter values in this worksheet, then the values on the Piping_Band_CAS worksheet for the associated Piping Band are used. Otherwise, the values in the TML_CAS worksheet are used.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader.</p> <p>To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.</p>
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.</p>
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>

Field Caption	Field ID	Data Type (Length)	Comments
Inspection Type	MI_CA_SET_ANALY_TYPE_CHR	Character (50)	If you do not enter a value in this cell, then data in this row is not loaded. If the TML is linked to a TML Group, then this cell may only contain a value that you have entered in the Inspection Type cell for the associated TML Group in the TML_Group_CAS worksheet. Otherwise, this cell may only contain a value that you have entered in the Inspection Type cell for the associated asset on the Asset_CAS worksheet.
Component ID	MI_TMLGROUP_COMP_ID_C	Character (50)	A value is required and must match one of the values in the corresponding cell in the Piping_Component worksheet.
Band ID	MI_TMLGROUP_BAND_ID_C	Character (50)	A value is required and must match one of the values in the corresponding cell in the Piping_Band worksheet.
Position	MI_TMLGROUP_POSITION_N	Numeric	A value is required and must match one of the values in the corresponding cell in the TML worksheet.
Std Deviation Factor	MI_CA_SET_STD_DEV_FCTR_NB R	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Default Inspection Interval (Months)	MI_CA_SET_INSP_INTRVL_NBR	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.

Field Caption	Field ID	Data Type (Length)	Comments
Minimum Corrosion Rate (Mils/year)	MI_CA_SET_MN_CR_NBR	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Allowable Measurement Variance (inches)	MI_CA_SET_ALLOW_VARIA_NBR	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.
Corrosion Rate Variance	MI_CA_SET_CRV_N	Numeric	If you do not enter a value in this cell, and if the TML is linked to a TML Group, then the value in the corresponding cell on the TML_Group_CAS worksheet is used. Otherwise, the value in the corresponding cell on the Asset_CAS or the Functional_Location_CAS worksheet is used.

Measurements Worksheet

On the Measurements worksheet, you will specify the TMs (that are or will be represented by Thickness Measurement records) that you want to create or update.

Field Caption	Field ID	Data Type (Length)	Comments
Equipment ID	MI_EQUIP000_EQUIP_ID_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Equipment Data Loader.</p> <p>To upload Functional Location data in the same worksheet, specify the Functional Location ID in this column.</p>
Functional Location ID	MI_FNCLOC00_FNC_LOC_C	Character (255)	<p>This column requires at least one cell to have a value. This column appears only in the Thickness Monitoring (TM) Functional Location Data Loader.</p>
CMMS System	MI_EQUIP000_SAP_SYSTEM_C	Character (255)	<p>If the Equipment or the Functional Location record for an asset has a value in the CMMS System field, enter that value in this column.</p> <p>To upload Functional Location data in the same worksheet, specify the CMMS System for the Functional Location value in this column.</p>
Equipment Technical Number	MI_EQUIP000_EQUIP_TECH_N BR_C	Character (255)	<p>This column appears only in the Thickness Monitoring (TM) Equipment Data Loader. If you are required to enter a value for the CMMS System cell for an asset, and the Equipment record for the asset has a value in the Equipment Technical Number field, enter that value in this column.</p> <p>If there is no value in the CMMS System field, this column can be blank, even if the Equipment record contains a value for the Equipment Technical Number field.</p>
Component ID	MI_TMLGROUP_COMP_ID_C	Character (255)	<p>A value is required and must match one of the values in the corresponding cell in the Piping_Component worksheet.</p>

Field Caption	Field ID	Data Type (Length)	Comments
Piping Band ID	MI_TMLGROUP_BAND_ID_C	Character (255)	A value is required and must match one of the values in the corresponding cell in the Piping_Band worksheet.
Position	MI_TMLGROUP_POSITION_N	Numeric	A value is required and must match one of the values in the corresponding cell in the TML worksheet.
Readings	MI_THICK_MEASU_READI_C	Character (2000)	A value is required. Enter a number greater than 0. If you have multiple readings, separate them with semicolons. If you do not enter a value in this cell, the data in this row is not loaded.
Measurement Date	MI_DP_MEAS_TAKEN_DT	Date	Enter a value in the following format: YYYY-MM-DD hh:mm:ss If you do not enter a value, the current date is used.

Field Caption	Field ID	Data Type (Length)	Comments
Measurement Taken By	MI_DP_MEAS_TAKEN_BY_CHR	Character	<p>Enter a value in the following format: <Last Name>, <First Name> ~ <User ID></p> <p>When you want to create a Thickness Monitoring record using the data loader workbook, and if your user ID appears in the Measurement Taken By field on a Thickness Measurement datasheet, then you need not enter a value in this cell. The appropriate value is automatically populated in the Measurement Taken By field after you load data. If not, enter a value that matches the user ID of a Security User in APM. Otherwise, the data in this row is not loaded.</p> <p>If, however, you do not want the Measurement Taken by field to be populated automatically, using the data loader workbook, update the Thickness Monitoring record by leaving the Measurement Taken By cell blank.</p>
Measurement Comment	MI_DP_MEAS_COMMENT_CHR	Character (255)	None
Temperature	MI_THICK_MEAS_TEMP_TAKEN_AT_N	Numeric	None

About the Thickness Monitoring (TM) Piping Data Loaders Load Verification

About This Task

After you load data, perform the following steps in APM to confirm the integrity and accuracy of the data that you have loaded:

Procedure

- Access the details of the import job. These details indicate if any errors were encountered during the data load. The log may help account for any records that are not loaded.
- In Thickness Monitoring or Record Manager, access the assets specified in the data loader workbook, and then verify that the expected TML Groups and TMLs are present or updated, and that any associated records that you expected to be created are also present in the database.
- To view a list of TML Groups created after a specific date, run the following query:

- For an SQL database:

```
SELECT [MI_TMLGROUP].[MI_TMLGROUP_ID_C] "TML Group ID",
[MI_TMLGROUP].[MI_TMLGROUP_DESCR_C]
"Description", [MI_TMLGROUP].LAST_UPDT_DT "LAST_UPDT_DT" FROM
[MI_TMLGROUP] WHERE
[MI_TMLGROUP].LAST_UPDT_DT >= CONVERT(VARCHAR(255),
(? :d :caption='Enter a Date'), 110)
```

- For an Oracle database:

```
SELECT [MI_TMLGROUP].[MI_TMLGROUP_ID_C] "TML Group ID",
[MI_TMLGROUP].[MI_TMLGROUP_DESCR_C]
"Description", [MI_TMLGROUP].LAST_UPDT_DT "LAST_UPDT_DT",
[MI_TMLGROUP].ENTY_ID "ENTY_ID"
FROM [MI_TMLGROUP] WHERE [MI_TMLGROUP].LAST_UPDT_DT >=
to_date(to_char(? :d :caption='Enter
a Date'), 'mm/dd/yyyy'), 'mm/dd/yyyy')
```

- To view a list of TMLs created after a specific date, run the following query:

- For an SQL database:

```
SELECT [MI Thickness Measurement Location].[MI_DP_ID_CHR] "TML
ID", [MI Thickness Measurement Location].
[MI_DP_ASSET_ID_CHR] "TML Asset ID", [MI Thickness Measurement
Location].LAST_UPDT_DT "LAST_UPDT_DT"
FROM [MI Thickness Measurement Location] WHERE [MI Thickness
Measurement Location].LAST_UPDT_DT >=
CONVERT(VARCHAR(255), (? :d :caption='Enter a Date'), 110)
```

- For an Oracle database:

```
SELECT [MI Thickness Measurement Location].[MI_DP_ID_CHR] "TML
ID", [MI Thickness Measurement Location].
[MI_DP_ASSET_ID_CHR] "TML Asset ID", [MI Thickness Measurement
Location].LAST_UPDT_DT "LAST_UPDT_DT",
[MI Thickness Measurement Location].ENTY_KEY "ENTY_KEY" FROM [MI
Thickness Measurement Location] WHERE
[MI Thickness Measurement Location].LAST_UPDT_DT >=
to_date(to_char(? :d :caption='Enter a Date'),
'mm/dd/yyyy'), 'mm/dd/yyyy')
```

- To view a list of Thickness Measurements created after a specific date, run the following query:

- For an SQL database:

```
SELECT [MI Thickness Measurement].[MI_THICK_MEASU_ID_CHR]
"Measurement ID", [MI Thickness Measurement].
[MI_DP_MEAS_TAKEN_BY_CHR] "Measurement Taken By", [MI Thickness
Measurement].[MI_THICK_MEAS_TML_KEY_C]
"TML Key", [MI Thickness Measurement].LAST_UPDT_DT "LAST_UPDT_DT"
FROM [MI Thickness Measurement] WHERE
[MI Thickness Measurement].LAST_UPDT_DT >= CONVERT(VARCHAR(255),
(? :d :caption='Enter a Date'), 110)
```

- For an Oracle database:

```
SELECT [MI Thickness Measurement].[MI_THICK_MEASU_ID_CHR]
"Measurement ID", [MI Thickness Measurement].
[MI_DP_MEAS_TAKEN_BY_CHR] "Measurement Taken By", [MI Thickness
Measurement].[MI_THICK_MEASU_READ_PF_C]
```

```
"Readings Pass/Fail", [MI Thickness Measurement].
[MI_THICK_MEAS_TML_KEY_C] "TML Key",
[MI Thickness Measurement].LAST_UPDT_DT "LAST_UPDT_DT", [MI
Thickness Measurement].ENTY_KEY "ENTY_KEY"
FROM [MI Thickness Measurement] WHERE [MI Thickness
Measurement].LAST_UPDT_DT >=
to_date(to_char(?? :d :caption='Enter a Date'), 'mm/dd/yyyy'),
'mm/dd/yyyy')
```

Configure Piping Data Loader Transaction Scopes

Before You Begin

You must be an administrator of the server where APM is installed.

About This Task

By default, the Piping data loaders used in TM split large amounts of data into the following transaction scopes:

- Asset level data
- Piping Components and Piping Bands in 50-count batches
- Thickness Measurement Locations in 100-count batches
- Measurements in 250-count batches

The guardrail for piping rotation or flip is set to 1 Asset, 100 components, and 17 bands.

However, based on the speed of your network connection, configuration of the APM Server, or other such factors, you may notice transaction scope errors while uploading large batches of data. To resolve this issue, you can configure the transaction scopes to reduce the number of Piping Components, Piping Bands, TMLs, and Measurements per batch.

Procedure

1. Access the server where APM is installed.
2. Navigate to the following folder:
C:\ProgramData\Meridium\
3. Access the `appsettings.Global.json` file.
4. As required, modify the following parameters:

Parameter	Description
<code>pipingBandDataLoaderBatchSize</code>	Defines the batch size of Piping Bands.
<code>pipingComponentDataLoaderBatchSize</code>	Defines the batch size of Piping Components.
<code>tmlDataLoaderBatchSize</code>	Defines the batch size of TMLs.
<code>thicknessMeasurementDataLoaderBatchSize</code>	Defines the batch size of thickness measurements.

5. Save the file.
6. Restart the following services:
 - Redis
 - IIS

The transaction scopes are updated.

Chapter 13

Admin

Topics:

- [Global Preferences](#)
- [Family Preferences](#)
- [Datalogger Mappings](#)

Global Preferences

Access TM Admin Preferences


Procedure

In the **Applications** menu, navigate to **ADMIN > Application Settings > Thickness Monitoring**. The **TM Admin Preferences** page appears.

The screenshot shows the TM Admin Preferences interface. On the left is a navigation pane with the following items: Global Preferences (selected), Family Preferences, TM Rules Lookup, and Datalogger Mappings. The main content area is titled 'Global Preferences' and contains three sections: 1. 'T-Min Calculator Preferences' with a checkbox for 'Use Interpolation for Stress Reference Tables' (unchecked) and a descriptive paragraph. 2. 'Task Preferences' with a checkbox for 'Auto Manage Tasks?' (checked) and a descriptive sentence. 3. 'Custom Corrosion Rate Options' with a sub-section 'Custom Corrosion Rate A' containing a 'Label' field with the value 'CUST STCR' and a 'Calculation Rule' field with the value 'Rules Library\Client\Corrosion_Rates\CalculateS'.

The following information appears in the page:

- **Global Preferences:** Lets you configure settings that apply throughout Thickness Monitoring. This section appears by default.
- **Family Preferences:** Lets you configure settings for the Equipment or TML Group families, or any other family that you use to store equipment or component data.
- **TM Rules Lookup:** Lets you view and modify the reference table values as needed.
- **Datalogger Mappings:** Lets you define the family field mappings for devices used to take measurements.

Tip: You can modify the Global Preferences by selecting .

Enable Interpolation

Before You Begin

Multiple records with varying temperatures and stress values may exist for a given combination of Material Specification, Material Grade, and Design Code values. So, after a match is found on Material Specification, Material Grade, and Design Code, Thickness Monitoring (TM) evaluates Design Temperature.

If the Design Temperature in the TML is an exact match to a temperature value in a Piping Stress or PV Stress record, TM will simply use the corresponding Allowable Stress value. For example, consider a TML that contains the following values:

- Material Specification = SA-216
- Material Grade = B
- Design Code = ASME B31.3
- Design Temperature = 100

Now, consider a Piping Stress record that contains the following values:

- Material Specification = SA-216
- Material Grade = B
- Design Code = ASME B31.3
- Design Temperature = 100
- Allowable Stress = 20000

In this case, the values in the TML are an exact match to the values in the Piping Stress record. Therefore, TM will use the Allowable Stress value of 20000 to calculate Maximum Allowable Working Pressure and T-Min.

Thickness Monitoring uses reference tables to look up the Allowable Stress values for performing T-Min calculations and for calculating Maximum Allowable Working Pressure. You have two choices regarding how the stress reference tables will be used to determine Allowable Stress when an exact match cannot be found:

- You can specify that the lowest temperature in the established range should be used.
- You can specify that Thickness Monitoring should use linear interpolation to determine the Allowable Stress.

By default, interpolation is disabled.


Procedure

1. Access the [TM Admin Preferences](#) page.

2. In the upper-right corner of the **Global Preferences** workspace, select .

The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **T-Min Calculator Preferences** section, select the **Use Interpolation for Stress Reference Tables** check box.

4. In the upper-right corner of the workspace, select .

The setting is saved, along with any other changes you have made to the preferences in the **Global Preferences** workspace.

Interpolation Examples

Interpolation is Enabled

If TM cannot find an exact match in the Piping Stress or PV Stress reference table, and the Application Settings specify that interpolation should be used, TM will calculate the interpolated Allowable Stress value using the temperature and stress values that make up a range that includes the TML Design Temperature.

For example, consider a Piping Stress reference table that contains the following two records.

	Record #1	Record #2
Material Specification	SA-403	SA-403
Material Grade	WP316	WP316
Design Code	ASME B31.3	ASME B31.3
Design Temperature	100	200
Allowable Stress	20000	18000

Now, consider a TML that contains the following values:

- Material Specification = SA-403
- Material Grade = WP316
- Design Code = ASME B31.3
- Design Temperature = 150

The TML Design Temperature falls within the range established by the two Piping Stress records in the table. Linear interpolation assumes that stress varies linearly as a function of temperature within the defined range. Using this assumption, the Allowable Stress at 150 degrees can be calculated using the following formula:

$$S_x = S_1 - (T_1 - T_x) / (T_1 - T_2) * (S_1 - S_2)$$

Where:

- **S_x** = Allowable Stress for the TML
- **S₁** = Allowable Stress at Lower Boundary
- **S₂** = Allowable Stress at Upper Boundary
- **T₁** = Temperature at Lower Boundary
- **T_x** = Temperature defined for TML
- **T₂** = Temperature at Upper Boundary

Given the values from our example, we calculate **S_x** as:

$$S_x = 20000 - ((100 - 150) / (100 - 200) * (20000 - 18000))$$

So:

$$S_x = 19000$$

This interpolated Allowable Stress value will then be used to populate the Allowable Stress field in the TML.

Note: For TM to determine Allowable Stress in this way, the Piping Stress and PV Stress reference tables must contain records that establish the range that includes the TML Design Temperature.

Interpolation is Disabled

If TM cannot find an exact match in the Piping Stress or PV Stress reference table, and the Application Settings specify that interpolation should not be used, TM will use an Allowable Stress value that corresponds to the lowest temperature value in the temperature range that includes the TML Design Temperature.

For example, consider a Piping Stress reference table that contains the following two records.

	Record #1	Record #2
Material Specification	SA-403	SA-403
Material Grade	WP316	WP316
Design Code	ASME B31.3	ASME B31.3
Design Temperature	100	200
Allowable Stress	20000	18000

Now, consider a TML that contains the following values:

- Material Specification = SA-403
- Material Grade = WP316
- Design Code = ASME B31.3
- Design Temperature = 150

In this case, the Design Temperature in the TML is not an exact match to a Piping Stress record. The TML Design Temperature, however, does fall within the temperature range established by the two Piping Stress records in the table. So, in this case, TM will use the record that contains the most conservative (i.e., lowest) Allowable Stress value. Therefore, in this case, an Allowable Stress value of 18,000 will be used in the TML.

Note: For TM to determine Allowable Stress in this way, the Piping Stress and PV Stress reference tables must contain records that establish the range that includes the TML Design Temperature.

Auto Manage Tasks


Before You Begin

Thickness Monitoring Tasks will be created automatically when you create Corrosion Analysis Settings for an asset or TML Group, or a record that stores equipment or component data for a Corrosion Analysis. APM provides an option that allows Thickness Monitoring Tasks to be updated automatically when you make changes to a Thickness Measurement Location (TML) record.


The Auto Manage Tasks setting is disabled by default.

Note: TM will create and update Thickness Monitoring Tasks automatically only if the Component ID setting is defined for family to which the TML is directly linked. If this setting is not defined, an error message will appear when TM attempts to create the Thickness Monitoring Task.

Procedure

1. Access the **Global Preferences** workspace.
2. In the upper-right corner of the workspace, select .

The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **Tasks Preferences** section, select the **Auto Manage Tasks?** check box.
4. In the upper-right corner of the workspace, select .

The setting is saved, along with any other changes you have made to the preferences in the **Global Preferences** workspace.

Results

When the Auto Manage Tasks setting is enabled, the following fields in Thickness Monitoring Task records will be updated when you make changes to a TML. The following list is not comprehensive.

- **Last Date:** The value in the Last Date field is populated with the most recent measurement date that is associated with the first TML referenced in the NID TMLs field in the associated Asset Corrosion Analysis record.

For example, if the NID TMLs field contained the Entity Keys of the following TMLs in the following order, the most recent measurement date (the value in the Measurement Taken Date field in the linked Thickness Measurement records) associated with TML 03 would be used to populate the Last Date field in the Thickness Monitoring Task record:

- TML 03
 - TML 14
 - TML 01
- **Desired Interval:** The value in the Desired Interval field is populated with the difference, in days, between the values in the Next Date and Last Date fields in the Thickness Monitoring Task record.

For example, if the value in the Next Date field is 9/5/2017 and the value in the Last Date field is 3/6/2015, the Desired Interval field would be populated with the value 914.


Use Minimum Measurement Interval for Corrosion Rates

Before You Begin



This option enables you to determine which Thickness Measurements are used for calculating (either Short Term or Long Term Corrosion Rates) based on a defined interval provided. Once enabled, you can define either a global minimum interval for measurements or you may also provide site-specific minimum intervals.

The Use Minimum Measurement Interval for Corrosion Rates setting is disabled by default.

Procedure

1. Access the **Global Preferences** workspace.
2. In the upper-right corner of the workspace, select .

The options in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **Custom Corrosion Rate Options** section, select the **Use Minimum Measurement Interval for Corrosion Rates** option.
The Measurement Interval grid appears with an initial row for Global (all) sites. By default, the Measurement Interval value is set to 12 Months.
 4. In the Measurement Interval column, as required, define the interval for all the sites.
 5. If settings for a specific site are needed, select .
 6. In the Measurement Interval column, as required, enter the interval values, and then select the required site(s) in the Sites list.
 7. In the upper-right corner of the workspace, select .
- The setting is saved along with any other changes you have made to the preferences in the **Global Preferences** workspace.

Results

When this setting is enabled, and the TML Corrosion Analyses are calculated, if the Short Term and Long Term options are enabled in the TML's Corrosion Analysis Settings, the minimum measurement intervals provided are used to determine the corrosion rate calculations.

For example, if the Use Minimum Measurement Interval for Corrosion Rates option is enabled and the default 12-month interval is saved for all the sites, consider the following two scenarios:

Short Term

The following measurements are captured on a TML:

- 1.24 IN – 4/15/2008
- 1.22 IN – 10/26/2015
- 1.18 IN – 2/18/2017
- 1.15 IN – 10/15/2017

When the Short Term corrosion rate is calculated for this TML, the calculation identifies the Last Measurement as the one on 10/15/2017 and the Near Measurement as the one on 2/18/2017. However, when the setting is enabled and the interval between the two measurements is not at least 12 months, the calculation moves to the next closest measurement for evaluation. The next measurement occurred is on 10/26/2015 and is valid for the measurement interval criteria. This measurement is then used as the Near Measurement when calculating the Short Term Corrosion Rate value. If the calculation needs to skip a measurement, the Short Term Based on Minimum Measurement Interval field on the TML Corrosion Analysis is set to true.

Note: The calculation continues to move back in the history of measurements looking for the valid measurement interval criteria. If valid interval is not found, the Short Term Corrosion Rate value is set to null and the Short Term Based on Minimum Measurement Interval field on the TML Corrosion Analysis is set to true.

Long Term

The following measurements are captured on a TML:

- 1.18 IN – 2/18/2017
- 1.15 IN – 10/15/2017

When the Long Term corrosion rate is calculated for this TML, the calculation identifies the Last Measurement as the one on 10/15/2017 and the Base Measurement as the one on 2/18/2017. However, when the setting is enabled and the interval between the two measurements is not at least 12 months,

the calculation determines there is no valid Long Term Corrosion Rate, and the value is set to null. Also, the Long Term Based on Minimum Measurement Interval field on the TML Corrosion Analysis is set to true.

Note: In this scenario, the Short Term corrosion rate is also set to null as the measurement interval criteria is not valid. Therefore, the Minimum Corrosion Rate as defined in the Corrosion Analysis Settings of the TML is used as the Controlling Corrosion Rate for the TML.

Next Steps

Define Custom Corrosion Rates

Before You Begin



Thickness Monitoring includes several baseline TML-level corrosion rates that you can choose to calculate for TML Corrosion Analyses. In addition to using these baseline corrosion rates, you can define custom corrosion rate calculations to use within Thickness Monitoring. Using the options on the **Global Preferences** workspace, you can define up to two custom calculations.



Before you can enable the use of custom corrosion rates, you must first create rules that define those corrosion rates. This documentation assumes that the necessary rules have already been defined.

Note: For more information on creating rules, refer to the Rules section of the documentation.

Procedure

1. Access the **Global Preferences** workspace.
2. Select .

In the **Global Preferences** workspace, the boxes and check boxes are enabled.  is replaced with .

3. In the **Custom Corrosion Rate Options** section, below the **Custom Corrosion Rate A** heading, in the **Label** box, enter the label that you want to use for this custom corrosion rate.
4. To the right of the **Calculation Rule** box, select .
The **Select a Project and Method from the Catalog** window appears.
Tip: If you know the path to the method, you can also enter it directly in the **Calculation Rule** box.
5. In the left pane of the window, navigate to and select the **Rules Library** folder containing the project in which the desired rule is defined.
The middle pane is populated with a list of projects that exist in the selected folder.
6. In the middle pane, select the project that contains the method that you want to use for the corrosion rate rule.
The right pane is populated with a list of valid methods.
7. In the right pane, select the method.
8. Select **Done**.
The **Select a Project and Method from the Catalog** window closes.
9. If you want to define a second custom corrosion rate, repeat steps 3 to 8 under the **Custom Corrosion Rate B** heading.
10. In the upper-right corner of the workspace, select .
The custom corrosion rate settings are saved along with any other changes to the settings on the **Global Preferences** workspace.

Define Readings Preferences

Procedure

1. Access the **Global Preferences** workspace.


2. Select .

The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **Readings Preferences** section, in the **Reading Tolerance** box, enter the value that defines the range within which readings must fall in order to pass evaluation.
4. In the **Readings Calculation Method** box, select the value that indicates how you want Thickness Measurement values to be calculated based on the values in the Readings field. You can choose Average, Minimum, Maximum, or Custom.

Note: For more information on how the Readings Tolerance value is used in calculation, refer to the [Reading Tolerance](#) on page 314 topic.

If you select Custom, perform the following steps:

- a) Next to the **Custom Rule for Readings Calculation** box, select .
- The **Select a Project and Method from the Catalog** window appears.
- b) In the pane containing the project folders, navigate to and select the **Rules Library** folder that contains the project that you want to use for the reading calculation rule.
A list of projects that exist in the selected folder appears.
- c) In the pane containing the projects, select the project that contains the method that you want to use for the readings calculation rule.
A list of valid methods within the project appears.
- d) Select the method.
- e) Select **Done**.
The **Select a Project and Method from the Catalog** window closes.

5. Select .

The settings in the **Global Preferences** workspace are updated.

Configure Nominal T-Min Lookup

Before You Begin

Nominal T-Min is a value that represents the minimum thickness of a pipe based upon accepted industry standards. The Nominal T-Min value takes into account various design specifications and determines the minimum thickness associated with that criteria. The Nominal T-Min value is retrieved using values from Thickness Measurement Location records and records in the Piping Nominal T-Min reference table. Using the **Nominal T-Min Preferences** section, you can configure which fields you want to use for retrieving the Nominal T-Min value for Thickness Measurement Location records that are linked to Equipment or TML Group records that represent pipes, or records that store equipment or component data for pipes.


In the **Nominal T-Min Preferences** section, under the **Fields for Nominal T-Min Lookup** heading is a list of all these fields that exist in the Piping Nominal T-Min family.

Each field in the Piping Nominal T-Min family corresponds to a field in the Thickness Measurement Location family. By selecting a field in the **Fields for Nominal T-Min Lookup** list, you are indicating that you want to use that field for looking up Nominal T-Min values. This means that values in the associated fields in Thickness Measurement Location records will be compared to values in the Piping Nominal T-Min


reference table and that a Nominal T-Min value will be returned only if a match is found. Any field that is not selected in the Fields for Nominal T-Min Lookup list will not be used for looking up the Nominal T-Min value. In other words, values in those fields of Thickness Measurement Location records are not required to match values in corresponding field in the Piping Nominal T-Min reference table.

Note: If no fields are selected in the Fields for Nominal T-Min Lookup list, the Nominal T-Min Lookup feature will be disabled. In other words, a Nominal T-Min value will never be retrieved automatically for any Thickness Measurement Location record.

Procedure

1. Access the **Global Preferences** workspace.
2. In the upper-right corner of the workspace, select .

The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **Nominal T-Min Preferences** section, in the **Fields for Nominal T-Min Lookup** list, select the fields that you want to use for retrieving Nominal T-Min values.
4. In the upper-right corner of the workspace, select .


The setting is saved, along with any other changes you have made to the preferences in the **Global Preferences** workspace.

Define Measurement Preferences

Before You Begin


If you enable this option and create Measurement Not Taken records and then later disable this option, any Measurement Not Taken records that you created will be ignored in the Corrosion Analysis (i.e., all calculations will be performed as if the Measurement Not Taken records did not exist).

Procedure

1. Access the **Global Preferences** workspace.
2. In the upper-right corner of the workspace, select .

The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **Measurement Preferences** section, select the **Allow Measurements to be Skipped** check box.
The Allow Consecutive Skipped Measurements check box is enabled.
4. If you want to create back-to-back Measurement Not Taken records, select the **Allow Consecutive Skipped Measurements** check box.
5. If you want to allow automatic correction of measurement values as Thickness Measurements are created and/or updated based on growth, select the **Correct Measurements Based on Growth** check box.
The Sites to Exclude list appears.
6. If you want to exclude any sites from the automatic correction, select the required site(s) in the **Sites to Exclude** list.

7. In the upper-right corner of the workspace, select .

The setting is saved, along with any other changes you have made to the preferences in the **Global Preferences** workspace.





Map Common Measurement Data Fields

Before You Begin

When you make changes to the **Common Measurement Data Field Mappings** section, the new fields you map will be made available on the **Measurement Data Entry** workspace, in the common measurement data section. By default, Measurement Comment and Measurement Status Indicator fields are available to map. Additionally, any custom fields you create for the Thickness Measurement family will appear in the list of available fields.





For example, if you select the Measurement Comment and Measurement Status Indicator fields to be mapped to the common measurement data section, the following screenshot illustrates how they will appear on the Measurement Data Entry workspace.

Procedure


1. Access the **Global Preferences** workspace.
2. In the upper-right corner of the workspace, select .
The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .
3. In the **Common Measurement Data Field Mappings** section, select up to three fields you want to appear in the common measurement data section of the **Measurement Data Entry** workspace.
4. In the upper-right corner of the workspace, select .
The setting is saved, along with any other changes you have made to the preferences in the **Global Preferences** workspace.

Modify the High Loss Value

Procedure

1. Access the **Global Preferences** workspace.
2. In the upper-right corner of the workspace, select .
The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .
3. In the **Color-Coding Preferences** section, in the **High Loss** box, enter a value between 0 and 100.
4. In the upper-right corner of the page, select .
The High Loss value is modified.

Results

- When you create or update a Thickness Measurement, if the percentage of decrease in the measurement value from the previous measurement is greater than or equal to the new High Loss value, then, in the **Analysis Overview** workspace, in the **TMLs** section,  appears in the row containing the TML. This, however, happens only if the TML does not meet the criteria for the categories Below T-Min or Overdue.

Define Pipe Rotation Preferences

About This Task

If you select this option, the piping rotation workflow is enabled, and the **Piping Asset** check box appears in the **Corrosion Analysis Settings** workspace for an Asset.

Procedure

1. Access the [Global Preferences](#) workspace.

2. Select .

The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **Pipe Rotation Preferences** section, select the **Enable Pipe Rotation** check box. If the **Allow Nested TML Groups?** check box is not in the selected state, the **Enable Pipe Rotation** window appears, confirming that the Allow Nested TML Groups option will be enabled.

4. Select **Yes**.

5. Select .

The setting is saved, along with any other changes that you have made to the preferences in the **Global Preferences** workspace. The **Allow Nested TML Groups?** check box is automatically selected.

Define Nested TML Groups Preferences

If you select this option, nested TML groups will be allowed, that is, TML Groups can be nested within other TML Groups.

Procedure

1. Access the [Global Preferences](#) workspace.

2. Select .

The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **Nested TML Groups** section, select the **Allow Nested TML Groups?** check box.

Note: In an earlier version, if you had previously configured the TML Group family preference and set the Has TML Group family in the Asset To Subcomponent field, then this check box will be selected automatically.

4. Select .

The setting is saved, along with any other changes that you have made to the preferences in the **Global Preferences** workspace.

Define Wall Ratio Preferences

About This Task

The Alert Levels in [TML Trends](#) graphs, Band Trends graphs, and Heat Maps and Piping Rotation widgets are determined using two parameters, that is, Alert Level 1 Max and Alert Level 2 Max. The default values

for Alert Level 1 Max and Alert Level 2 Max are 1.5 and 1.2 respectively. You can modify these values from the **Wall Ratio Preferences** section.

Procedure

1. Access the [Global Preferences workspace](#).
2. Select .

The boxes and check boxes in the **Global Preferences** workspace are enabled.  is replaced with .

3. In the **Wall Ratio Preferences** section, for the alert levels whose maximum wall ratio value you want to modify, enter values in the **Alert Level 2 Max** box and the **Alert Level 1 Max** box.

Note: The minimum value that can be entered in the **Alert Level 1 Max** box and the **Alert Level 2 Max** box is 1.

4. Select .
- The Alert Level 2 Max and the Alert Level 1 Max values are modified.




Manage Thickness Monitoring Rules Lookup Records


Before You Begin

Thickness Monitoring Rules Lookup records create a reference table of values that are used by APM Thickness Monitoring for performing certain calculations. Like all reference table records, Thickness Monitoring Rules Lookup records can be viewed most easily in the Bulk Data Form or through a query. For your convenience, the TM Administrative Tasks page contains a link that allows you to open Thickness Monitoring Rules Lookup records in the Bulk Data Form, where you can view and modify the reference table values as needed.

Procedure

1. Access the [TM Admin Preferences page](#).
2. Select the **TM Rules Lookup** tab.
A list of all TM Rules Lookup records are displayed in the bulk data form.

Note: Unsaved changes to the TM bulk data form result in a  appearing in the first column. After saving, the  becomes a .

3. Make any necessary changes, and then select .
- Any changes to or new TM Rules Lookup records are saved.

Family Preferences

About Family Preferences





You will use the [Family Preferences workspace](#) to define the fields that will be used for families to populate the TML Asset ID Field for a Thickness Measurement Location record.

Configure Family Preferences

About This Task

Thickness Monitoring is configured to use the TML Group family to store data as the foundational source of records to which other records, such as Asset Corrosion Analyses and TML Groups will be linked. You can configure the Component ID For each family from the **Family Preferences** workspace.

Procedure

1. Access the [TM Admin Preferences](#) page, and then select **Family Preferences** in the left pane. The **Family Preferences** workspace appears.
2. Select .
The boxes in the **Family Preferences** workspace are enabled.  is replaced with .
3. For each family that you want to configure, select the TML Asset ID field from the corresponding drop-down list box.
4. Select .
The Family Preferences are saved.

Datalogger Mappings

Create a Datalogger Mapping

About This Task


Datalogger Mappings are one-to-one relationships between fields in APM families and fields on [various dataloggers that are supported by Thickness Monitoring](#).



The **Datalogger Mappings** workspace contains a list of [baseline mappings](#). This topic describes how to create an additional mapping.

Important: To avoid data integrity issues:

- Do not modify mappings for the TML Asset ID and TML ID fields.
- When you add a mapping, ensure that:
 - The source and target fields are of the same data type.
 - The combination of source and target fields is unique (that is, there is a one-to-one relationship between the source and target fields).

Procedure

1. Access the [TM Admin Preferences](#) page.
2. In the left pane, select the **Datalogger Mappings** tab.
The Datalogger Mappings workspace appears, displaying a list of mappings.
3. Navigate to the blank row at the bottom of the list, and enter values in the [available fields](#).
Tip: If you want to add more mappings, press Tab. Another blank row appears at the bottom of the list.
4. Select .

The Datalogger Mapping is created. In the row containing the mapping that you have added, the  icon is replaced with the  icon.

Important: After the Datalogger Mapping is created, for these additional fields to appear in the **Send To** section of the **TM Dataloggers** page, the `\\Public\Meridium\Modules\Thickness Monitoring\Queries\Datalogger TMLs catalog` query must be modified. In addition, to use the Piping Rotation and Flip functionality, the `\\Public\Meridium\Modules\Thickness Monitoring\Piping Rotation\Queries\Datalogger TMLs - Piping Asset` catalog query must be modified.

Results

- If the value in the Transfer Direction field is Send To (T), then, for the datalogger for which you have created the mapping:
 - The newly created mapping appears in the grid in the **Send To** section on the **TM Dataloggers** page.
 - When you [Send Data to a Datalogger](#) on page 114, the value in the Source Field field that you have specified in the mapping is also sent to the device.
- If the value in the Transfer Direction field is Receive From (F), then, for the datalogger for which you have created the mapping:
 - The newly created mapping appears in the grid in the **Receive From** section on the **TM Dataloggers** page.
 - When you [Receive Data from a Datalogger](#) on page 116, the value in the Source Field field that you have specified in the mapping is populated with the value from the device field.


Delete a Datalogger Mapping


About This Task

Important: Do not delete the mapping between the following fields. If you do so, you will not be able to send or receive data using the datalogger.

Source Field	Source Family	Target Field
TML Asset ID	Thickness Measurement Location	Asset ID
TML ID	Thickness Measurement Location	Datapoint ID
Number of Readings	Thickness Measurement Location	Number of Readings
Readings	Thickness Measurement	Reading Values
Measurement Taken Date	Thickness Measurement	Measurement Taken Date

Procedure

1. [Access the TM Admin Preferences page.](#)
2. In the left pane, select the **Datalogger Mappings** tab.
The **Datalogger Mappings** workspace appears, displaying a list of mappings.
3. In the upper-right corner of the workspace, select .
4. In the row containing the mapping that you want to delete, select the check box.

5. In the upper-right corner of the workspace, select , and then select **Delete**.
A message appears, asking you to confirm that you want to delete the mapping.
6. Select **Yes**.
The Datalogger Mapping is deleted.

Results

Depending on the value in the Transfer Direction field in the mapping that you deleted, the data related to the mapping is no longer sent to or received from the datalogger.

Datalogger Mapping Records

Datalogger Mapping records are used to determine the relationship between fields in APM families and fields used in a datalogger. This topic provides an alphabetical list and description of the fields that exist for the Datalogger Mapping family. The information in the table reflects the baseline state and behavior of these fields.

This family is not enabled for site filtering, which means that records in this family can be accessed by any user with the appropriate license and family privileges. For more information, refer to the [Sites](#) section of the documentation.

Field	Data Type	Description	Behavior and Usage
Asset Type	Character	Indicates whether the mapping is applicable only to piping assets or to all assets.	The default value is null. When the value in this field is Piping Asset, the mapping for piping assets supersedes the mapping for all assets. This field is populated by the MI_DLG_ASSET_TYPE System Code Table.
Device Type	Character	The type of the datalogger whose field you want to map.	This field contains the description of all the System Codes in the M655 System Code Table. You can choose from the following baseline values: <ul style="list-style-type: none"> • GE DMS2 • GE DMS Go/Go+ • Olympus 37DL Plus Ultrasonic Thickness Gage • Olympus 37DL Plus Ultrasonic Thickness Gage

Field	Data Type	Description	Behavior and Usage
Source Family	Character	The name of the APM family whose field you want to map as the source.	<p>If the value in the Transfer Direction field is Send To (T), then this field contains the following list of families:</p> <ul style="list-style-type: none"> • Thickness Measurement Location • TML Corrosion Analysis <p>If the value in the Transfer Direction field is Receive From (F), then this field contains the following list of families:</p> <ul style="list-style-type: none"> • Thickness Measurement • Thickness Measurement Location
Source Field	Character	The name of the field that you want to map as the source.	This field contains a list of fields in the family that you have selected in the Source Family field.
Target Field	Character	The name of the field that you want to map as the target.	<p>This field contains a list of fields in the datalogger that you have selected in the Device Type field. It contains the description of the system Codes in the M658 System Code Table. You must only use the baseline fields that appear in this field.</p> <p>By default, on the TM Dataloggers page, in the Send To and Receive From sections, the rows in the grids are arranged in the alphabetical order of the values in the Target Field column.</p>
Transfer Direction	Character	Indicates whether data is sent to or received from the datalogger.	<p>This field contains the description of all the System Codes in the M656 System Code Table. You can choose from the following baseline values:</p> <ul style="list-style-type: none"> • Send To (T) • Receive From (F)

Baseline Datalogger Mapping Records

The following table provides the field values in baseline Datalogger Mappings.

Device Type	Transfer Direction	Source Family	Source Field	Target Field
GE DMS Go/Go+	Receive From (F)	Thickness Measurement	Measurement Taken Date	Date Last Updated
GE DMS Go/Go+	Receive From (F)	Thickness Measurement	Readings	Reading Values
GE DMS Go/Go+	Receive From (F)	Thickness Measurement Location	TML Asset ID	Asset ID
GE DMS Go/Go+	Receive From (F)	Thickness Measurement Location	TML ID	Datapoint ID
GE DMS Go/Go+	Send To (T)	Thickness Measurement Location	TML Asset ID	Asset ID
GE DMS Go/Go+	Send To (T)	Thickness Measurement Location	TML ID	Datapoint ID
GE DMS Go/Go+	Send To (T)	Thickness Measurement Location	Location	Datapoint Location
GE DMS Go/Go+	Send To (T)	Thickness Measurement Location	Number of Readings	Number of Readings
GE DMS Go/Go+	Send To (T)	TML Corrosion Analysis	Last Measurement Date	Date Last Updated
GE DMS Go/Go+	Send To (T)	TML Corrosion Analysis	Last Measurement Value	Measurement Value
GE DMS2	Receive From (F)	Thickness Measurement	Measurement Taken Date	Date Last Updated
GE DMS2	Receive From (F)	Thickness Measurement	Readings	Reading Values
GE DMS2	Receive From (F)	Thickness Measurement Location	TML Asset ID	Asset ID
GE DMS2	Receive From (F)	Thickness Measurement Location	TML ID	Datapoint ID
GE DMS2	Send To (T)	Thickness Measurement Location	TML Asset ID	Asset ID
GE DMS2	Send To (T)	Thickness Measurement Location	TML ID	Datapoint ID
GE DMS2	Send To (T)	Thickness Measurement Location	Location	Datapoint Location
GE DMS2	Send To (T)	Thickness Measurement Location	Number of Readings	Number of Readings
GE DMS2	Send To (T)	TML Corrosion Analysis	Last Measurement Date	Date Last Updated
GE DMS2	Send To (T)	TML Corrosion Analysis	Last Measurement Value	Measurement Value

Device Type	Transfer Direction	Source Family	Source Field	Target Field
Olympus 37DL Plus Ultrasonic Thickness Gage	Receive From (F)	Thickness Measurement	Measurement Taken Date	Date Last Updated
Olympus 37DL Plus Ultrasonic Thickness Gage	Receive From (F)	Thickness Measurement	Readings	Reading Values
Olympus 37DL Plus Ultrasonic Thickness Gage	Receive From (F)	Thickness Measurement Location	TML Asset ID	Asset ID
Olympus 37DL Plus Ultrasonic Thickness Gage	Receive From (F)	Thickness Measurement Location	TML ID	Datapoint ID
Olympus 37DL Plus Ultrasonic Thickness Gage	Send To (T)	Thickness Measurement Location	TML Asset ID	Asset ID
Olympus 37DL Plus Ultrasonic Thickness Gage	Send To (T)	Thickness Measurement Location	TML ID	Datapoint ID
Olympus 37DL Plus Ultrasonic Thickness Gage	Send To (T)	Thickness Measurement Location	Location	Location Description
Olympus 37DL Plus Ultrasonic Thickness Gage	Send To (T)	Thickness Measurement Location	Number of Readings	Number of Readings
Olympus 37DL Plus Ultrasonic Thickness Gage	Send To (T)	TML Corrosion Analysis	Last Measurement Date	Date Last Updated
Olympus 37DL Plus Ultrasonic Thickness Gage	Send To (T)	TML Corrosion Analysis	Last Measurement Value	Measurement Value
Olympus 38DL Plus Ultrasonic Thickness Gage	Receive From (F)	Thickness Measurement	Measurement Taken Date	Date Last Updated
Olympus 38DL Plus Ultrasonic Thickness Gage	Receive From (F)	Thickness Measurement	Readings	Reading Values
Olympus 38DL Plus Ultrasonic Thickness Gage	Receive From (F)	Thickness Measurement Location	TML Asset ID	Asset ID
Olympus 38DL Plus Ultrasonic Thickness Gage	Receive From (F)	Thickness Measurement Location	TML ID	Datapoint ID

Device Type	Transfer Direction	Source Family	Source Field	Target Field
Olympus 38DL Plus Ultrasonic Thickness Gage	Send To (T)	Thickness Measurement Location	TML Asset ID	Asset ID
Olympus 38DL Plus Ultrasonic Thickness Gage	Send To (T)	Thickness Measurement Location	TML ID	Datapoint ID
Olympus 38DL Plus Ultrasonic Thickness Gage	Send To (T)	Thickness Measurement Location	Location	Location Description
Olympus 38DL Plus Ultrasonic Thickness Gage	Send To (T)	Thickness Measurement Location	Number of Readings	Number of Readings
Olympus 38DL Plus Ultrasonic Thickness Gage	Send To (T)	TML Corrosion Analysis	Last Measurement Date	Date Last Updated
Olympus 38DL Plus Ultrasonic Thickness Gage	Send To (T)	TML Corrosion Analysis	Last Measurement Value	Measurement Value

Chapter 14

Deployment and Upgrade

Topics:

- [Deployment](#)
- [Upgrade](#)

Deployment

Deployment

Refer to the deployment information here [Deploy Thickness Monitoring for the First Time](#).

Upgrade

Upgrade

Refer to the upgrade information here: Upgrade Thickness Monitoring.

Chapter 15

Reference

Topics:


- [General Reference](#)
- [Family Field Descriptions](#)
- [Corrosion Rates in Thickness Monitoring](#)
- [Calculations](#)
- [Family Search Configuration](#)

General Reference

TM Data Model


The following diagram illustrates how families are related within the TM data model. In the following image, boxes represent entity families, and arrows represent relationship families that are configured in the baseline database.


Data Model



TM Piping Rotation Data Model

The following diagrams illustrate how families are related within the TM Piping Rotation data model. In the following image, boxes represent entity families, and arrows represent relationship families that are configured in the baseline database.





TM Security Groups

The following table lists the baseline Security Groups available for users within this module, as well as the baseline Roles to which those Security Groups are assigned.

Important: Assigning a Security User to a Role grants that user the privileges associated with all of the Security Groups that are assigned to that Role. To avoid granting a Security User unintended privileges, before assigning a Security User to a Role, be sure to review all of the privileges associated with the Security Groups assigned to that Role. Also, be aware that additional Roles, as well as Security Groups assigned to existing Roles, can be added via Security Manager.

Security Group	Roles
MI Thickness Monitoring Administrator	MI Mechanical Integrity Administrator
MI Thickness Monitoring Inspector	MI Mechanical Integrity Administrator MI Mechanical Integrity Power MI Mechanical Integrity User
MI Thickness Monitoring User	MI Mechanical Integrity Administrator MI Mechanical Integrity Power MI Mechanical Integrity User
MI Thickness Monitoring Viewer	MI APM Viewer MI Mechanical Integrity Viewer

The baseline family-level privileges that exist for these Security Groups are summarized in the following table.

Family	MI Thickness Monitoring Administrator	MI Thickness Monitoring Inspector	MI Thickness Monitoring User	MI Thickness Monitoring Viewer
Entity Families				
Corrosion	View, Update, Insert	View, Update, Insert	View, Update, Insert	View
Datapoint	View, Update, Insert	View, Update, Insert	View, Update, Insert	View
Datapoint Measurement	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert	View
Equipment	View	View	View	View
Human Resource	View, Update, Insert, Delete	View	View	View
Inspection Task	View	View, Update	View	View
Inventory Group Configuration	View	View	View	View
Materials of Construction	View	View	View	View
Meridium Reference Tables	View, Update, Insert, Delete	View	View	View
RBI Inspection Auto-Selection Criteria	View	View	View	View
Resource Role	View, Update, Insert, Delete	View	View	View
Security Group	View	View	View	View
Security User	View	View	View	View
Settings	View, Update, Insert	View, Update, Insert	View	View
Task Execution	View, Insert	View, Insert	View	View
Thickness Monitoring Task	View, Update, Insert, Delete	View, Update, Insert	View, Update, Insert	View
TML Group	View, Update, Insert, Delete	View, Update, Insert, Delete	View	View
Relationship Families				
Belongs to a Unit	View, Update, Insert, Delete	View, Update, Insert	View, Update, Insert	View
Equipment Has Equipment	View	View	View	View
Group Assignment	View	View	View	View
Has Archived Corrosion Analyses	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View

Family	MI Thickness Monitoring Administrator	MI Thickness Monitoring Inspector	MI Thickness Monitoring User	MI Thickness Monitoring Viewer
Has Archived Corrosion Analysis Settings	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Archived Subcomponent Analysis Settings	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Archived Subcomponent Corrosion Analyses	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Corrosion Analyses	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Corrosion Analysis Settings	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Datapoints	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Inspections	None	None	None	View
Has Measurements	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Roles	View, Update, Insert, Delete	View	View	View
Has Task Execution	View, Insert	View, Insert	View	View
Has Task Revision	View, Insert	View, Insert	View	View
Has Tasks	View, Insert	View, Insert	View, Insert	View
Has TML Group	View, Update, Insert, Delete	View, Update, Insert, Delete	View	View
Is a User	View	View	View	View
User Assignment	View	View	View	View

The following table lists the baseline Security Groups available for users within this module, as well as the baseline Roles to which those Security Groups are assigned.

Important: Assigning a Security User to a Role grants that user the privileges associated with all of the Security Groups that are assigned to that Role. To avoid granting a Security User unintended privileges, before assigning a Security User to a Role, be sure to review all of the privileges associated with the Security Groups assigned to that Role. Also, be aware that additional Roles, as well as Security Groups assigned to existing Roles, can be added via Security Manager.

Security Group	Roles
MI Thickness Monitoring Administrator	MI Mechanical Integrity Administrator
MI Thickness Monitoring Inspector	MI Mechanical Integrity Administrator MI Mechanical Integrity Power MI Mechanical Integrity User
MI Thickness Monitoring User	MI Mechanical Integrity Administrator MI Mechanical Integrity Power MI Mechanical Integrity User
MI Thickness Monitoring Viewer	MI APM Viewer MI Mechanical Integrity Viewer

The baseline family-level privileges that exist for these Security Groups are summarized in the following table.

Family	MI Thickness Monitoring Administrator	MI Thickness Monitoring Inspector	MI Thickness Monitoring User	MI Thickness Monitoring Viewer
Entity Families				
Corrosion	View, Update, Insert	View, Update, Insert	View, Update, Insert	View
Datapoint	View, Update, Insert	View, Update, Insert	View, Update, Insert	View
Datapoint Measurement	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert	View
Equipment	View	View	View	View
Human Resource	View, Update, Insert, Delete	View	View	View
Inspection Task	View	View, Update	View	View
Inventory Group Configuration	View	View	View	View
Materials of Construction	View	View	View	View
Meridium Reference Tables	View, Update, Insert, Delete	View	View	View
RBI Inspection Auto-Selection Criteria	View	View	View	View
Resource Role	View, Update, Insert, Delete	View	View	View
Security Group	View	View	View	View
Security User	View	View	View	View
Settings	View, Update, Insert	View, Update, Insert	View	View

Family	MI Thickness Monitoring Administrator	MI Thickness Monitoring Inspector	MI Thickness Monitoring User	MI Thickness Monitoring Viewer
Task Execution	View, Insert	View, Insert	View	View
Thickness Monitoring Task	View, Update, Insert, Delete	View, Update, Insert	View, Update, Insert	View
TML Group	View, Update, Insert, Delete	View, Update, Insert, Delete	View	View
Relationship Families				
Belongs to a Unit	View, Update, Insert, Delete	View, Update, Insert	View, Update, Insert	View
Equipment Has Equipment	View	View	View	View
Group Assignment	View	View	View	View
Has Archived Corrosion Analyses	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Archived Corrosion Analysis Settings	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Archived Subcomponent Analysis Settings	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Archived Subcomponent Corrosion Analyses	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Corrosion Analyses	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Corrosion Analysis Settings	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Datapoints	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Inspections	None	None	None	View
Has Measurements	View, Update, Insert, Delete	View, Update, Insert, Delete	View, Update, Insert, Delete	View
Has Roles	View, Update, Insert, Delete	View	View	View
Has Task Execution	View, Insert	View, Insert	View	View
Has Task Revision	View, Insert	View, Insert	View	View
Has Tasks	View, Insert	View, Insert	View, Insert	View
Has TML Group	View, Update, Insert, Delete	View, Update, Insert, Delete	View	View

Family	MI Thickness Monitoring Administrator	MI Thickness Monitoring Inspector	MI Thickness Monitoring User	MI Thickness Monitoring Viewer
Is a User	View	View	View	View
User Assignment	View	View	View	View

Field Mappings in the Default View of the TML Grid

In the **Analysis Overview** workspace, the grid in the **TMLs** section displays values in the following fields:

Field	Family
TML ID	Thickness Measurement Location
TML Asset ID	Thickness Measurement Location
Minimum Thickness	Thickness Measurement Location
Number of Readings	Thickness Measurement Location
Corrosion Rate	TML Corrosion Analysis
Remaining Life	TML Corrosion Analysis
Factor Remaining Life Date	TML Corrosion Analysis
Scheduled Next Inspection Date	TML Corrosion Analysis
Projected T-min Date	TML Corrosion Analysis
Last Measurement Value	TML Corrosion Analysis
Last Measurement Date	TML Corrosion Analysis
Near Measurement Value	TML Corrosion Analysis






The values in the **Remaining Life** column are calculated based on the current date and the value in the Projected T-Min Date field in the TML Corrosion Analysis family. This value is displayed in years.

About Allowable Stress

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About Color-Coding

Color-coding lets you see at a glance whether certain conditions exist for a given Thickness Measurement Location (TML) or Thickness Measurement. A color-coding category is assigned to each TML or Thickness Measurement based on the following criteria:

Category	Visual Cue	Criteria for a TML	Criteria for a Thickness Measurement
Below T-Min		The value in the Measurement Value field in the latest Thickness Measurement is less than the value in the Minimum Thickness field.	The value in the Measurement Value field is less than the value in the Minimum Thickness field in the associated TML.
Overdue		The value in the Scheduled Next Inspection Date or the Projected T-min Date field is earlier than the current date.	N/A
High Loss		The decrease in the measurement value of the latest Thickness Measurement compared to that of the previous one is greater than or equal to a specified percentage. Note: The default value is 30 percent. You can, however, modify this value .	The decrease in the measurement value of the latest Thickness Measurement compared to that of the previous one is greater than or equal to a specified percentage. Note: The default value is 30 percent. You can, however, modify this value .
Growth		The measurement value of the latest Thickness Measurement is greater than that of the previous one.	The measurement value of the latest Thickness Measurement is greater than that of the previous one.
Normal		The TML does not meet the criteria for any of the aforementioned categories.	The Thickness Measurement does not meet the criteria for any of the aforementioned categories.

Note: The values displayed in the **Measurements** section are rounded up to four decimal places. When assigning a color-coding category, instead of these rounded up values, the actual field values are considered.

These categories appear at the top of the **TMLs** section in the **Analysis Overview** workspace. The number in parentheses next to each category indicates the number of records that meet the criteria for each category. The visual cue appears in each row in the list of TMLs and Thickness Measurements.

Tip: You can filter the TMLs for each category by selecting the category at the top of the section. You can remove the filter by selecting the same category again.

Even if a TML or a Thickness Measurement meets the criteria for more than one category, only one color-code is assigned to each record, based on the following priority:

- Below T-Min
- Overdue
- High Loss
- Growth

Example: Color-Coding

Suppose a TML contains the following field values:

- **Minimum Thickness:** 1.2 inches
- **High Loss:** 10 percent (as specified on the **TM Admin Preferences** page)

Suppose the TML contains the following Thickness Measurements.

Measurement ID	Measurement Value (inches)
TM-1	1.34
TM-2	1.20

The following table describes the color-coding category that will be applied to each Thickness Measurement.

Measurement ID	Color-Coding Category	Reason
TM-1	Normal	The Measurement Value does not meet the criteria for any other categories.
TM-2	High Loss	The percentage of decrease between the latest Measurement Value (1.20 inches) and the previous one (1.34 inches) is greater than 10 percent.

Suppose you have created two more Thickness Measurements with the following Measurement Values:

Measurement ID	Measurement Value (inches)
TM-3	1.01
TM-4	1.21

The following table describes the color-coding category that will be applied to each Thickness Measurement.

Measurement ID	Color-Coding Category	Reason
TM-1	Normal	The Measurement Value does not meet the criteria for any other categories.
TM-2	Normal	Although the percentage of decrease in the Measurement Value (1.20 inches) from the previous one (1.34 inches) is greater than 10 percent, since this is no longer the latest Thickness Measurement, the category Normal is applied instead of High Loss.
TM-3	Below T-Min	The Measurement Value (1.01 inches) is less than Minimum Thickness (1.2 inches).
TM-4	Growth	The Measurement Value (1.21 inches) is greater than the previous one (1.01 inches).

Suppose the current date is December 31, 2017, and the TML Corrosion Analysis associated with the TML contains the following field values:

- **Scheduled Next Inspection Date:** January 01, 2018
- **Projected T-min Date:** January 02, 2018

For the TML, color-coding category is applied based on the following logic:

- **Below T-Min:** The value in the Measurement Value field (1.21 inches) of the latest Thickness Measurement (TM-4) is greater than the value in the Minimum Thickness field (1.2 inches). Therefore, the category Below T-Min is not applied to the TML.
- **Overdue:** The Scheduled Next Inspection Date (January 01, 2018) and the Projected T-Min Date (January 02, 2018) are later than the current date (December 31, 2017). Therefore, the category Overdue is not applied to the TML.
- **High Loss:** There is no decrease in the Measurement Value of the latest Thickness Measurement (1.21 inches) compared to that of the previous one (1.01 inches). Therefore, the category High Loss is not applied to the TML.
- **Growth:** The Measurement Value of the latest Thickness Measurement (1.21 inches) is greater than that of the previous one (1.01 inches). Therefore, the category Growth is applied to the TML.

About the Measurement Data Entry (MDE) Workspace

The Measurement Data Entry workspace is used for entering Thickness Measurement readings for multiple TMLs. It is divided into two areas: the common measurement data section, and the data entry grid.

Common Measurement Data

The common measurement data section appears at the top of the Measurement Data Entry workspace, and allows you to define values that will be distributed to cells in the corresponding columns for each Thickness Measurement Location (TML) listed in the data entry grid.

The Common Measurement Data section provides three boxes in which you can enter data:

- **Measurement Taken Date**
- **Measurement Taken By**
- **Temperature**


You can customize this section to make additional boxes available. Data entered in these boxes becomes the default value in the corresponding cell in each row.

Changes to the common measurement data section will not be applied to any rows in the data entry grid that already contain data.

Data Entry Grid

The data entry grid appears below the common measurement data section. The grid will be populated with one row for each TML linked to the record that you selected when accessing the Measurement Data Entry workspace.

By default, the grid is sorted in ascending order according to the value in the TML ID column.

Some TMLs will require you to enter multiple readings, as determined by the value in the Number of Readings field in a TML. You can enter multiple readings on the data entry grid by specifying the values separated by semi-colon or by selecting  in the row corresponding to a TML. [A measurement value will be determined based on the readings.](#)

The MIExecution Service

The MIExecution Service is a service available in the APM server, which processes jobs in the Inspection Management, Integrity Mobile, Risk Based Inspection, and Thickness Monitoring module queues. It uses a single shared ActiveMQ queue service across APM.

Supported Job Types

- Inspection Management
- Integrity Mobile
- Risk Based Inspection
- Thickness Monitoring

Configuration

You can configure the following parameters of the MIExecution Service:

Parameter	Description	Default Value
ConcurrencyLimit	The maximum number of messages consumed concurrently.	100
Retries	The number of times the service retries to send the messages to ActiveMQ in case of a failure.	5

For instructions of configuring these settings, refer to .

Catalog Items

Graphs

The Catalog folder `\\Public\Meridium\Modules\Thickness Monitoring\Graphs` contains the following items.

Item Name	Behavior and Usage
Corrosion Rate Dist	This graph appears on the Thickness Monitoring Overview page, and is based on the Corrosion Distribution query. It displays the corrosion rates of assets with calculated Asset Corrosion Analyses, ordered from highest rate of corrosion to lowest.
Remaining Life Less than 180 Months Graph	This graph appears on the Thickness Monitoring Overview page, and is based on the Remaining Life Less than 180 Months query. It displays the remaining life of assets with calculated Asset Corrosion Analyses, ordered from lowest remaining life to highest.

Piping Rotation

The Catalog folder `\\Public\Meridium\Modules\Thickness Monitoring\Piping Rotation\Queries` contains the following items.

Item Name	Behavior and Usage
Datalogger TMLs - Piping Asset	Used to populate the list of items in the Select TMLs pane for piping assets.
Measurement Input Reference for Piping Asset	Returns TMLs and additional reference data used for entering Thickness Measurements in the Measurement Data Entry workspace for piping assets. The following reference columns in the data entry grid are populated by this query: <ul style="list-style-type: none"> • Component ID • Piping Band ID • Position • TML ID • Minimum Thickness • Last Measurement Value • Last Measurement Date
Piping Components with Number of Positions	Returns the components for a piping asset and the number of positions in the bands for each component.
Rotation History for Component	Used to populate the list in the PIPE ROTATION: HISTORY section of the Component Details workspace for a piping component.
Rotation Revisions by Rotation Event and Band	None
Rotation What-Ifs for Component	Used to populate the list in the PIPE ROTATION: WHAT-IFS section of the Component Details workspace for a piping component.

Queries

The Catalog folder **\\Public\Meridium\Modules\Thickness Monitoring\Queries** contains the following items.

Item Name	Behavior and Usage
Assets Near or Past Retirement	Used on the Thickness Monitoring Overview workspace to return a list of all assets with Asset Corrosion Analyses that are within 5 years of or past the retirement date. The list is displayed when you select the Assets Near or Past Retirement Date tab.
Assets with TM Tasks	Used on the Thickness Monitoring Overview workspace to return a list of all assets with Thickness Monitoring Tasks. The list is displayed in the TM Tasks box.
AvailableTMTasks	Returns all Thickness Monitoring Tasks related to the supplied assets.
Corrosion Distribution	Used to populate the data in the Corrosion Rate Distribution graph on the Thickness Monitoring Overview workspace.
Datalogger TMLs	Used to populate the list of items in the Select TMLs pane for non-piping assets.

Item Name	Behavior and Usage
Degradation Rates Greater than Expected	Used to populate the list in the Degradation Distribution box on the Thickness Monitoring Overview workspace.
Excessive Corrosion	Used on the Thickness Monitoring Overview workspace to return all assets with Asset Corrosion Analyses, and a Controlling Corrosion Rate greater than 20 Mils/year. The list is displayed when you select the Excessive Corrosion tab.
Measurement Input Reference	Returns TMLs and additional reference data used for entering Thickness Measurements in the Measurement Data Entry workspace.
Measurement Input Reference Count	Returns the count of TMLs on the Measurement Data Entry workspace.
Measurements Near or Less than T-Min	Used on the Thickness Monitoring Overview workspace to return all assets with measurements that fall within 10 Mils or less of T-Min.
ML_TASKS_FOR_MDE	Returns the Inspection Tasks on the Measurement Data Entry workspace and is filtered to exclude tasks that are marked as Completed or Rejected.
Remaining Life Less than 180 Months	Used to populate the data in the Remaining Life graph on the Thickness Monitoring Overview workspace.
Thickness Inspections	Used on the Thickness Monitoring Overview workspace to return all assets with a Next Inspection Date, including past dates. This list is displayed when you select the Thickness Inspections tab.
TM Assets	Used on the Thickness Monitoring Overview workspace to display a list of all assets with Thickness Monitoring data linked to the selected Functional Location. It is also used to populate the list of all assets that the selected functional location contains on the Select Assets to Load for Dataloggers window, in the TM Dataloggers page.
TM Assets Requiring a Calculation	Used on the Thickness Monitoring Overview workspace to display a list of all assets with Asset Corrosion Analyses that must be recalculated. This list is displayed when you select the Assets Requiring a Calculation Assets Requiring a Calculation tab.
TM Overview Filter Parameters	None
TML Groups for an Asset	Returns a list of all TML Groups linked to the selected asset.
TMLs for an Asset	Returns a list of all TMLs linked to the selected asset or TML Group.

TM Rules Lookup

Thickness Monitoring includes a set of baseline Thickness Monitoring Rules Lookup records and the associated Rules Library projects. You can use the baseline records as they are delivered, or you can modify them to suit your specific needs. Like all reference table records, Thickness Monitoring Rules

Lookup records are best viewed through a query. You can manage Thickness Monitoring Rules Lookup records via [TM Admin Preferences](#).

Thickness Monitoring Rules

The following table provides a list of the fields that exist in the Thickness Monitoring Rules Lookup family, descriptions of these fields, and information about any corresponding Thickness Measurement Location (TML) fields.

Field Name	Field Description	Corresponding TML Field
Asset Type	Contains a value that identifies the type of equipment to which a TML is linked. The value in this field determines which values are available in the Design Code field. For example, when Piping is selected in the Asset Type field, only piping design codes will appear in the Design Code field.	This field exists simply to facilitate the creation of new Thickness Monitoring Rules Lookup records by filtering values in the Design Code field.
Code Year	Contains a list of years associated with the selected Design Code.	Code Year (T-Min Formula)
Design Code	Contains a list of design codes that are appropriate for the equipment type selected in the Asset Type field.	Design Code
Component Type	Contains a list of component types.	Determined by the equipment type, which is derived from the value in the Design Type field, and can be any of the following fields: <ul style="list-style-type: none"> • Vessel Type for Pressure Vessel TMLs. • Tank Type for Tank TMLs. • No Mapping for Piping TMLs.
Formula Classification	Contains a list of formula classifications.	Determined by the equipment type, which is derived from the value in the Design Type field, and can be any of the following fields: <ul style="list-style-type: none"> • Piping Formula for Piping TMLs. • PV Formula for Pressure Vessel TMLs. • No Mapping for Tank TMLs.

Field Name	Field Description	Corresponding TML Field
T-Min Formula Rule	Contains a reference to a project in the Rules Library.	This value is derived for each TML based on values in other fields. Although the derived value is not stored in the TML itself, it identifies the formula that will be used to determine the Calculated T-Min value for a TML.
MAWP Formula Rule	Contains a reference to a project in the Rules Library.	This value is derived for each TML based upon values in other fields. Although the derived value is not stored in the TML itself, it is used to determine the Maximum Allowable Working Pressure value for a TML.

Default Datalogger Settings

The following table provides a list of default settings for each datalogger. You must review them and [modify](#) if needed before sending or receiving data from a datalogger.

Datalogger	Connection Type	Baud Rate	COM Port	Datalogger Service Port	File Mode
GE DMS Go	USB	N/A	N/A	2014	NA
GE DMS Go+	USB	N/A	N/A	2014	NA
GE DMS2	Serial	Per Device Setting	COM1	2014	NA
Olympus (Panametrics) 37DL Plus Ultrasonic Thickness Gage	Serial	1200	COM1	2014	NA
Olympus (Panametrics) 38DL Plus Ultrasonic Thickness Gage	USB	N/A	N/A	2014	Thickness

Note: The Olympus (Panametrics) 38DL Plus Ultrasonic Thickness Gage also supports the serial connection type. When you set the Connection Type to Serial, the Olympus (Panametrics) 38DL Plus Ultrasonic Thickness Gage uses the same default settings as the Olympus (Panametrics) 37DL Plus Ultrasonic Thickness Gage.

Limitations When Using Dataloggers

This topic provides a list of limitations when using each type of datalogger.

GE DMS Go and GE DMS Go+

- You must specify a directory in the **File Directory** box. Files will be sent to and received from the **Meridium** folder that is created in the specified directory.
- The GE DMS Go and GE DMS Go+ devices use only the first 32 characters of the file name that is used to send data. If the file name is longer than 32 characters, a message appears, specifying the original item name and the truncated item name.

If multiple files are sent to the device, and the first 32 characters of the file names are the same, then a single file will be created on the device using the first 32 characters, which stores the data in all the files.

- The GE DMS Go and GE DMS Go+ devices use only the first 16 characters of the TML ID. If the TML ID is longer than 16 characters, a message appears, specifying that the TML ID will be truncated to 16 characters.

Important: Because of the truncation, if duplicate TML IDs are created in the device, it collects data from both the locations. However, while receiving the data, it updates the data only for the first TML ID.

GE DMS2

- The GE DMS2 device uses only the first 32 characters of the file name that is used to send data. If the file name is longer than 32 characters, a message appears, specifying the original item name and the truncated item name.

If multiple files are sent to the device, and the first 32 characters of the file names are the same, then a single file will be created on the device using the first 32 characters, which stores the data in all the files.

- The GE DMS2 device uses only the first 16 characters of the TML ID. If the TML ID is longer than 16 characters, a message appears, specifying that the TML ID will be truncated to 16 characters.

Important: Because of the truncation, if duplicate TML IDs are created in the device, it collects data from both the locations. However, while receiving the data, it updates the data only for the first TML ID.

Olympus (Panametrics) 37DL Plus Ultrasonic Thickness Gage

- The Olympus (Panametrics) 37DL Plus Ultrasonic Thickness Gage does not accept Asset IDs containing lowercase characters.

Olympus (Panametrics) 38DL Plus Ultrasonic Thickness Gage

- The Olympus (Panametrics) 38DL Plus Ultrasonic Thickness Gage does not accept Asset IDs containing lowercase characters.
- The following characters are supported on the Olympus 38DL Plus device, A-Z, 0-9, and the following special characters – (hyphen) . (period) / (forward slash) , (comma) : (colon) # (hash) * (asterisk). When data, especially TML Asset ID and TML IDs are being created, it is important to consider that these are the only supported characters for this device. If a TML with other special characters is sent to the device, it will result in an error on the device while attempting to send from APM.
- The Olympus 38DL Plus has an inactive timer which will turn the device off after a certain amount of time of unuse. To disable this, you can press the SETUP MENU key, select SYSTEM, and change the value for INACTIVE TIME to OFF

TM URLs

There are two URL routes associated with Thickness Monitoring, that is, **tm** for non-piping assets, and **tm-piping** for piping assets. The following table describes the various paths that build on the route, and the elements that you can specify for each route.

Tip: For more information, refer to the URLs section of the documentation.

Element	Description	Accepted Value(s)	Notes
<p>tm/unit: Opens the Thickness Monitoring Overview workspace.</p> <p>tm/unit/<UnitEntityKey>: Displays the selected unit on the Thickness Monitoring Overview workspace.</p>			
<UnitEntityKey>	Specifies the Functional Location or Unit you want to view in TM.	Any Entity Key that corresponds to a Unit or Functional Location.	Required.
<p>tm/asset/<AssetEntityKey>: Displays the selected non-piping asset in the Analysis Overview workspace.</p> <p>tm-piping/asset/<AssetEntityKey>: Displays the selected piping asset in the Analysis Overview workspace.</p> <p>tm/asset/<AssetEntityKey>/settings: Displays the selected non-piping asset in the Corrosion Analysis Settings workspace.</p> <p>tm-piping/asset/<AssetEntityKey>/settings: Displays the selected piping asset in the Corrosion Analysis Settings workspace.</p> <p>tm/asset/<AssetEntityKey>/input: Displays the selected non-piping asset in the Measurement Data Entry workspace.</p> <p>tm-piping/asset/<AssetEntityKey>/input: Displays the selected piping asset in the Measurement Data Entry workspace.</p>			
<AssetEntityKey>	Specifies the asset you want to view in TM.	Any Entity Key that corresponds to an asset.	Required.
<p>tm/asset/<AssetEntityKey>/subcomponent/<TMLGroupEntityKey>: Displays the selected TML Group for a non-piping asset in the Analysis Overview workspace.</p> <p>tm-piping/asset/<AssetEntityKey>/subcomponent/<TMLGroupEntityKey>: Displays the selected TML Group for a piping asset in the Analysis Overview workspace.</p> <p>tm/asset/<AssetEntityKey>/subcomponent/<TMLGroupEntityKey>/settings: Displays the selected TML Group for a non-piping asset in the Corrosion Analysis Settings workspace.</p> <p>tm-piping/asset/<AssetEntityKey>/subcomponent/<TMLGroupEntityKey>/settings: Displays the selected TML Group for a piping asset in the Corrosion Analysis Settings workspace.</p> <p>tm/asset/<AssetEntityKey>/subcomponent/<TMLGroupEntityKey>/input: Displays the selected TML Group for a non-piping asset in the Measurement Data Entry workspace.</p> <p>tm-piping/asset/<AssetEntityKey>/subcomponent/<TMLGroupEntityKey>/input: Displays the selected TML Group for a piping asset in the Measurement Data Entry workspace.</p>			
<TMLGroupEntityKey>	Specifies a TML Group linked to an asset that you want to view in TM.	Any Entity Key that corresponds to a TML Group.	Required.
<p>tm/asset/<AssetEntityKey>/tml/<TMLEntityKey>: Displays the selected TML for a non-piping asset in the Analysis Overview workspace.</p> <p>tm-piping/asset/<AssetEntityKey>/tml/<TMLEntityKey>: Displays the selected TML for a piping asset in the Analysis Overview workspace.</p> <p>tm/asset/<AssetEntityKey>/tml/<TMLEntityKey>/settings: Displays the selected TML for a non-piping asset in the Corrosion Analysis Settings workspace.</p> <p>tm-piping/asset/<AssetEntityKey>/tml/<TMLEntityKey>/settings: Displays the selected TML for a piping asset in the Corrosion Analysis Settings workspace.</p>			
<UnitEntityKey>	Specifies a TML linked to an asset that you want to view in TM.	Any Entity Key that corresponds to a TML.	Required.

Example URLs

Example URL	Destination
tm/unit	The Thickness Monitoring Overview workspace.
tm/unit/2305330	The Thickness Monitoring Overview workspace for the specified unit.
tm/asset/2509505	The Analysis Overview workspace for the specified non-piping asset.
tm-piping/asset/64263085162	The Analysis Overview workspace for the specified piping asset.
tm/asset/2509505/settings	The Corrosion Analysis Settings workspace for the specified non-piping asset.
tm-piping/asset/64263085162/settings	The Corrosion Analysis Settings workspace for the specified piping asset.
tm/asset/2509505/input	The Measurement Data Entry workspace for the specified non-piping asset.
tm-piping/asset/64263085162/input	The Measurement Data Entry workspace for the specified piping asset.
tm/asset/2509505/subcomponent/3476094	The Analysis Overview workspace for the TML Group with Entity Key 3476094, which is linked to the non-piping asset with Entity Key 2509505.
tm-piping/asset/64263085162/subcomponent/64263438219	The Analysis Overview workspace for the Component or Band with Entity Key 64263438219, which is linked to the piping asset with Entity Key 64263085162.
tm/asset/2509505/subcomponent/3476094/settings	The Corrosion Analysis Settings workspace for the TML Group with Entity Key 3476094, which is linked to the non-piping asset with Entity Key 2509505.
tm-piping/asset/64263085162/subcomponent/64263438219/settings	The Corrosion Analysis Settings workspace for the Component or Band with Entity Key 64263438219, which is linked to the piping asset with Entity Key 64263085162.
tm/asset/2509505/subcomponent/3476094/input	The Measurement Data Entry workspace for the TML Group with Entity Key 3476094, which is linked to the non-piping asset with Entity Key 2509505.
tm-piping/asset/64263085162/subcomponent/64263438219/input	The Measurement Data Entry workspace for the Component or Band with Entity Key 64263438219, which is linked to the piping asset with Entity Key 64263085162.
tm/asset/2509505/tml/6225073	The Analysis Overview workspace for the TML with Entity Key 6225073, which is linked to the non-piping asset with Entity Key 2509505.
tm-piping/asset/64263085162/tml/64263438232	The Analysis Overview workspace for the TML with Entity Key 64263438232, which is linked to the piping asset with Entity Key 64263085162.

Example URL	Destination
tm/asset/2509505/tml/6225073/settings	The Corrosion Analysis Settings workspace for the TML with Entity Key 6225073, which is linked to the non-piping asset with Entity Key 2509505.
tm-piping/asset/64263085162/tml/64263438232/settings	The Corrosion Analysis Settings workspace for the TML with Entity Key 64263438232, which is linked to the piping asset with Entity Key 64263085162.

TM System Code Tables

The following table lists the System Code Tables used to support various functions throughout Thickness Monitoring.

Table ID	Table Description	Usage
CITP	Corrosion Inspection Type	Populates the Corrosion Inspection Type field in Corrosion Analysis Settings. You can modify the System Codes in this System Code Table if you want to use custom TML Analysis Types.
CRAM	Corrosion Analysis Methods	Unknown
DPAC	Datapoint Access	Populates the Access field in TMLs.
DPCN	Datapoint Condition	Unknown
DPCR	Datapoint Corrosion Analysis Methods	Populates the Corrosion Rate Options in Corrosion Analysis Settings.
DPIN	Datapoint Insulation	Unknown
DPTP	Datapoint Type	Unknown
DSCD	Design Code	Populates the Design Code list in TMLs.
INST	Inspection Status Code	Unknown
INSM	Inspection Interval Types	Unknown
MI_ASSET_TYPE	Asset Type	Populates the Asset Type list in Thickness Monitoring Rules Lookup records.
MI_DLG_ASSET_TYPE	Datalogger Mapping Asset Type	Populates the Asset Type list in Datalogger Mapping records.
MI_MEAS_STAT_IND_BASIS	Measurement Status Indicator Basis	Populates the Measurement Status Indicator Basis field of Thickness Measurements records.
MI_MIN_THICKNESS_TYPE	Minimum Thickness Type	Populates the Minimum Thickness Type field in the Thickness Measurement Location.
MI_PIPE_MOVE_TYPES	Piping Movement Types	Populates the Movement Type list in the Pipe Rotation/Flip dialog.

Table ID	Table Description	Usage
MI_PIPE_WHAT_IF_TYPES	What If Types	Populates the What-If Method field of Pipe Rotation Event records.
MI_RESOURCE_ROLE	List of user roles	Populates the Role list in Resource Role records.
MI_STATUS_INDICATOR	TML Status Indicator	Populates the Status Indicator list in TMLs.
MI_TML_GROUP_BAND_TYPES	Piping Band Types	Populates the Piping Band Type field of TML Group records.
MI_TML_GROUP_COMP_TYPES	Piping Component Types	Populates the Piping Component Type field of TML Group records.
MI_TML_GROUP_TYPES	TML Group Types	Populates the TML Group Type field of TML Group records.
PIPFMU	Pipe Formula	Populates the Formula Classification list in Thickness Monitoring Rules Lookup records.
PVFMU	Pressure Vessel Formula	Populates the Formula Classification list in Thickness Monitoring Rules Lookup records.
SLCR	Straight Line Corrosion Methods	Unknown
T_MIN_CUSTOM_EQUATIONS	T-Min Calculator Custom Equations	Unknown.
STCR	Statistical Corrosion Methods	Unknown
TNKT	Tank Type	Populates the Component Type list in Thickness Monitoring Rules Lookup records.
VSTP	Vessel Type	Populates the Component Type list in Thickness Monitoring Rules Lookup records.

Other standard System Code Tables, such as UOME, MATG, and MATL, are also used in Thickness Monitoring.

TM Site Filtering

All of the families included in the Thickness Monitoring module employ the APM **Site** Control. This means that you can access or modify only the records in TM that are assigned to the same site to which you are assigned.

Tip: For more information, refer to the Site Filtering section of the documentation.

Example: Viewing TMLs

Consider an organization that has three sites, Site X, Site Y, and Site Z.

- TML A: Assigned to Site X
- TML B: Assigned to Site Y
- TML C: Assigned to Site Z

- TML D: No site assigned (global record)

Note: A global record in TM only occurs if there was an error in the data load or if the site location was changed by a Super User. Global records are not recommended Best Practices in TM.

Scenario 1: User assigned to only Site X

When this user accesses the TMLs from an analysis, he or she will see:

- TML A
- TML D

Scenario 2: User assigned to both Site X and Site Y

When this user accesses the TMLs from an analysis, he or she will see:

- TML A
- TML B
- TML D

Scenario 3: Super User

When this user accesses the TMLs from an analysis he or she will see:

- TML A
- TML B
- TML C
- TML D

Family Field Descriptions

Thickness Monitoring Analyses, Corrosion Analysis Settings, and Tasks

The following tables provide lists of various fields that are defined for the Asset Corrosion Analysis, TML Corrosion Analysis, and Corrosion Analysis Settings families in the baseline APM database. Depending on how your system has been configured, additional fields may be available in the families, and some fields may not behave exactly as described in the table.

Note: Although the fields are listed in alphabetical order in the tables, they will appear in a different order in the application. This list is not comprehensive. Baseline fields that are not displayed in the application are omitted. Certain datasheets may be divided into tabs.

This family is enabled for site filtering, which means that records in this family can be assigned to a specific site and will only be accessible to users who are assigned to the same site and have the appropriate license and family privileges. For more information, refer to the [Sites](#) section of the documentation.

Asset Corrosion Analysis

Each Asset Corrosion Analysis contains read-only fields that store calculations and summary information. This data is derived from the TML Corrosion Analyses that are linked to the TMLs for the asset or TML Group. The following table provides an alphabetical list of the fields that are visible on the tabs of an Asset Corrosion Analysis datasheet.

Field	Data Type	Description	Behavior and Usage
Analysis ID	Character	Identifies the Asset Corrosion Analysis.	<p>Always disabled.</p> <p>The Analysis ID is created automatically, and consists of the ID from the related asset or TML Group, the Analysis Type, and the text Corrosion Analysis.</p>
Analysis Required	Boolean	When selected, indicates that data has changed such that the analysis must be recalculated.	<p>Always disabled.</p> <p>The check box in this field is selected automatically by Thickness Monitoring. It is cleared when the analysis is calculated.</p>
Asset Calc Adjusted Next Insp Date	Date	Specifies the date of the next required inspection of the asset or TML Group, based on the Asset Average Corrosion Rate.	<p>Always disabled.</p> <p>This field is populated with the most conservative (i.e., earliest) date from the Asset Average Corrosion Rate Next Inspection Date fields in the TML Corrosion Analyses linked to the analysis.</p> <p>This field is populated only if the Controlling Corrosion Rate setting in the related Corrosion Analysis Settings has been set to Average or Formula, and the Apply CCR to TML Rem Life Next Insp Date Calc check box was selected at the same time.</p>

Field	Data Type	Description	Behavior and Usage
Asset Calc Adjusted Remaining Life	Numeric	Specifies the remaining life of the asset or TML Group, based on the Asset Average Corrosion Rate.	<p>Always disabled.</p> <p>This field is populated with the most conservative (i.e., lowest) value from the Asset Average Corrosion Rate Remaining Life fields in the TML Corrosion Analyses linked to the analysis.</p> <p>This field is populated only if the Controlling Corrosion Rate setting in the related Corrosion Analysis Settings has been set to Average or Formula, and the Apply CCR to TML Rem Life Next Insp Date Calc check box was selected at the same time.</p>
Asset Calc Adjusted Retire Date	Date	Specifies the recommended retirement date for the asset or TML Group, based on the Asset Average Corrosion Rate.	<p>Always disabled.</p> <p>This field is populated with the most conservative (i.e., earliest) date from the Asset Average Corrosion Rate Retirement Date fields in the TML Corrosion Analyses linked to the analysis.</p> <p>This field is populated only if the Controlling Corrosion Rate setting in the related Corrosion Analysis Settings has been set to Average or Formula, and the Apply CCR to TML Rem Life Next Insp Date Calc check box was selected at the same time.</p>
Asset Calculated Next Insp Date	Date	Specifies the date of the next required inspection of the asset or TML Group.	<p>Always disabled.</p> <p>This field is populated with the most conservative (i.e., earliest) date from the Scheduled Next Inspection Date fields in the TML Corrosion Analyses linked to the analysis.</p>

Field	Data Type	Description	Behavior and Usage
Asset Calculated Remaining Life	Numeric	Specifies the remaining life of the asset or TML Group.	Always disabled. This field is populated with the most conservative (i.e., lowest) value from the Remaining Life fields in the TML Corrosion Analyses linked to the analysis.
Asset Calculated Retire Date	Date	Specifies the recommended retirement date for the asset or TML Group.	Always disabled. This field is populated with the most conservative (i.e., earliest) date from the Retirement Date fields in the TMLs linked to the analysis.
Average Corrosion Rate	Numeric	Specifies the average rate at which the asset or TML Group is corroding.	Always disabled. By default, this field is calculated by taking the sum of the Corrosion Rates for all TML Corrosion Analyses linked to the analysis, and dividing it by the number of linked TMLs. For TMLs with negative corrosion rates, the corrosion rates are replaced with zero for the purpose of calculation. The value in this field may change based on the following options in the related Corrosion Analysis Settings: <ul style="list-style-type: none"> • Safety Factor • Minimum Number of TMLs • Percentile
Average Corrosion Rate Standard Deviation	Number	Numeric	None.
Average Corrosion Rate TML's Used	Text	Stores a list of TMLs that were used for calculating the Average Corrosion Rate for the Asset Corrosion Analysis.	Always disabled. This list is used to construct the Based on list of TMLs that appear as links in the Summary section of the Analysis Output workspace for the asset or TML Group.

Field	Data Type	Description	Behavior and Usage
Controlling Corrosion Rate	Numeric	Specifies the corrosion rate of the asset or TML Group.	Always disabled. This field is determined using the corrosion rates that exist for the TMLs linked to the analysis, and the Controlling Corrosion Rate option (Average, Formula, or Maximum) selected in the related Corrosion Analysis Settings.
Corrosion Inspection Type	Character	Specifies the type of inspection (UT, RT, or TML) for the Asset Corrosion Analysis.	Always disabled. This field is populated automatically based on the related Corrosion Analysis Settings. Only data from linked TML Corrosion Analyses with a Corrosion Inspection Type that matches this field will be used with this analysis.
Estimated Remaining Life	Numeric	Specifies the remaining life of the asset or TML Group.	Always disabled. In the related Corrosion Analysis Settings, if the Apply CCR to TML Rem Life Next Insp Date Calc check box is selected, this field is populated with the value in the Asset Calc Adjusted Remaining Life field. Otherwise, this field is populated with the value in the Asset Calculated Remaining Life field.
Last Date / Time Analysis Calculated	Date	Specifies the date and time when the analysis was last calculated.	Always disabled. This field is populated automatically when the analysis is calculated.
Maximum Allowable Working Pressure	Numeric	Specifies the Maximum Allowable Working Pressure for the asset or TML Group.	Always disabled. This field is populated with the most conservative (i.e., lowest) value from the Maximum Allowable Working Pressure fields in the TML Corrosion Analyses linked to the analysis.

Field	Data Type	Description	Behavior and Usage
Maximum Corrosion Rate	Numeric	Specifies the highest rate at which the asset or TML Group is corroding.	Always disabled. This field is populated with the highest rate from the Corrosion Rate fields in the TML Corrosion Analyses linked to the analysis.
Maximum Historical Corrosion Rate	Numeric	Specifies the highest corrosion rate that has ever been calculated for any TML that is linked to analysis.	Always disabled. When the analysis is recalculated, this field is only updated if the value in the Controlling Corrosion Rate field for any TML Corrosion Analysis linked to the analysis exceeds the current value of this field. If the value in this field is exceeded by the Controlling Corrosion Rate from multiple TML Corrosion Analyses, only the highest value is used to populate this field.
Projected T-min Date	Date	Specifies the recommended retirement date for the asset or TML Group.	Always disabled. In the related Corrosion Analysis Settings, if the Apply CCR to TML Rem Life Next Insp Date Calc check box is selected, this field is populated with the value in the Asset Calc Adjusted Retire Date field. Otherwise, this field is populated with the value in the Asset Calculated Retire Date field.
Scheduled Next Date Asset	Date	Specifies the date of the next required inspection of the asset or TML Group.	Always disabled. In the related Corrosion Analysis Settings, if the Apply CCR to TML Rem Life Next Insp Date Calc check box is selected, this field is populated with the value in the Asset Calc Adjusted Next Insp Date field. Otherwise, this field is populated with the value in the Asset Calculated Next Insp Date field.

Field	Data Type	Description	Behavior and Usage
Statistical Corrosion Rate	Numeric	Specifies an average corrosion rate that is calculated after eliminating certain TMLs that are identified as statistical outliers.	Always disabled. This field is calculated by performing a statistical analysis of the Corrosion Rates for all TML Corrosion Analyses linked to the analysis. For TMLs with negative corrosion rates, the corrosion rates are replaced with zero (for the purpose of calculation).
Statistical Corrosion Rate TMLs Used	Text	Stores a list of TMLs that were used for calculating the Statistical Corrosion Rate for the Asset Corrosion Analysis.	Always disabled.
Archived By	Text	Specifies the user who archived the analysis.	Always disabled. This field is populated automatically on the Archival of the TM analysis.
Archived Date	Date	Specifies the date and time when the analysis was archived.	This field is populated automatically when the analysis is archived.

TML Corrosion Analysis

For each TML linked to an asset or TML Group, a TML Corrosion Analysis is created. Fields in the TML Corrosion Analysis are read-only and are updated based on calculations for the TML and any related Thickness Measurements. The following table provides an alphabetical list of the fields that are visible on the TML Corrosion Analysis datasheet.

Field	Data Type	Description	Behavior and Usage
Alert Level	Numeric	Indicates the TML alert level, based on the Wall Ratio.	This field is always disabled.
Allowable Measurement Variance Applied	Boolean	When selected, indicates that the Allowable Measurement Variance has been used to determine the Short Term Corrosion Rate.	This field is always disabled. The check box in this field is selected automatically if the Allowable Measurement Variance has been used to calculate the value in the Short Term Corrosion Rate field.

Field	Data Type	Description	Behavior and Usage
Analysis ID	Character	Identifies the TML Corrosion Analysis.	Always disabled. The Analysis ID is created automatically, and consists of the ID of the TML, the Corrosion Inspection Type, and the text Corrosion Analysis.
Analysis Required	Boolean	When selected, indicates that data has changed such that the analysis must be recalculated.	Always disabled. The check box in this field is selected automatically by Thickness Monitoring. It is cleared when the analysis is calculated.
Asset Average Corrosion Rate	Numeric	Specifies the average corrosion rate for the asset or TML Group, calculated using the Controlling Corrosion Rate from all linked TML Corrosion Analyses.	Always disabled. This field is populated only if the Controlling Corrosion Rate setting in the related Corrosion Analysis Settings has been set to Average or Formula, and the Apply CCR to TML Rem Life Next Insp Date Calc check box was selected at the same time.
Asset Average Corrosion Rate Next Inspection Date	Date	Specifies the date of the next required inspection, based on the Asset Average Corrosion Rate Remaining Life.	Always disabled. This field is populated only if the Controlling Corrosion Rate setting in the related Corrosion Analysis Settings has been set to Average or Formula, and the Apply CCR to TML Rem Life Next Insp Date Calc check box was selected at the same time.
Asset Average Corrosion Rate Remaining Life	Numeric	Specifies the remaining life for the TML, based on the Asset Average Corrosion Rate.	Always disabled. This field is populated only if the Controlling Corrosion Rate setting in the related Corrosion Analysis Settings has been set to Average or Formula, and the Apply CCR to TML Rem Life Next Insp Date Calc check box was selected at the same time.

Field	Data Type	Description	Behavior and Usage
Asset Average Corrosion Rate Retirement Date	Date	Specifies the recommended retirement date for the TML, based on the Asset Average Corrosion Rate Remaining Life.	Always disabled. This field is populated only if the Controlling Corrosion Rate setting in the related Corrosion Analysis Settings has been set to Average or Formula, and the Apply CCR to TML Rem Life Next Insp Date Calc check box was selected at the same time.
Base Measurement Date	Date	Specifies the date the Thickness Measurement used for the Base Measurement Value was taken.	Always disabled. If the Base Measurement Value field is populated, this field is populated with the Measurement Taken Date for the Thickness Measurement used as the Base Measurement.
Base Measurement Value	Numeric	Specifies the value of the Thickness Measurement that was recorded first based on the value in the Measurement Taken Date field.	Always disabled. This field is populated when at least one Thickness Measurement has been recorded for the TML.
Corrosion Inspection Type	Character	Specifies the type of inspection (UT, RT, or TML) for the TML Corrosion Analysis.	Always disabled. This field is populated automatically based on the related Corrosion Analysis Settings.

Field	Data Type	Description	Behavior and Usage
Corrosion Rate	Numeric	Specifies the maximum corrosion rate of the calculated corrosion rates selected in the related Corrosion Analysis Settings.	<p>Always disabled.</p> <p>This field is populated with the value of the highest calculated corrosion rate. Only the corrosion rates selected in the asset Corrosion Analysis Settings are calculated.</p> <p>In the Analysis Output section of the Analysis Overview workspace for a TML, this corresponds to the Controlling Corrosion Rate.</p> <p>If Thickness Measurements are not available and corrosion rates cannot be calculated, this field will be populated with the Minimum Corrosion Rate defined in the related Corrosion Analysis Settings.</p>
Custom Calculation A Corrosion Rate	Numeric	Specifies the corrosion rate determined by custom corrosion rate A, as defined in the TM Admin Preferences.	<p>Always disabled.</p> <p>The values in this table correspond to the baseline field and datasheet captions that exist for these fields. These captions are not dynamic based upon the label specified for the corrosion rates in the application settings. If you want these captions to match the custom labels that you have defined for these calculations, you will need to customize the captions via the Configuration Manager application.</p>

Field	Data Type	Description	Behavior and Usage
Custom Calculation A Loss	Numeric	Specifies the amount of corroded material calculated by custom corrosion rate A, as defined in the TM Admin Preferences.	<p>Always disabled.</p> <p>The values in this table correspond to the baseline field and datasheet captions that exist for these fields. These captions are not dynamic based upon the label specified for the corrosion rates in the application settings. If you want these captions to match the custom labels that you have defined for these calculations, you will need to customize the captions via the Configuration Manager application.</p> <p>This feature is only available in the on-premises version of APM.</p>
Custom Calculation B Corrosion Rate	Numeric	Specifies the corrosion rate determined by custom corrosion rate B, as defined in the application settings.	<p>Always disabled.</p> <p>The values in this table correspond to the baseline field and datasheet captions that exist for these fields. These captions are not dynamic based upon the label specified for the corrosion rates in the application settings. If you want these captions to match the custom labels that you have defined for these calculations, you will need to customize the captions via the Configuration Manager application.</p> <p>This feature is only available in the on-premises version of APM.</p>

Field	Data Type	Description	Behavior and Usage
Custom Calculation B Loss	Numeric	Specifies the amount of corroded material calculated by custom corrosion rate B, as defined in the application settings.	<p>Always disabled.</p> <p>The values in this table correspond to the baseline field and datasheet captions that exist for these fields. These captions are not dynamic based upon the label specified for the corrosion rates in the application settings. If you want these captions to match the custom labels that you have defined for these calculations, you will need to customize the captions via the Configuration Manager application.</p> <p>This feature is only available in the on-premises version of APM.</p>
Custom Rate A Retirement Date	Date	Specifies the recommended retirement date for the TML, based on custom corrosion rate A.	<p>Always disabled.</p> <p>This field is determined using the value in the Custom Calculation A Corrosion Rate field.</p> <p>This feature is only available in the on-premises version of APM.</p>
Custom Rate B Retirement Date	Date	Specifies the recommended retirement date for the TML, based on custom corrosion rate B.	<p>Always disabled.</p> <p>This field is determined using the value in the Custom Calculation B Corrosion Rate field.</p> <p>This feature is only available in the on-premises version of APM.</p>
Factor Remaining Life Date	Date	Specifies a date based on the Remaining Life Factor in the related Corrosion Analysis Settings.	<p>Always disabled.</p> <p>When the associated TML is below T-Min, this field is populated with the value in the Last Measurement Date field.</p> <p>When the associated TML is not below T-Min, a calculation is used to determine the date with which this field is populated.</p>

Field	Data Type	Description	Behavior and Usage
Interval Next Inspection Date	Date	Specifies the date of the next required inspection for the TML.	Always disabled. This field is populated with a date based on the Default Inspection Interval in the related Corrosion Analysis Settings.
Last Measurement Date	Date	Specifies the date the Thickness Measurement used for the Last Measurement Value was taken.	Always disabled. If the Last Measurement Value field is populated, this field is populated with the Measurement Taken Date for the Thickness Measurement used as the Last Measurement.
Last Measurement Value	Numeric	Specifies the value of the Thickness Measurement that was recorded last based on the value in the Measurement Taken Date field.	Always disabled.
Least Squares Corrosion Rate	Numeric	Specifies a value that represents the corrosion rate that was determined using the Least Squares linear regression method. Note: The Least Squares method plots the thickness measurements for the TML and then draws a line that minimizes the sum of the squares of the offsets of the datapoints. The Least Squares Corrosion Rate represents the slope of the line on the plot.	Always disabled. This field is populated only if the Least Squares option for the Corrosion Rate Options setting is selected in the related Corrosion Analysis Settings.
Least Squares Retirement Date	Date	Specifies the recommended retirement date for the TML, based on the Least Squares Corrosion Rate.	Always disabled. This field is populated only if the Least Squares option for the Corrosion Rate Options setting is selected in the related Corrosion Analysis Settings.

Field	Data Type	Description	Behavior and Usage
Long Term Based On Minimum Measurement Interval	Boolean	Indicates when the Long Term Corrosion Rate is based on the Minimum Measurement Interval criteria.	Always disabled. This field is populated only if the Long Term Corrosion Rate was affected by the Minimum Measurement Interval preferences.
Long Term Corrosion Rate	Numeric	Specifies a value that represents the corrosion rate over the time between the first and last measurements.	Always disabled. The rate of corrosion between the Base Measurement Value and the Last Measurement Value is calculated using the following equation: Long Term Corrosion Rate = Long Term Loss / Long Term Interval This field is populated only if the Long Term option for the Corrosion Rate Options setting is selected in the related Corrosion Analysis Settings.
Long Term Loss	Numeric	Specifies the amount of material that was corroded over the time between the first and last measurements.	Always disabled. The amount of material corroded between the Base Measurement Value and the Last Measurement Value is calculated using the following equation: Long Term Loss = Base Measurement Value - Last Measurement Value This field is populated only if the Long Term option for the Corrosion Rate Options setting is selected in the related Corrosion Analysis Settings.
Long Term Retirement Date	Date	Specifies the recommended retirement date for the TML, based on the Long Term Corrosion Rate.	Always disabled. This field is populated only if the Long Term option for the Corrosion Rate Options setting is selected in the related Corrosion Analysis Settings.

Field	Data Type	Description	Behavior and Usage
Maximum Allowable Working Pressure	Numeric	Specifies the maximum pressure at which the associated asset is designed to operate.	Always disabled. This field is populated only if the TML contains the data necessary to perform the calculation, and only for assets or TML Groups that represent pipes or components that make up pipes.
Maximum Historical Corrosion Rate	Numeric	Specifies the highest corrosion rate calculated during the life of the TML. The Maximum Historical Corrosion Rate may come from any of the calculated corrosion rates.	Always disabled. When the analysis is recalculated, this field is only updated if one of the calculated corrosion rates that is selected in the related Corrosion Analysis Settings exceeds the current value in this field.
Minimum Corrosion Rate Used	Boolean	When selected, indicates the value in the Corrosion Rate field has been set to the Minimum Corrosion Rate value defined in the related Corrosion Analysis Settings.	Always disabled. The check box in this field is selected automatically when the Minimum Corrosion Rate value is used to populate the Corrosion Rate field.
Near Measurement Date	Date	Specifies the date the Thickness Measurement used for the Near Measurement Value was taken.	Always disabled. If the Near Measurement Value field is populated, this field is populated with the Measurement Taken Date for the Thickness Measurement used as the Near Measurement.
Near Measurement Value	Numeric	Specifies the value of the Thickness Measurement that was recorded next-to-last based on the value in the Measurement Taken Date field.	Always disabled. This field is populated when at least two Thickness Measurements have been recorded for the TML.
Projected T-min Date	Date	Specifies the date when the TML will reach its minimum thickness.	Always disabled. This field is calculated using the current rate of corrosion and the T-Min value for the TML.

Field	Data Type	Description	Behavior and Usage
Remaining Life	Numeric	Specifies in the months the remaining life of the TML after the date of the last measurement recorded.	Always disabled. This field is calculated using the current rate of corrosion and the T-Min value for the TML.
Scheduled Next Inspection Date	Date	Specifies the date of the next suggested inspection of the TML.	Always disabled. If both the Interval Next Inspection Date and Factor Remaining Life Date fields are populated, this field will be populated with the most conservative (i.e., earliest) of the two dates. If only the Interval Next Inspection Date or Factor Remaining Life field is populated, this field will be populated with the date from that field. If neither the Interval Next Inspection Date or Factor Remaining Life fields are populated, this field will be populated with the date from the Projected T-Min Date field.
Short Term Based On Minimum Measurement Interval	Boolean	Indicates when the Short Term Corrosion Rate is based on the Minimum Measurement Interval criteria.	Always disabled. This field is populated only if the Short Term Corrosion Rate was affected by the Minimum Measurement Interval preferences.
Short Term Corrosion Rate	Numeric	Specifies a value that represents the corrosion rate over the time between the next-to-last and last measurements.	Always disabled. The rate of corrosion between the Near Measurement Value and the Last Measurement Value is calculated using the equation: Short Term Corrosion Rate = Short Term Loss / Short Term Interval This field is populated only if the Short Term option for the Corrosion Rate Options setting is selected in the related Corrosion Analysis Settings.

Field	Data Type	Description	Behavior and Usage
Short Term Loss	Numeric	Specifies the amount of material that was corroded over the time between the next-to-last and last measurements.	Always disabled. The amount of material that is corroded between the Near Measurement Value and the Last Measurement Value is calculated using the following equation: Short Term Loss = Near Measurement Value - Last Measurement Value This field is populated only if the Short Term option for the Corrosion Rate Options setting is selected in the related Corrosion Analysis Settings.
Short Term Retirement Date	Date	Specifies the recommended retirement date for the TML, based on the Short Term Corrosion Rate.	Always disabled. This field is populated only if the Short Term option for the Corrosion Rate Options setting is selected in the related Corrosion Analysis Settings.
Verify Measurements	Character	When the value in this field is Yes, indicates that linked Thickness Measurements require manual verification.	Always disabled. This field is populated automatically if the Measurement Value field in linked Thickness Measurements requires manual verification based upon the Corrosion Rate Variance validation.

Corrosion Analysis Settings

Each Asset and TML Corrosion Analysis has a set of related Corrosion Analysis Settings. In the case of TML Corrosion Analyses, most values in the Corrosion Analysis Settings are inherited from the settings specified for the asset or TML Group to which the TML is linked. When you [create](#) or [modify Corrosion Analysis Settings](#), you are viewing a representation of the Corrosion Analysis Settings datasheet linked to the Asset or TML Corrosion Analysis.

It is recommended that you only access the datasheet in the context of the Corrosion Analysis Settings Workspace. The following table provides an alphabetical list of the fields that are visible on the Corrosion Analysis Settings workspace.

Corrosion Analysis Settings are accessible via an asset or TML Group, or via a TML. The table refers to the former as the asset level, and the latter as the TML level.

Field	Data Type	Description	Behavior and Usage
Allowable Measurement Variance	Numeric	Specifies a value for the amount of variation that is allowed between values in the Measurement Value fields of the two most recent Thickness Measurements linked to the related TML.	This field is used to validate measurement data. The value in this field is only considered if it is greater than 0.
Apply CCR to TML Rem Life Next Insp Date Calc	Boolean	When selected, indicates that Asset and TML Corrosion Analyses will use adjusted values for determining corrosion rate, remaining life, and next inspection dates.	This field is only considered if the Controlling Corrosion Rate is set to Average or Formula. When the check box in this field is selected, in an Asset Corrosion Analysis, the following occurs: <ul style="list-style-type: none"> The Asset Controlling Next Insp Date field is set to the value of the Asset Calc Adjusted Next Insp Date field. The Asset Controlling Remaining Life field is set to the value of the Asset Calc Adjusted Remaining Life field. The Asset Controlling Retire Date is set to the value of the Asset Calc Adjusted Retire Date field. When the check box in this field is selected, in a TML Corrosion Analysis the following fields are populated, if possible: <ul style="list-style-type: none"> Asset Average Corrosion Rate Asset Average Corrosion Rate Next Inspection Date Asset Average Corrosion Rate Remaining Life Asset Average Corrosion Rate Retirement Date
Analysis ID	Character	Identifies the related TML Corrosion Analysis.	This field is disabled and populated with a value in the following format: <ID of the TML> - <the Corrosion Inspection Type> Corrosion Analysis.

Field	Data Type	Description	Behavior and Usage
Comments	Text	Stores comments.	This field is not visible at the TML level.
Controlling Corrosion Rate	Character	Specifies the method (Maximum, Average, or Formula) by which a corrosion rate will be calculated for the asset.	<p>This field is disabled at the TML level.</p> <p>Required.</p> <p>When Average is selected, in the related Asset Corrosion Analysis, the Controlling Corrosion Rate field will be populated with the value in the Average Corrosion Rate field. Additionally, when Average is selected, the following fields appear:</p> <ul style="list-style-type: none"> • Apply CCR to TML Rem Life Next Insp Date Calc • Safety Factor • Minimum Number of TMLs • Percentile <p>When Formula is selected, in the related Asset Corrosion Analysis, the Controlling Corrosion Rate field will be populated with the value in the Statistical Corrosion Rate field. Additionally, when Formula is selected, the Apply CCR to TML Rem Life Next Insp Date Calc field appears.</p> <p>When Maximum is selected, in the related Asset Corrosion Analysis, the Controlling Corrosion Rate field will be populated with the value in the Maximum Corrosion Rate field. By default, when you create Corrosion Analysis Settings, Maximum is selected.</p>

Field	Data Type	Description	Behavior and Usage
Corrosion Rate Options	Boolean	Indicates which corrosion rates will be calculated for the TML.	<p>This section is disabled at the TML level.</p> <p>The check boxes correspond to the following fields on the Corrosion Analysis Settings datasheet:</p> <ul style="list-style-type: none"> • Least Squares corresponds to Corrosion Rate Options - Least Square. • Short Term corresponds to Corrosion Rate Options - Short Term. • Long Term corresponds to Corrosion Rate Options - Long Term. <p>By default, the Short Term and Long Term check boxes are selected.</p> <p>If custom corrosion rates are enabled, additional check boxes will be visible that correspond to those corrosion rates. Custom corrosion rates are only available in the on-premises version of APM.</p> <p>Additionally, the check boxes determine the data that will be plotted on the TML Trends Graph.</p>
Corrosion Rate Variance	Numeric	Specifies a value for the amount of variation that is allowed between the Short Term Corrosion Rate in the related TML Corrosion Analysis, and the Minimum Corrosion Rate.	<p>This field is used to validate measurement data.</p> <p>The value in this field is only considered if it is greater than 0.</p>
Default Inspection Interval	Numeric	Specifies in months the default interval for inspections for the TML.	<p>This field is used to populate the Interval Next Inspection Date field in the related TML Corrosion Analysis.</p>

Field	Data Type	Description	Behavior and Usage
Default T-Min	Numeric	Specifies the default minimum thickness value for calculations in the related corrosion analysis.	<p>This field is disabled at the TML level.</p> <p>If the related TML Corrosion Analysis has no value in the Minimum Thickness field, the value in this field is used instead.</p> <p>By default, this field is 0.</p>
Inspection Interval Options	Boolean	<p>When selected, indicate that Remaining Life Factor and Default Inspection Interval should be used to determine the Factor Remaining Life Date and Interval Next Inspection Date, respectively. Additionally, this determines how Scheduled Next Inspection Date will be calculated for the related corrosion analysis.</p>	<p>This field is disabled at the TML level.</p> <p>The check boxes correspond to the following fields on the Corrosion Analysis Settings datasheet:</p> <ul style="list-style-type: none"> • Factor Remaining Life corresponds to Inspection Interval Options - Factor Remaining Life. • Inspection Interval corresponds to Inspection Interval Options - Inspection Interval. <p>When the Factor Remaining Life check box is selected, the Remaining Life Factor field is used to calculate the Factor Remaining Life Date field in the related TML Corrosion Analysis.</p> <p>When the Inspection Interval check box is selected, the Default Inspection Interval field is used to calculate the Interval Next Inspection Date field.</p>
Minimum Corrosion Rate	Numeric	Specifies the default minimum corrosion rate value for calculations in the related corrosion analysis.	If a corrosion rate cannot be determined in the related corrosion analysis, the value in this field is used instead.

Field	Data Type	Description	Behavior and Usage
Minimum Number of TMLs	Numeric	Specifies the minimum number of TMLs that must be used to calculate the Average Corrosion Rate when the Percentile field is less than 100.	<p>This field is only considered if the Controlling Corrosion Rate is set to Average.</p> <p>When the value in the Percentile field excludes TMLs from being used to calculate the Average Corrosion Rate, the value in this field ensures a minimum number of TMLs are still used to make the calculation.</p> <p>For example, assume the Minimum Number of TMLs field was set to 20. If the value in the Percentile field determined that only the 10 TMLs with the highest rate of corrosion linked to an asset should be used to calculate Average Corrosion Rate, the value in the Minimum Number of TMLs field would take precedence, and the 20 TMLs highest rate of corrosion would be used instead.</p> <p>By default, the value in this field is 1.</p>

Field	Data Type	Description	Behavior and Usage
Percentile	Numeric	Specifies what percentage of TMLs linked to an asset should be used to calculate Average Corrosion Rate.	<p>This field is only considered if the Controlling Corrosion Rate is set to Average.</p> <p>This field determines the percentage of TMLs linked to an asset or TML Group that will be used to calculate the Average Corrosion Rate for the related Asset Corrosion Analysis. The TMLs used will always be those with the most conservative (highest) corrosion rates.</p> <p>For example, if you have an asset with 50 linked TMLs, and the Percentile field is set to 20, the 10 TMLs with the highest rate of corrosion will be used to calculate the Average Corrosion Rate for the asset.</p> <p>By default, value in this field is 100, which means all TMLs linked to an asset are used to calculate the Average Corrosion Rate.</p>
Piping Asset	Boolean	When selected, indicates that the Asset is a Piping Asset and suitable for Piping Rotation.	<p>This field is always disabled at the child level of the parent asset.</p> <p>This field is enabled only if you enable the piping rotation workflow from the TM Admin Preferences page.</p>
Remaining Life Critical Number of TMLs	Numeric	Obsolete: This field is no longer used during the calculation of remaining life for an asset.	N/A
Remaining Life Factor	Numeric	Specifies a value that is used to multiply the Remaining Life in the related TML Corrosion Analysis.	<p>This field is disabled at the TML level.</p> <p>The value in this field must be greater than 0 and less than or equal to 1. It is only used to multiply the value in the Remaining Life field in the related TML Corrosion Analysis if the Factor Remaining Life check box is selected.</p>

Field	Data Type	Description	Behavior and Usage
Safety Factor	Numeric	Specifies a value that is used to multiply the calculated average in order to determine the Average Corrosion Rate.	<p>This field is only considered if the Controlling Corrosion Rate is set to Average.</p> <p>The value in this field is used as a multiplier for the Average Corrosion Rate in an Asset Corrosion Analysis, which determines the displayed value in the Average Corrosion Rate field.</p> <p>By default, the value in this field is 1, which means the actual Average Corrosion Rate will be used.</p>
Std Deviation Factor	Numeric	Specifies a value that is used to determine outliers when calculating Statistical Corrosion Rate.	<p>This field is only considered if the Controlling Corrosion Rate is set to Formula.</p> <p>The value in this field is used as a multiplier for TML CR SD when calculating the Statistical Corrosion Rate in the related Asset Corrosion Analysis.</p> <p>By default, the value in this field is 2.</p>
Use Minimum Corrosion Rate	Boolean	When selected, indicates that when the calculated corrosion rate for a TML is less than the Minimum Corrosion Rate, the Minimum Corrosion Rate will be used for calculations instead.	<p>This field is disabled at the TML level.</p> <p>When the check box is selected, the value in the Minimum Corrosion Rate field will be used for calculations in place of the value in the Corrosion Rate field in the related TML, if that value is less than the Minimum Corrosion Rate.</p> <p>Note: If the Use Minimum Corrosion Rate check box is cleared and only one Thickness Measurement is linked to a TML, the Minimum Corrosion Rate will be used.</p>

Thickness Monitoring Tasks

The following table lists the Thickness Monitoring Task fields that are populated automatically when a Thickness Monitoring Task record is created. The following table provides an alphabetical list of the fields visible on the Thickness Monitoring Task datasheet.

Field	Data Type	Description	Behavior and Usage
Asset ID	Character	Specifies a unique ID for the asset.	The Record ID of the Equipment or TML Group record to which the Thickness Monitoring Task record is linked.
Coverage	Numeric	Specifies the percentage of the asset to be inspected.	By default, this field is set to 0.
Desired Interval	Numeric	Specifies the desired time between inspections.	By default, this field is set to 0.
Equipment Technical Number	Character	Specifies a unique ID for the asset that is recognized by operations and inspection personnel.	The value in this field is typically from a piping and instrumentation diagram.
Last Date	Date	Specifies the date on which the asset was last inspected.	This field is populated with the date the asset or TML Group was last inspected.
Max Date	Date	Specifies the date on which the maximum interval will be reached.	This field is populated with the date in the Calculated Date field in the linked Asset Corrosion Analysis.
Max Interval	Numeric	Specifies the maximum time between inspection events.	By default, this field is set to 0.
Min Date	Numeric	Specifies the date on which the asset may become eligible for inspection.	This field is populated with the date in the Calculated Date field in the linked Asset Corrosion Analysis.
Min Interval	Numeric	Specifies the minimum time between inspection events.	By default, this field is set to 0.
Modifiable	Boolean	Indicates that you have allowed this record to be modified by others.	By default, this field is False.
Next Date	Date	Specifies the date on which the next inspection must be performed.	This field is populated with the date in the Asset Controlling Next Insp Date field in the linked Asset Corrosion Analysis.

Field	Data Type	Description	Behavior and Usage
Next Date Basis	Character	Specifies the driver of the next date.	Usually, the value for the driver in this field is a Code, a company policy, or based on Remaining Life calculations.
Reason	Text	Specifies why this work is being requested.	For example, a value in this field could be Defects found on asset.
Rejectable	Boolean	Indicates that this task can be rejected by the requested approver.	By default, this field is False.
Reoccurring	Boolean	Indicates that this is a repeating task.	By default, this field is False.
Task Description	Character	Specifies the work to be performed during the execution of the task.	For example a value in this field could be Insulation to be replaced.
Task ID	Character	Specifies a unique ID for the task.	This field is populated automatically when the Thickness Monitoring Task is created.
Task State	Character	Specifies the state of the task in the approval and execution process.	Usually, the states available in this field are created to support the workflow of the organization.
Task Type	Character	Specifies what inspection methodology should be used for this task.	For example, a value in this field could be Internal Inspection, or External Inspection.
Unconstrain Min/Max Dates	Boolean	Indicates that you will set the Max and Min Date fields manually.	By default, this field is False.

TML Groups, TMLs, and Measurements

The following tables provide a list of various fields that are defined for the TML Group, Thickness Measurement Location, and Thickness Measurement families in the baseline APM database. Depending on how your system has been configured, additional fields may be available in the families, and some fields may not behave exactly as described in the table.

Note: Although the fields are listed in alphabetical order in the tables, they will appear in a different order in the application. This list is not comprehensive. Baseline fields that are not displayed in the application are omitted. Certain datasheets may be divided into sections.

This family is enabled for site filtering, which means that records in this family can be assigned to a specific site and will only be accessible to users who are assigned to the same site and have the appropriate license and family privileges. For more information, refer to the [Sites](#) section of the documentation.

TML Group

Field	Data Type	Description	Behavior and Usage
Comments	Text	Stores comments.	None
Component ID	Character	Specifies a unique ID for the component.	The value in this field must be entered when a component is created, and must be unique within the asset.
Corrosion Group	Character	Specifies a system level identifier.	The value in this field appears as text following the TML Group ID.
Description	Character	Specifies a short description of the TML Group.	None.
Distance from Inlet	Number	Specifies a value that indicates the distance of the band from the inlet of the component.	This field is populated automatically from the value that you have entered when creating the band.
Drawing Number	Character	Specifies a unique ID for the Isometric Drawing, PFD or P&ID.	The value in this field helps the inspector identify where the TML Group is located on an asset.
Line Class	Character	Specifies a class (Class 1, Class 2, Class 3, or Injection Point) that is used to determine inspection intervals based on API 570.	This field is relevant only to Piping assets.
Material Grade	Character	Specifies a Material Grade for the TML Group.	The list of valid values for this field comes from the Materials of Construction family Used for determining Allowable Stress.
Material Specification	Character	Specifies a Material Specification for the TML Group.	The list of valid values for this field comes from the Materials of Construction family Used for determining Allowable Stress.
Material Type	Character	Specifies a Material Type for the TML Group.	The list of valid values for this field comes from the Materials of Construction family Used for determining Allowable Stress.

Field	Data Type	Description	Behavior and Usage
Number of Positions	Number	Specifies the number of TML positions on a band.	This field is always disabled. This field is populated automatically from the value that you have entered when creating the band.
Operating Pressure	Number	Specifies an Operating Pressure for the TML Group.	The value in this field should be less than the Design Pressure of the component.
Operating Temperature	Number	Specifies an Operating Temperature for the TML Group.	The value in this field should be less than the Design Temperature of the component.
Piping Band ID	Character	Specifies a unique ID for the band.	The value in this field must be entered when a band is created, and must be unique within the component.
Piping Band Type	Character	Specifies the type of band (that is Mirror, Center, Odd, or Extradados).	This field is populated automatically from the value that you have entered when creating the band. This field is populated by the MI_TML_GROUP_BAND_TYPES System Code Table. Note: The Extradados Band Type is only available when the Piping Component Type is either Bent Elbow or Mitered Elbow.
Piping Component Type	Character	Specifies the type of Piping Component (that is Straight Spool, Bent Elbow, or Mitered Elbow).	This field is always disabled. This field is populated automatically from the value that you have entered when creating the component. This field is populated by the MI_TML_GROUP_COMP_TYPES System Code Table.
System Type	Character	Specifies a classification for a TML Group (i.e., Floor of a Tank).	None

Field	Data Type	Description	Behavior and Usage
TML Group ID	Character	Specifies a unique ID for the TML Group.	The value in this field is populated automatically when the TML Group is created.
TML Group Type	Character	Specifies the type of TML Group (that is Piping Component or Piping Band).	This field is always disabled. This field is populated automatically based on whether you are creating a Piping Component or a Piping Band. This field is populated by the MI_TML_GROUP_TYPES System Code Table.

Thickness Measurement Location

Thickness Measurement Location records contain various fields that store information to identify a TML. When you create a new TML, you will need to supply information in some of these fields. The values in other fields will be populated or calculated automatically based on other values in the TML and related values.

Field	Data Type	Description	Behavior and Usage
Access	Character	Specifies a special requirement (Man Lift, Ladder, or Scaffold) for how a location must be accessed.	A value should be selected in this field when the TML is created, but can be modified later.
Additional Thickness	Number	Specifies the thickness that is over that which is required to prevent loss of containment plus corrosion allowance.	None.
Allowable Stress	Number	Specifies a value that represents the maximum amount of pressure that can safely be withstood at a given TML.	This field is enabled only if the Override Allowable Stress check box is selected. Otherwise, this field is disabled and populated automatically.
Apex Angle	Number	The angle of any conical section of the asset.	The value in this field is used for conical T-Min calculations.
Calculated	Number	Stores the value after the T-Min is calculated for the TML.	This field is automatically populated when the T-Min is calculated for the first time. If you change the value in the Minimum Thickness Type field to Calculated, then the value from this field will be populated to the Minimum Thickness field.

Field	Data Type	Description	Behavior and Usage
Code Year (Allowable Stress Lookup)	Character	Specifies the year in which the Design Code was defined or updated.	This field appears as a list retrieved from the Piping Stress, PV Stress or Tank Stress reference table based on the value in the Design Code field. The value in this field is used to populate the Allowable Stress field.
Code Year (T-Min Formula)	Character	Specifies the year in which the Design Code was defined or updated.	The Code Year (T-Min Formula) field is populated with a list of years that exist in Thickness Monitoring Rules Lookup records and correspond to the value in the Design Code field in the TML. The value in the Code Year (T-Min Formula) field is used for determining which formula will be used for calculating the T-Min and Maximum Allowable Working Pressure values.
Component Type	Character	Specifies the type of component being inspected.	The value in this field is used to populate the Allowable Stress field.
Corrosion Allowance	Number	Specifies the additional thickness built in by design to allow for a specific expected corrosion rate and usable life of the asset.	The value in this field is used to determine the remaining life of the asset.
Course Height	Number	Specifies the height of each shell course on an AST.	The value in this field allows the user to calculate the static head pressure for each shell course and thus the minimum allowable thickness needed.
Course Number	Number	Specifies the shell course on an AST being inspected or to which the TML is assigned.	For Tanks of the type Welded Shell, the value in this field is used to calculate the Allowable Stress field.

Field	Data Type	Description	Behavior and Usage
Design Code	Character	Specifies a design code associated with the TML that is used for calculating T-Min.	This field appears as a list that is populated by the DSCD System Code Table. The value in this field is used to filter the list of values that appear in the Code Year (Allowable Stress Lookup) field. It is also used to determine the equipment type of a given Thickness Measurement Location. The MI_ASSET_TYPE System Code Table contains references to System Codes in the DSCD System Code Table.
Design Factor	Number	Specifies a factor used to calculate T-Min.	This field is a consideration of the design metal temperature (based on ambient temperatures), the maximum design temperature, the design specific gravity, the corrosion allowance (if any), and the seismic factor. The value in this field must be between 0 and 1. It will be rounded to 2 decimal places. The value in this field is used as an input for the T-Min Calculator only when Design Code is set to B31.8.
Design Pressure	Number	Specifies the maximum pressure at the TML.	This value is taken from the original design documents for the piece of equipment.
Design Temperature	Number	Specifies the maximum temperature at the TML.	This value is taken from the original design documents for the piece of equipment.
Dish Radius	Number	None.	None.
Distance From the Bottom	Number	Specifies a value that indicates how far the TML is from the bottom of the tank.	This field applies only to TMLs that are linked to assets or TML Groups that represent Tanks.

Field	Data Type	Description	Behavior and Usage
Excluded From Analysis	Boolean	Indicates whether the TML will be excluded from the Corrosion Analysis.	<p>This field is read-only in the Thickness Measurement Location and displays the value that is defined via the Exclude TMLs window.</p> <p>When this check box is selected, the TML will not be used when performing asset corrosion calculations, and the Scheduled Next Inspection Date, Projected T-Min Date, and Estimated Remaining Life for the TML will be set to null.</p> <p>In addition, the corrosion rates for the excluded TMLs will be calculated for the TML Corrosion Analysis, but will not be used to determine a corrosion rate for the Asset Corrosion Analysis.</p> <p>Only members of the MI Thickness Monitoring Inspector Security Group can exclude TMLs from an analysis.</p>
Fill Height	Number	Specifies the normal operating liquid height in the AST.	The value in this field may be used to calculate T-Min.
Floor Plate has Detection?	Boolean	Indicates whether or not the AST has a means to detect a leak.	The value in this field may be used to extend the recommended inspection intervals.
Floor Plate has Reinforced Lining?	Boolean	Indicates whether or not the AST has a lined and/or reinforced floor.	The value in this field may allow the user to specify a lower T-Min.
Head Diameter	Number	Specifies the diameter of a circular or cylindrical Head.	The value in this field is used for calculating T-Min.
Inside Diameter	Number	Specifies the diameter of a circular or cylindrical asset, measured using the inside wall.	The value in this field is used for calculating T-Min.
Inside Radius	Number	Specifies the radius of a circular or cylindrical asset, measured to the inside wall.	The value in this field is used for calculating T-Min.

Field	Data Type	Description	Behavior and Usage
Inspection Sequence Number	Number	Specifies a value that indicates the order in which a given TML will be inspected with respect to the other TMLs linked to the same asset or TML Group.	This field is used only to facilitate TML based inspection workflows, and is not used in any calculations.
Insulated Flag	Boolean	Indicates whether the asset or TML Group is insulated at the TML.	This check box should be selected if the equipment is insulated. This field is for reference only. It does not have any affect on calculations.
ISO Drawing Number	Character	Specifies a unique ID for the Isometric Drawing, PFD or P&ID.	This will help the inspector identify where a TML is located on an asset.
Joint Factor	Number	None.	None.
Knuckle Radius	Number	None.	None.
Location	Character	Specifies the location of the TML on the asset or component.	This field used to provide a description of the location on the asset or component. When creating a new TML, you should type a description that will help you and others locate this TML.
Material Grade	Character	Specifies the grade of material used for the TML.	This field appears as a list that is filtered based on the value in the Material Specification field as specified in the Piping Stress, PV Stress, or Tank Stress reference table. The value in this field is used to populate the Allowable Stress field.
Material Specification	Character	Specifies the industrial specification of the material used for the TML.	This field appears as a list that is filtered based on the value in the Design Code field as specified in the Piping Stress, PV Stress, or Tank Stress reference table. The value in this field is used to populate the Allowable Stress field.
Material Type	Character	Specifies the type of material used for the TML.	This field is used to provide a description of material used at the location on the asset or component.

Field	Data Type	Description	Behavior and Usage
Maximum Operating Fill Height	Number	Specifies the maximum fill height for the AST.	The value in this field is used for calculating T-Min on an AST.
Mechanical Allowance	Number	None.	None.
Minimum Tensile Strength	Number	None.	None.
Minimum Thickness	Number	Specifies the T-Min value for the TML, which is the minimum wall thickness allowed at the specific location. Typically, you will want to replace an asset or component before any of its TMLs reach the minimum thickness.	The value in this field can be entered manually , or it can be calculated on the T-Min Calculator workspace . If this field does not contain a value, a value of 0 will be used in any calculations that use the T-Min value.
Minimum Thickness Type (obsolete)	Character	Specifies how the T-Min value was obtained. This field is populated with one of the following values: <ul style="list-style-type: none"> • Calculated. • Nominal. • User Defined. 	This field is populated automatically only after the Minimum Thickness field has been populated.
Minimum Thickness Type	Character	Specifies how the T-Min value was obtained. This field is populated with System code table (MI_MIN_THICKNESS_TYPE) .	This field is populated automatically only after the Minimum Thickness field has been populated.
Minimum Yield Strength	Number	None.	None.
Nominal Thickness	Number	Specifies a value that is intended to represent the value of the first measurement recorded for a TML, if the base measurement is recorded from a design specification or other published standard.	The value in this field is populated automatically based on a specified Piping Nominal Diameter value. This value is used to create a Nominal Measurement for a piping asset.
Number of Readings	Number	Specifies the number of values that can be entered in the Readings field in Thickness Measurements that are linked to the TML.	This field accepts only whole number, values between 1 (one) and 26. The data entry grid that is available in the Readings field will have a number of rows based on the value in this field.

Field	Data Type	Description	Behavior and Usage
Outside Diameter	Number	Specifies the diameter of a circular or cylindrical asset, measured using the outside wall.	The value in this field is used for calculating T-Min . The value in this field is populated automatically based on a specified Piping Nominal Diameter value.
Outside Radius	Number	Specifies the diameter of a circular or cylindrical asset, measured to the outside wall.	The value in this field is used for calculating T-Min.
Override Allowable Stress	Boolean	Indicates that the Allowable Stress field has been modified manually.	When this check box is selected, the Allowable Stress field is enabled and a value can be entered manually.
Override Minimum Thickness Type	Boolean	This field stores whether the Minimum Thickness Type field has been overridden or not.	If this field check box is checked, you can select multiple options from the picklist in the Minimum Thickness Type field. The system auto-calculates the values for each selection. If the Minimum Thickness Type is set to a value other than User Defined, Minimum Thickness will be Disabled. If this field check box is unchecked, and you change the value in the Minimum Thickness field, then the Minimum Thickness Type will be set to User Defined. Note: If this field is set, the Minimum Thickness calculations will not be saved for that TML from the T-Min screen.
Piping Formula	Character	Specifies the B31.3 piping formula.	The values in this list are populated from the PIPFMU System Code Table. This field controls which B31.3 formula is used for the T-Min calculator.

Field	Data Type	Description	Behavior and Usage
Piping Nominal Diameter - DN	Number	Specifies a Nominal Diameter for piping.	<p>DN (Nominal Diameter) data is considered a dimensionless designator, meaning that it does not have an assigned unit of measure and is determined by ASME specifications. The value in this field is used to populate fields for Piping Nominal Diameter.</p> <p>When you select a value for either the Piping Nominal Diameter - NPS or the Piping Nominal Diameter - DN fields:</p> <ul style="list-style-type: none"> • A list of possible values is generated for the Schedule field in the Piping section of the TML datasheet. • After a value is selected for the Schedule field, the Pipe Properties reference table populates the Nominal Thickness and the Outside Diameter fields in the Design General section of the TML datasheet.

Field	Data Type	Description	Behavior and Usage
Piping Nominal Diameter - NPS	Number	Specifies a Nominal Pipe Size for piping.	<p>NPS (Nominal Pipe Size) considered a dimensionless designator, meaning that it does not have an assigned unit of measure and is determined by ASME specifications. The value in this field is used to populate fields for Piping Nominal Diameter.</p> <p>When you select a value for either the Piping Nominal Diameter - NPS or the Piping Nominal Diameter - DN fields:</p> <ul style="list-style-type: none"> A list of possible values is generated for the Schedule field in the Piping section of the TML datasheet. After a value is selected for the Schedule field, the Pipe Properties reference table populates the Nominal Thickness and the Outside Diameter fields in the Design General section of the TML datasheet.
Plate Thickness	Number	Specifies the thickness of the plates used to construct an AST.	The value in this field is used for determining nominal thickness for an AST.
Position	Number	Stores the position number currently occupied by a TML.	<p>This field is always disabled.</p> <p>This field is populated automatically after the band is created and during a rotation or flip.</p>
Previous Band	Character	Stores the Band ID of the band previously occupied by a TML.	<p>This field is always disabled.</p> <p>This field is populated automatically during a rotation or flip.</p>
Previous Position	Number	Stores the position number previously occupied by a TML.	<p>This field is always disabled.</p> <p>This field is populated automatically during a rotation or flip.</p>

Field	Data Type	Description	Behavior and Usage
Renew Historical Sequence Number	Number	Specifies a value that indicates the number of times a given Thickness Measurement Location has been renewed.	This field is read-only and contains no value if the Thickness Measurement Location has never been renewed.
Schedule	Character	Specifies a piping schedule for the TML.	The value in this field, along with the value in either the Piping Nominal Diameter - ND or the Piping Nominal Diameter - NPS field, uses the Pipe Properties reference table to populate the Nominal Thickness and the Outside Diameter fields in the Design General section of the TML datasheet.
Shell Type	Character	Specifies the geometry of the Shell.	The value in this field is used for calculating T-Min.
Specific Gravity	Number	Specifies the molecular weight of the representative fluid in an AST.	The value in this field is used to calculate: <ul style="list-style-type: none"> T-Min for an AST. Allowable Stress for tanks of the type, Annular Ring .
Status Changed By	Character	Specifies the name of the APM Security User who last changed the value in the Status Indicator field.	This field is always disabled. This field is populated automatically whenever the Status Indicator is changed. When a TML is created, this field is populated with the name of the Security User who created it.
Status Changed Date	Date	Specifies the date when the value in the Status Indicator field was last changed.	This field is always disabled. This field is populated automatically whenever the Status Indicator is changed. When a TML is created, this field is populated with the current date.

Field	Data Type	Description	Behavior and Usage
Status Indicator	Character	Specifies the status of the TML, either Active or Inactive.	<p>This field contains a list of values from the MI STATUS INDICATOR System Code Table. In the baseline APM database, the list contains the following values:</p> <ul style="list-style-type: none"> • Active. • Inactive. <p>When this value is modified, the Status Changed By and Status Changed Date will be updated automatically.</p> <p>When this field is set to Inactive, values will be deleted from the following fields in the linked TML Corrosion Analysis:</p> <ul style="list-style-type: none"> • Remaining Life. • Projected T-min Date. • Factor Remaining Life Date. • Interval Next Inspection Date. • Scheduled Next Inspection Date. <p>Additionally, an inactive TML will not be included in corrosion calculations for an Asset Corrosion Analysis.</p>
Tank Diameter	Number	Specifies the diameter of a tank.	<p>This value is only used for TMLs that are linked to assets or TML Groups that represent tanks or components of a tank.</p> <p>Note: If this field contains a value that is greater than 200, T-Min cannot be calculated for the TML.</p>
Tank Type	Character	Specifies the method of construction for an AST.	The value in this field will be used to calculate T-Min and Allowable Stress.
Temperature Factor	Number	None.	None.

Field	Data Type	Description	Behavior and Usage
TML Analysis Type	Character	<p>Specifies the type of analysis (UT, RT, or TML).</p> <p>The value used by the Asset Corrosion Analysis to determine how to group the analysis results. A value must be selected in this field when the Thickness Measurement Location is created.</p>	<p>This field is populated with a list of values that are stored in the Inspection Type field in the Corrosion Analysis Settings that are linked to the asset or TML Group to which the TML is linked. In the baseline database, these values are stored as System Codes in the System Code Table CITP (Corrosion Inspection Type). By default, this System Code Table contains three System Codes: UT, RT, and TML.</p> <ul style="list-style-type: none"> • UT (ultrasonic thickness) and RT (radiographic thickness) are provided for customers who want to classify TMLs according to inspection type and then perform calculations on each set. • TML is provided for customers who prefer to analyze all TMLs together.
TML Asset ID	Character	Specifies the ID of the Equipment or TML Group record for which the TML is created.	<p>This field is always disabled.</p> <p>This field is populated automatically after the TML is first saved based on the Component ID Field setting for the Equipment or TML Group family.</p>
TML Comment	Character	Stores descriptive information that is not recorded in another field in the TML.	None.
TML ID	Character	Specifies a unique ID for the TML.	The value in this field must be entered when a TML is created, and must be unique.
Vessel Type	Character	Specifies the geometry of the vessel.	The value in this field determines what formula is used when calculating T-Min.

Thickness Measurements

Thickness Measurements contain various fields that store information to identify a specific thickness reading at a TML. When you create a new Thickness Measurement, you will need to supply information in some of these fields. The values in other fields will be populated automatically based upon other values in the Thickness Measurement.

Field	Data Type	Description	Behavior and Usage
Historical Sequence Number	Number	Specifies a value that identifies the renewal sequence of the Thickness Measurement.	For example, if a Thickness Measurement Location has three Active Thickness Measurements, when the Thickness Measurement Location is renewed for the first time, the Historical Sequence Number of those three Thickness Measurements will be set to 1. If the Thickness Measurement Location is renewed again, the Historical Sequence Number of any Thickness Measurements that are Active at the time of the renewal will be set to 2.
Instrument Probe	Number	Specifies a value that uniquely identifies the specific probe that was used to collect the measurement value. This field is populated only when a measurement is recorded using a handheld device.	None.
Measurement Comment	Character	Specifies additional information about the measurement.	This field is used to store descriptive information that is not recorded in another field in the Thickness Measurement.
Measurement ID	Character	Specifies the Record ID of the Thickness Measurement.	The value from the Record ID field is copied to the Measurement ID field when the Thickness Measurement is saved. Note that if you modify the ID Template of the Thickness Measurement family and update existing Record IDs, values in the Measurement ID field will not be updated in existing Thickness Measurements until those measurements are saved.

Field	Data Type	Description	Behavior and Usage
Measurement Imported by Data Loader	Boolean	Indicates whether the Thickness Measurement is loaded by the data loader.	This field is populated with the value True if the Thickness Measurement record is loaded by the data loader. If the value in this field is True, duplicate validations are removed when the record is loaded through data loader.
Measurement Status Changed By	Character	Specifies the first and last names of the APM Security User who last changed the value in the Measurement Status Indicator field.	This value is populated from a list of System Codes in the MI_MEAS_STAT_IND_BASIS System Code Table whenever the value in the Measurement Status Indicator field is changed, either manually or automatically (for example, when the root Thickness Measurement Location is renewed).
Measurement Status Indicator	Character	Specifies whether the Thickness Measurement is Active or Inactive.	Thickness Measurements that are flagged as Inactive are not used for performing TML Corrosion Analysis calculations. When the value in this field is set to Inactive as a result of rotation or flip of a piping component, if the user performs an undo operation on the rotation or flip, the value in this field is set to null.

Field	Data Type	Description	Behavior and Usage
Measurement Status Indicator Basis	Character	Indicates the basis for which the value in the Measurement Status Indicator was changed to Inactive.	<p>This value is populated automatically from a list of System Codes in the MI_MEAS_STAT_IND_BASIS System Code Table whenever the value in the Measurement Status Indicator field is changed to Inactive.</p> <p>This field is populated when:</p> <ul style="list-style-type: none"> • TMLs are renewed • Piping components are rotated or flipped • A measurement is manually inactivated from the Measurement Status Indicator field • A nominal measurement is set to inactive after two actual measurements <p>Note: This field must not be included in data loader workbooks.</p>

Field	Data Type	Description	Behavior and Usage
Measurement Taken By	Character	Specifies the person who recorded the measurement value in the following format: <Last Name>, <First Name> ~ <User ID>	<p>The list in this field contains the names of individual(s) who have been granted the TM Technician role.</p> <p>When you create a Thickness Measurement, if you have been granted the TM Technician role, the value is set by default to your name. You can change the value by selecting another name in the list.</p> <p>The default rule on the Measurement Taken By field specifies that the list is restricted, meaning that you cannot type your own value in the list. If the default rule has been modified to make the list unrestricted, you will be able to type a value in this field, and save it with the Thickness Measurement.</p> <p>The Human Resource records used to populate this field are filtered based on the user's applied sites. If the Human Resource record is not associated with a specific user, the record is included by default.</p>
Measurement Taken Date	Date	Specifies the date that the measurement value was recorded.	This may be the date that the Thickness Measurement was created, or it may be a different date, particularly if the Thickness Measurement was created some time after the measurement was physically recorded.

Field	Data Type	Description	Behavior and Usage
Measurement Value	Number	Specifies the value, in inches, for a given thickness measurement.	<p>The Measurement Value represents the thickness of the asset or component at the TML on the Measurement Taken Date.</p> <p>The Measurement Value can be a reading that was taken physically or that was recorded based on a design code or specification. This field is populated automatically with the value in the Uncorrected Measurement field.</p>
Measurement Verified	Character	Specifies whether the Measurement Value has been manually verified.	<p>This field is populated with a list of System Codes in the MI_YES System Code Table.</p> <p>After the value in the Verify Measurement field has been set to Yes, this field should be set to Yes to indicate that the measurement data in question has been validated and corrected if needed.</p>
Nominal	Boolean	Indicates whether the measurement was taken physically (the check box is not selected) or recorded from another source, such as a published design specification (the check box is selected).	<p>All Nominal Thickness Measurements will be set automatically to Inactive after two subsequent Actual Thickness Measurements have been created. Thickness Measurements that are marked as Inactive will not be used for performing TML Corrosion Analysis calculations. This means that after two or more Actual Thickness Measurements exist, Nominal Thickness Measurements will no longer be used in calculations.</p>

Field	Data Type	Description	Behavior and Usage
Readings	Character	Specifies values that represent the readings that were collected for a given thickness measurement.	<p>The number of values that can be recorded in the Readings field corresponds to the value in the Number of Readings field in the Thickness Measurement Location to which the Thickness Measurement is linked.</p> <p>The Readings field provides access to an editable grid that contains one row per reading value that can be entered.</p> <p>After values have been entered in the Readings field in a given Thickness Measurement, the value in the Uncorrected Measurement field in that same measurement is calculated based on the Application Settings that have been defined for measurement readings.</p>
Readings Pass/Fail	Character	Specifies a value that indicates whether the values in the Readings field passed or failed evaluation based on the Reading Tolerance setting.	This field is populated with a list of System Codes in the MI_PASS_FAIL_ONLY System Code Table.
Status Changed Date	Date	Specifies the date that the value in the Status Indicator field was last changed.	This field is updated automatically whenever the value in the Status Indicator field changes.
Temperature	Number	Specifies the temperature at which the measurement value was recorded.	This is an optional field that, by default, stores the value entered by the user. This field is provided so that custom rules can be developed, if desired, to allow for a calculation that will adjust the measurement value based upon the temperature at which the reading was taken.

Field	Data Type	Description	Behavior and Usage
Uncorrected Measurement	Number	Specifies a value that is the result of the calculation that was performed against values in the Readings field.	The Uncorrected Measurement field is meant to serve as an intermediate storage location between the Readings and Measurement Value fields. If needed, you can create custom rules for the Measurement Value field so that the Uncorrected Measurement value is adjusted based on additional factors and the result of that calculation becomes the value in the Measurement Value field.
Verify Measurement	Character	Specifies a value that indicates whether the value in the Measurement Value field requires manual verification based on the Allowable Measurement Variance and/or Corrosion Rate Variance validation.	This field is populated with a list of System Codes in the MI_YES_NO System Code Table.

Thickness Monitoring Rules Lookup

Field	Data Type	Description	Behavior and Usage
Asset Type	Character	Specifies the following asset type associated with a TML: <ul style="list-style-type: none"> • Piping • Pressure Vessel • Tank 	This value is User defined. You should select appropriate values from the picklist.
Code Year	Character	Specifies the year in which the Design Code was defined or updated. The Code Year field is populated with a list of years that exist in Thickness Monitoring Rules Lookup records and correspond to the value in the Design Code field in the TML.	This value is User defined. You should select appropriate values from the picklist.
Component Type	Character	Specifies the Component type.	This value is User defined. You should select appropriate values from the picklist.

Field	Data Type	Description	Behavior and Usage
Design Code	Character	Specifies a design code associated with the TML that is used for calculating T-Min and allowable stress.	This value is User defined. You should select appropriate values from the picklist.
Formula Classification	Character	Specifies the formulas associated with the each asset type.	This value is User defined. You should select appropriate values from the picklist.
Formula Rule	Character	This field stores the formula location for Calculating the T-Min.	This value is User defined. Users shall select the more options button and then select a project and method from the catalog.
MAWP Formula Rule	Character	This field stores the formula location for Calculating MAWP.	This value is User defined. Users shall select the more options button and then select a project and method from the catalog.
T-Min Formula Policy	Character	This field stores the Policy ID.	A picklist will be displayed with all the policies.

TML Position, Pipe Rotation Event, and Position Rotation Revision

The following tables provide a list of various fields that are defined for the TML Position, Pipe Rotation Event, and Position Rotation Revision families in the baseline APM database. These families are specific to piping assets and are necessary for Piping Rotation and Flip. Depending on how your system has been configured, additional fields may be available in the families, and some fields may not behave exactly as described in the table.

Note: Although the fields are listed in alphabetical order in the tables, they will appear in a different order in the application. This list is not comprehensive. Baseline fields that are not displayed in the application are omitted. Certain datasheets may be divided into sections.

This family is enabled for site filtering, which means that records in this family can be assigned to a specific site and will only be accessible to users who are assigned to the same site and have the appropriate license and family privileges. For more information, refer to the [Sites](#) section of the documentation.

TML Position

For each TML linked to a band, a TML Position is created. TML Positions contain read-only fields that store position information for each TML. The following table provides an alphabetical list of the fields that are visible on the TML Position datasheet.

Field	Data Type	Description	Behavior and Usage
Position ID	Numeric	Stores the position of the TML in a band.	This field is always disabled. This field is populated automatically during the creation of the TML in a band.
Top Center	Boolean	Indicates if the TML is at the top center position.	This field is always disabled. This field is assigned automatically during the creation of the TML in a band.

Pipe Rotation Event

Field	Data Type	Description	Behavior and Usage
Component ID	Character	Stores the component ID of the piping component.	This field is always disabled. This field is automatically populated during a rotation or flip.
Move Type	Character	Identifies the type of movement (that is Rotate or Flip).	This field is always disabled. This field is automatically populated during a rotation or flip. This field is populated by the MI_PIPE_MOVE_TYPES System Code Table.
Moved By	Character	Stores the Security User key of the user that performed the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
Movement Date	Date	Stores the date of the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
Rate Method	Character	Stores the Rate Method specified when performing a rotation or flip.	The value in this field must be selected when performing a rotation or flip.
Remaining Life After	Numeric	Stores the remaining life of the component after the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.

Field	Data Type	Description	Behavior and Usage
Remaining Life Before	Numeric	Stores the remaining life of the component before the rotation or flip. This is calculated with reference to the date on which the movement is performed.	This field is always disabled. This field is automatically populated during a rotation or flip.
Retirement Date After	Date	Stores the retirement date of the component after the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
Retirement Date Before	Date	Stores the retirement date of the component before the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
Reverted	Boolean	Indicates whether or not the Piping Rotation Event has been reverted as a result of the undo movement operation.	This field is always disabled. This field is automatically populated when an undo movement operation is performed.
Rotation Sequence Number	Numeric	Stores the sequence number of the movement.	This field is always disabled. This field is automatically populated during a rotation or flip.
Scenario ID	Character	Stores the Scenario ID for a What If scenario.	The value in this field must be entered when a What If scenario is created.
Top Center Moved To	Numeric	Stores the Position ID of the position that the top center was moved to.	This field is always disabled. This field is automatically populated during a rotation or flip.
What If Method	Character	Stores the method used to generate the What If scenario.	This field is always disabled. This field is populated automatically when a What If scenario is created. This field is populated by the MI_PIPE_WHAT_IF_TYPES System Code Table.

Position Rotation Revision

When a piping component is rotated or flipped, a Position Rotation Revision is created for each TML. Fields in the Position Rotation Revision are read-only and are updated during a rotation or flip. The following table provides an alphabetical list of the fields that are visible on the Position Rotation Revision datasheet.

Field	Data Type	Description	Behavior and Usage
Corrosion Rate	Numeric	Stores the Controlling Corrosion Rate of the TML that occupied the position before the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
Piping Band ID	Character	Specifies a unique ID for the band.	This field is always disabled. This field is automatically populated during a rotation or flip.
Position ID	Numeric	Stores the position of the TML in a band.	This field is always disabled. This field is automatically populated during a rotation or flip.
Previous Band	Character	Stores the band ID of the band previously occupied by the TML.	This field is always disabled. This field is automatically populated during a rotation or flip.
Remaining Life After	Numeric	Stores the remaining life of the TML that occupies the position after the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
Remaining Life Before	Numeric	Stores the remaining life of the TML that occupied the position before the rotation or flip. This is calculated with reference to the date on which the movement is performed.	This field is always disabled. This field is automatically populated during a rotation or flip.
Retirement Date After	Date	Stores the retirement date of the TML that occupies the position after the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
Retirement Date Before	Date	Stores the retirement date of the TML that occupied the position before the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
Revision Sequence	Numeric	Stores the sequence of the position revision.	This field is always disabled. This field is automatically populated during a rotation or flip.

Field	Data Type	Description	Behavior and Usage
TML After	Character	Stores the ID of the TML that occupies the position after the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.
TML Before	Character	Stores the ID of the TML that occupied the position before the rotation or flip.	This field is always disabled. This field is automatically populated during a rotation or flip.

Datalogger History

Datalogger History contains various fields that store the history of data sent to and received from the Olympus 38DL Plus Ultrasonic Thickness Gage datalogger device. The following table provides an alphabetical list of the fields that are visible in the Datalogger History datasheet.

Field	Data Type	Description	Behavior and Usage
Device Type	Character	Stores the device type of the datalogger device the file was sent to.	This field is populated automatically with the value representing the datalogger device the file was sent to. This field is populated by the M655 System Code Table.
File Name	Character	Stores the file name of the file sent to the datalogger device.	This field is populated automatically with the file name of the file sent to the datalogger device.
Receive Date	Date	Stores the date when the files were received from the datalogger device.	This field is populated automatically with the date on which data was received from the datalogger device.
Send Date	Date	Stores the date when the files were sent to the datalogger device.	This field is populated automatically with the date on which data was sent to the datalogger device.
Status	Character	Stores the current status of the datalogger file (that is Sent, Received).	This field is populated automatically by the MI_DLG_HIST_STATUSES System Code Table.
TML JSON	Text	Stores the JSON object representing the collection of TMLs for a given file in the order that they were sent to or received from a datalogger device.	This field is populated automatically when files are sent to or received from a datalogger device.

Corrosion Rates in Thickness Monitoring

About Corrosion Rates

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About Custom Corrosion Rates

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Long Term Corrosion Rate (LTCR)

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Short Term Corrosion Rate (STCR)

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Least Squares Corrosion Rate (LSCR)

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Maximum Historical Corrosion Rate (MHCR)

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Calculations

Overview of TM Calculations

A Corrosion Analysis includes one or more assets and all the TM-specific records that are linked to them. As you conduct a Corrosion Analysis, various calculations and validations are performed, and the results are stored in various records involved in the Corrosion Analysis.

In this section of the documentation, we provide descriptions of the calculations and validations that are performed within a Corrosion Analysis. These descriptions are classified according to the type of record for which the calculation or validation is performed:

- **Asset Corrosion Analysis:** Stores summary information and calculations that are performed using the information in the related Thickness Measurement Location and Thickness Measurement records.
- **TML Corrosion Analysis:** Stores summary information and calculations performed using the information in related Thickness Measurement Location and Thickness Measurement records.
- **Thickness Measurement:** Stores measurement data and performs calculations. The values calculated in Thickness Measurement records are used for calculating values in the associated TML Corrosion Analysis record.

Thickness Monitoring uses specific formulas, equations, and estimation methods to arrive at the values that are stored in these records. In order to understand the information that is displayed to you for a given analysis, you must understand how the values were determined.

Measurement Calculations

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Datasheet Calculations

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About Interpolation

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About the Calculated T-Min Formulas

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Reference Tables that are Used to Calculate Allowable Stress

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Maximum Allowable Working Pressure (MAWP) Calculation

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

About Fields Required for Calculated T-Min

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Interpret the Calculation Details

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Piping Nominal T-Min Reference Table

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Piping Nominal Diameter

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Tank T-Min Annular Ring Reference Table

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Reading Tolerance

This topic has been intentionally excluded from the APM product documentation website. This topic is available to you via the product documentation that is provided within the APM system.

Family Search Configuration

Family Search Configuration

The following families for Thickness Monitoring are included in the Global Search:

- Analysis
- Asset Corrosion Analysis
- Corrosion
- Datapoint
- Materials of Construction
- Pipe Properties
- Piping Nominal T-Min
- Piping Stress
- PV Nominal T-Min
- PV Stress
- Tank Nominal T-Min
- Tank Stress
- Tank T-Min Annular Ring
- Thickness Monitoring Task
- Thickness Measurement Location
- TML Group

By default, the search results for all the other families for Thickness Monitoring are excluded from Global Search.

Note: You can configure a family to be included or excluded from the Global Search using the Search Configuration.

Chapter 16

Troubleshooting

Topics:

- [Troubleshooting Scenarios](#)

Troubleshooting Scenarios

Troubleshooting Scenarios

The following topics can help you troubleshoot issues that you may have with the Thickness Monitoring module:

- [Datalogger device is not connected to the system](#) on page 316
- [Meridium Device Service not found](#) on page 316
- [Device Service is Installed but USB is not accessible due to permissions](#) on page 317
- [Ultra-MATE software version compatibility Issue with DMS Go+ device](#) on page 317
- [Incorrect readings are received](#) on page 318
- [Meridium Device Service is not running under an authorized service account](#) on page 318
- [OnDMS Go/DMS Go+ device readings with A-Scan saved do not properly load in the Datalogger interface](#) on page 319
- [Unable to Connect to Olympus Epoch 650](#) on page 319
- [Unable to Take Readings on Olympus Epoch 650](#) on page 320

Datalogger device is not connected to the system

Description

In the datalogger settings window, the **File Directory** drop-down list box is empty. Instead, the following error message appears below the **File Directory** drop-down list box: `Invalid Input: File Directory is required. If your file directory list is empty. Check if your service port is valid. When you attempt to send TMLs, the following error message appears: The device drive could not be found. Please ensure the SD card is inserted in the device.`

Cause

This issue may occur if the Meridium Device Service is not running under an authorized service account.

Note: This issue is applicable only for DMS Go/Go+ devices.

Solution

To check if the datalogger device is connected, perform the following steps:

1. Access the Devices and drives in windows.
2. Verify if the USB Drive is available.
3. If the USB Drive is not available, make sure that the datalogger device is properly connected to the system.

Meridium Device Service not found

Description

When you attempt to send data to a datalogger, following error is displayed on the TM Dataloggers page:

`Meridium Device Service Not Found`

Cause

This issue may occur due to any of the following reasons:

- Meridium Device Service is not installed in the system.
- APM uses a secured URL (https).

Solution

on all the machines that connect to devices with Thickness Monitoring.

Note: If you are using HTTPS to connect to APM, follow the instructions in KBA 000055071 to install the Meridium Device Service.

Device Service is Installed but USB is not accessible due to permissions

Description

When you attempt to send TML data, the following error message appears:

```
Error: <Directory>.dmsdr was not successfully sent to the GE DMS Go/Go+ device. Please check and make sure that all of the settings for the current device are correct. This might be due to the device having to change the file name because of limitations inherent in the device.
```

Additionally, the following error message appears in the log file:

```
Sending message of type ACTION_FAILED to client.
```

Note: This issue is applicable only for DMS Go/Go+ devices.

Cause

This issue may occur if you do not have USB access in your system.

To verify if you have USB access in your system, perform the following steps:

1. Navigate to the USB drive folder.
2. Access the Meridium folder.
3. Create a text file.

If you see an Access Denied message, you do not have USB access in your system.

Solution

Contact your system administrator to provide USB access in your system.

Ultra-MATE software version compatibility Issue with DMS Go+ device

Description

When you attempt to send TML data using a DMS Go+ device, the data processing starts, but never gets completed. The loading spinner continues to spin. You can also access the log file from the log folder in the service path folder to check the following error message:

```
Exception occurred while processing the resuestLength cannot be less than zero. Parameter name: length
```

Cause

The data format in DMS Go+ is changed in version 3.29. UltraMATE version older than 2.60.35 are not able to read data created with DMS Go+ version 3.29 due to the changed data format. UltraMATE version 2.60.28 or lower are able to read data created with DMS Go+ version 3.28 or lower.

Solution

We recommend customers with an existing valid license of UltraMATE software to download the UltraMATE version 2.60.35. Contact Waygate Technology technical support for obtaining the newer version of Ultramate Lite.

Access [Waygate Technologies' Remote Service Contact](#) for more support.

Incorrect readings are received

Description

If you are a non-English customer, you may receive incorrect readings from the device.

Cause

When you receive thickness measurement data from a TM Datalogger in a system where the Windows Region format is set to any region other than English (United States), you may receive incorrect measurement values. For example, if you are using APM in a system where the windows culture is set to Finnish (fi-FI) culture, a value of 0.75 inches may be received as 75234724750 inches.

Solution

- Follow the instructions in KBA 000055684.
or
- Uninstall the previous version and on all of the machines that connect to devices with Thickness Monitoring.

Meridium Device Service is not running under an authorized service account

Description

When you attempt to send TML data, the following error message appears:

```
Error: <Directory>.dmsdr was not successfully sent to the GE DMS Go/Go+ device. Please check and make sure that all of the settings for the current device are correct. This might be due to the device having to change the file name because of limitations inherent in the device.
```

Note: This issue is applicable only for DMS Go/Go+ devices.

Cause

Depending on the IT security policy of your company, Meridium Device Service may use an unauthorized system service account.

Solution

Perform the following steps:

1. Run `services.msc` to open the Services Manager.

McAfee Service Controller	Manages M...	Running	Automatic (T...
McAfee Task Manager	Allows sche...	Running	Automatic
McAfee Validation Trust Protection Service	Provides val...	Running	Automatic
Meridium Devices Service	Meridium D...		Automatic
MessagingService_c87213b	Service sup...		Manual (Trig...
Microsoft (R) Diagnostics Hub Standard Collector Service	Diagnostics ...		Manual

2. From the list of services, right-click on Meridium Devices Service, and then select **Properties**.
3. Access the **Log On** tab.
4. Select **This account**.
5. Enter your administration credentials, and then select **OK**.

OnDMS Go/DMS Go+ device readings with A-Scan saved do not properly load in the Datalogger interface

Description

When you attempt to receive the TML data using a DMS Go/DMS Go+ device, the data processing starts, but it never gets completed.

You can also access the log file from the log folder in the service path folder to check the following error message:

```
Exception occurred while processing the request Year, Month, and Day parameters describe an un-representable DateTime.
```

Cause

Using the Thickness Monitoring module, when you collected data with the DMS Go+ device and held the **Send** button for more than two seconds, the device also stored an A-Scan reading. The Thickness Monitoring Datalogger interface was unable to process this file or display the readings.

Solution

Follow the instructions in KBA 000034204.

Note: This issue is applicable only for DMS Go/Go+ devices.

Unable to Connect to Olympus Epoch 650

Description

You cannot connect to the Olympus Epoch 650 datalogger device from APM.


Cause

Incorrect connection settings in the Olympus Epoch 650 datalogger or in APM.

Solution

Procedure

1. To correct the settings in the datalogger device:

- a) Press **FULL/NEXT** on the device until the **Inst Setup** option appears.
 - b) Press F3 on the device.
The **Inst Setup** submenu appears.
 - c) Press P1 on the device to select **General** from the submenu.
The **General Setup** page appears.
 - d) Verify the following values:
 - **Communications Protocol**: Must be set to **Multi Char**.
 - **Communications Device**: Must be set to **USB**.
 - e) If either of the values is incorrect, press **FULL/NEXT** until the option is highlighted, and press the corresponding button to set the value.
 - f) Save your changes.
2. To correct the settings in APM:
- a) [Access the TM Dataloggers page](#).
 - b) Select .
 - c) Verify the following values:
 - The device Olympus Epoch 650 is selected in the drop-down list box in the upper-left corner of the page.
 - The **COM Port** is correct.

Tip: To determine the COM port of the device in Windows:

 - i. Access Device Manager.
 - ii. Under Ports (COM & LTP), verify the COM port next to the USB Serial device.

Unable to Take Readings on Olympus Epoch 650

Description

You cannot take readings using the Olympus Epoch 650 datalogger device.

Cause

The Corrosion Gage feature is not enabled by default on the Olympus Epoch 650 device.

Solution

Procedure

To enable the Corrosion Gage feature in the datalogger device:

- a) Press **FULL/NEXT** on the device until the **Inst Setup** option appears.
- b) Press F3 on the device.
The **Inst Setup** submenu appears.
- c) Press P1 on the device to select **General** from the submenu.
The **General Setup** page appears.
- d) Verify whether **Corrosion Gage** is set to **ON**. If not, press **FULL/NEXT** until the option is highlighted, and press **P2** to set the value to **ON**.
- e) Save your changes.