



Getting Started



Contents

Chapter 1: Overview	1
What is GE Digital APM?	2
Chapter 2: The Basic GE Digital APM System Architecture	3
GE Digital APM System Components	4
The GE Digital APM Server	4
GE Digital APM Database Server	5
SQL Server Report Server	5
Chapter 3: Quick Start Guide	6
Getting Started	7

Copyright GE Digital

© 2023 General Electric Company.

GE, the GE Monogram, and Predix are either registered trademarks or trademarks of All other trademarks are the property of their respective owners.

This document may contain Confidential/Proprietary information of and/or its suppliers or vendors. Distribution or reproduction is prohibited without permission.

THIS DOCUMENT AND ITS CONTENTS ARE PROVIDED "AS IS," WITH NO REPRESENTATION OR WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF DESIGN, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE. ALL OTHER LIABILITY ARISING FROM RELIANCE UPON ANY INFORMATION CONTAINED HEREIN IS EXPRESSLY DISCLAIMED.

Access to and use of the software described in this document is conditioned on acceptance of the End User License Agreement and compliance with its terms.

Chapter 1

Overview

Topics:

- [What is GE Digital APM?](#)

What is GE Digital APM?

Production facilities often face problems related to recurring equipment failures, including:

- Unplanned downtime.
- The inability to maintain planned production rates.
- High costs of fixing problems that result from equipment failures.
- Threats to employee and environmental safety.

Data related to equipment failures and the impact that they have on a facility can be recorded using a data collection tool. Collecting failure data alone, however, cannot prevent the same problems from occurring in the future. What production facilities need is a tool that will analyze the failure data to help decrease the number of equipment failures, which will in turn increase profit margins.

The GE Digital APM system fulfills this need.

You can use GE Digital APM tools to analyze and process data that is collected in and transferred from an external system (e.g., SAP). After the data exists in GE Digital APM, it can be analyzed to determine the state of your equipment and the reliability, trends, potential risks, and probability of failures associated with that equipment. Based on the gathered data and associated analyses, you can map out the impact of projected changes and then make recommendations and suggest strategies for future equipment maintenance.

Chapter 2


The Basic GE Digital APM System Architecture

Topics:

- [GE Digital APM System Components](#)
- [The GE Digital APM Server](#)
- [GE Digital APM Database Server](#)
- [SQL Server Report Server](#)

GE Digital APM System Components

In its most basic implementation, the GE Digital APM system consists of the machines shown in the following image.



The following are critical elements of the GE Digital APM system::

- The GE Digital APM Server
- GE Digital APM Database Server
- The Redis Server
- The ElasticSearch Server
- The ActiveMQ Server
- The SQL Server Report Server
- Web Browser
- Mobile Device

The GE Digital APM Server

A computer on which the GE Digital APM Server software is installed. The GE Digital APM Server machine contains Internet Information Services (IIS), which serves as the host for communication between the various systems. The GE Digital APM Server:

- Contains and executes the GE Digital APM business objects implemented using the .NET transaction management framework.
- Receives requests from a client, processes those requests, connects to the database to retrieve information, and returns that information to the client.
- Executes and enforces the business logic and business rules.
- Processes data.
- Performs calculations.

Your GE Digital APM system could include multiple GE Digital APM Server instances.

- GE Digital APM Server machines that will receive and process requests from users are referred to as dedicated GE Digital APM Servers. You can have one or more dedicated APM Servers in your implementation. The number of dedicated APM Servers that you need will depend upon the number of users you have.

- GE Digital APM Server instances that exist to support other GE Digital APM components are referred to as supporting GE Digital APM Servers. We recommend that you install a supporting instance of the GE Digital APM Server on every GE Digital APM Server machine.

Refer to the documentation on Redis for information about its incorporation into server configurations.

GE Digital APM Database Server

The computer on which the database software (Oracle or SQL Server) and the physical GE Digital APM databases or schemas reside. Your Database Server may contain multiple GE Digital APM databases or schemas (e.g., a test database and a production database). The GE Digital APM Database Server answers requests for data from GE Digital APM Servers. The GE Digital APM database or schema contains the metadata (information about Entity families, fields, System Codes, etc.) and the tables containing actual data. The GE Digital APM system allows for a single, central database. This approach enables cross-site and cumulative analyses.

SQL Server Report Server

The computer on which the SQL Server Reporting Services is installed. The SQL Server Report Server stores SQL Server reports. Reports can be developed via GE Digital APM, and when they are saved to the GE Digital APM Catalog, they will be simultaneously uploaded to the SQL Server Report Server. After they exist on the SQL Server Report Server, they can be easily viewed by other GE Digital APM users.

In addition to the custom reports that can be created using SQL Server Reporting Services, the GE Digital APM database contains baseline SQL Server Reporting Services reports.

Note that, while the SQL Server Report Server is part of the basic GE Digital APM architecture, it is not considered a GE Digital APM Server. Therefore, you are not required to install a supporting instance of the GE Digital APM Server on the SQL Server Report Server machine. You will, however, need to install the GE Digital APM Adapter for SSRS on this machine.

Chapter 3

Quick Start Guide

Topics:

- [Getting Started](#)

Getting Started

This topic is intended to get you started with the baseline deployment for GE Digital APM.

Step 1: Obtain access to your GE Digital software and documentation

Download the GE Digital APM distribution package. To contact the Support team, go to: <http://www.ge.com/digital/support>.

Step 2: Review the product architecture

Review the [system architecture](#) to understand the various components that are required to work with GE Digital APM.

Step 2: Review the prerequisites

Before you set up your system, it is important that you make sure the computer on which you want to install GE Digital APM meets the minimum requirements. Use the following links to review the system requirements:

- [Basic GE Digital APM System Requirements](#)
- [Module System Requirements](#)

Step 3: Install GE Digital APM

Run the installer to install GE Digital APM. Refer to [Install the GE Digital APM Server Components](#) for further details on the Installation steps.

Step 4: Install additional components

After you complete the basic GE Digital APM application server installation, install additional server components, and optionally extend the environment to include single-sign-on, mobile application, and non-English translations in GE Digital APM. Refer to for further installation details, information about configuration options, and a description of steps to perform after installation.

Step 5: Activate licenses

License activation determines which modules and products will be available in GE Digital APM. You require license activation for all the modules; only then you can use them. Refer to [About Activating Licensing](#) for information on how to activate a license.